

## PART 4

## CHAPTER 1 — MALFUNCTIONS AND EMERGENCY PROCEDURES

## Contents

Index of Malfunctions and Emergency Procedures ... ..	Para 1
---	-----------

## Index of Malfunctions and Emergency Procedures

1. The following table shows where, in the Flight Reference Cards and Aircrew Manual, each subject is covered.

<i>Malfunction or Emergency</i>	<i>FRC Card No</i>	<i>Part</i>	<i>Chap</i>	<i>Para</i>
Abandoned take-off ... ..	—	3	1	26
Braking on wet surfaces ... ..	—	3	3	12
Ditching ... ..	17	—	—	—
Engagement of arrester barrier (Mks 5, 6, 12 and 12A) ... ..	17	—	—	—
<i>Electrics</i>				
Alternator failure ... ..	21(R)	1	1	26
Transformer failure ... ..	21(R)	1	1	31
TRU failure ... ..	21(R)	1	1	32
<i>Engine</i>				
Compressor stall ... ..	—	3	2	4
Failure to start ... ..	—	3	1	7
Failure in flight ... ..	14	—	—	—
Fire ... ..	13(R)	1	3	8
Flame out ... ..	14(R), 15	—	—	—
Icing ... ..	—	1	3	23
Oil pressure failure ... ..	18(R)	1	3	27
Relighting ... ..	14(R)	—	—	—

			<i>FRC</i>			
			<i>Card No</i>	<i>Part</i>	<i>Chap</i>	<i>Para</i>
<i>Escape</i>						
Canopy jettison	...	...	17	1	8	7
Ejection	...	...	17(R)	1	10	49
Ejection limitations	...	...	12	2	1	18
Seat malfunctions	...	...	17(R)	1	10	53
<i>Fuel</i>						
Asymmetric transfer	...	...	18(R)	1	2	28
Transfer air pressure failure			19	1	2	22
Booster pump failure	...	...	19	1	2	26
Restriction in supply	...	...	—	1	2	27
Gauges misreading	...	...	—	1	2	15
Proportioner errors	...	...	—	1	2	16
Low level warning	...	...	19(R)	1	2	16
<i>Hydraulic Failures</i>						
System failures	...	...	19(R), 20	1	4	13
Failure on take-off	...	...	—	3	1	25
Undercarriage emergencies	...	...	15(R), 16	1	6	9, 14, 15
IFIS fuse failure	...	...	—	1	7	6
Manual flying procedures	...	...	15	3	4	—
Oxygen failures	...	...	18	1	10	48
<i>Powered Flying Controls</i>						
Trimming failures	...	...	21	1	5	26
Tailplane motor seizure	...	...	20	1	5	29
Q-gearing failure	...	...	21	1	5	30
Datum shift failure	...	...	21	1	5	32
Pressurisation failure	...	...	18	1	9	10
				1	10	47
Spin recovery	...	...	—	3	2	36

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

