

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A. L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
		G.A. OF INSTRUMENTS AND PANELS (1880/501A and 501A/UN) Spares for:—				
5K/3394	AS.3360-B6B	BONDING, flexible	8	—	C	
4534	1880/927	BUSH, rubber	2	—	MR/C	FA.1
4535	1880/931	BUSH, rubber	4	—	MR/C	FA.1
4536	1880/933	BUSH, rubber	8	—	MR/C	FA.1
6B/2754		COMPASS, Type E.2B	1	—	A	FA.1
		Attachment parts for 6B/2754:—				
28D/1213254	AS.4565-2B	Bolt	2	—	C	
28DU/9419525	A.171-2B	Bolt	2	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
28W/9471274	SP.124-B	Washer	2	—	C	
6B/3221		COMPUTER, Tacan, offset, Type B	1	—	A	FA.3
		OR				
6B/2905		COMPUTER, Tacan, offset, Type A	1	—	A	FA.3
4111	1880/537A	CRATE assy, front cockpit (Pre-mod. 134)	1	—	B	FA.1 & 6
6574	1880/537A/UN	CRATE assy, front cockpit (Pre-mod. 134)	1	—	MR/B	
9151	1880/537A/1	CRATE assy, front cockpit (Mod. 134)	1	—	MR/B	
8037	1880/537A/UN/1	CRATE assy, front cockpit (Mod. 134)	1	—	MR/B	
		Spares for:—				
8604	1880/611A	BRACKET assy, pivot	2	—	MR/C	FA.6
		Attachment parts for 1880/611A:—				
28D/1007973	AS.1242-2B	Bolt	2	—	C	
28M/1086618	AGS.2002-B1	Nut	2	—	MR/C	
28W/9419474	SP.15-B	Washer	2	—	C	
8042	1880/1375	BUSH	2	—	C	FA.6
8043	1880/1375UN	BUSH	2	—	C	
8044	1880/1377	BUSH	2	—	C	FA.6
8045	1880/1377UN	BUSH	2	—	C	FA.6
		Attachment parts for 1880/1375, 1375UN, 1377 and 1377UN:—				
28D/1007468	AS.1242-3B	Bolt	2	—	C	
28DU/9434472	A.173-2C	Bolt	2	—	C	
28M/1086618	AGS.2002-B1	Nut	2	—	C	
28M/9438421	A.125-C	Nut	2	—	C	
8046	1880/1379	Plate (use with 1880/1375)	1	—	C	FA.6
8047	1880/1379UN	Plate (use with 1880/1375UN)	1	—	C	
8048	1880/1381	Plate (use with 1880/1377)	1	—	C	FA.6
8049	1880/1381UN	Plate (use with 1880/1377UN)	1	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
28W/9156626	SP.122-C	Washer	2	—	C	
	1881/2725	BRACKET (Mod. 708)	1	16G. L.73	LM	
		Attachment parts for 1881/2725:—				
28DU/9419976	A.102-16D	Bolt	2	—	C	
28M/1275904	AS.8600-D	Nut	2	—	C	
	1881/2731	Spacer	1	—		
28W/9457834	SP.124-D	Washer	2	—	C	
	1880/1349	PACKING, inner	1	—	MR/C	FA.6
	1880/1351	PACKING, outer	1	—	MR/C	FA.6
	1880/1352	PACKING, outer	1	—	MR/C	FA.6
	1880/1359	PACKING, inner	1	—	MR/C	FA.6
6575	1880/571A	LEVER assy, ejector, port	1	—	MR/C	FA.1
6576	1880/572A	LEVER assy, ejector, starboard	1	—	MR/C	FA.1
		Attachment parts for 1880/571A and 572A:—				
28P/814	SP.4-A4	Pin	1	—	C	

RESTRICTED

GNAT T. Mk. 1

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
28P/1202460 6577	SP.9-C4 1880/537B	Pin, split	1	—	C	FA.1
		Washer, shim	A/R	—	MR/C	
6578	1880/573A	LEVER assy, pivot	2	—	MR/C	FA.1
6579	1880/609	Attachment parts for 1880/573A:—				
28P/1007947	SP.9-A3	Pin	4	—	MR/C	FA.1
28W/9419473	SP.15-A	Pin, split	4	—	C	
28W/1990896	SP.124-A	Washer	4	—	C	
		Washer	4	—	C	
28P/13625	SP.9-A3	PIN, split	1	—	C	
4112	1880/607	SCREW (Pre-mod. 134)	1	—	C	
6581	1880/607/UN	SCREW (Pre-mod. 134)	1	—	MR/C	
8050	1880/1387	SCREW, special (Mod. 134)	1	—	C	FA.1
8051	1880/1387/UN	SCREW, special (Mod. 134)	1	—	C	
4113	1880/603	TRUNNION	1	—	MR/C	FA.1
		Attachment parts for 1880/537A, 537A/UN and 537A/UN/1:—				
28D/1011019	A.25-8C	Bolt	2	—	C	
28DU/9419569	A.102-8D	Bolt	2	—	C	
28D/9140644	A.25-9C	Bolt	2	—	C	
28DU/9419970	A.102-9D	Bolt	2	—	C	
28M/9433473	AGS.2002-C1	Nut	4	—	C	
6956	FOS.40/4	Nut	4	—	MR/C	
28W/9419475	SP.15-C	Washer	4	—	C	
28W/1014056	SP.124-C	Washer	4	—	C	
		CRATE assy, rear cockpit (1880/969A and 969A/UN) Spares for:—				
4530	1880/1035A	BLIND assy (Pre-mod. 134)	1	—	B	
9156	1880/1035A/1	BLIND assy (Mod. 134)	1	—	MR/B	
6589	1880/1035A/UN	BLIND assy (Pre-mod. 134)	1	—	MR/B	
8039	1880/1035A/UN/1	BLIND assy (Mod. 134)	1	—	MR/B	FA.5
		Spares for:—				
4532	1880/1045	PIN	1	—	MR/C	FA.5
4533	1880/1047	SPRING, torsion	1	—	MR/C	FA.5
6591	1880/1035H	STRIP and BLIND, sub-assy (Pre-mod. 134)	1	—	MR/C	FA.5
8053	1880/1035K	STRIP and BLIND, sub-assy (Mod. 134)	1	—	MR/C	
6590	1880/1035B	STRIP, stiffening	1	—	MR/C	FA.5
	AS.2809-4-045	TUBE, distance	2	—	MR/LM	
	AS.2304-090	TUBE, distance	1	—	MR/LM	
		Attachment parts for 1880/1035A, 1035A/1, 1035A/UN and 1035A/UN/1:—				
4531	1880/1043	Bolt	1	—	C	FA.5
6592	1880/1043/UN	Bolt	1	—	MR/C	
28M/9433473	AGS.2002-C1	Nut	1	—	C	
6956	FOS.40/4	Nut	1	—	MR/C	
28W/9419475	SP.15-C	Washer	1	—	C	
28W/9457834	SP.124-D	Washer	1	—	C	
5CZ/6582	Ward Brooke WB.1110/D/10B	BLOCK, terminal	1	—	B	
		Complete with:—				
28M/10308	AGS.2002-A4	Nut	20	—	C	
28W/9995407	SP.25-A	Washer	20	—	C	
		OR				
5CZ/7380	Ward Brooke WB.1110/D/10B/N	BLOCK	1	—	B	
		Attachment parts for 5CZ/6582 or 5CZ/7380:—				
6536	1880/1317	Pillar, fixing	2	—	MR/C	FA.4

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
5CZ/6589	Ward Brooke WB.1110/S/10B	BLOCK, terminal	2	—	B	
		Complete with:—				
28M/10308	AGS.2002-A4	Nut	10	—	C	
28W/9995407	SP.25-A	Washer	10	—	C	
		OR				
5CZ/7383	Ward Brooke WB.1110/S/10B/N	BLOCK, terminal	2	—	B	
		Attachment parts for 5CZ/6589 or 5CZ/7383				
6536	1880/1317	Pillar, fixing	2	—	MR/C	FA.4
5CZ/6111	Ward Brooke WB.1110/5	CDVER, terminal block	2	—	C	
5CZ/6107	Ward Brooke WB.1110/10	COVER, terminal block	1	—	C	
		Attachment parts for 5CZ/6111 and 5CZ/6107:—				
28S/1212705	A.40-B10	Screw	2	—	C	
28W/1200328	AGS.2037-B	Washer	2	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
4537	1880/1037A	CASE assy, map, rear	1	—	MR/B	FA.1
		Spares for:—				
6937	FOS.24/1	CLEAT assy	4	—	MR/C	
6939	FOS.25/1	PLATE, mounting	1	—	MR/C	
6585	1883/607	SPRING	1	—	MR/C	FA.1
		Attachment parts for 1880/1037A:—				
28D/9133011	A.25-2C	Bolt	1	—	C	
28DU/9419565	A.102-1D	Bolt	1	—	C	
28D/1214471	AS.3297-2C	Bolt	1	—	C	
28DU/9480270	A.173-2D	Bolt	1	—	C	
28M/9433473	AGS.2002-C1	Nut	2	—	C	
6956	FOS.40/4	Nut	2	—	MR/C	
28W/9419475	SP.15-C	Washer	2	—	C	
28W/9457834	SP.124-D	Washer	2	—	C	
28W/9419404	SP.16-C	Washer	1	—	C	
28W/5806394	SP.125-D	Washer	1	—	C	
6593	1880/1323	CLIP, saddle	1	—	MR/C	FA.1
		Attachments parts for 1880/1323:—				
28S/9419453	A.31-B14	Screw	2	—	C	
28S/1201331	A.205-B14	Screw	2	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
28W/9471274	SP.124-B	Washer	2	—	C	
1498092	1880/539A/2	CRATE, rear cockpit (Mod. 708)	1	—	MR/B	
1498093	1880/539A/UN/2	CRATE, rear cockpit (Mod. 708)	1	—	MR/B	FA.1
		Spares for:—				
8064	1880/611A	BRACKET assy, pivot	2	—	MR/C	FA.1
		Attachment parts for 1880/611A:—				
28D/1007973	AGS.1242-2B	Bolt	2	—	C	
28M/1086618	AGS.2002-B1	Nut	2	—	MR/C	
28W/9419474	SP.15-B	Washer	2	—	C	

RESTRICTED

GNAT T. Mk. 1

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 8

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
8042	1880/1375	BUSH	2	—	C	FA.6
8043	1880/1375UN	BUSH	2	—	C	
8044	1880/1377	BUSH	2	—	C	
8045	1880/1377UN	BUSH	2	—	C	
		Attachment parts for 1880/1375, 1375UN, 1377 and 1377UN:—				
28D/1007468	AS.1242-3B	Bolt	2	—	C	FA.6
28DU/9434472	A.173-2C	Bolt	2	—	C	
28M/10327	AGS.2002-B1	Nut	2	—	C	
28M/9438421	A.125-C	Nut	2	—	C	
8046	1880/1379	Plate (use with 1880/1375)	1	—	C	FA.6
8047	1880/1379UN	Plate (use with 1880/1375UN)	1	—	C	
8048	1880/1381	Plate (use with 1880/1377)	1	—	C	
8049	1880/1381UN	Plate (use with 1880/1377UN)	1	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	FA.6
28W/9156626	SP.122-C	Washer	2	—	C	
	1880/1343	PACKING, outer	1	—	MR/C	
	1880/1344	PACKING, outer	1	—	MR/C	
	1880/1345	PACKING, inner	1	—	MR/C	FA.6
	1880/1346	PACKING, inner	1	—	MR/C	
6575	1880/571A	LEVER assy, ejector (Pre-mod. 134)	1	—	MR/C	
8040	1880/571A/1	LEVER assy, ejector (Mod. 134)	1	—	MR/C	
6576	1880/572A	LEVER assy, ejector (Pre-mod. 134)	1	—	MR/C	FA.1
8041	1880/572A/1	LEVER assy, ejector (Mod. 134)	1	—	MR/C	
		Attachment parts for 1880/571A and 572A:—				
28P/814	SP.4-A4	Pin	1	—	C	
28P/13625	SP.9-A3	Pin, split	1	—	C	FA.1
6577	1880/537B	Washer, shim	A/R	—	MR/C	
6578	1880/573A	LEVER assy, pivot	2	—	MR/C	
		Attachment parts for 1880/573A:—				
6579	1880/609	Pin, special	2	—	MR/C	FA.1
28P/1007947	SP.9-A3	Pin, split	2	—	C	
28W/9419473	SP.15-A	Washer	2	—	C	
28W/17541	SP.124-A	Washer	2	—	C	
4112	1880/607	SCREW (Pre-mod. 134)	1	—	C	FA.1
6581	1880/607/UN	SCREW (Pre-mod. 134)	1	—	MR/C	
8050	1880/1387	SCREW, special (Mod. 134)	1	—	C	
8051	1880/1387/UN	SCREW, special (Mod. 134)	1	—	C	
6583	1880/1013	SPIGOT	2	—	MR/C	FA.1
4113	1880/603	TRUNNION	1	—	MR/C	
4540	1880/1049A	CRATE assy, Tacan computer	1	—	B	
6586	1880/1049A/UN	CRATE assy, Tacan computer	1	—	MR/B	
		Spares for:—				
6937	FOS.24/1	CLEAT assy	1	—	MR/C	FA.1
6985	FOS.52/1	CLEAT assy	1	—	MR/C	
‡5323	1311/3317A	PLATE assy, bolt	1	—	MR/C	
‡6588	1311/3317A/UN	PLATE assy, bolt	1	—	MR/C	
		Spares for:—				
28D/13461	AS.3297-2C	BOLT	1	—	C	FA.1
28DU/9480270	A.173-2D	BOLT	1	—	C	
4541	1883/495	PLATE catch	1	—	MR/C	
		Attachment parts for 1883/495:—				
5508	1880/1151	Pin	1	—	MR/C	FA.1
28P/811	SP.4Y-A1	Pin	2	—	C	

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 14

REF. No.	PART NUMBER	DESCRIPTION					No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
		1	2	3	4	5			M.R. L.M.	
28P/1007740	SP.9-B4					Pin, split	2	—	C	FA.1
28P/13563	SP.9-B5					Pin, split	1	—	C	
28W/9419401	SP.10-B					Washer	2	—	C	
28W/9419454	SP.10-C					Washer	1	—	C	
28W/9419486	SP.16-B					Washer	2	—	C	
6587	1880/1153					Washer	2	—	MR/C	
4542	1883/497					SPRING	1	—	MR/C	FA.1
						Attachment parts for 1880/1049A and 1049A/UN:—				
28D/13132	AS.3297-1C					Bolt	2	—	C	
28DU/9480269	A.173-1D					Bolt	2	—	C	
28M/10328	AGS.2002-C1					Nut	2	—	C	
28M/9438428	A.126-D					Nut	2	—	C	
28W/9419475	SP.15-C					Washer	2	—	C	
28W/9457834	SP.124-D					Washer	2	—	C	
28W/9419404	SP.16-C					Washer	2	—	C	
28W/17551	SP.125-D					Washer	2	—	C	
						LABEL, Dymomite "AL"	1	—	—	
						LABEL, Dymomite "AM"	1	—	—	
						LABEL, Dymomite "P"	1	—	—	
						LABEL, Dymomite "R"	1	—	—	
5CZ/6399	Ward Brooke WB.1110/24					SPACER, terminal	A/R	—	C	
5CZ/6400	Ward Brooke WB.1110/25					SPACER, terminal	A/R	—	C	
						Attachment parts for 1880/969A and 969A/UN:—				
28D/1011019	A.25-8C					Bolt	2	—	C	
28DU/9419569	A.102-8D					Bolt	2	—	C	
28W/9419475	SP.15-C					Washer	2	—	C	
28W/1014056	SP.124-C					Washer	2	—	C	
6B/3244						DISPLAY, navigation, type B (Mod. 312)	2	—	A	FA.1
6A/6854						INDICATOR, attitude	2	—	A	FA.1
						INDICATOR, air speed, sector (1880/1281A and 1281A/UN) Spares for:—				
8246	1881/2529A/UN					CABLE assy, No. 94 (Mod. 108)	1	—	C	FA.3
7840	1880/1601A					FAIRING, assy (Mod. 197)	1	—	MR/C	FA.1
						Attachment parts for 1880/1601A:—				
28D/15616	AS.4598-1C					Bolt	13	—	C	
28DU/9419534	A.113-1D					Bolt	13	—	C	
6A/7916	Kelvin Hughes KAB.2901-W					INDICATOR, air speed (Mod. 108)	1	—	—	FA.3
						Attachment parts for 6A/7916:—				
28S/1012446	A.205-B32					Screw, panhead	2	—	C	
8248	1880/1313					PACKING (Mod. 108)	2	—	C	FA.3
4548	1880/929					LINER, bush (Pre-mod. 134)	2	—	MR/C	
8052	1880/1389					LINER, bush (Mod. 134)	2	—	MR/C	FA.1
10AJ/144						MOUNTING A.V., type 953	2	—	B	FA.1
						Attachments parts for 10AJ/144:—				
28D/1007979	AS.1246-1B					Bolt	2	—	C	
28DU/9480226	A.116-1B					Bolt	2	—	C	
28M/10327	AGS.2002-B1					Nut	2	—	C	
6954	FOS.40/2					Nut	2	—	MR/C	
28W/9419474	SP.15-B					Washer	2	—	C	
28W/17542	SP.124-B					Washer	2	—	C	

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 14

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
4024	1880/971A	MOUNTING assy, A.V. top front, port	1	—	B	FA.4
	1880/971A/UN	MOUNTING assy, A.V. top front, port	1	—	—	
4025	1880/972A	MOUNTING assy, A.V. top front, starboard	1	—	B	FA.4
	1880/972A/UN	MOUNTING assy, A.V. top front, starboard	1	—	—	
		Spares for:—				
3098	1880/511A	BRACKET, assy, port	1	—	MR/C	FA.4
3099	1880/512A	BRACKET assy, starboard	1	—	MR/C	FA.4
10AJ/5340- 99-1983		MOUNTING A.V., type 953	1	—	B	
		Attachment parts for 10AJ/5340-99-120-1983:—				
28D/1010658	A.25-1B	Bolt	4	—	C	
28DU/9419560	A.102-1B	Bolt	4	—	C	
28M/10327	AGS.2002-B1	Nut	4	—	C	
6954	FOS.40/2	Nut	4	—	MR/C	
28W/9419474	SP.15-B	Washer	8	—	C	
28W/17542	SP.124-B	Washer	8	—	C	
		Attachment parts for 1880/971-2A and 971-2A/UN:—				
28D/1011248	A.25-16E	Bolt	1	—	C	
28DU/9414355	A.102-16E	Bolt	1	—	C	
28M/7002430	AGS.2002-E1	Nut	1	—	C	
28M/9418915	A.125-E	Nut	1	—	C	
10A/17930		Washer, check	A/R	—	C	
4018	1880/975A	MOUNTING assy, A.V. lower front, port	1	—	B	FA.4
	1880/975A/UN	MOUNTING assy, A.V. lower front, port	1	—	—	
4019	1880/976A	MOUNTING assy, A.V. lower front, starboard	1	—	B	FA.4
	1880/976A/UN	MOUNTING assy, A.V. lower front, starboard	1	—	—	
		Spares for:—				
6568	1880/973A	BRACKET assy, port	1	—	MR/C	FA.4
6569	1880/947A	BRACKET, assy, starboard	1	—	MR/C	FA.4
10AJ/144		MOUNTING A.V. type 953	1	—	B	FA.4
		Attachment parts for 10AJ/144:—				
28D/1010658	A.25-1B	Bolt	2	—	C	
28DU/9419560	A.102-1B	Bolt	2	—	C	
28M/10327	AGS.2002-B1	Nut	2	—	C	
6954	FOS.40/2	Nut	2	—	MR/C	
28W/9419474	SP.15-B	Washer	4	—	C	
28W/17542	SP.124-B	Washer	4	—	C	
		Attachment parts for 1880/975-6A and 975-6A/UN:—				
28D/1011248	A.25-16E	Bolt	1	—	C	
28DU/9414355	A.102-16E	Bolt	1	—	C	
28M/7002430	AGS.2002-E1	Nut	1	—	C	
28M/9418951	A.125-E	Nut	1	—	C	
10A/17930		Washer, check	A/R	—	C	

EQUIPMENT—AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 15

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
4022	1880/979A	MOUNTING assy, A.V., top, rear, port	1	—	B	FA.5
	1880/979A/UN	MOUNTING assy, A.V., top, rear, port	1	—	—	
4023	1880/980A	MOUNTING assy, A.V., top, rear, starboard	1	—	B	FA.5
		(Pre-mod. 295)				
	1880/980A/UN	MOUNTING assy, A.V., top, rear, starboard	1	—	—	
		(Pre-mod. 295)				
		Attachment parts for 1880/979-80A and 979-80A/UN:—				
28DU/1011248	A.25-16E	Bolt	1	—	C	
28DU/9414355	A.102-16E	Bolt	1	—	C	
28M/7002430	AGS.2002-E1	Nut	1	—	C	
28M/9418915	A.125-E	Nut	1	—	C	
10A/17930		Washer	A/R	—	C	
1443924	1880/1699A	MOUNTING assy, A.V., top, rear, starboard (Mod. 295)	1	—	—	
—	1880/1699A/UN	MOUNTING assy, A.V., top, rear, starboard (Mod. 295)	1	—	—	
		Spares for:—				
6572	1880/977A	BRACKET assy, port	1	—	MR/C	FA.5
6573	1880/978A	BRACKET assy, starboard (Pre-mod. 295)	1	—	MR/C	FA.5
1443923	1880/1697A	BRACKET assy, starboard (Mod. 295)	1	—	—	
10AJ/5340- 99-120-1983		MOUNTING A.V., type 953	1	—	B	
		Attachment parts for 10AJ/5430-99-120-1983:—				
28D/1010658	A.25-1B	Bolt	4	—	C	
28DU/9419560	A.102-1B	Bolt	4	—	C	
28M/10327	AGS.2002-B1	Nut	4	—	C	
6954	FOS.40/2	Nut	4	—	MR/C	
28VV/9419474	SP.15-B	Washer	8	—	C	
28VV/17542	SP.124-B	Washer	8	—	C	

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
4020	1880/983A	MOUNTING assy, A.V., lower, rear, port	1	—	B	FA.5
	1880/983A/UN	MOUNTING assy, A.V., lower, rear, port	1	—	—	
4021	1880/984A	MOUNTING assy, A.V., lower, rear, starboard	1	—	B	FA.5
	1880/984A/UN	MOUNTING assy, A.V., lower, rear, starboard	1	—	—	
		Spares for:—				
6570	1880/981A	BRACKET assy, port	1	—	MR/C	FA.5
6571	1880/982A	BRACKET assy, starboard	1	—	MR/C	FA.5
10AJ/144		MOUNTING A.V., type 953	1	—	B	
		Attachment parts for 10AJ/144:—				
28D/1010658	A.25-1B	Bolt	4	—	C	
28DU/9419560	A.102-1B	Bolt	4	—	C	
28M/1086618	AGS.2002-B1	Nut	4	—	C	
6954	FOS.40/2	Nut	4	—	MR/C	
28W/9419474	SP.15-B	Washer	16	—	C	
28W/9471274	SP.124-B	Washer	16	—	C	
		Attachment parts for 1880/983-4A and 1880/983-4A/UN:—				
28D/1011248	A.25-16E	Bolt	1	—	C	
28DU/9414355	A.102-16E	Bolt	1	—	C	
28M/7002430	AGS.2002-E1	Nut	1	—	C	
28M/9418915	A.125-E	Nut	1	—	C	
10A/17930		Washer	A/R	—	C	
28M/1006473	A.27-CT	NUT, for panel stop	1	—	C	
28M/9419540	A.103-DT	NUT, for panel stop	1	—	C	
		PANEL assy, instrument, front (1880/497A/3) and 497A/UN/3) (Pre-mod. 442)				
		PANEL assy, instrument, front (1880/497A/4) (Pre-mod. 295)				
		PANEL assy, instrument, front (1880/497A/UN/4) (Pre-mod. 295)				
	—	PANEL assy, instrument, front (1880/497A/5)	—	—	—	FA.2
	—	(Mod. 295)				
		PANEL assy, instrument, front (1880/497A/UN/5)	—	—	—	
		(Mod. 295)				
		Spares for:—				
		PANEL assy, front (1880/635A/3 and 635A/UN/3) (Mod. 455)				
		PANEL assy, front (1880/635A/4) (Pre-mod. 652)				
		PANEL assy, front (1880/635A/UN/4) (Pre-mod. 652)				
		PANEL assy, front 1880/635A/5 (Mod. 652)				FA.2
		PANEL assy, front 1880/635A/UN/5 (Mod. 652)				
		Spares for:—				
6A/6201976	Kollsman L82621-04-010	ALTIMETER, Mk. 29B (Mod. 708)	1	—	A	FA.2
		Attachment parts for 6A/6201976:—				
5CX/5477		Bridge, piece	1	—	B	FA.2
28S/1008085	A.32-B32	Screw	2	—	C	
28S/16871	A.204-B40	Screw	2	—	C	
6A/6204138	Kollsman L84380-00-100	Plate, mooring	1	—	—	
6A/8978		ALTIMETER, cabin combined, Mk. 26 (Mod. 568)	1	—	A	FA.2
		Attachment parts for 6A/8978:—				
28S/16874	A.205-B32	Screw	4	—	C	

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 16

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
5CW/7830	Page Engineering	BUTTON, push	1	—	B	FA.2
4108	C/180/C1	CHANNEL	1	—	MR/C	FA.2
4107	1880/873	CHANNEL	1	—	MR/C	FA.2
	1880/875	CLEAT	1	—	MR	FA.2
	1814/1187	COLLET	18	—	C	
5CX/5320	Thorn 80/10/0282	FILAMENT, 28V, .04A	66	—	B	FA.2
5L/9959118		GAUGE, fuel contents	1	—	A	FA.2
6A/6217	Smith AG.124	Attachment parts for 6A/6217:—				
28S/1008085	A.32-B-32	Screw	4	—	C	
6D/2605	B.O.C. 803161	GAUGE, oxygen contents (Mod. 255)	1	—	A	FA.2
28S/1008085	A.32-B32	Attachment parts for 6D/2605:—				
		Screw	4	—	C	
4118	1880/667A	GUARD assy, switch	2	—	MR/B	FA.2
		Spares for:—				
	1880/915	LABEL, "ON"	2	—	MR	FA.2
	AS.2809/2/05	TUBE, distance	2	—	MR/LM	
6A/6006		HORIZON, artificial, standby, Mk. 6D	1	—	A	FA.2
28S/1012446	A.205-B32	Attachment parts for 6A/6006:—				
		Screw	3	—	C	
6A/8551	Kelvin Hughes	INDICATOR, air speed (Mod. 385)	1	—	A	FA.3
28S/1012446	PW.2202/KAB/MB/1	Attachment parts for 6A/8551:—				
	A.205-B32	Screw	4	—	C	
9154	1880/947A/2	INDICATOR assy, centralized, warning	1	—	B	
9340	1880/947A/3	INDICATOR assy, centralized, warning (Mod. 591)	1	—	B	
1483535	1880/947A/4	INDICATOR assy, centralized, warning	1	—	B	
		(Pre-mod. 652)				
8182	1880/947A/UN/2	INDICATOR assy, centralized, warning (Mod. 75)	1	—	MR/B	
9341	1880/947A/UN/3	INDICATOR assy, centralized, warning (Mod. 591)	1	—	MR/B	
1483536	1880/947A/UN/4	INDICATOR assy, centralized, warning	1	—	MR/B	
		(Pre-mod. 652)				
1496888	1880/947A/5	INDICATOR assy, centralized, warning (Mod. 652)	1	—	B	FA.2/4
1496889	1880/947A/UN/5	INDICATOR assy, centralized, warning (Mod. 652)	1	—	MR/B	
		Spares for:—				
5CZ/6497	Ward Brooke	BLOCK, terminal	2	—	B	
5CW/6400	WB.1110-S/58	BUTTON, cancel	1	—	B	
28E/9436947	Page C.180/A/1/C	CLIP, "P"	2	—	C	
	AS.3180-4B	Attachment parts for AS.3180-4B:—				
28M/10287	AGS.2001-B1	Nut	1	—	C	
6954	FOS.40/2	Nut	1	—	MR/C	
28S/9419453	A.31-B16	Screw	1	—	C	
28S/1201335	A.205-B16	Screw	1	—	C	
28S/15869	AS.2994-5B	Screw	1	—	C	
28S/9435595	A.204-B16	Screw	1	—	C	
28W/9419474	SP.12-B	Washer	1	—	C	
28W/17542	SP.124-B	Washer	1	—	C	
5CX/5320	Thorn 80-10-0282	COLLET	10	—	C	
4550	1880/951A	COVER assy.	1	—	MR/B	FA.4
6535	1880/951A/UN	COVER assy.	1	—	MR/B	
		Spares for:—				
28M/10211	AGS.2008-B3	NUT, anchor	2	—	C	
28M/18641	A.141-B	NUT, anchor	2	—	C	
28M/16456	AGS.2019-B3	NUT, anchor	2	—	C	
28M/9482082	A.162-B	NUT, anchor	2	—	C	
5L/9959118		FILAMENT, 28V .04A	13	—	B	FA.2
8010	1880/953	FRAME, indicator (Mod. 133)	2	—	MR/C	FA.4
5404	1880/1201A	HOLDER assy	1	—	MR/C	FA.4

RESTRICTED

EQUIPMENT—AIRCRAFT DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 15

REF No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
5CX/5319	Thorn 80-10-0281	LAMPHOLDER	2	—	C	
4553	Cannon 20418-2	LOCK, female	2	—	C	
5K/	Permark B.3 x 1/8"	MARKER, P.V.C. (coded yellow)	A/R	—	C	
4559	1880/965	PACKING	4	—	MR/C	FA.4
4560	1880/967	PACKING	2	—	MR/C	FA.4
6536	1880/1317	PILLAR, fixing	4	—	MR/C	FA.4
8011	1880/1347A	PLATE (Mod. 133)	2	—	MR/C	FA.4
1497105	1880/947D	PLATE, engraved, sub assy (Mod. 652)	1	—	MR/C	FA.4
	1880/949A	PLATE assy, front	1	—	MR	FA.4
10W/0113239	—	RESISTANCE, 220 ohms	1	—	C	FA.4
8012	1880/1329A	SCREEN, night (Mod. 133)	1	—	MR/C	FA.4
5CW/7807	Page A.223	SHROUD	1	—	C	FA.2
5CW/6751	Page A.236	SHROUD	1	—	C	FA.2
5K/	Permark A.3 x 1/4"	SLEEVE, synthetic black	A/R	—	C	
5K/	Permark A.5 x 1/4"	SLEEVE, synthetic black	A/R	—	C	
5K/	Permark A.3 x 1/2"	SLEEVE, synthetic red	A/R	—	C	
	1880/1331	SLIDE (Mod. 133)	2	—	MR	FA.4
4558	Cannon DB.25S	SOCKET, 25 pin	1	—	C	
8008	1880/947B/1	SWITCH (Mod. 133)	1	—	MR/B	FA.2
5CW/6403	Page C.180A/3/F	SWITCH	1	—	B	FA.2
5CW/7554	Page C.675A/2/M	SWITCH	1	—	B	FA.2
33B/636		VARNISH, polan	A/R	—	C	
5E/910-0175		WIRE, equipment red	A/R	—	C	
5E/910-0176		WIRE, equipment blue	A/R	—	C	
5E/910-0177		WIRE, equipment green	A/R	—	C	
5E/910-0178		WIRE, equipment yellow	A/R	—	C	
5E/910-0179		WIRE, equipment black	A/R	—	C	
5E/910-0180		WIRE, equipment white	A/R	—	C	
5E/910-0181		WIRE, equipment brown	A/R	—	C	
5E/910-0185		WIRE, equipment pink	A/R	—	C	
285/1008085	A.32-B32	Attachment parts for 947A/5 and 947A/UN/5:—				
285/1012446	A.205-B32	Screw	3	—	C	
		Screw	3	—	C	
6B/2977	Ferranti	INDICATOR, directional, type A	1	—	A	FA.2
28DU/9419607	A.113-12B	Attachment parts for 6B/2977:—				
		Bolt	2	—	C	
5GZ/5074		INDICATOR (external tanks empty)	2	—	B	FA.2
6A/8538	Sangamo Weston S.63-4-1287	INDICATOR, fuel trim (Mod. 455)	1	—	B	FA.2
285/1012446	A.205-B32	Attachment parts for 6A/8538:—				
		Screw	4	—	C	
6A/8465	Smith PW/1.HSD	INDICATOR, flap	1	—		FA.2
6A/5653		Attachment parts for PW/1.HSD:—				
		Clamp, indicator flap	1	—	B	FA.2
5CZ/5003		INDICATOR, oxygen	1	—	B	FA.2
6A/5845		INDICATOR, rate of climb, Mk. 3P	1	—	A	FA.2
		(Pre-mod. 533)				
5CX/5477		Attachment parts for 6A/5845:—				
28S/1008085	A.32-B32	Bridge piece, type C	1	—	B	FA.2
		Screw	4	—	C	
6A/7677	—	INDICATOR, rate of climb, Mk. 3Q (Mod. 533) ...	1	—	A	FA.2
		Spares for:—				
28F/4051943	AGS.3095	CONNECTOR, static	1	—	C	
28F/19987	AGS.3099	GASKET, "O" ring	1	—	C	
5CX/5477		Attachment parts for 6A/7677:—				
28S/1008085	A.32-B32	Bridge piece, type C	1	—	B	
		Screw	4	—	C	

RESTRICTED
EQUIPMENT—AIRCRAFT

GNAT T. Mk. 1

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 19

REF. No.	PART NUMBER	DESCRIPTION					No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
		1	2	3	4	5			M.R. L.M.	
6A/3251						INDICATOR 5, R.P.M.	1	—	A	FA.2
19 6A/1037233						Attachment parts for 6A/3251:—				
19 6A/7002040						Clamp (Alt. to 6A/7002040)	1	—	C	FA.2
6A/4984						Clamp (Alt. to 6A/1037233)	1	—	C	FA.2
						INDICATOR, temperature, exhaust gas	1	—	A	FA.2
19 6A/1037233						Attachment parts for 6A/4984:—				
19 6A/7002040						Clamp (Alt. to 6A/7002040)	1	—	C	FA.2
						Clamp (Alt. to 6A/1037233)	1	—	C	FA.2
5CX/5762	Dowty DN.1050-Z					INDICATOR, undercarriage	1	—	B	FA.2
19 6A/1037233						Attachment parts for 5CX/5762:—				
19 6A/7002040						Clamp (Alt. to 6A/7002040)	1	—	C	FA.2
						Clamp (Alt. to 6A/1037233)	1	—	C	FA.2
4130	1880/663A					LAMPHOLDER assy	1	—	MR/B	FA.2
7880	1880/663A/UN					LAMPHOLDER assy	1	—	MR/B	
						Spares for:—				
28N/18917	AS.4937/37					INSERT, wire thread	4	—	C	
28N/9482122	AS.8456/37					INSERT, wire thread	4	—	C	
8683	1804/1237					LABEL (Mod. 442)	1	—	C	FA.2
	1804/1247					LABEL (Mod. 513)	1	—		FA.2
4131	1880/655A					LAMPHOLDER assy	1	—	MR/B	
7881	1880/655A/UN					LAMPHOLDER assy	1	—	MR/B	
						Spares for:—				
28N/18917	AS.4947/37					INSERT, wire thread	4	—	C	
28N/9482122	AS.8456/37					INSERT, wire thread	4	—	C	
5CX/5491						LIGHT, pillar	28	—	B	FA.2
6A/3300						MACHMETER	1	—	A	FA.2
						Attachment parts for 6A/3300:—				
5CX/5477						Bridge piece	1	—	B	FA.2
28S/1008085	A.32-B32					Screw	4	—	C	
8312	1880/1125A/2					PANEL, assy, secondary warning (Mod. 291)	1	—	MR/B	FA.4
						Spares for:—				
3928	1880/627					BUSH, insulating (Amendt. 620/4)	1	—	MR/C	FA.4
3929	1880/865					BUSH, insulating	1	—	MR/C	FA.4
8313	1880/653/2					COVER (Mod. 291)	1	—	MR/C	FA.4
4923	1880/1127					PAD	1	—	MR/C	FA.4
8315	1880/1361A/1					SCREEN assy (Mod. 291)	1	—	MR/C	FA.4
						Spares for:—				
8023	1880/1403					LABEL, "AC"	1	—	C	
8022	1880/1401					LABEL, "DC"	1	—	C	
8025	1880/1407					LABEL, "ELEV"	1	—	C	
8021	1880/1399					LABEL, "FUEL"	1	—	C	
8020	1880/1397					LABEL, "F.TR"	1	—	C	
8024	1880/1405					LABEL, "HOOD"	1	—	C	
8018	1880/1391					LABEL, "ICE"	1	—	C	
8019	1880/1395					LABEL, "OIL"	1	—	C	
8026	1880/1409					LABEL, "TRIM"	1	—	C	
8316	1880/1427/1					SCREEN, night (Mod. 291)	1	—	MR/C	FA.4
4195	1880/901					SLIDE	1	—	MR/C	FA.4
						Attachment parts for 1880/1125A:—				
28S/1008085	A.32-B32					Screw	3	—	C	
28W/1200328	AGS.2037-B					Washer	3	—	C	
	1880/635B/7					PANEL, sub-assy (Mod. 708)	1	—	MR/B	FA.2
						Spares for:—				
7673	1880/1465					FAIRLEAD, front instrument panel (Mod. 66) .	2	—	MR/C	FA.2
4124	1880/889					LABEL, "ANTI-ICE"	1	—	MR/C	FA.2

RESTRICTED

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 19

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
	1880/871	LABEL, compass control	1	—	MR	FA.3
	1880/1311	LABEL, "FLIGHT DIRECTOR" (Mod. 103)	1	—	MR	FA.2
	1880/1203	LABEL, "EXTERNAL TANKS EMPTY"	1	—	MR	
4122	1880/679	LABEL, fast erection, A.H.	1	—	MR/C	FA.2
4121	1880/677	LABEL, fast erection, nav	1	—	MR/C	FA.2
	1880/1301	LABEL, "LOW FUEL" (Mod. 66)	1	—	MR	
4120	1880/673	LABEL, oxygen flow	1	—	MR/C	FA.2
	1880/1307	LABEL, pitot static valve	1	—	MR	
4119	1880/671	LABEL, standby	1	—	MR/C	FA.2
28P/1202460	SP.9-C4	PLATE, split	4	—	C	
	1880/1205	PLATE, blanking	1	—	MR	FA.2
	1880/1751	PLATE, mounting (Mod. 708)	1	—		
		Attaching parts for 1880/1751:—				
28S/16871	A.204-B40	Screw	2	—	C	
28M/1275903	AS.8600-B	Nut	2	—	C	
5CX/5642	Thorn 80/10/0280	PLUNGER assy	18	—	B	
28S/1200066	A.33-B20	SCREW	4	—	C	
28S/9998419	A.204-B20	SCREW	4	—	C	
4193	1880/647A	SHIELD, oxygen indicator	1	—	MR/C	FA.2
5CX/5761	Thorn 80/10/0277	SPRING, contact	18	—	C	
5408	1880/1189	STQP, rubber	2	—	MR/C	FA.2
5930-99- 051-0501						
		SWITCH	3	—	B	FA.2
	Pye 523/L.1	SWITCH, locking (Mod. 211)	1	—	B	
		Attaching parts for 523/L.1:—				
28S/1008085	A.32-B32	Screw	2	—	C	
28S/1012446	A.205-B32	Screw	2	—	C	
	Page Engineering					
5CW/8067	C/180/F20/GT	SWITCH, push	1	—	B	FA.2
5CW/8435	C/181/C1	SWITCH, push	1	—	B	FA.2
6A/5904		VALVE, pitot-static 2 way	1	—	A	FA.2
		Attachment parts for 6A/5904:—				
28D/1013284	AS.1248-2C	Bolt	2	—	C	
28DU/9419534	A.113-1D	Bolt	2	—	C	
28M/9433473	AGS.2002-C1	Nut	2	—	C	
6955	FOS.40/4	Nut	2	—	MR/C	
6852	FOS.6-3/16	Tag	1	—	MR/C	
4199	1880/651	WASHER	A/R	—	MR/C	FA.2
28W/9419475	SP.15-C	WASHER	2	—	C	
28W/1014056	SP.124-C	WASHER	2	—	C	
		PANEL assy, front, instrument, wired				
		(1881/1389A/1 and 1389A/UN/1)				
		PANEL assy, front, instrument, wired				
		(1881/1389A/2 and 1389A/UN/2)				
		(Mod. 295)				
		Spares for:—				
5K/7645	—	INSERT, socket	14	—	MR	
6775	1881/2199	LABEL, met-cal ""	2	—	MR/C	
	1881/1845A/2	LOOM assy, No. 48, front instrument panel	1	—	MR	
	1881/1845A/3	LOOM assy, No. 48, front instrument panel	1	—	MR	FA.2
		(Mod. 295)				
5X/7226	Hellermann HC.128	PIN, taper	14	—	MR	
		Attachment parts for 1881/1845A/3:—				
28E/9436819	AS.3180-3B	Clip, "P"	5	—	C	
28E/9436947	AS.3180-4B	Clip, "P"	7	—	C	
28E/1201807	AS.3180-5B	Clip, "P"	11	—	C	
28E/1201809	AS.3180-6B	Clip, "P"	3	—	C	

RESTRICTED

GNAT T. Mk. 1

EQUIPMENT—AIRCRAFT**DASHBOARDS, INSTRUMENTS AND PANELS**

Issued with A.L. No. 19

REF. No.	PART NUMBER	DESCRIPTION					No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
									M.R. L.M.	
		1	2	3	4	5				
28E/9000882	AS.3180-7B					Clip, "P"	2	—	C	
28E/8018278	AS.3180-8B					Clip, "P"	1	—	C	
28M/1086618	AGS.2002-B1					Nut	16	—	C	
6954	FOS.40/2					Nut	16	—	MR/C	
28S/9419453	A.31-B14					Screw	18	—	C	
28S/1201331	A.205-B14					Screw	18	—	C	
5F/2279	Hellermann HV.3254					Strapping	A/R	—	C	
5F/2280	Hellermann HV.3255					Studs	A/R	—	C	
28W/9419474	SP.15-B					Washer	29	—	C	
28W/9471274	SP.124-B					Washer	29	—	C	
						Attachment parts for 1880/497A/UN:—				
28M/9438423	A.125-E					Nut	4	—	C	
28W/9419405	SP.15-E					Washer	4	—	C	
28W/9471273	SP.124-E					Washer	4	—	C	
						PANEL assy, instrument, rear (1880/499A/1 and 499A/UN/1) (Mod. 295)		—	—	FA.3
						Spares for:—				
						PANEL assy, rear (1880/1687/2 and 1687A/UN/2) (Mod. 295)				
						Spares for:—				
6A/1146374	Kollsman L.83261-04-010					ALTIMETER, Mk. 30A (Mod. 708)	1	—	A	FA.3
						Attachment parts for 6A/1146374:—				
28S/	A.205-B40					Screw	4	—	C	
6A/6204138	Kollsman L84380-00-100					Plate, mooring	1	—	C	
6A/8978						ALTIMETER, cabin, combined Mk. 26 (Mod. 568)	1	—	A	FA.3
						Attachment parts for 6A/8978:—				
28S/1012446	A.205-B32					Screw	4	—	C	
5CW/7830	Page Engineering C/180/C1					BUTTON, push	1	—	B	FA.3
						Attachment parts for 5CW/7830:—				
	Page Engineering A.212					Nut	1	—		
4108	1880/873					CHANNEL	1	—	MR/C	FA.3
4107	1880/875					CHANNEL	1	—	MR/C	FA.3
5CX/5320	Thorn 80/10/0282					COLLET	18	—	C	
5L/9951271						FILAMENT	2	—	B	FA.3
5L/9959118						FILAMENT, 28V .04A	63	—	B	FA.3
6A/6217	Smith AG.124					GAUGE, fuel contents	1	—	A	FA.3
						Attachment parts for 6A/6217:—				
28S/2887	A.32-B32					Screw	4	—	C	
6A/2693						GAUGE, hydraulic pressure	1	—	A	FA.3
						Attachment parts for 6A/2693:—				
28S/1012446	A.205-B32					Screw	4	—	C	
6D/2605	B.O.C. 803161					GAUGE, oxygen contents (Mod. 255)	1	—	A	FA.3
						Attachment parts for 6D/2605:—				
28S/1008085	A.32-B32					Screw	4	—	C	

RESTRICTED

RESTRICTED
EQUIPMENT—AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 19

REF. No.	PART NUMBER	DESCRIPTION					No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
		1	2	3	4	5			M.R. L.M.	
6A/6006						HORIZON, artifical, standby Mk. 6D	1	—	A	FA.3
5CX/5477						Attachment parts for 6A/6006:—	1	—	B	FA.3
28S/1012446	A.205-B32					Bridgepiece, grey	3	—	C	
						Screw				
6A/8551	Kelvin Hughes PW/2202/KAB/ MB/1					INDICATOR, air speed (Mod. 385)	1	—	A	FA.3
28S/1012446	A.205-B32					Attachment parts for 6A/8551:—				
						Screw	4	—	C	
6B/2977						INDICATOR, directional	1	—	A	FA.3
28DU/9419607	A.113-12B					Attachment parts for 6B/2977:—				
						Screw	2	—		
6A/4984						INDICATOR, exhaust gas temperature	1	—	A	FA.3
						Attachment parts for 6A/4984:—				
19 6A/1037233						Clamp (Alt. to 6A/7002040)	1	—	C	FA.3
19 6A/7002040						Clamp (Alt. to 6A/1037233)	1	—	C	FA.3
5CZ/5074						INDICATOR, external tanks empty	2	—	B	FA.3
6A/8465	Smiths PW.1.HSD					INDICATOR, flap	1	—		FA.3
						Attachment parts for PW/1.HSD:—				
6A/5653	STD.1503					Clamp	1	—	C	
5CZ/5003						INDICATOR, oxygen	1	—	C	FA.3
6A/5845						INDICATOR, rate of climb	1	—	A	FA.3
						Attachment parts for 6A/5845:—				
5CX/5477						Bridgepiece, grey	1	—	B	
28S/2887	A.32-B32					Screw	4	—	C	FA.3
6A/7677						INDICATOR, rate of climb, Mk. 3Q (Mod. 533) ..	1	—	A	FA.3
						Spares for:—				
28F/4051943	AGS.3095					CONNECTION, static	1	—	C	
28F/19987	AGS.3099					GASKET, "O" ring	1	—	C	
						Attachment parts for 6A/7677:—				
5X/5477	—					Bridgepiece, type "C"	1	—	B	
28S/1008085	A.32-B32					Screw	4	—	C	
6A/3251						INDICATOR, % R.P.M., Mk. 11	1	—	A	FA.3
						Attachment parts for 6A/3251:—				
19 6A/1037233						Clamp (Alt. to 6A/7002040)	1	—	C	FA.3
19 6A/7002040						Clamp (Alt. to 6A/1037233)	1	—	C	FA.3
6A/8449	Smiths PW/885-FL					INDICATOR, tailplane	1	—	A	FA.3
28S/1008085	A.32-B32					Attachment parts for PW.885-FL:—				
						Screw	4	—	C	
5CX/5762	Dowty DN/1050Z					INDICATOR, undercarriage	1	—	B	FA.3
						Attachment parts for 5CX/5762:—				
19 6A/1037233						Clamp (Alt. to 6A/7002040)	1	—	C	FA.3
19 6A/7002040						Clamp (Alt. to 6A/1037233)	1	—	C	FA.3
8683	1804/1237					LABEL (Mod. 442)	1	—	C	FA.3
—	1804/1247					LABEL (Mod. 513)	1	—	C	FA.3
	1880/1307					LABEL, 2-way valve	1	—	MR	FA.3
6A/2775						LABEL, fluorescent	1	—	C	
5CX/5133						LAMP, warning	2	—	C	FA.3
						Attachment parts for 5CX/5133:—				
28D/1007979	AS.1246/1B					Bolt	4	—	C	
28DU/9480226	A.116-1B					Bolt	4	—	C	
28M/1086618	AGS.2002-B1					Nut	4	—	C	
6954	FOS.40/2					Nut	4	—	MR/C	

RESTRICTED

RESTRICTED
EQUIPMENT—AIRCRAFT

GNAT T. Mk. 1

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 19

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
‡4130	1880/663A	LAMPHOLDER assy	1	—	MR/B	FA.3
7880	1880/663A/UN	LAMPHOLDER assy	1	—	MR/B	
		Spares for:—				
28N/18917	AS.4947/37	INSERT, wire thread	4	—	C	
28N/9482122	AS.8456/37	INSERT, wire thread	4	—	C	
4131	1880/665A	LAMPHOLDER assy	1	—	MR/B	FA.3
7881	1880/665A/UN	LAMPHOLDER assy	1	—	MR/B	
		Spares for:—				
28N/18917	AS.4947/37	INSERT, wire thread	4	—	C	
28N/9482122	AS.8456/37	INSERT, wire thread	4	—	C	
5CX/5491		LIGHT, pillar	29	—	B	FA.3
6A/3300		MACHMETER	1	—	A	
		Attachment parts for 6A/3300:—				
28S/1008085	A.32-B32	Screw	4	—	C	
8031	1880/1109/1	PANEL, secondary warning (Mod. 133)	1	—	MR/B	FA.5
		Spares for:—				
3928	1880/627	BUSH, insulating	1	—	MR/C	FA.5
8028	1880/621/1	COVER (Mod. 133)	1	—	MR/C	FA.5
4936	1880/1113	PAD	1	—	MR/C	FA.5
8030	1880/1365A	SCREEN assy (Mod. 133)	1	—	MR/C	FA.5
		Spares for:—				
8021	1880/1399	LABEL, "FUEL"	1	—	C	
8020	1880/1397	LABEL, "F.TR"	1	—	C	
8018	1880/1391	LABEL, "ICE"	1	—	C	—
8019	1880/1395	LABEL, "OIL"	1	—	C	—
8029	1880/1425	SCREEN, night (Mod. 133)	1	—	MR/C	FA.5
4196	1880/883	SLIDE	1	—	MR/C	FA.5
		Attachment parts for 1880/1109/1:—				
28S/1008085	A.32-B32	Screw	2	—	C	
28W/1200328	AGS.2037B	Washer	2	—	C	
8035	1880/1111/1	PANEL, secondary warning (Mod. 133)	1	—	MR/B	FA.5
		Spares for:—				
3929	1880/865	BUSH, insulating	1	—	MR/C	FA.5
8032	1880/881/1	COVER (Mod. 133)	1	—	MR/C	FA.5
4936	1880/1113	PAD	1	—	MR/C	FA.5
8034	1880/1363A	SCREEN assy (Mod. 133)	1	—	MR/C	FA.5
		Spares for:—				
8023	1880/1403	LABEL, "AC"	1	—	C	
8022	1880/1401	LABEL, "DC"	1	—	C	
8025	1880/1407	LABEL, "ELEV."	1	—	C	
8024	1880/1405	LABEL, "HOOD"	1	—	C	—
8026	1880/1409	LABEL, "TRIM"	1	—	C	
8036	1880/1411A	SCREEN assy	1	—	C	FA.5
8033	1880/1429	SCREEN, night (Mod. 133)	1	—	MR/C	FA.5
4196	9880/883	SLIDE	1	—	MR/C	FA.5
		Attachment parts for 1880/1111/1:—				
28S/1008085	A.32-B32	Screw	2	—	C	
28W/1200328	AGS.2037B	Washer	2	—	C	
	1880/687B/4	PANEL, sub-assy (Mod. 708)	1	—	MR/B	
	1880/687B/UN/4	PANEL, sub-assy (Mod. 708)	1	—	MR/B	FA.3
		Spares for:—				

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 14

REF. No.	PART NUMBER	DESCRIPTION					No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
		1	2	3	4	5			M.R. L.M.	
6544	1880/1155					BRACKET	1	—	MR/C	
	1880/1203					LABEL, "EXTERNAL TANKS EMPTY"	1	—	MR	FA.3
4127	1880/695					LABEL, "FAST ERECTION AH"	1	—	MR/C	FA.3
4126	1880/693					LABEL, "FAST ERECTION NAV."	1	—	MR/C	FA.3
4125	1880/691					LABEL, "FAST ERECTION STANDBY DI" ...	1	—	MR/C	FA.3
4120	1880/673					LABEL, "OXY. FLOW"	1	—	MR/C	FA.3
6540	1880/629A					STOP assy (15th-24th A/C)	1	—	MR/C	FA.3
6541	1880/630A					STOP assy (15th-24th A/C)	1	—	MR/C	FA.3
6542	1880/1175A					STOP assy (25th and SUB A/C)	1	—	MR/C	FA.3
6543	1880/1176A					STOP assy (25th and SUB A/C)	1	—	MR/C	
28P/9429619	SP.9-C5					PIN, split	4	—	C	
	1880/1205					PLATE, blanking	1	—	MR	FA.3
5CX/5642	Thorn 80/10/0280					PLUNGER assy	18	—	B	
28S/1200066	A.33-B20					SCREW	4	—	C	
28S/9998419	A.204-B20					SCREW	4	—	C	
5CX/5761	Thorn 80/10/0277					SPRING, contact	18	—	C	
5CW/540						SWITCH, type B	1	—	B	
5CW/8067	Page Engineering C/180/F20.GT					SWITCH, push	1	—	B	FA.3
	Page Engineering A.212					Attachment parts for 5CW/8067:— Nut	1	—		
6A/5904						VALVE, 2-way pitot-static	1	—	A	FA.3
						Attachment parts for 6A/5904:— Bolt	2	—	C	
28D/1013284	AS.1248-2C					Bolt	2	—	C	
28DU/9419534	AS.113-1D					Bolt	2	—	C	
28M/10328	AGS.2002-C1					Nut	2	—	C	
6956	FOS.40/4					Nut	2	—	MR/C	
6852	FOS.6-3/16					Tag, wire locking	1	—	MR/C	
28W/9419475	SP.15-C					Washer	2	—	C	
28W/1014056	SP.124-C					Washer	2	—	C	

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
		PANEL assy, instrument, rear, wired (1881/1391A and 1391A/UN)				
		PANEL assy, instrument, rear, wired (1881/1391A/1 and 1391A/UN/1)				
		Spares for:—				
5CZ/6497	Ward Brooke WB.1110/S/5B	BLOCK, terminal	2	—	B	
		Attachment parts for 5CZ/6497:—				
28M/1086618	AGS.2002-B1	Nut	2	—		
28S/1200033	A.31-B24	Screw	2	—		
28W/9419474	SP.15-B	Washer	4	—		
	1881/2077A	LOOM, cable (Mod. 295)	1	—		
	1881/2077A/1	LOOM, cable (Mod. 295)	1	—		
		Spares for:—				
5X/7226	Hellermann HC.1281	PIN, taper (Mod. 295)	6	—	C	
7417	1881/1847	LOOM assy, No. 49, rear instrument panel	1	—	MR/B	
1443925	1881/1847/1	LOOM assy, No. 49, rear instrument panel	1	—	MR/B	FA.3
		(Mod. 295)				
		Spares for:—				
5X/7226	Hellermann HC.1281	PIN, taper (Mod. 295)	12	—	C	
5X/7645	—	SOCKET, insert (Mod. 295)	1	—	C	
	1881/2079	LOOM assy, No. 65 panel lights	1	—	—	
	1881/2079A/1	LOOM assy, No. 65 panel lights (Mod. 295)	1	—	—	FA.3
		Spares for:—				
5X/7226	Hellermann HC.1281	PIN, taper	4	—	C	
		Attachment parts for 1881/1847/1 and 2079/1:—				
5412	1881/1659A	Clip assy	2	—	MR/C	FA.3
28E/9436819	AS.3180-3B	Clip, "P"	2	—	C	
28E/9436947	AS.3180-4B	Clip, "P"	5	—	C	
28E/1201807	AS.3180-5B	Clip, "P"	17	—	C	
28E/1201809	AS.3180-6B	Clip, "P"	1	—	C	
28E/9000882	AS.3180-7B	Clip, "P"	2	—	C	
5416	1881/1543	Piece, distance	1	—	MR/C	FA.3
28M/1086618	AGS.2002-B1	Nut	11	—	C	
28M/9438426	A.126-B	Nut	11	—	C	
28S/1200034	A.31-B16	Screw	12	—	C	
28S/1200033	A.31-B24	Screw	2	—	C	
28S/1201335	A.205-B16	Screw	1	—	C	
5F/2279	Hellermann HV.3254	Strapping	A/R	—	C	
5F/2280	Hellermann OP.3255	Stud, Helvyn, P.V.C.	A/R	—	C	
33B/636		Varnish	A/R	—	C	
28W/1200328	AGS.2037-B	Washer	4	—	C	
28W/9419474	SP.15-B	Washer	26	—	C	
5419	1881/1669	PLATE, mounting	1	—	MR/C	FA.3
		Attachment parts for 1881/1669:—				
5417	1881/1655	Piece, distance	3	—	MR/C	FA.3
7412	1881/2107	Piece, distance	3	—	MR/C	FA.3
28S/1200034	A.31-B16	Screw	3	—	C	
28S/1200033	A.31-B24	Screw	3	—	C	
28S/1201335	A.205-B16	Screw	3	—	C	
28S/16873	A.205-B24	Screw	3	—	C	
	AS.2810-4-030	Tube, distance	3	—	MR/LM	
28W/1200328	AGS.2037-B	Washer	3	—	C	

RESTRICTED**EQUIPMENT-AIRCRAFT****DASHBOARDS, INSTRUMENTS AND PANELS**

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
28M/9438423	A.125-E	Attachment parts for 1880/499A and 499A/UN:—				
28W/9419405	SP.15-E	Nut	4	—	C	
28W/9471273	SP.124-E	Washer	4	—	C	
		Washer	4	—	C	
		PANEL and Shroud assy, instrument top (1880/1545A and 1545A/UN) (Mod. 299)				
		Spares for:—				
6A/6443		ACCELEROMETER	1	—	A	FA.3
		Attachment parts for 6A/6443:—				
28S/9998415	A.205-B28	Screw	3	—	C	
28W/9471274	SP.124-B	Washer	3	—	C	
	Smiths					
6A/8461	PW/TW/HSD/BU	INDICATOR, aileron position (Mod. 299)	1	—	A	FA.3
		Attachment parts for 6A/8461:—				
6A/5653		CLAMP (Mod. 299)	1	—	C	
5CZ/4335566		INDICATOR, electro-magnetic (Mod. 299)	2	—	B	FA.3
	Sangamo-Weston					
6A/9119	S.63-4-1287.W	INDICATOR, feel, trim (Mod. 455)	1	—	B	
		Attachment parts for 6A/9119:—				
28S/999415	A.205-B28	Screw	4	—	C	
28W/9471274	A.124-B	Washer	4	—	C	
	1880/1647	LABEL, yaw indicator, left (Mod. 403)	1	—	MR	FA.5
	1880/1649	LABEL, yaw indicator, right (Mod. 403)	1	—	MR	FA.5
28M/9438441	A.130-J	NUT	1	—	C	
28M/10318	AGS.2002-B3	NUT	1	—	C	
28M/9438437	A.130-B	NUT	1	—	C	
‡8559	1880/1545F/UN	PANEL assy	1	—	MR/B	FA.5
		Consisting of:—				
‡7836	1881/2727	BRACKET (Mod. 708)	1	16G. L.73	LM	
‡7837	1880/513/1	CHANNEL, reinforcing, port (Mod. 197)	1	—	MR/C	FA.5
‡7838	1880/513/UN/1	CHANNEL, reinforcing, port (Mod. 197)	1	MR/C		
‡8164	1880/515/1	CHANNEL, reinforcing, starboard (Mod. 197)	1	MR/C	FA.5	
8161	1880/1671A	PANEL assy, instrument, upper (Mod. 299)	1	—	MR/C	FA.5
8162	1880/1619A	SHROUD assy (Mod. 353)	1	—	C	FA.6
	1880/1619A/UN	SHROUD assy (Mod. 353)	1	—	MR/C	—
		Spares for:—				
8879	1880/1613A	BRACKET	1	—	MR/C	FA.6
8163	1880/1615	SHROUD	1	—	C	FA.6
‡7776	1880/1549A	SHROUD assy (Mod. 299)	1	—	C	FA.5
‡7777	1880/1549A/UN	SHROUD assy (Mod. 299)	1	—	MR/C	
		Spares for:—				
7766	1880/1595	ANGLE (Mod. 299)	1	—	MR/C	
		Attachment parts for 1880/1595:—				
28D/8337	AS.1248-1B	Bolt	2	—	C	
28DU/9419535	A.113-1/2B	Bolt	2	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
28W/9471274	SP.124-B	Washer	2	—	C	
7765	1880/1563	ANGLE, plug attachment (Mod. 299)	1	—	MR/C	FA.5
28M/13774	AGS.2019-B1	NUT, anchor	2	—	C	
28M/9438470	A.158-B	NUT, anchor	2	—	C	

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 18

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
28S/9435712	A.31-B8	SCREW	1	—	C	FA.5
28S/9994992	A.205-B8	SCREW	1	—	C	
7779	1880/1605	TUBE, distance (Mod. 299)	2	—	MR/C	
28W/9419477	SP.15-J	WASHER	1	—	C	
28W/17546	SP.124-J	WASHER	1	—	C	
		Attachment parts for 1880/1545A and 1545A/UN:—				
28D/15616	AS.4598-1C	Bolt	3	—	C	FA.5
28DU/9419534	A.113-1D	Bolt	3	—	C	
28M/10328	AGS.2002-C1	Nut	2	—	C	
6956	FOS.40/4	Nut	2	—	MR/C	
28W/9419475	SP.15-C	Washer	3	—	C	
28W/9457834	SP.124-C	Washer	3	—	C	
28S/2796	A.31-C40	SCREW, for panel stop	1	—	C	FA.4
28S/1008305	A.205-D40	SCREW, for panel stop	1	—	C	
		SHIELD assy, anti-glare (1880/541A and 541A/UN) ...				
		Spares for:—				
6A/5418		ACCELEROMETER	1	—	A	
		Attachment parts for 6A/5418:—				
28D/12536	A.25-13C	Bolt	1	—	C	FA.4
28DU/9419570	A.102-13D	Bolt	1	—	C	
28M/10328	AGS.2002-C1	Nut	1	—	C	
6956	FOS.44/4	Nut	1	—	MR/C	
28W/9419475	SP.15-C	Washer	1	—	C	
28W/9457834	SP.124-D	Washer	1	—	C	
18 9619	1880/1371A	ANGLE assy, guide, port	1	—	MR	FA.4
18 9620	1880/1373A	ANGLE assy, guide, starboard	1	—	MR	FA.4
‡ 7567	1880/541AK	ANGLE sub-assy	1	—	MR/C	FA.4
4545	1880/547	BEARING	1	—	MR/C	FA.4
4527	1880/559	BEARING	1	—	MR/C	FA.4
5CX/5478		BRIDGE, pillar light, port	2	—	B	FA.4
		Attachment parts for 5CX/5478:—				
28S/1200033	A.31-B24	Screw	2	—	C	FA.4
28S/9129541	A.205-B24	Screw	2	—	C	
28D/9480230	A.116-5B	Bolt	2	—	C	
28W/9416642	SP.47-B	Washer	2	—	C	
7416	1881/2039A	CABLE assy, No. 56	1	—	MR	FA.4
	1881/2041A	CABLE assy, No. 57	1	—	MR/B	FA.4
9160	1880/1285A	CARDHOLDER assy, frequency, wired, port	1	—	—	FA.4
6564	1880/1285A/UN	CARDHOLDER assy, frequency, wired, port	1	—	MR/C	
		Spares for —				
7415	1881/2045A	CABLE assy, No. 59	1	—	MR/B	FA.4
5L/9959118		FILAMENT, 28V, .04A	4	—	B	FA.4
5CX/5844	Thorn 80-10-0071	HOLDER, lamp	4	—	B	FA.4
28M/12099	AGS.2007-B3	NUT, anchor	4	—	C	
28M/9482093	A.140-B	NUT, anchor	4	—	C	
		Attachment parts for 1880/1285A and 1285A/UN:—				
28D/15896	AS.4566-1B	Bolt	2	—	C	FA.4
28DU/9480248	A.170-1B	Bolt	2	—	C	
28W/9419474	SP.15-B	Washer	2	—	C	
28W/17542	SP.124-B	Washer	2	—	C	

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 12

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
9159	1880/1227A	CARDHOLDER assy, frequency, starboard	1	—	—	FA.4
6567	1880/1227A/UN	CARDHOLDER assy, frequency, starboard	1	—	MR/C	
		Spares for:—				
7414	1881/2047A	CABLE assy, No. 60	1	—	MR/B	FA.4
5L/9959118		FILAMENT, 28V, .04A	4	—	B	FA.4
5CX/5844	Thorn 80-10-0071	HOLDER, lamp	4	—	B	FA.4
28M/12099	AGS.2007-B3	NUT, anchor	4	—	C	
28M/9482093	A.140-B	NUT, anchor	4	—	C	
		Attachment parts for 1880/1227A and 1227A/UN:—				
28D/1007982	AS.1248-1C	Bolt	1	—	C	
28DU/9419534	A.113-1D	Bolt	1	—	C	
28W/9419475	SP.15-C	Washer	1	—	C	
28W/9457834	SP.124-D	Washer	1	—	C	
4910	1875-1159	Gasket (Mod. 492)	1	—	C	FA.4
6A/2693		GAUGE, pressure	1	—	A	FA.4
		Attachment parts for 6A/2693 —				
28D/9140644	A.25-9C	Bolt	1	—	C	
28DU/9419970	A.102-9D	Bolt	1	—	C	
28M/10328	AGS.2002-C1	Nut	1	—	C	
6956	FOS.40/4	Nut	1	—	MR/C	
28W/9419475	SP.15-C	Washer	1	—	C	
28W/9457834	SP.124-D	Washer	1	—	C	
6A/8461	Smith PW/52/HSD/BU	INDICATOR, aileron position (Mod. 299)	1	—	A	
		Attachment parts for 6A/8461 —				
6A/5653		Clamp (Mod. 299)	1	—	C	
5CZ/5073		INDICATOR, electro-magnetic (Mod. 299)	2	—	B	
5CX/5133		LAMP, warning, Type D	2	—	B	FA.4
		Attachment parts for 5CX/5133 —				
28D/15783	AS.4598-1B	Bolt	4	—	C	
28DU/9419536	A.113-1B	Bolt	4	—	C	
28M/10327	AGS.2002-B1	Nut	4	—	C	
6954	FOS.40/2	Nut	4	—	MR/C	
7368	1880/541AL/UN	MEMBER assy, edge	1	—	MR/C	FA.4
		Spares for:—				
±6588	1311/3317A/UN	PLATE assy, bolt	2	—	MR/C	
		Attachment parts for 1880/541AL/UN:—				
28DU/9419566	A.102-3D	Bolt	2	—	C	
28DU/9419597	A.113-2B	Bolt	5	—	C	
28DU/9419534	A.113-1D	Bolt	2	—	C	
28M/9438428	A.126-D	Nut	2	—	C	
28W/17542	SP.124-B	Washer	5	—	C	
28W/9457834	SP.124-D	Washer	6	—	C	
	1880/1721	MOUNTING sub-assy, stopwatch (Mod. 586)	1	—	MR	
		Spares for:—				
6B/3822		STOPWATCH	1	—	A	

RESTRICTED

EQUIPMENT-AIRCRAFT

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 17

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
1483531	1880/1695	PIPE assy, de-mist (Mod. 492)	1	—	B	FA.4
		Spares for:—				
4926	1880/1059A	CONNECTION assy	1	—	C	FA.4
		Attachment parts for 1880/1695:—				
28DU/9419566	A.102-3D	Bolt	2	—	C	
28D/9419534	A.25-3C	Bolt	2	—	C	
4910	1875/1159	Gasket	1	—		FA.4
28W/9419475	SP.15-C	Washer	2	—	C	
28W/9457834	SP.124-D	Washer	2	—	C	
1443989	1880/1539A/2	SHIELD assy, anti-glare (Mod. 386)	1	—	MR/C	FA.4
1443990	1880/1539A/UN/2	SHIELD assy, anti-glare (Mod. 403) (Mod. 586)	1	—	MR/C	
		Spares for:—				
7766	1880/1595	ANGLE (Mod. 299)	1	—	MR/C	
		Attachment parts for 1880/1595:—				
28DU/9419535	A.113-1/2B	Bolt	2	—	C	
28M/9438246	A.126-B	Nut	2	—	C	
28W/9471274	SP.124-B	Washer	2	—	C	
7765	1880/1563	ANGLE, plug attachment (Mod. 299).	1	—	MR/C	
†8756	1880/1541/1	PANEL, instrument (Mod. 403)	1	—	MR/C	
		Attachment parts for 1880/1539A/UN:—				
28DU/9419534	A.113-1D	Bolt	2	—	C	
28M/9157972	A.126-D	Nut	4	—	C	
28W/9457834	SP.124-D	Washer	4	—	C	
		SHIELD (wired) assy, anti-glare (1881/2405A and A/UN) (Mod. 299)				
		Spares for:—				
9197	1881/2305A	CABLE assy, No. 78 (Mod. 299)	1	—	MR	
		Spares for:—				
5CX/5491		PILLAR, light	5	—	C	
5L/9959118		FILAMENT	4	—	C	
		Attachment parts for 1881/2305A:—				
28D/9128739	AS.1248-1/2B	Bolt	4	—	C	
28DU/9419535	A.113-1/2B	Bolt	5	—	C	
	Insuloid Ltd.					
5K/9325192	NX.3	Plasklip	5	—	MR/C	
28M/1086618	AGS.2002-B1	Nut	5	—	C	
7030	FOS.63/2/1	Nut	5	—	MR/C	
28W/9419474	SP.15-B	Washer	5	—	C	
28W/9471274	SP.124-B	Washer	5	—	C	
7342	1880/1357A	STRAP assy	1	—	MR/C	FA.4
7343	1880/1341A	STRAP assy	1	—	MR/C	FA.4
5CW/8963		SWITCH	2	—	B	
9043	1880/1661	SPRING (Amendt. 260A)	2	—	MR/C	FA.1
	1880/269	STOP, synthetic rubber, 2" x 1.2" x .75"	2	Shore 35-40	MR/LM	
4573	1880/935	TUBE, distance	2	—	MR/C	FA.1
4574	1880/937	TUBE, distance	4	—	MR/C	FA.1
28W/11059	AGS.2037-C	WASHER, for panel stop	1	—	C	
8254	1880/1537	WASHER, packing	4	—	C	FA.5

RESTRICTED

A/C SERIAL NOS.

EQUIPMENT AIRCRAFT

ADDENDUM PAGE FA. 1

XM 704-709 ONLY

DASHBOARDS, INSTRUMENTS AND PANELS

Issued with A.L. No. 6

REF. No.	PART NUMBER	DESCRIPTION	No. OFF	MATL. SPEC.	CL. OF ST.	PLATE No.
					M.R. L.M.	
		1 2 3 4 5				
		G.A. OF INSTRUMENTS AND PANELS (1880/501A)				
		Spares for:-				
		PANEL assy, instrument, front (1880/497A)				
		Spares for:-				
		PANEL assy, (1880/635A)				
		Spares for:-				
6A/5650	Smith I.H.S.D.	INDICATOR, flap position	1	-	A	FA. 2
		PANEL assy, instrument, rear (1880/499A)				
		Spares for:-				
		PANEL assy, (1880/687A)				
		Spares for:-				
6A/5650	Smith I.H.S.D.	INDICATOR, flap position	1	-	A	FA. 3

RESTRICTED

Gnat T. Mk.1


RESTRICTED

Plate FA.1

Issued with AL No.17

INSTRUMENTS AND PANELS, ASSEMBLY.

(REF. DRG. 1880/501A)




FA.1


EQUIPMENT AIRCRAFT

FA.1


RESTRICTED









INSTRUMENT PANEL, IN FRONT COCKPIT
(REF DRG 1880/635A/5)





INSTRUMENT PANEL, IN REAR COCKPIT.
(REF. DRG. 1880/499/1)





DETAILS

(INSTRUMENTS & PANELS IN REAR COCKPIT)



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

