

Chapter 1  
ELECTRICAL SYSTEM

LIST OF GROUPS

- 1 General information
- 2 *(Not used)*
- 2A D.C. Power and Distribution (Post Mod.697)
- 3 A.C. Power and Distribution
- 3A A.C. Power and Distribution (Post Mod.353 and 395)
- 4 Engine Starting and Ignition
- 5 Fuel System Controls (Pre Mod.38 and 274)
- 5A Fuel System Controls (Post Mod.38 and 274)
- 6 Flying Controls
- 7 Alighting Gear Controls
- 8 Heating Ventilation and De-Icing Controls  
(Pre.Mod.176 and 177)
- 8A Heating and Ventilation Controls  
(Post Mod.176 and 177)
- 9 Warning and Emergency Equipment
- 10 Lighting
- 11 Miscellaneous
- 12 ◀ Bomb Fuzing and Release - Normal
- 13 Bomb Fuzing and Release - Special ▶
- 14 E.C.M. Power Supplies
- 15 E.C.M. Cooling System

RESTRICTED

This file was downloaded  
from the RTFM Library.  
Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

