

VULCAN No. 2

EQUIPMENT, SPECIAL OPERATIONAL (S.O.O.)

Page HE. 1

ALTERNATIVE PANEL FOR 6000 LB.

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of	Plate and Illust'n No.
					St. M.R.	
		1 2 3 4				
11022	7V8963	ALTERNATIVE BOMBING PANEL	1	—	A	
		(Mod. 537) (1339)				
		Spares for:—				
5X/4491769	1V7870	Block, earthing, 12 amp.	1	—	C	
5X/4500051	—	Block, fuse, 6-way	1	—	C	
	5V8963	BOARD, RESISTOR MOUNTING,	1	—		
		GROUP				
		Spares for:—				
	WELWYN					
10W/0216096	—	Resistor, 62K	1	—		
5CY/9992777	—	Breaker, circuit, 25 amp.	1	—	B	
5CY/9550804	—	Breaker, circuit, 35 amp.	1	—	B	
5CY/4376383	—	Breaker, circuit, 15 amp.	1	—	B	
5CY/4376060	—	Breaker, circuit, 45 amp.	1	—	B	
5L/9959122	A260	Bulb, 28V 2W	4	—	B	
	6V8963	Bus-bar	1	—		
	3SS4171	Connector, terminal	1	—		
5CY/4520	—	Cover, circuit-breaker	4	—	C	
10H/9718192	AS5	Fuse, 5 amp.	1	—	C	
10H/9718191	AS10	Fuse, 10 amp.	1	—	C	
10H/23860	AS20	Fuse, 20 amp.	1	—	C	
5CW/5756	—	Guard, locking	1	—	C	
	PAGE					
	C500D	Indicator, "press to test" white lamp	1	—		
	PAGE					
	C500A	Indicator, "press to test" red lamp	1	—		
	PAGE					
	C500C	Indicator, "press to test" amber lamp	1	—		
5CX/1645	—	Lamp, warning, clear	1	—	B	
5X/4500062	—	Link, commoning, 6-way	1	—	C	
	1V8932	LOOM, CABLE, GROUP		—		
	9V8963	PANEL, C/W LABELS, GROUP	1	—		
	ROTAX					
5CW/4405757	N13531	Plate	2	—	C	
5CW/5014	—	Relay, type 9B, No. 1	1	—	B	
	ROTAX					
5CW/4405756	N135530	Shroud	1	—	C	
5CW/1085840	A257	Support, and cable sleeve	3	—	C	
5CW/1047699	—	Switch, double	1	—	B	
5CW/5823	—	Switch, single pole	1	—	B	
5CW/5825	—	Switch, single pole	1	—	B	
	FERRANTI					
	R132	Transformer		—		
	HIVAC					
5L/9962110	CC10L	Tube, neon	1	—	B	

EQUIPMENT, SPECIAL OPERATIONAL (S.O.O.)
ROCKET ASSISTED TAKE OFF (REMOVABLE EQUIPMENT)

Ref. No.	Part No.	Description	No. off				Matl. Spec.	Cl. of St.	Plate and Illust'n No.
			1	2	3	4		M.R.	
		EQUIPMENT, REMOVABLE, FOR ATTACHMENT OF SPECTRE NACELLE, PORT AND STARBOARD (0-3748) (Mod. 2) Spares for :—							
	BSS1425	Eyebolt, 1/4" BSF, drogue line attachment...	1			—		HF1/1	
	128325	HOUSING, RELEASE UNIT, L.H., GROUP	1			—		HF1/2	
	22Z8325	Spares for :— Block, terminal (made from G.E.C. Ltd. Ltd. Part. No. C7039P)	1			—		HF1/3	
11A/1082747		Block, terminal contactor ...	2			—	C	HF1/4	
	13Z8325	Bush, flanged, 1 1/2" dia. x 1" long ...	1			DTD130		HF1/5	
	12Z8325	Bush, flanged, 1 1/4" dia. x 3/8" long ...	1			DTD130		HF1/6	
5K/9517023	SP40C8	Grommet ...	1			—	C	HF1/7	
5K/9518243	SP40C10	Grommet ...	1			—	C	HF1/8	
	7085S6002	Label, "forward" ...	1			L59		HF1/9	
	21Z8325	LOOM, CABLE, GROUP ...	1			—		HF1/10	
	14Z8325	Plunger, 3/4" dia. x 4" long ...	1			S1		HF1/11	
	15Z8325	Spring, 22G, spring wire ...	1			—		HF1/12	
	VICKERS A1832/131	Strip, rubber ...	2			—		HF1/13	
11A/4082	—	Unit, electrical mechanical jettison ...	1			—	A	HF1/14	
5576	1Z9147	PANEL, ACCESS, INCORPORATING DOOR OVER R.A.T.O. NACELLE RELEASE, GROUP	1			—	A	HF1/15	
	12Z9147	Spares for :— Bearing, spigot, .625" x 2.25" x 1.0" ...	4			L65		HF1/16	
28N/5548	AGS899/1	Collar, 3/8" i/dia., plunger and door connector	2			—	C	HF1/17	
	7Z9147	DOOR, ACCESS, L.H., GROUP ...	1			—		HF1/18	
	8Z9147	DOOR, ACCESS, R.H., GROUP ...	1			—		HF1/19	
	9Z9147	Housing, plunger, 3/8" x 2 1/2" long ...	2			L56		HF1/20	
28N/9156370	SP21	Nipple, lubricating, 1/4" BSF ...	2			—	C	HF1/21	
	3Z9147	PANEL, ACCESS, GROUP ...	1			—		HF1/22	
	EFS/45B	Spares for :— Fastener, self ejecting ...	10			—	C	HF1/23	
	14Z9147	Pin, eccentric, 1/2" dia. x 1 1/2" long ...	2			S1		HF1/24	
28P/2211515	SP4/Y/A5	Pin, solid, 3/8" dia. ...	2			—	C	HF1/25	
28P/9710567	SP90/C4	Pin, split, 1/4" dia. x 1/2" long ...	2			—	C	HF1/26	
	10Z9147	Plunger, 3/4" dia. x 2.1" long ...	2			S1		HF1/27	
	13Z9147	Shim, laminated ...	4			—		HF1/28	
	11Z9147	Spring, 18G, spring wire ...	2			Spring steel		HF1/29	

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

