

**PART 4**  
**EMERGENCIES**

**List of Chapters**

	<b>Chapter</b>
<b>EMERGENCY PROCEDURES...</b>	<b>1</b>

## **PART 4**

### **CHAPTER 1 - EMERGENCY PROCEDURES**

#### **Contents**

	Para
General ... ..	1
<b>EMERGENCY PROCEDURES</b>	
Canopy Jettison ... ..	2
Abandoning ... ..	3

## **GENERAL**

1. Advice on emergencies procedures in the Viking is contained in the FRCs.

## **EMERGENCY PROCEDURES**

### **Canopy Jettison**

2. To jettison the canopy:
  - a. Pull the red canopy jettison handle on the right wall and the canopy opening lever on the left of the canopy both fully back simultaneously.
  - b. Push the canopy up and away.

### **Abandoning**

3. Abandon the aircraft as follows:
  - a. Jettison the canopy as described above.
  - b. Release the seat harness.
  - c. Stand up and exit from the side of the cockpit nearer to the ground.
  - d. When clear of the aircraft grip the parachute D-ring and pull firmly to its full extent.

**Note 1:** If circumstances permit, the rear seat pilot should abandon the aircraft first.

**Note 2:** The minimum safe height for abandonment is 800 feet AGL, in level flight.

4. The following table lists the location of the emergency procedures covered in the text of the Manual and in the Flight Reference Cards.

<i>Emergency</i>	<i>Location in Manual</i>			<i>Location in FRC (Card)</i>
	<i>Part</i>	<i>Chap</i>	<i>Para</i>	
Canopy jettison	4	1	2	4
Abandoning	4	1	3	4

*Intentionally Blank*