



9131B

Fig. 2 Pressure ratio control assembly
 (Effect of GFS 204)

Fig/ Index	Part No.	123456	Nomenclature	Usage Code	Units /Assy
2-	1	755-1-08722-001+	CONTROL ASSY, PRESSURE RATIO (SEE FIG 1 FOR NHA)	A	RF
	1h	755-1-09800-001+	CONTROL ASSY, PRESSURE RATIO (SEE FIG 1 FOR NHA)	B	RF
	2	568-4-24482-027	.SCREW, TRANSIT		2
	3	755-4-08498	.COVER, TRANSIT		1
	4	568-4-24482-028	.SCREW, TRANSIT		2
	5	755-4-08497	.COVER, TRANSIT		1
	6	RR51S	.CIRCLIP (K0009) (999-4-01549-002)		1
	7	755-4-05377	.FILTER		1
	8	RR51S	.CIRCLIP (K0009) (999-4-01549-002)		1
	9	755-4-05377	.FILTER		1
	10	755-2-07599	.NUT, SPECIAL		1
	11	755-2-08844	.ORIFICE		1
	12	RR51S	.CIRCLIP (K0009) (999-4-01549-002)		1
	13	755-4-05377	.FILTER		1
	14	755-2-08039	.CUP, SPRING		1
	15	755-4-07697	.SPRING, VALVE LOADING		1
	16	AS20908	.BOLT (U1653) (991-4-01440-008)		2
	17	983-4-98000-004	.WASHER		2
	18	755-2-08797	.COVER		1
	19	755-2-08986	.COVER		1
	20	AS20624	.NUT (U1653) (991-4-01425-005)		2
	21	983-4-98000-004	.WASHER		2
	22	AS20918	.BOLT (U1653) (991-4-01440-018)		1
	23	AS20909	.BOLT (U1653) (991-4-01440-009)		2
	24	AS20915	.BOLT (U1653) (991-4-01440-015)		1
R	25	755-1-08725	.ELEMENT ASSY, FLUIDIC GFS202	A	1
R	25h	755-1-09837-000	.ELEMENT ASSY, FLUIDIC GFS204	B	1
	26	AGS3706	..INSERT, SCREWLOCK (U1653) (991-4-01421-006)		2
	27	755-2-07786	.GASKET		1
	28	754-2-04006	.RING, RETAINING		1
	29	755-2-07951	.DOWEL		2
	30	755-2-06680-002	.SCREW		4
	31	983-4-98000-002	.WASHER		4
	32	755-4-08798	.LABEL	A	1
	32h	755-4-09826-000	.LABEL (PRE MOD 2581)	B	1
	32j	755-4-08798	.LABEL (POST MOD 2581)	B	1
	33	755-2-06955	.COVER		1
	34	A104-1D	.BOLT (K7766) (991-4-00115-002)		2

+ Item not illustrated

Fig./ Index	Part No.	Nomenclature 123456	Usage Code	Units /Assy
R 2 35	SP44C	.WASHER, TAB, R.H. (K7766) (991-4-00002-004)		1
R 36	SP46C	.WASHER, TAB, L.H. (K7766) (991-4-00002-056)		1
R 37	AL28A66	.LOCKNUT (K7766) (991-4-00056-043)		1
38	755-2-06950	.SCREW, ADJUSTING		1
39	755-2-08877	.PLATE, SUPPORT		1
40	755-2-08876	.BUSH, ELEMENT		2
41	755-2-08098	.CLIP, RETAINING		1
42	755-2-08150	.PLATE, SPRING SUPPORT		1
43	755-4-06944	.SPRING, VALVE RETURN		1
44	755-2-08170	.SEAT, SPRING		1
45	755-1-08086	.ROD ASSY, VALVE		1
46	755-1-08841 +	.HOUSING ASSY, VALVE (PRE MOD 2492)		1
R 46a	755-1-10043-000+	.HOUSING ASSY, VALVE (POST MOD 2492)		1
47	755-2-06962	..BEARING		1
R 48	AGS3731	..INSERT, SCREWLOCK (U1653) (991-4-01421-031)		2
R 49	AGS375c	..INSERT, SCREWLOCK (U1653) (991-4-01421-056)		4
50	755-2-08839 +	..HOUSING, VALVE (PRE MOD 2492)		RF
50a	755-2-10042-000	..HOUSING, VALVE (POST MOD 2492)		RF

+ Item not illustrated

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

