

Chapter Thirty-three

REASSEMBLING THE SUB-ASSEMBLIES

THIS CHAPTER, which describes the reassembling of the sub-assemblies prior to reassembling the complete engine, is sub-divided as follows:—

Main shaft assembly, including dynamic balancing	Chapter 33A
Air-intake	Chapter 33B
Centre housing.. .. .	Chapter 33C
Top wheelcase.. .. .	Chapter 33D
Bottom wheelcase	Chapter 33E
Oil sump	Chapter 33F
Diffuser casing.. .. .	Chapter 33G
Centre casing	Chapter 33H
Nozzle ring	Chapter 33I
Combustion chambers	Chapter 33J
Exhaust system	Chapter 33K
Miscellaneous	Chapter 33L

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

