

CHAP 4 AIRFRAME SP 454 AL 11 SHEET 1 OF 3	SERVICING PROCEDURE F53 T55	BAC F53 & T55 (SA) 5A3A Section 1 2nd Edition
Main Undercarriage Leg Fitting Jack Bracket - Re-torque load Bolts		AFSC 43151/42152 43171/42172
Safety and Servicing Notes are to be complied with throughout the work detailed on this card.		TIME EST
NOTE: This procedure is a sequent action to SP 60 (AF) and SP 455 (AF) at 50 (plus/minus 10) retractions and then every 100 (plus/minus 10) retractions. Only release torque load and re-apply the torque load to one bolt in turn.		ASSOCIATED PROCEDURES SP60 (AF) SP106 (AF) SP119 (AF)
	<u>43151</u>	
1. PREPARATION		
1.1 Aircraft	(i) Raise on jacks until all wheels are clear of the ground. (ii) Trestle at Frame 59. (iii) Connect hydraulic rigs I.A.W. SP 106 (AF).	
	<u>43151/42152</u>	
2. REMOVAL		
2.1 Retraction jack, eye end assembly.	(i) Disconnect from the main fitting bracket. (ii) Move clear of the lugs and support the jack.	
	<u>43171/42172</u>	
3. INSPECTION STAGE		
3.1 Jack bracket bolts.	(i) Place a coinciding mark across adjacent faces of bolt heads and bracket with a sharp pointed pencil. (ii) Release each bolt in turn 0.10 in of circumference from the adjacent marks. (iii) Re-torque load each bolt in turn to installation figure recorded on RSAF Form 1600-1. To regain this torque load value it should be achieved at the coinciding of the marks or up to 0.10 in of circumference beyond the bracket mark. (iv) Lock all bolts with wire (See Fig.1).	

Continued Overleaf

CHAP 4 AIRFRAME	SERVICING PROCEDURE	BAC F53 & T55 (SA)
SP 454 AL 9	F53	T55
SHEET 2 OF 3		5A3A Section 1 2nd Edition

Safety and Servicing Notes are to be complied with throughout the work detailed on this card.

4 3 1 5 1 / 4 2 1 5 1

4. TEST

4.1 Retraction jack eye end assembly. Check override I.A.W. SP 119 (AF).

4 3 1 7 1 / 4 2 1 7 2 (INSPECTOR)

5. INSPECTION STAGE

5.1 Retraction jack eye end assembly. Inspect sub-item 4.1 for correct override I.A.W. SP 119 (AF).

6. FITTING

6.1 Retraction jack eye end assembly.

- (i) Reconnect to leg main fitting bracket I.A.W. SP 119 (AF).
- (ii) Lubricate with grease XG287.

4 3 1 5 1 / 4 2 1 5 2

7. TEST

7.1 Undercarriage Test SP 106 (AF).

4 3 1 7 1 / 4 2 1 7 2 (INSPECTOR)

8. INSPECTION STAGE

8.1 Main undercarriage leg. Independent check of:

- (i) Assembly and locking.
- (ii) Function.

4 3 1 5 1

9. COMPLETION

9.1 Aircraft.

- (i) Remove hydraulic rigs I.A.W. SP 106 (AF).
- (ii) Remove trestle and lower off jacks.



Continued

CHAP. 4 AIRFRAME
S.P. 454 A.L. 8
SHEET 3 OF 3

SERVICING PROCEDURE
F53 T55

BAC F53 & T55 (SA)
5A3A Section 1
2nd Edition

Safety and Servicing Notes are to be complied with
throughout the work detailed on this card.



WIRE LOCKING AND SEALING OF BOLTS
FIGURE 1

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

