

FUSELAGE
AIR BRAKE SYNCHRONISING JACK INSTALLATION

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		AIR BRAKE SYNCHRONISING JACK, INSTALLATION (E.B2.00.59)	—	—	—	3/7
		Spares for:—				
26FZ/5542	EEAS.143/6	. CLIP, pipe, single, 1/4" o/d	1	L72	C	3/3
		Attachments:—				
28D/9149452	A25/3B	. Bolt, 4 BA hex. head	1	—	C	3/1
28M/1278189	AGS 2001/B/1	. Nut, stiff, 4 BA	1	—	C	3/5
28W/9419465	SP13/B	. Washer, 4 BA plain	1	—	C	3/4
5234	E B2.11.14629	. FAIRLEAD, for synchronising shaft	1	LFS26	C	1/17
5235	E.B2.11.14631	. FAIRLEAD, for synchronising shaft	1	LFS26	C	1/18
		Attachments:—				
28D/9133012	A25/3C	. Bolt, 2 BA hex. head	2	—	C	1/15
28M/1278190	AGS.2001/C/1	. Nut, stiff, 2 BA	2	—	C	1/20
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	1/19
5236	E B2.11.4977	. LEVER, Messier synchronising valve operating, group	1	—	B	1/1
		Consisting of:—				
28N/13510	HOFFMANN CJO	. . BEARING	1	—	C	1/2
28D/1013172	AS 1242/5C	. . BOLT, 2 BA c'sk head, lever attachment	1	—	C	1/16
28M/9433473	AGS 2002/C/1	. . NUT, stiff, 2 BA, lever attachment	1	—	C	1/14
5237	E.B2.11.4981	. LEVER, Messier synchronising valve Teleflex control operating rod connecting, group (Pre-Mod. 4578)	1	—	B	1/23
	E.B2.11.18445	. LEVER, assembly (Mod. 4578)	1			
		Spares for:—				
28N/13510	HOFFMANN CJO	. . BEARING	1	—	C	1/24
28D/1010030	A25/6C	. . BOLT, 2 BA hex. head, lever attachment	1	—	C	1/25
28M/9433473	AGS.2002/C/1	. . NUT, stiff, 4 BA	1	—	C	1/21
28W/9419402	SP13/C	. . WASHER, 2 BA, plain (Pre-Mod. 4578)	1	—	C	
	SP122/D	. . WASHER, 2 BA, plain (Mod. 4578)	1	—		
5238	E.B2.11.4993	. LEVER, port bell crank, Teleflex and Messier synchronising rod connecting, group	1	—	B	1/35
		Spares for:—				
28N/13510	HOFFMANN CJO	. . BEARING	2	—	C	1/39
	E.B2.11.4991	. . TUBE, distance	1	L54	—	1/40
		Attachments:—				
28M/1011467	A27/ES	. Nut, 1/4" BSF slotted	1	—	C	1/37
28P/9527619	SP90/C7	. Pin, split	1	—	C	1/36
28W/9418921	SP13/E	. Washer, 1/4" BSF plain	1	—	C	1/38

FUSELAGE
AIR BRAKE SYNCHRONISING JACK INSTALLATION

Ref. No.	Part No.	Description	No. off	Mtl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
5239	E.B2.11.4999	. LEVER, starboard, bellcrank, Teleflex and position transmitter operating shaft connecting Spares for:—	1	—	B	2/34
28N/13510	HOFFMANN CJO	. . BEARING	2	—	C	2/35
	E.B2.11.4991	. . TUBE, distance	1	L54	—	2/36
12998	E.B2.11.17953	. LEVER, starboard connecting to position transmitter, air brake and Teleflex control, group Spares for:—	1	—	B	2/48
	E.B2.11.7051	. . LEVER, Teleflex control connecting, group Spares for:—	1	—	—	2/49
28N/13510	HOFFMANN CJO	. . . BEARING	1	—	C	2/50
	E.B2.11.7055	. . LEVER, position transmitter connection Spares for:—	1	—	—	2/33
28N/13510	HOFFMANN CJO	. . . BEARING	1	—	C	2/32
	E.B2.11.7061	. . LEVER, air brake connecting, group Spares for:—	1	—	—	2/11
28N/13510	HOFFMANN CJO	. . . BEARING	1	—	C	2/10
28P/16266	SP31/K8	. . PIN, split, taper, lever attachment	3	—	C	2/12
	E.B2.11.7917	. LINE, starboard, bell crank lever, group Consisting of:—	1	—	—	2/43
5241	E.B2.11.7925	. . FORK-END, R.H.	1	L65	C	2/40
5243	E.B2.11.7926	. . FORK-END, L.H.	1	L65	C	2/47
28M/1007403	A27/ET	. . NUT, 1/4" BSF thin	1	—	C	2/44
28M/13454	A27/ETL	. . NUT, 1/4" BSF thin L.H.	1	—	C	2/46
5244	E.B2.11.7911	. . ROD, screwed, L.H. and R.H. Attachments:—	1	L65	C	2/45
26FZ/220	EEAS.12/1	. Bolt, 2 BA hex. head	2	S11	C	2/42
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S11	C	2/38
28P/9527619	SP90/C7	. Pin, split	2	—	C	2/37
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	2/39
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	2/41
	E.B2.11.7919	. LINK, port air brake, group Consisting of:—	1	—	—	1/13
5241	E.B2.11.7925	. . FORK-END, R.H.	1	L65	C	1/5
5243	E.B2.11.7926	. . FORK-END, L.H.	1	L65	C	1/9
28M/1007403	A27/ET	. . NUT, 1/4" BSF thin	1	—	C	1/6
28M/13454	A27/ETL	. . NUT, 1/4" BSF thin L.H.	1	—	C	1/8

FUSELAGE
AIR BRAKE SYNCHRONISING JACK INSTALLATION

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
5245	E.B2.11.7913	. ROD, screwed, L.H. and R.H	1	L65	C	1/7
		Attachments:—				
26FZ/220	EEAS.12/1	. Bolt, 2 BA hex. head	2	S11	C	1/3
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S11	C	1/11
28P/9527619	SP90/C7	. Pin, split	2	—	C	1/12
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	1/4
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	1/10
	E.B2.11.7921	. LINK, position transmitter, group	1	—	—	2/52
		Consisting of:—				
5241	E.B2.11.7925	. . FORK-END, R.H.	2	L65	C	2/31
5243	E.B2.11.7926	. . FORK-END, L.H.	1	L65	C	2/24
28M/1007403	A27/E1	. . NUT, 1/4" BSF thin	1	—	C	2/28
28M/13454	A27/E1L	. . NUT, 1/4" BSF thin, L.H.	1	—	C	2/30
5246	E.B2.11.7915	. . ROD, screwed, L.H. and R.H.	1	L65	C	2/29
		Attachments:—				
26FZ/220	EEAS.12/1	. Bolt, 2 BA hex. head	2	S11	C	2/22
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S21	C	2/26
28P/9527619	SP90/C7	. Pin, split	2	—	C	2/27
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	2/23
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	2/25
	E.B2.11.7923	. LINK, port, bell crank lever, group	1	—	—	1/34
		Consisting of:—				
5241	E.B2.11.7925	. . FORK-END, R.H.	2	L65	C	1/29
28M/13376	A29/EP	. . NUT, 1/4" BSF plain	2	—	C	1/32
5247	E.B2.11.7927	. . ROD, screwed	1	L65	C	1/33
		Attachments:—				
26FZ/220	EEAS.12/1	. Bolt, 2 BA hex. head	2	S11	C	1/31
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S11	C	1/27
28P/9527619	SP90/C7	. Pin, split	2	—	C	1/26
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	1/28
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	1/30
	E.B2.11.14889	. LINK, between air brake and synchronising mechanism group	1	—	—	2/4
		Consisting of:—				
5241	E.B2.11.7925	. . FORK-END	1	L65	C	2/3
5242	E.B2.11.14887	. . FORK-END, adjustable	1	L65	C	2/6
28M/13376	A29/EP	. . NUT, 1/4" BSF plain	1	—	C	2/5
		Attachments:—				
26FZ/220	EEAS.12/1	. Bolt, 2 BA hex. head	2	S11	C	2/1
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S11	C	2/8
28P/9527619	SP90/C7	. Pin, split	2	—	C	2/9
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	2/2
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	2/7

Restricted

Page H4

**FUSELAGE
AIR BRAKE SYNCHRONISING JACK INSTALLATION**

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
5248	E.B2.11.7433	. PIN, special, air brake operating jack connection and anchor	2	S97	C	3/20
28N/2001540	AGS.2031/4	. Attachments:— Circlip	2	—	C	3/21
7247	E.B2.11.16301	. Pin, special, air brake operating jack anchor	2	S97	C	3/15
28D/9138768	A25/ 1/2C	. Attachments:— Bolt, 2 BA hex. head	2	—	C	3/17
28W/9419402	SP13/C	. Washer, 2 BA plain	2	—	C	3/16
30A/3055	†	. Wire, locking, 22 SWG	QR	DTD189	C	3/18
1484227	E.B2.07.877	. STOP, Teleflex control safety (E.B2.11.14545)	1	L72	C	3/2
5250	E.B2.11.7083	. TELEFLEX, cable assembly, between synchronising valve and position transmitter on frame 53	1	—	B	3/6
26FZ/220	EEAS.12/1	. Attachments:— Bolt, 2 BA hex. head	2	S11	C	3/11
28D/9436920	A25/1C	. Bolt, 2 BA hex. head	4	—	C	3/10
26FZ/1122	EEAS.63	. Nut, 2 BA slotted	2	S11	C	3/13
28M/1278190	AGS.2001/C/1	. Nut, stiff, 2 BA	4	—	C	3/8
28P/9527619	SP90/C7	. Pin, split	2	—	C	3/14
28W/9419454	SP10/C	. Washer, 2 BA plain	2	—	C	3/12
28W/9419402	SP13/C	. Washer, 2 BA plain	6	—	C	3/9
	E.B2.81.10005	. TRANSMITTER, position, assembly	1	—	—	2/19
		Consisting of:—				
5251	E.B2.11.7079	. . LEVER, transmitter operating, group	1	—	B	2/13
		Spares for:—				
28N/13510	HOFFMANN CJO	. . . BEARING	1	—	C	2/14
28D/9133013	A25/5C	. Attachments:— Bolt, 2 BA hex. head	1	—	C	2/17
28M/9433473	AGS.2002/C/1	. . Nut, stiff, 2 BA	1	—	C	2/15
28W/9419402	SP13/C	. . Washer, 2 BA plain	1	—	C	2/16
6A/4102	SANGAMO WESTON S.132/1/11	. . TRANSMITTER, position	1	—	A	2/18
28M/9433473	AGS.2002/C/1	. Attachments:— Nut, stiff, 2 BA	2	—	C	2/21
26FZ/12292	EEAS.1/7C	. Screw, 2 BA c'sk head, 120°	2	S96	C	2/20
	AS.2808/10/041	. TUBE, distance	1	—	—	2/51
5252	E.B2.11.7431	. WASHER, special, hydraulic swivel pipes mounting	1	Tufnol "ASP" Sheet	C	3/19

Restricted