

FUSELAGE
ASSEMBLY OF AIR BRAKE TO FUSELAGE, STARBOARD

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	—	ASSEMBLY OF AIR BRAKE TO FUSELAGE, STARBOARD (E.B2.11.14432)	—	—	—	6/1
		Spares for:—				
4315	E.B2.11.14251	. BOLT, hinge, lower bearing	1	S97	C	6/65
4316	E.B2.11.14253	. BOLT, hinge, upper bearing	1	S97	C	6/64
70	E.B2.11.14430	. DOOR, air brake, group	1	—	A	6/2
		Spares for:—				
28843	E.B2.11.14238	. . BEARING, upper hinge, air brake door, group	1	—	B	6/56
		Spares for:—				
2A/8059324	TORRINGTON B.912	. . . BEARING, needle, roller	2	—	B	6/61
4320	E.B2.11.14243	. . . TUBE, distance	1	L56	C	6/63
		Attachments:—				
28M/1201610	AGS.2001/E/1	. . Nut, stiff, 1/4" BSF	8	—	C	6/55
26FZ/1032	EEAS.1/2E	. . Screw, 1/4" BSF 120° c'sk head	8	S96	C	6/53
28W/9418921	SP13/E	. . Washer, 1/4" BSF plain	8	—	C	6/54
	E.B2.11.14442	. . BEARING, lower hinge, air brake door, group	1	—	—	6/60
		Spares for:—				
2A/8059324	TORRINGTON B.912	. . . BEARING, needle roller	2	—	B	6/68
4319	E.B2.11.14241	. . . TUBE, distance	1	L56	C	6/67
		Attachments:—				
28M/1201610	AGS.2201/E/1	. . Nut, stiff, 1/4" BSF	8	—	C	6/59
26FZ/1032	EEAS.1/2E	. . Screw, 1/4" BSF 120° c'sk head	8	S96	C	6/57
28W/9418921	SP13/E	. . Washer, 1/4" BSF plain	8	—	C	6/58
4317	E.B2.11.12993	. . BLOCK, trunnion bearing	1	—	C	6/92
		Attachments:—				
28D/1011238	A25/3E	. . Bolt, 1/4" BSF hex. head	1	—	C	6/43
28D/1008151	A25/4E	. . Bolt, 1/4" BSF hex. head	6	—	C	6/41
28W/9419405	SP15/E	. . Washer, 1/4" BSF plain	3	—	C	6/42
4322	E.B2.11.12994	. . BLOCK, trunnion bearing	1	—	C	6/44
		Attachments:—				
28D/1011238	A25/3E	. . Bolt, 1/4" BSF hex. head	1	—	C	6/43
28D/1008151	A25/4E	. . Bolt, 1/4" BSF hex. head	6	—	C	6/41
28W/9419405	SP15/E	. . Washer, 1/4" BSF plain	3	—	C	6/42
4324	E.B2.11.4970	. . BRACKET, synchronising link attachment	1	—	C	6/51
		Attachments:—				
26FZ/1034	EEAS.1/3E	. . Screw, 1/4" BSF 120° c'sk head	4	S96	C	6/52
4325	E.B2.11.12803	. . BUSH, spherical, trunnion block	2	S97	C	6/49
28N/1007712	AGS.2031/24	. . CIRCLIP, trunnion securing	1	—	C	6/91

Restricted

Page HB2

FUSELAGE
ASSEMBLY OF AIR BRAKE TO FUSELAGE, STARBOARD

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
4327	E.B2.11.14444	. . LATCH, air brake door, group	1	—	B	6/86
		Spares for:—				
28D/1214865	AS.1246/2B	. . . BOLT, 4 BA round head, pivot bracket mounting	1	—	C	6/76
28D/9130082	AS.1246/3B	. . . BOLT, 4 BA round head, pivot bracket mounting	1	—	C	6/75
	E.B2.11.14445	. . . BRACKET, plunger and micro-switch connection lever pivot	1	L65	—	6/88
13454	E.B2.11.5235	. . . COLLAR, micro-switch tappet	1	L40	C	6/78
	E.B2.11.5227	. . . LEVER, plunger and micro-switch connecting	1	L65	—	6/90
28M/9403519	A27/BP	. . . NUT, 4 BA plain, for pivot bracket mounting bolt	2	—	C	6/82
	E.B2.11.5229	. . . PIN, roller plunger	1	L65	—	6/72
4328	E.B2.11.5231	. . . PIN, tappet, micro-switch	1	L65	C	6/85
29P/1009706	SP4Y/A2	. . . PIN, shackle, plunger and micro-switch tappet to lever connecting	2	—	C	6/81
28P/1013114	SP4Y/B8	. . . PIN, shackle, lever pivot	1	—	C	6/83
28P/1021104	SP90/C3	. . . PIN, split, pivot pin retaining	3	—	C	6/80
4329	E.B2.11.5233	. . . SPRING, micro-switch tappet	1	Spring Steel	C	6/89
4331	AS.2808/5/015	. . . TUBE, distance	2	—	C	6/84
	AS.2809/3/041	. . . TUBE, distance	1	—	—	6/73
28W/9419465	SP13/B	. . . WASHER, 4 BA plain, plunger and micro-switch tappet thrust and bracket mounting	2	—	C	6/74
28W/9419402	SP13/C	. . . WASHER, 2 BA plain, pivot pin thrust	3	—	C	6/93
		Attachments:—				
28D/8133011	A25/2C	. . Bolt, 2 BA hex. head	1	—	C	6/79
28D/9133012	A25/3C	. . Bolt, 2 BA hex. head	2	—	C	6/77
28D/1200119	A25/4C	. . Bolt, 2 BA hex. head	1	—	C	6/71
10032	EEAS.296/22/40C	. . Bolt, 2 BA special	1	S97	C	6/70
10015	EEAS.296/27/40C	. . Bolt, 2 BA special	1	S97	C	6/87
26FZ/1102	EEAS.41/2	. . PIN, sealing	16	—	C	6/38
26FZ/5073	EEAS.65	. . PLATE, serial number	1	—	C	
5993	E.B2.11.15331	. . SHIM, laminated, at bearing blocks	2	—	C	6/39
	E.B2.11.1972	. . SKIN, outer	1	L65	—	6/8
	E.B2.11.1974	. . SKIN, inner	1	L65	—	6/7
	E.B2.07.916	. . SKIN, inner (E.B2.11.1976)	1	L65	—	6/6
	E.B2.11.2504	. . SKIN, inner, upper	1	L65	—	6/5
	E.B2.11.17070	. . SKIN, outer	1	L65	—	6/4

Restricted

BD

FUSELAGE
ASSEMBLY OF AIR BRAKE TO FUSELAGE, STARBOARD

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
19198	E.B2.11.18099	. . TRUNNION, door operating jack attachment assembly Spares for:—	1	—	C	6/47
28N/9156370	SP21	. . . NIPPLE, grease	2	—	C	6/46
20260	E.B2.11.18091	. . . PLUG	2	S92	C	6/45
18695	E.B2.11.18085	. . . TRUNNION	1	S99	C	6/50
28N/9156370	SP21	. NIPPLE, grease	2	—	C	6/3
28FP/9482442	AVIAN. DEVELS. A419	. PIN, "pip," quick release	2	—	C	6/15
4345	E.B2.11.14245	. TUBE, distance, lower bearing hinge bolt	1	S82	C	6/69
4346	E.B2.11.14247	. TUBE, distance, upper bearing hinge bolt	1	S82	C	6/62
4334	E.B2.11.15594	. UNIT, lock, air brake, door, assembly Spares for:—	1	—	B	6/13
2967	E.B1.20.7623	. . BOLT, special, plunger operating lever jack attachment	1	S96	C	6/22
21475	E.B2.07.717	. . CHANNEL, and bearing, assembly (E.B2.11.5189) Attachments:—	1	—	—	6/28
28D/9436920	A25/1C	. . Bolt, 2 BA hex. head	3	—	C	6/12
28D/9133012	A25/3C	. . Bolt, 2 BA hex. head	1	—	C	6/9
28M/1278190	AGS.2001/C/1	. . Nut, stif, 2 BA	4	—	C	6/29
28W/9419402	SP13/C	. . Washer, 2 BA plain	4	—	C	6/30
6012	E.B2.11.15583	. . CHANNEL, and bearing, assembly Spares for:—	1	—	C	6/20
13517	SYMONDS EW.1	. . . NUT, anchor, corner, 1/4" BSF Attachments:—	2	—	C	6/14
28D/9133014	A25/13C	. . Bolt, 2 BA hex. head	2	—	C	6/19
	SA.2806/4/115	. . Tube, distance	2	—	—	6/37
6125	GEO. SALTER 5100/31	. . CIRCLIP, truarc. plunger operating lever pivot pin retaining	1	—	C	6/35
5K/9132076	HELLERMANN HT.0813/3/C	. . CLIP, cable securing	1	—	C	6/11
13460	E.B2.11.15585	. . LEVER, c/w bush, plunger operating	1	—	C	6/23
28N/9156370	SP21	. . NIPPLE, grease, for plunger operating jack attachment bolt	1	—	C	6/21
4335	E.B2.11.5215	. . PIN, anchor, air brake door lock nut, hydraulic jack Attachments:—	1	—	C	6/16
28P/9554984	SP90/E7	. . Pin, split	1	—	C	6/17
28W/9419489	SP16/J	. . Washer, 3/8" BSF plain	1	—	C	6/18
4336	E.B2.11.5219	. . PIN, pivot, for plunger operating lever	1	S96	C	6/33

FUSELAGE
ASSEMBLY OF AIR BRAKE TO FUSELAGE, STARBOARD

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
28670	E.B2.11.12739	. . PLUNGER, air brake door latch unit	1	L65	C	6/36
4337	E.B2.11.5217	. . ROLLER, micro-switch operating lever link	1	S97	C	6/35
		Attachments:—				
28P/1012221	SP4Y/B12	. . Pin, shackle	1	—	C	6/24
28P/1202460	SP9/C4	. . Pin, split	1	—	C	6/27
28W/9419402	SP13/C	. . Washer, 2 BA plain	1	—	C	6/26
4338	E.B2.11.5187	. . SPRING, compression, plunger loading	1	Spring Steel	C	6/32
13462	AS.2808/7/05	. . TUBE, distance, plunger, operating lever	1	—	C	6/34
35024	E.B2.11.18257	. . UNIT, micro-switch, group	1	—	A	5/20
		Spares for:—				
	E.B2.11.14421	. . . BARREL, operating plunger	1	S94 or S117	—	5/8
4340	E.B2.11.5183	. . . BOLT, special, 8 BA micro-switch mounting	2	S96	C	5/5
5E/3876	†	. . . CABLE, uniefglass 20	QR	—	C	5/13
8723	GEO. SALTER 6100/43	. . . CIRCLIP, truearc	1	—	C	5/4
19797	E.B2.11.18097	. . . LEVER, trip	1	S15	C	5/18
		Attachments:—				
28P/1207870	SP4Y/B11	. . . Pin, shackle	1	—	C	5/2
28P/1021104	SP90/C3	. . . Pin, split	1	—	C	5/3
28W/9419402	SP13/C	. . . Washer, 2 BA plain	1	—	C	5/6
4342	E.B2.11.14423	. . . SPINDLE, operating, plunger	1	S95	C	5/7
4343	E.B1.11.4327	. . . SPRING, 18 SWG	1	Spring Steel	C	5/9
5CW/4632	B.T.H. CX.116667	. . . SWITCH, type L.H.E.11.A1/3	1	—	A	5/15
5X/9462951	HELLERMANN HC.294	. . . TERMINAL, ring tongue	2	—	C	5/12
4331	AS.2808/5/015	. . . TUBE, distance	2	—	C	5/11
4344	E.B2.11.5185	. . . WASHER, special 18 SWG	2	L72	C	5/14
		Attachments:—				
28D/9436920	A25/1C	. . Bolt, 2 BA hex. head	4	—	C	5/19
9340	EEAS.238/2A	. . WASHER, "D", cable clip spacing	1	L72	C	6/10
		Attachments:—				
28D/1011030	A25/2E	. Bolt, 1/4" BSF hex. head	2	—	C	6/31
30A/3055	†	. WIRE, locking, 22 SWG	QR	DTD189	C	6/66