

SERVICES
STARTER PIPES AT FRAME 25

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1 2 3 4 5 6				
	—	STARTER PIPES, AT FRAME 25, ASSEMBLY (E.B5.53.17) (Mod. 9133)	—	—	—	
21352	E.F3.53.115	Spares for:— · CONNECTOR, pipe, 5/8" BSP, for air and fuel pipes at frame 25	2	L65	C	
		Attachments:—				
28D/9133012	A25/3C	· Bolt, 2 BA hex. head	3	—	C	
28M/9433473	AGS.2002/C/1	· Nut, stiff, 2 BA hex. head	3	—	C	
4851	EEAS.20/1/ER	· TAB, locking	4	L72	C	
10613	E.F2.53.179	· FAIRLEAD, assembly, at frame 25	1	—	C	
		Attachments:—				
28D/9419497	A25/12C	· Bolt, 2 BA hex. head	2	—	C	
10438	E.F2.53.81	· NIPPLE, coupling, pipe to connector, frame	4	BAC.M37	C	
23140	E.B5.53.10047	· PIPE, assembly, air starter, No. 1 engine, from bulkhead connector at frame 25 to coupling forward of frame 26, 5/8" o/d x 22 SWG	1	L56	C	
	E.L3.53.21	· PIPE, assembly, fuel starter, No. 1 engine, from bulkhead connector at frame 25 to coupling forward of frame 26, 5/8" o/d x 22 SWG (Mod. 9133)	1	L56	—	

Restricted

Page MAF2

SERVICES
STARTER PIPES AT FRAME 25

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		123456				

Restricted

BD