

LIST OF CONTENTS

Introduction

PART I DESCRIPTIVE

Fuel system	<i>Para.</i>
General information	1
Fuel transfer	2
Low pressure fuel delivery	3
Fuel recuperators	4
Fuel contents	5
Fuel contents indicators	6
Ventral tank empty indicator... ..	7
Fuel pump switches	8
Fuel pressure warning indicators	9
Management	
Normal use... ..	10
Duration of inverted flight	11
 Engine controls	
Engine power controls	12
Throttle servo control... ..	13
Reheat	14
Operation of reheat	15
Jet pipe temperature control... ..	16
Engine starting system... ..	17
Engine starting switches	18
Engine relight switches	19
Engine instruments	20
Engine anti-icing	21
 Fire protection	
Fire zones	22
Fire extinguishers	23
Fire detection	24
Summary of warning presentation	25
Inertia crash switches... ..	26

Hydraulic systems						<i>Para.</i>
General information	...	...	...	...	...	27
Pumps	...	...	...	...	...	28
Accumulators	...	...	...	...	...	29
Pressure failure indication	...	...	...	...	...	30
 Flying controls						
General information	...	...	...	...	...	31
Ailerons	...	...	...	...	...	32
Tail plane...	...	...	...	...	...	33
Rudder	...	...	...	...	...	34
Rudder and tail-plane feel	...	...	...	...	...	35
Aileron feel	...	...	...	...	...	36
Trimming	...	...	...	...	...	37
Emergency characteristics of power-operated controls	...	...	...	...	...	38
Flaps	...	...	...	...	...	39
Air brakes...	...	...	...	...	...	40
Trim and air brake indicator...	...	...	...	...	...	41
 Autopilot system						
General information	...	...	...	...	...	42
Pilot's controls...	...	...	...	...	...	43
Three-axis autostabilization...	...	...	...	...	...	44
Attitude hold	...	...	...	...	...	45
Autopilot/I.L.S. coupling	...	...	...	...	...	46
Autostabilizer actuators	...	...	...	...	...	47
 General services						
Lighting gear	...	...	...	...	...	48
Lighting-gear controls and indicators	...	...	...	...	...	49
Lighting-gear emergency controls	...	...	...	...	...	50
Wheel brakes	...	...	...	...	...	51
Brake parachute	...	...	...	...	...	52

Air systems

	<i>Para.</i>
General information	53
Electrical accessories drive unit	54
Cockpit air conditioning	55
Cockpit temperature control	56
Cockpit pressurization... ..	57
Canopy seal inflation	58
Quarter panels and canopy hot-air de-misting ...	59
Ram air valve	60

Miscellaneous equipment

Pressure head and vent valve heating	61
External lighting	62
Normal cockpit lighting	63
Emergency cockpit lighting	64
Windscreen de-misting	65

Warning systems

Standard warning system	66
Auxiliary warnings panel	67

Electrical system

Power supplies	68
Air turbine underspeed... ..	69
Air turbine overspeed	70
D.C. system	71
D.C. power failure	72
A.C. system	73
Inverter supply	74
Inverter manual control	75
Instrument supply change-over in flight	76
Alternator failure warning	77

Flight and navigational instruments

Dynamic reference system	78
Master reference gyro	79
M.R.G. erection switch... ..	80
Attitude indicator, Type F1M... ..	81
Heading indicator (Mk.5FT compass)... ..	82
◀ Turn-and-slip indicator and artificial horizon... ▶	83
Combined speed indicator	84

Flight and navigational instruments - *continued*

	<i>Para.</i>
Altimeter	85
Miscellaneous instruments	86
Radio and radar equipment	
V.H.F. installation (not XG 310)	87
Automatic direction finder installation	88
Rebecca installation	89
◀ Tacan installation	90
I.L.S. installation	91
Canopy	
Canopy control and operation... ..	92
Canopy jettison	93
Ejection seat	
Mk.4BS and Mk.4BSA/Mk.1 automatic ejection seats	94
Strapping in procedure... ..	95
Normal operation of the seat... ..	96
Leaving the seat after landing	97 ▶
Oxygen system	
Normal oxygen supply	98
Emergency oxygen... ..	99
Clothing	100

SUPPLEMENTS

Aerodynamic flight trials (XG 310)
Phase 1 auto attack system - Part 1 (XG 307)

PART 2 LIMITATIONS

Engine limitations - Avon Mk.210	101
Airframe limitations	102

PART 3 HANDLING

Management of systems

Management of the fuel system	103
Engine handling - ground running	104
Engine operating data	105
Engine management for maintenance of electrical power... ..	106

RESTRICTED

Management of systems - *continued*

	<i>Para.</i>
Management of reheat	107
Management of cockpit pressurizing and air conditioning system	108
Use of engine anti-icing (XG308-310)	109
Management of autopilot modes	110

Starting, taxiing and take-off

External checks	111
Internal checks	112
Starting the engines	113
Failure to start... ..	114
Checks after starting	115
Checks before taxiing	116
Taxiing	117
Checks before take-off... ..	118
Take-off	119

Handling in flight

Checks after take-off	120
Safety speeds	121
Climbing	122
General flying	123
Stalling	124
Spinning	125
High-speed flying limitations	126
High-speed flying characteristics	127
Flight conditions involving high structural loads... ..	128

Circuit procedure and landing

Approach and landing	129
Instrument approach	130
Going round again	131
Flapless landing... ..	132
Checks after landing	133
Checks after taxiing	134

PART 4 EMERGENCY HANDLING

	<i>Para.</i>
Engine failure on take-off	135
Single-engine failure in flight	136
Relighting	137
Fuel drill for single-engine recovery	138
Double engine flame-out	139
Electrical failure considerations	140
Electrical failures - pilot's procedures	141
Autostabilizer/autopilot malfunction... ..	142
Action in the event of autostabilizer/autopilot malfunction	143
Emergency use of oxygen	144
Jettisoning the canopy	145
Abandoning the aircraft in flight	146
Action in the event of engine fire	147
Action in the event of reheat warnings	148
Action if cockpit temperature fails	149
Ventral tank jettison	150
Emergency jettison of guided weapons	151
Hydraulic feel inoperative	152
Action if ventral tank fuel fails to transfer	153
Tail plane trim malfunction	154
Action in the event of rudder manual reversion (XA 847 and 853 only)	155
Undercarriage emergency lowering	156
Brake parachute failure on landing	157

PART 5 OPERATING DATA

(to be issued later)

PART 6 ILLUSTRATIONS

- ◀ Cockpit - port side
- Cockpit - forward view
- Cockpit - starboard side ▶

RESTRICTED