

EQUIPMENT AIRCRAFT-INSTRUMENTS

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Place No.
	E.261280	INSTRUMENT PANELS, ASSEMBLY	-	-		
	A.231150	Bracket, mounting for bomb and R.P. panel	1	L.72		
	A.221827	Bracket, mounting for bomb and R.P. panel	1	L.72		
10L/16264	Std.2045/17/26	Clip, sleeved	1	-		
	-	Controller, D.M.E. type 8197	1	-	A.	
	E.233875	Cover, windscreen reflection, group	1	-		
	F.231555	Hook	2	Spr. Steel		
29G/2098	Carr N.608	Socket, "lift-ode-dot"	9	-		
29G/2096	Carr 708A	Washer, back	9	-		
5L/9951273		Filament, 3-5w	2	-	C.	
10651	F.232337	Finisher, and mounting angle at D.M.E. controller	-	-		
10652	F.232338	Finisher, and mounting angle at D.M.E. controller	-	-		
	9946	Indicator, aileron, neutral position (Mod. 782)	1	L.72	C.	
	8543	Mounting, port instrument panel	6	Rubber	C.	
	D.261053	MOUNTING, PANEL, ASSEMBLY (Mod. 2489)	-	-		
8718	A.208746	Bracket, for anti-vibration mounting	5	-	C.	
5373	A.203162	Bracket, for anti-vibration mounting	2	-	C.	FC.1
8719	A.214988	Bracket, for anti-vibration mounting	1	-	C.	
4134	Std.1285/3/BB	Connector, earthing	8	-	C.	
27H/3248	F.211792	Mounting, anti-vibration	8	-	B.	
27H/3219	-	Mounting, anti-vibration, non-magnetic	8	-	B.	
3868	F.168524	Washer, at anti-vibration mounting	24	DTD.610	C.	
	A.237842	Mounting, tail chute lamp, assembly	-	-		
	A.237840	Cover, group	1	-		
	A.237839	Cover	1	-		
	F.240347	Flap, group	1	-		
	F.236677	Hinge	1	-		
	A.237840/1	Pin, pivot	1	S.1.B		
	F.237863	Spring	1	Sp. Stl.		
	A.237841	Mounting, lamp, group	1	-		
	A.237838	Block, terminal	1	-		
	F.237836	Bracket, lamp mounting	1	-		
	Bulgin MES.18	Holder, lamp (c/w grommet)	2	-		
	F.237835	Plate, base	1	-		
	RC.206	Tag, 4 BA	3	-		
	F.240020	Packing, for tail chute lamp	1	-		
	C.231148	Panel, control, for bomb and R.P., group	1	-		
	C.237757	Cable, A.13 (See cable chart)	1	-		
8706	F.214078	Cover, spring, inboard, group	1	-	C.	
5K/2724	-	Cover, spring	1	-	C.	
8707	F.214079	Cover, spring, outboard, group	1	-	C.	
5K/2724	-	Cover, spring	1	-	C.	
8708	F.214077	Flap, switch, group	1	-	B.	
	F.228684	Guard, tail chute switch	1	L.72		
5CW/5765	-	Guard, switch	2	-	B.	
	B.231149	Panel, switch mounting	1	L.72		
	Std.1606/45/A14	Screw, retaining switch	4	Brass	C.	
1178	Std.1606/44/B.12	Screw, retaining switch	6	Brass	C.	5
5829	Std.1606/44/A.14	Screw, retaining switch	8	Brass	C.	5
4661	Std.1606/45/B.12	Screw, retaining switch	4	Brass	C.	5
5CW/6332	Rotax D.10007	Switch, tail chute	1	-	A.	
5CW/540	Rotax D.0701	Switch, D.P., push	2	-	B.	
5CW/936	-	Switch, 3-way rotary type "B"	1	-	B.	
5CW/7540	-	Switch, S.P. c/o N.C.P.	1	-	B.	

EQUIPMENT AIRCRAFT—INSTRUMENT PANELS

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
5CW/7548	C.W.C. Ltd. XD.784						1	—	B.	
5D/1760							1	—	B.	
751	Std.915/A/20						4	DTD.610	C.	4
	D.260033						—	—		
6A/8267	—						1	—	A.	
	D.261374						1	—		
	B.231443						1	—		
	Std.2044/6/052						1	—		
5CW/5253	Hellermann HV.3710						1	—	C.	
5CW/5252	Hellermann HV.3711						1	—	C.	
6A/	Std.1503						1	—		
	Std.2045/28/22						1	—		
	Std.2045/18/24						2	DTD.610	MR/C	4
	3735						2	—	C.	
6A/2519	—						2	—	C.	
6A/7677	—						1	—	A.	
6A/6216	—						1	—	A.	
6A/3158	—						1	—	A.	
6A/6438	Smiths MF/858/FL						1	—	A.	
6A/5942	Smiths 19.HSD						1	—	A.	
5CZ/6001	Dowty C.5165.Y Mk. 2						2	—	A.	
5CZ/5003	Dowty Mk. 14						1	—	A.	
6A/5546	—						1	—	A.	
	A.216487						1	L.72		
	F.223732						1	L.72		
	A.230888						1	L.72		
	F.237794						1	L.72		
	D.245995						—	—		
5CZ/432	—						1	—	B.	
	F.222196						1	L.72		FC.1
5L/9959118	—						26	—	B.	
5CW/5045	Rotax N.65290						21	—	C.	
5CX/5360	Thorn 80/10/1236						1	—	B.	
5CX/5351	Thorn 80/10/1193						1	—	B.	
5CX/5352	Thorn 80/10/1192						4	—	B.	
5CX/5353	Thorn 80/10/1190						1	—	B.	
5CX/5355	Thorn 80/10/1191						2	—	B.	
5CX/5356	Thorn 80/10/1189						1	—	B.	
5CX/5357	Thorn 80/10/1194						1	—	B.	
5CX/5364	Thorn 80/10/0855						2	—	B.	
	9446						6	Brass	C.	5
	4179						4	Brass	C.	3
	3840						4	Brass	C.	5
	4114						4	Brass	C.	5
	7970						4	Brass	C.	5
	9447						2	Brass	C.	5
	9448						6	Brass	C.	5
26AQ/4158	Std.1606/44/C36						2	Brass	C.	5

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description					No. Of	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
5830	Std.1606/45/A14						2	Brass	C.	5
9450	Std.1606/45/A18						2	Brass	C.	5
5CW/2530	—						2	—	B.	
5K/301	Ross Courtney No. 00						2	—	C.	
7100	Std.915/B10						2	DTD.610	C.	4
1940	Std.1231/1						1	S.3	C.	4
6A/3300	Mechanisms Ltd. M.1691						1	—	A.	
	D.260033/1						—	—		
	F.188326						2	—		
	—						—	—		
	D.260032						1	L.72		FC.1
3601†	A.191177/5						1	T.9	C.	
8710	A.208536/8						1	L.54	C.	
8711	A.208536/7						1	L.54	C.	
8712	A.208536/3						1	L.54	C.	
8713	A.208536/4						1	L.54	C.	
9740	A.208536/5						1	L.54	C.	
1178	Std.1606/44/B12						2	Brass	C.	5
4179	Std.1606/44/B20						2	Brass	C.	5
1720	Std.1606/44/B24						4	Brass	C.	5
3857	Std.1606/44/C24						4	Brass	C.	5
4660	Std.1606/45/B14						3	Brass	C.	5
3860	Std.1606/45/B20						4	Brass	C.	5
3861	Std.1606/45/B24						8	Brass	C.	5
3895	Std.1606/45/B10						4	Brass	C.	5
8717	Std.1606/45/B28						12	Brass	C.	5
3863	Std.1606/45/C24						4	Brass	C.	5
4116	Std.1606/45/C28						4	Brass	C.	5
3865	Std.1606/45/C32						4	Brass	C.	5
8714	Std.1606/45/C44						4	Brass	C.	5
9951	Std.2095/208/B20						4	—		
9952	Std.2095/208/B24						4	—		
9953	Std.2095/208/B28						12	—		
9955	Std.2095/208/D24						4	—		
9956	Std.2095/208/D28						4	—		
9957	Std.2095/208/D32						4	—		
	Std.2095/209/B24						4	—		
	Std.1948/11						1	—		
5F/2281	AS.2508						QR	—	C.	
5F/2302	NY.3342						QR	—	C.	
5C W/7748	C.W.C. Ltd. XD.789						1	—	B.	
5CW/7540	C.W.C. Ltd. XD.778						1	—	B.	
6A/2801	Smiths 114.R.V.						1	—	A.	
6A/3577	—						1	—	A.	
5CW/4327	Rotax N.100397/1						1	—	C.	
5CW/4328	Rotax N.100397/2						1	—	C.	
	Std.1509/12/032						2	T.4		
	Std.1509/23/065						4	T.4		

EQUIPMENT AIRCRAFT—INSTRUMENT PANELS

Ref. No.	Part No.	Description	1 2 3 4 5					No. Off	Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5				
6A/7041	KVC.0101	Unit, vibrator (Mod. 1002)						1	—	A.	
6B/563	—	Unit, gyro, type "B"						1	—	A.	
4162	Std.915/B/22	Washer, 4 BA.....						12	DTD.610	C.	4
10654	F.239237	Washer, taper						2	—	C.	
	D.260997	PANEL, CENTRE, ASSEMBLY						—	—		
6A/3451	—	Accelerometer, Mk. 2						1	—	A.	
6A/4246	—	Adaptor, plate						1	—		
6A/4245	—	Altimeter, Mk. 21						1	—	A.	
	F.230727	Block, packing						1	—		
5CZ/432	—	Block, terminal, type "B," 3-way						1	—	B.	
	B.230511	Bracket, mounting						1	L.72		
5CY/9992777	B.T.H. or Thorn	Breaker, circuit, type "A," 25 amps.						2	—	A.	
	F.222196	Bracket, mounting						1	—		
	F.230515	Bracket, switch						1	—		
	D.260426	Cable, F.40, group (See cable chart)						1	—	B.	
	D.231388	Cable, F.62, group (See cable chart)						1	—	B.	
	B.254859	Cable, F.65, group (See cable chart)						1	—	B.	
	B.231309	Cable, F.66, group (See cable chart)						1	—	B.	
	F.257143	Cover, dolly						1	—		FC.1
5CX/5001	Std.1512/29	Disc, identification warning lamp						1	—	B.	4
5L/9959118	—	Filament, 28V., .04 amp.						17	—	B.	
5L/9951284	—	Filament, 28V., 3.5 watt						1	—	B.	
5L/9951273	Rotax N.56091	Filament, 28V., 3.5 watt						7	—	B.	
6A/4310	Smiths AG.26	Gauge, fuel contents						2	—	A.	
5CW/5045	Rotax N.65290	Grommet						3	—	C.	
	Honeywell 5PA.8	Guard, switch						1	—		
	F.232705	Guard, switch						1	L.72		
10490	F.240266	Guard, switch						1	—	C.	
9671	F.226393	Guard, switch						1	—	C.	
4121	F.200057	Handle, switch						1	Rubber	C.	FC.1
10AF/530	—	Indicator, D.M.E						1	—	A.	
5CZ/5210	Dowty C.5165.Y Mk. 7	Indicator, magnetic						2	—	B.	
5CZ/6001	Dowty C.6165.Y Mk. 2	Indicator, magnetic						2	—	A.	
5CZ/5123	Plessey CZ.74109/2	Indicator, magnetic						2	—	B.	
10Q/16328	—	Indicator, bearing (Radio compass)						1	—	B.	
	F.240355	Label (Mod. 2451)						1	—		
	Rotax H.2805	Lamp, warning, "Amber"						4	—		
5CX/1635	Rotax H.2703	Lamp, warning, type "A"						1	—	B.	
5CX/1069	Rotax H.2702	Lamp, warning, type "A"						1	—	A.	
5CX/1553	Rotax H.1004	Lamp, warning, type "B" (Red)						1	—	B.	
5CX/5352	Thorn 80/10/1192	Light, bridge, type "C"						2	—	B.	
	F.232295	Light, bridge, special						1	—	B.	
5CX/5364	Thorn 80/10/0855	Light, pillar, "red"						10	—	B.	
1940	Std.1231/1	Lug, locking						1	S.3	C.	
4490	F.199451	Nut, securing guard plate at tank selector switches						2	L.65.C	C.	
	D.229939	Panel, instrument, centre, group						1	—		FC.1
	F.234374	Mounting, indicator						1	L.72		
	F.230514	Mounting, indicator						1	L.72		
	F.260430	Mounting, indicator						1	L.72		
	D.260381/1	Panel						1	L.72		
5830	Std.1606/45/A14	Screw...						1	Brass		
	Std.1509/1/020	Tube, distance						1	T.4		
	Std.1509/12/160	Tube, distance						2	T.4		
4707	Std.915/A14	Washer						4	DTD.610		
4982	Std.915/B14	Washer						2	DTD.610		
	C.229940	Plate, label						1	—		

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Store	Plate No.	
			1	2	3	4	5				
7966	F.214772	Plate, guard, at tank selector switches	2	L.72		
	F.232409	Screen, night	1	—	—	FC.1
	Std.1606/44/A28	Screw, securing terminal block	3	Brass	C.	5
9946	Std.1606/44/A20	Screw, roundhead, 6 BA	3	Brass	C.	5
3838	Std.1606/44/B8	Screw, roundhead, 4 B.A.	4	Brass	C.	5
3837	Std.1606/44/B10	Screw, roundhead, 4 B.A.	4	Brass	C.	5
1178	Std.1606/44/B12	Screw, roundhead, 4 B.A.	4	Brass	C.	5
1637	Std.1606/44/B14	Screw, roundhead, 4 B.A.	4	Brass	C.	5
3386	Std.1606/44/B20	Screw, roundhead, 4 B.A.	4	Brass	C.	5
8717	Std.1606/45/B28	Screw, roundhead, 4 B.A.	4	Brass	C.	5
7970	Std.1606/44/B36	Screw, roundhead, 4 B.A.	4	Brass	C.	5
9540	Std.1606/45/A18	Screw, roundhead, 6 B.A.	4	Brass	C.	5
4661	Std.1606/45/B12	Screw, countersunk, 4 B.A.	29	Brass	C.	5
3861	Std.1606/45/B24	Screw, countersunk, 4 B.A.	9	Brass	C.	5
3859	Std.1606/45/B10	Screw, countersunk, 4 B.A.	3	Brass	C.	5
3860	Std.1606/45/B20	Screw, roundhead, 4 B.A.	2	Brass	C.	5
	F.230726	Spacer, at circuit-breaker studs	4	S.1		
	F.214771	Stud, for guard plate at tank selector switches	2	S.95.B	C.	
5CW/6332	Rotax D.10007	Switch, D.P. parachute dolly...	1	—	B.	
	Honeywell	Switch, D.P.	1	—		
	2TL1-3D										
5CW/7539	C.W.C. Ltd.	Switch, S.P., change over	1	—	B.	
	XD.777										
5CW/7542	C.W.C. Ltd.	Switch, S.P., change over, centre "OFF"	2	—	B.	
	XD.776										
5CW/6311	—	Switch, fire warning, push	1	—	B.	
5CW/6551	—	Switch, S.P., luminous dolly	1	—	B.	
5CW/7541	C.W.C. Ltd.	Switch, S.P., "ON-OFF"	3	—	B.	
	XD.779										
5CW/7543	C.W.C. Ltd.	Switch, S.P., change over (centre "OFF" spring return)	1	—	B.	
	XD.780										
5CW/7548	C.W.C. Ltd.	Switch, D.P. C/O (centre "OFF")	1	—	B.	
	XD.784										
5CW/7748	C.W.C. Ltd.	Switch, D.P., change over (no centre position)	1	—	B.	
	XD.789										
5CW/7552	C.W.C. Ltd.	Switch, D.P., change over (centre and one side "ON" spring return to centre)	1	—	B.	
	XD.788										
5CW/7550	C.W.C. Ltd.	Switch, D.P.	1	—	B.	
	XD.787										
5CW/4327	Rotax N.100397/1	Transfer, "ON"	7	—	C.	
5CW/4328	Rotax N.100397/2	Transfer, "OFF"	8	—	C.	
5CW/4331	Rotax N.100397/5	Transfer, "OPEN"	1	—	C.	
5CW/4337	Rotax N.100397/11	Transfer, "CLOSE"	1	—	C.	
5CW/4335	Rotax N.100397/9	Transfer, "AUTO"	2	—	C.	
5CW/4344	Rotax N.100397/18	Transfer, "DIM"	1	—	C.	
5CW/4345	Rotax N.100397/19	Transfer, "BRIGHT"	1	—	C.	
5CW/4346	Rotax N.100397/20	Transfer, "IN"	1	—	C.	
5CW/4347	Rotax N.100397/43	Transfer, "OUT"	2	—	C.	
5CW/6689	Rotax N.147415/1	Transfer, "JETTISON"	1	—	C.	
5CW/6690	Rotax N.147415/2	Transfer, "STREAM"	1	—	C.	
	5768	Tube, distance	4	T.4	C.	4
5CW/4528	—	Window, red	1	—	C.	
	C 260243	PANEL, STARBOARD, ASSEMBLY	—	—	—	
6A/8267	—	Altimeter, Mk. 19F	1	—	A.	
	C.222341	Cable, F.11, group (See cable chart)	1	—		
5CW/5252	HV.3711	Cap, Helvin, sea grey	2	—	C.	
6B/2775	—	Compass, repeater, Mk. 2	1	—	A.	
6A/3158	—	Indicator, airspeed, Mk. 12A	1	—	A.	

EQUIPMENT AIRCRAFT—INSTRUMENT PANELS

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
6A/6216	—	Indicator, artificial horizon, Mk. 4E	1	—	A.	
5CZ/5003	—	Indicator, magnetic	1	—	A.	
5CZ/6001	Dowty C.5165Y Mk. 2	Indicator, magnetic	2	—	A.	
	C.230233	LIGHTING, MINIATURE PILLAR ON STARBOARD INSTRUMENT PANEL, ASSEMBLY	—	—		
5CZ/432	—	Block, terminal, type "B," 3-way	1	—	B.	
	F.222196	Bracket, for terminal block,	1	L.72		FC.1
5L/9959118	—	Filament, 28V., 0.4 amps.	12	—	B.	
5CW/5045	Rotax N.65290	Grommet	6	—	C.	
5CX/5351	Thorn 80/10/1193	Light, bridge, type "B"	1	—	B.	
5CX/5352	Thorn 80/10/1192	Light, bridge, type "C"	3	—	B.	
5CX/5357	Thorn 80/10/1194	Light, bridge, type "H"	1	—	B.	
5CX/5364	Thorn 80/10/0855 (Red)	Light, bridge	2	—	B.	
9446	Std.1606/44/A20	Screw, securing dimmer switch	2	Brass	C.	5
6356	Std.1606/44/B32	Screw, securing bridge light	2	Brass	C.	5
7970	Std.1606/44/B36	Screw, securing bridge light	6	Brass	C.	5
3857	Std.1606/44/C24	Screw, securing bridge light	2	Brass	C.	5
9448	Std.1606/44/C32	Screw, securing bridge light	2	Brass	C.	5
5830	Std.1606/45/A14	Screw, securing terminal block	2	Brass	C.	5
9450	Std.1606/45/A18	Screw, securing terminal block	2	Brass	C.	5
5CW/2530	—	Switch, dimmer, type "R," 75 ohms.	1	—	B.	
6A/3300	Smiths KMA/0201K C.260241	Machmeter, Mk. 3A	1	—	A.	
	C.260242	PITÔT COUPLINGS, STARBOARD INSTRUMENT PANEL, ASSEMBLY	—	—		
6A/2519	—	Connector, static and pressure	2	—	C.	
	A.230790/1	Pipe, static, pitôt connection to tee union on machmeter	1	T.9		
	A.230790/2	Pipe, pressure, pitôt connection to tee union on machmeter	1	T.9		
	A.230790/3	Pipe, static, tee union on machmeter to tee union	1	T.9		
	A.230790/4	Pipe, pressure, tee union on machmeter to elbow on airspeed indicator	1	T.9		
	A.230790/5	Pipe, static, tee union to elbow on airspeed indicator	1	T.9		
	A.230790/10	Pipe, static, tee union to elbow on altimeter	1	T.9		
3858	Std.1606/45/B8	Screw, securing single pole switch	4	Brass	C.	5
8717	Std.1606/45/B28	Screw, securing compass repeater	8	Brass	C.	5
4114	Std.1606/45/B32	Screw, securing altimeter	8	Brass	C.	5
4115	Std.1606/45/C20	Screw, countersunk, 2 B.A.	4	Brass	C.	5
3863	Std.1606/45/C24	Screw, countersunk, 2 B.A.	3	Brass	C.	5
3865	Std.1606/45/C32	Screw, countersunk, 2 B.A.	4	Brass	C.	5
9953	Std.2095/208/B28	Screw, unified thread	4	—		
9954	Std.2095/208/B32	Screw, unified thread	8	—		
9955	Std.2095/208/D24	Screw, unified thread	3	—		
9957	Std.2095/208/D32	Screw, unified thread	4	—		
4162	Std.915/B/22	Washer	8	DTD.610	C.	4

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description	1 2 3 4 5					No. Off	Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5				
5CW/7540	C.W.C. Ltd. XD.778	Switch, S.P. change over no centre " OFF " (Mod. 1041)					2	—	B.		
5CW/4327	Rotax N.100397/1	Transfer, " ON "					2	—	C.		
5CW/4328	Rotax N.100397/2	Transfer, " OFF "					2	—	C.		
6A/7041	Kelvin Hughes K.C.0101	Unit, vibrator (Mod. 1002)					1	—			
	B.231487	PANEL, SIDE, STARBOARD, ASSEMBLY					—	—			
	D.231465	Cable, F.36, assembly (See cable chart)					1	—			
	Std.2045/23	Clip, for cables at flap selector					1	—			
	B.212355	Panel, group					1	L.72		FC.1	
	F.212983	Plate, stop					1	L.72			
4179	Std.1606/44/B20	Screw, roundhead, 4 B.A.					2	Brass	C.	5	
1720	Std.1606/44/B24	Screw, roundhead, 4 B.A.					1	Brass	C.	5	
3839	Std.1606/44/B16	Screw, roundhead, 4 B.A.					1	Brass	C.	5	
	Std.1606/44/B36	Screw, roundhead, 4 B.A.					1	Brass			
5CW/6987	Dowty C.5183.Y Mk. 4D	Selector, undercarriage Mk. 4					1	—	A.		
5CW/6329	Dowty C.5148.Y Mk. 19	Selector, flaps					1	—	A.		
	B.231472	PANEL, SIDE, PORT, ASSEMBLY					—	—			
	D.231451	Cable, F.13, assembly (See cable chart)					1	—			
	C.237716	Cable, F.68, assembly (See cable chart)					1	—			
5CW/5252	—	Cap, helvin, sea grey					1	—	C.		
5CX/5000	Std.1512/28	Disc, identification					1	—	B.		
5L/9951286	—	Filament, 28V., 2-5W.					9	—	B.		
5L/9951273	—	Filament, 28V., 3-5W.					2	—	B.		
5CX/5164	—	Indicator, undercarriage, position, type " D1 "					1	—	B.		
5CZ/6001	Dowty C.5165Y Mk. 2	Indicator, magnetic, elevator power					1	—	B.		
5CZ/5073	Dowty C.5165Y Mk. 1	Indicator, magnetic, air brake					1	—	B.		
	A.216486	Label					1	L.72			
5CX/4013	—	Lamp, undercarriage warning, iris type					1	—	A.		
5CX/1553	Rotax H.1104 (Red)	Lamp, hydraulic pressure warning, type " B "					1	—	B.		
	B.215011	Panel, group					1	L.72		FC.1	
1178	Std.1606/44/B12	Screw, roundhead, 4 B.A.					1	Brass	C.	5	
1637	Std.1606/44/B14	Screw, roundhead, 4 B.A. (AS.920/85)					2	Brass	C.	5	
3839	Std.1606/44/B16	Screw, roundhead, 4 B.A.					4	Brass	C.	5	
4179	Std.1606/44/B20	Screw, roundhead, 4 B.A.					6	Brass	C.	5	
3858	Std.1606/45/BB	Screw, countersunk, 4 B.A.					3	Brass	C.	5	
1943	Std.1606/45/B16	Screw, countersunk, 4 B.A.					2	Brass	C.	5	
5CW/6968	Dowty C.1223.Y Mk. 15N	Switch, flap lever					1	—	A.		
5CW/7748	Rotax D.10002	Switch, D.P. change over, no centre position (Mod. 2486)					1	—	B.		
5CW/7541	C.W.C. Ltd. XD.779	Switch, S.P. " on-off," upright " off "					1	—	B.		
5CW/8570	Dowty C.5182.Y Mk. 8D	Switch, undercarriage (Mod. 1012)					1	—	A.		
5CW/4327	Rotax N.100397/1	Transfer, " ON "					1	—	C.		
5CW/4328	Rotax N.100397/2	Transfer, " OFF "					1	—	C.		
5CW/4346	Rotax N.100397/20	Transfer, " IN "					1	—	C.		
5CW/4347	Rotax N.100397/43	Transfer, " OUT "					1	—	C.		

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5			
	B.261295	PLATE, SWITCH, TAIL CHUTE, ASSEMBLY ...						—		
5CY/5380	B.T.H. LGA/6	Breaker , circuit					1	—	A.	
5CW/5252	—	Cap , sea grey					2	—	C.	
5CY/5361	—	Cover , trip button					1	—		
10H/11718	—	Fuse , 5 amp.					1	—		
10H/0590100	—	Holder , fuse					1	—		
	B.261806	Lead , extension, F151 (See cable chart)					1	—		
	A.261294	Plate , switch mounting					1	—		
3837	Std.1606/44/B10	Screw , roundhead, 4 B.A.					4	Brass	C. 5	
1639	Std.1606/44/A6	Screw , roundhead, 6 B.A.					2	Brass	C. 5	
	N.S.F.7675-B102	Switch , grey dolly					1	—	A.	
5CW/7540	C.W.C. Ltd. XD.778	Switch , S.P. c/o N.C.P.					1	—	A.	
1178	Std.1606/44/B12	Screw , roundhead, 4 B.A.					1	Brass	C. 5	
4179	Std.1606/44/B20	Screw , roundhead, 4 B.A.					2	Brass	C. 5	
1720	Std.1606/44/B24	Screw , roundhead, 4 B.A.					2	Brass	C. 5	
4614	Std.1606/44/C16	Screw , roundhead, 2 B.A., securing aileron, neutral position indicator (Mod. 782)					2	Brass	C. 5	
3856	Std.1606/44/C20	Screw , roundhead, 2 B.A.					4	Brass	C. 5	
	D.260383	Shield , glare, centre, group					1	—		
	D.222376/4	Strip , retaining (Local Manufacture)					15"	L.72		
6656	Std.2088/2	Strip , sealing					15"	Rubber	C.	
29G/2180	Carr 882	Stud , 2 B.A.					2	—		
	C.232477	Shield , glare, port, group					1	—		
	C.232477/2	Strip , retaining (Local Manufacture)					16"	L.72		
6656	Std.2808/2	Strip , sealing					16"	Rubber	C.	
29G/2180	Carr 882	Stud , 2 B.A.					2	—		
	C.232478	Shield , glare, starboard, group					1	—		
	C.232478/2	Strip , retaining (Local Manufacture)					17"	L.72		
6656	Std.2088/2	Strip , sealing					17"	Rubber	C.	
29G/2180	Carr 882	Stud , 2 B.A.					2	—		
	A.223946	Shield , glare, side					1	—		
	A.221853	Strut , support, for bomb and R.P. panel					1	L.72		
5F/2301	Hellermann NY.18007	Strapping , $\frac{1}{2}$ " wide					QR	P.V.C.	C.	
5F/2302	Hellermann NY.3342	Stud					2	—	C.	
	Std. 1509/2/060	Tube , distance, starboard panel					1	T.4		
	Std.1509/3/026	Tube , distance, port panel mounting					3	T.4		
	Std.1509/3/076	Tube , distance, port panel mounting					3	T.4		
9777	F.231121	Washer , port panel mounting					3	DTD.5509	FC.1	
	Std.1285/3DE	Wire , bonding					1	Copper cord		

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Score	Place No.
		1	2	3	4	5				
SUMMARY OF STOCK ITEMS										
28D/1007971	A25.1B	Bolt, 4 B.A.	-	-	-	-
28D/1010658	A25.1B	Bolt, 4 B.A.	-	-	-	-
28D/1008149	A25.2B	Bolt, 4 B.A.	-	-	-	-
28D/9419452	A25.3B	Bolt, 4 B.A.	-	-	-	-
28D/1011006	A25.5B	Bolt, 4 B.A.	-	-	-	-
28D/9436920	A25.1C	Bolt, 2 B.A.	-	-	-	-
28D/9133011	A25.2C	Bolt, 2 B.A.	-	-	-	-
28D/1010030	A25.7C	Bolt, 2 B.A.	-	-	-	-
28D/1011247	A25.13E	Bolt, 1/2" B.S.F.	-	-	-	-
28D/8300	AS.1242.1B	Bolt, 4 B.A.	-	-	-	-
28D/9131782	AS.1242.2B	Bolt, 4 B.A.	-	-	-	-
28D/12119	AS.1242.19B	Bolt, 4 B.A.	-	-	-	-
28D/8337	AS.1248.1B	Bolt, 4 B.A.	-	-	-	-
28D/1007981	AS.1248.1C	Bolt, 2 B.A.	-	-	-	-
28D/11981	AS.1248.12E	Bolt, 1/2" B.S.F.	-	-	-	-
28N/258	SP.58.G	Burr	-	-	-	-
28F/13603	AGS.838/8	Bush	-	-	-	-
28E/5452	AGS.895/1	Clip, spring	-	-	-	-
28E/18865	AGS.1163/16	Clip	-	-	-	-
28F/5107	AGS.838/3	Connection, elbow	-	-	-	-
28F/5105	AGS.838/2	Connection, tee	-	-	-	-
5K/3404	AS.3360/E4.E	Lead, bonding	-	-	-	-
5K/3355	AS.3360/B4.B	Lead, bonding	-	-	-	-
28M/5236	A.14.E.B.	Nut, 1/2" B.S.F.	-	-	-	-
28M/13734	A54.B	Nut, 4 B.A.	-	-	-	-
28M/14534	A54.C	Nut, 2 B.A.	-	-	-	-
28F/5108	AGS.838.4	Nut, union	-	-	-	-
28M/10286	AGS.2001.A1	Nut, 6 B.A.	-	-	-	-
28M/10287	AGS.2001.B1	Nut, 4 B.A.	-	-	-	-
28M/10290	AGS.2001.E1	Nut, 1/2" B.S.F.	-	-	-	-
28M/10326	AGS.2002.A1	Nut	-	-	-	-
28M/10327	AGS.2002.B1	Nut, 4 B.A.	-	-	-	-
28M/10309	AGS.2002.B4	Nut, 4 B.A.	-	-	-	-
28M/10328	AGS.2002.C1	Nut, 2 B.A.	-	-	-	-
28M/10310	AGS.2002.C4	Nut, 2 B.A.	-	-	-	-
28M/7002430	AGS.2002.E1	Nut, 1/2" B.S.F.	-	-	-	-
28M/12344	AGS.2002.E4	Nut, 1/2" B.S.F.	-	-	-	-
28S/13887	A32.B10	Screw, 4 B.A.	-	-	-	-
28S/5694	A32.B40	Screw, 4 B.A.	-	-	-	-
28S/2856	A32.C12	Screw, 2 B.A.	-	-	-	-
28F/5104	AGS.838.1	Union, straight	-	-	-	-
28F/5105	AGS.838.2	Union, tee	-	-	-	-
28F/5107	AGS.838.3	Union, elbow	-	-	-	-

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
28W/9419473	SP.15.A	Washer,	6	B.A....	~	---	---
28W/9419474	SP.15.B	Washer,	2	B.A....	~	---	---
28W/9419475	SP.15.C	Washer,	2	B.A....	~	---	---
28W/9419405	SP.15.E	Washer,	1/2"	dia.	~	---	---
28W/9419486	SP.16.B	Washer,	4	B.A....	~	---	---
28W/9419404	SP.16.C	Washer,	2	B.A....	~	---	---
28W/9419487	SP.16.E	Washer,	1/2"	B.S.F.	~	---	---
28W/3090	AGS.163.D	Washer,	spring		~	---	---
28W/9416642	SP.47.B	Washer,	spring		~	---	---

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

