

RESTRICTED

Hunter T. Mk.77. AIRCRAFT

## APPENDIX 'A'

## SECTION 'F' Power Unit

1	2	3	5	6	7	9	10
1F		<u>ENGINE CHANGE UNIT:-</u> For Hunter T. Mk.77 <u>aircraft:-</u> Refer to R.D.I. Spec. 3208 latest issue Engine - AVON Mk.122 To Eng. R.D. Spec. 2332 <u>BOX GEAR:-</u> <u>Accessory Drive:-</u> <u>Equipment A.D.E.171:-</u> <u>Gearbox:-</u>	C	C	1		
2F	37L/5007	Type TG.5/8 <u>Drive Shaft:-</u>	C	C	1		
3F	37L/364 OR	Type GD.9/44 OR	C	C	1		
4F	37L/385	Type GD.9/19 <u>Drive Shaft:-</u>					
5F	37L/363	Coupling Engine Type EC.2/5	C	C	1		
6F		<u>EXTINGUISHER, FIRE:-</u> <u>Automatic:-</u> Refer to Section 'D' Aircraft Services and Miscellaneous					
7F		<u>Spray Rings:-</u> Refer to D.I.S. Part A <u>LAMPS, Warning:-</u>					
8F		Refer to Section 'B' Electrical					

RESTRICTED



RESTRICTED

Hunter T. Mk.77.

AIRCRAFT

APPENDIX 'A'

SECTION 'F' Power Unit

1	2	3	5	6	7	9	10
9F	5UA/6273	<u>GENERATOR, Engine Driven:-</u> <u>24 Volt, 6KW:-</u>  Type 515A	C	C	2		
10F		<u>BATTERIES, Cut Out:-</u> <u>CIRCUIT BREAKERS:-</u> <u>FUSES &amp; FUSE BOXES:-</u> <u>INVERTORS:-</u>  <u>RESISTANCE &amp; RECTIFIER UNITS:-</u> <u>SUPPRESSOR:-</u> <u>VOLTAGE REGULATORS:-</u>  Refer to Section 'B' Electrical					
11F	37A/1790	<u>IGNITION UNIT:-</u> <u>High Energy:-</u>  B.T.H. Type C-10-T/S/3	C	C	2		
12F	6A/3344	<u>TACHOMETER:-</u> <u>Generator:-</u>  Mk.8C	C	C	1		
13F	36VV/	<u>PIPES, JET:-</u>  Type JP.123 (incorporating Mod. J.P.113)	C	C	1		
14F		<u>PUMPS, FUEL Electric:-</u>  Refer to Section 'B' Electrical					
15F	37J/8006	<u>PUMP, Hydraulic:-</u>  Dowty A.8003.Y/RH/3000, 5 G.P.M.	C	C	1		
16F AL 17		<u>STARTER, GAS TURBO:-</u>  B.T.H. Type TBS.720, Mk.2 Ref. No. 37F/11005 Refer to Engine Change Unit					
17F		<u>Accessories:-</u> <u>Cartridges, Cap, Electric:-</u> <u>Engine Starting:-</u>  Refer to Section 'A' Armament under Pyrotechnics					

RESTRICTED



RESTRICTED

Hunter T. Mk.77.

AIRCRAFT

APPENDIX 'A'

SECTION 'F' Power Unit

1	2	3	5	6	7	9	10
18F	6A/1912	<u>SWITCH:-</u> <u>Differential:-</u> Mk. 1E	C	C	3		
19F		<u>TRANSMITTER, PRESSURE:-</u> Smith Inductor refer to E.C.U. schedule (D.I.S) Part A)					
20F	6A/2715	<u>Accessories:-</u> Transformer Smith Type 213 M.V. 115/26V	C	C	1		
21F		<u>GAUGE, Oil Pressure:-</u> Refer to Section 'C' Instrument					

RESTRICTED



The P/Q Family

Why "P/Q"?

The P/Q family of Masks

MCA "Warning Connector"

P/Q 1

P/Q 2

P/Q 4

V-Type

V-Type Separator

V-Type

V-Type

A-Type

V-Type MK2

A-Type MK2

A-Type

Quick Don

A-13A/1

A-13A/2

This file was downloaded from the RTFM Library. Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm) Please see site for usage terms, and more aircraft documents.