

EQUIPMENT AIRCRAFT - FATIGUE METER INSTALLATION

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
5CZ/10537947	D.233619	METER, FATIGUE, ASSEMBLY								
	# B.221106	Block, terminal					1		B	
	# B.216904	Cable, FM.1, group					1			
	# F.216906	Cable, FM.2, group					1			
	# A.216905	Bracket, fuseholder					1	L.72		
	# B.233682	Cable, FM.3, group					1			
6A/9668	B.233766	Landing, for access panel assembly								
	B.233766	Landing					1			
10087	A.233683	Meter, fatigue Mk.15 (Mod.1273)					1		A	
1919	Std.1341/3	Panel, access					1	L.72	C	
4613	Std.1335/C/18	Stud, earthing point					1		C	
4659	Std.1335/C/22	Washer					1	L.4, L.34	C	
		Washer					1	or L.17	C	
10666	Std.2008/C/325	Washer, tab (Mod.951)					2	L.4, L.34 or L.17 S.84	C	
# For details see Cable Chart.										

EQUIPMENT AIRCRAFT - FATIGUE METER INSTALLATION

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
SUMMARY OF STOCK ITEMS										
28D/1010658	A25.1B	Bolt,	4	B.A.						
28D/1008149	A25.2B	Bolt,	4	B.A.						
28D/9133011	A25.2C	Bolt,	2	B.A.						
28M/1006504	A27.BT	Nut,	4	B.A.						
28M/1011467	A27.ES	Nut,	1/4"	B.S.F.						
28M/10326	AGS.2002.A1	Nut,	6	B.A.						
28M/10327	AGS.2002.B1	Nut,	4	B.A.						
28M/10328	AGS.2002.C1	Nut,	2	B.A.						
28M/7002430	AGS.2002.E1	Nut,	1/4"	B.S.F.						
5K/9560937	SP.93-A8	Grommet								
28S/1200062	A33.A20	Screw,	6	B.A.						
28W/9419473	SP.15A	Washer,	6	B.A.						
28W/9419474	SP.15B	Washer,	4	B.A.						
28W/9419486	SP.16B	Washer,	4	B.A.						
28W/9419404	SP.16C	Washer,	2	B.A.						

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

