

RESTRICTED

AF 113

BOOK 4

PART II

CODED AIR PUBLICATIONS

MASTER LISTS FOR AIRCRAFT

PART II

NOTE ON THE MASTER LISTS

Part II of AP 113 Book 4 consists of master lists containing the reference numbers of coded air publications and air diagrams that are either exclusive to specific aircraft types or nearly so. These lists are being gradually supplanted by APs that provide such details rather more comprehensively; the aircraft types already subject to the new arrangement and the reference numbers of the supplanting APs are:

Buccaneer S Mk 2	AP 101B-1202-4W
Bulldog	AP 101B-3801-1 (or AP 101B-3801-5W)
Gazelle	AP 101C- ⁰⁹⁰¹ -3A 0903
Harrier All Mks	AP 101B-0600-5W
Hawk T Mk 1	AP 101B-4401-1Z
Hercules C Mk 1 & W Mk 2	AP 101B- ⁰⁷⁰¹ -5W 0702
Jaguar GR Mk 1	AP 101B-3101-1Z
Jaguar T Mk 2	AP 101B-3102-1Z
Jet Provost Mk 5	AP 101B-2305-4W
Jetstream All Mks	AP 101B-4600-1Z
Lynx AH Mk 1 & HAS Mk 2	AP 101C-1300-1Z
Nimrod All Mks	AP 101B-0500-5W
Phantom All Mks	AP 101B-0900-1Z (or AP 101B-0900-5W)
Puma	AP 101C-0801-1A (or AP 101C-0801-5W)
Sea King All Mks	AP 101C-0400-1Z

PART II (a)

NOTES ON MASTER LIST

1. This part of the catalogue lists available unclassified and restricted coded air publications and air diagrams relevant to specific types and marks of aircraft and other major equipments.
2. Not all the publications and diagrams are peculiar to one aircraft or other equipment. Where a component, assembly or system is installed in two or more aircraft for example, the relevant publication or diagram will be included in each master list, but where there is an applicability to a large number of aircraft types it will not be included.
3. Individual master lists do not include publications or diagrams of a general informatory character which it is assumed are held as a matter of course by user units concerned with the subject matter. For example, a publication containing general servicing information for electrical equipment is expected to be available to all concerned personnel and is not included in the electrical equipment section of each master list.
4. To keep the master list as up-to-date as possible, some items may appear in Part II in advance of availability of the air publications. The only means of ascertaining availability is to refer to the appropriate subject Group in Part III or to the Publications Supplement to Defence Council Instructions (RAF) Class "T".

PUBLICATION MASTER LISTS
FOR AIRCRAFT

ANDOVER Mk 1

Aircraft

101B

-0300-3C
-0300-4G
-0300-13
-0301-1A
-0301-1B
-0301-1C
-0301-1D
-0301-1E
-0301-1F
-0301-1G
-0301-2
-0301-3A
-0301-4A1
-0301-4A2
-0301-4A3
-0301-4A4
-0301-4B1
-0301-4B2
-0301-4C1
-0301-4C2
-0301-4C3
-0301-4C4
-0301-4D
-0301-4F
-0301-4G
-0301-4M
-0301-6A
-0301-6B
-0301-9
-0301-10
-0301-11A
-0301-11B
-0301-11C
-0301-11D
-0301-12
-0301-14
-0301-15
-0301-D19
-0301-D34A
-0301-D34C
-0301-16A
-0301-16B

101S

-0306-1

Aero-Engines (including AAPUs
and Propellers)

102C

-0502-2

102P

-02-16AC
-0201-2

Aero-Engine Equipment

103C

-0102-2
-0102-16AC

Aircraft Landing Gear

104B

-0300-5F
-0300-16C

104C

-0301-16AC
-1002-16

104E

-1003-16C
-1004-16C
-1005-16C

104F

-1002-1

104G

-1003-1
-1006-1
-1006-5F

104J

-1005-1
-1005-5F

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B

-0202-1
-0206-1
-0310-1
-0390-1
-0409-1
-0411-1
-0412-1
-0413-1
-0414-13A
-0508-16C
-0510-1
-0511-1
-0512-1
-0513-1
-0514-1
-0606-16C
-0607-16C
-0714-16C
-0716-1
-0717-1
-0718-1
-0719-16C
-0720-16C
-0721-16C
-0722-1
-0723-16C
-0725-1
-0728-1
-0729-1
-0730-1
-0730-5F
-0743-1
-0750-1
-0751-1
-0752-1
-0753-1
-0754-1
-0755-16
-0913-16
-0914-16C

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls--contd

105B--contd

-0915-16C
-0917-16C
-0918-16C
-0919-16
-0950-16C
-1001-1
-1302-1
-1504-1
-1509-16
-1804-16AC
-1805-16C
-1806-16
-2201-5F
-2201-16C
-07192-1

105C

-0303-1
-0509-1
-0515-1
-0601-16C

105E

-0402-2
-0402-5F
-0402-16
-0501-5F
-0502-5F
-0503-5F
-0504-5F
-0505-5F
-0506-5F
-0507-5F
-0701-16

105F

-0102-5F
-0202
-0301-5F

Aircraft Fuel, Oil and Water
Systems

106C

-0309-1
-0411-1
-0412-1
-0502-1

106G

-0106-16
-0209-16A

Aircraft Environment Control
Equipment

107B

-0128-1
-0206-1

**Aircraft Environment Control
Equipment-cont**

107B--cont

-0216-1
-0217-16
-0218-16
-0405-16A
-0509-5F
-0509-16A
-0902-13A
-0945-1
-0954-1
-1003-5F
-1003-16A
-1009-16A
-1011-16A
-1105-16A
-1107-13A
-1121-1

107C

-0216-16

107D

-0810-5F
-0810-12
-0903-16

107E

-0104-1

**Parachutes and Personnel
Safety and Survival Equipment
(Airborne)**

108C

-0111-1
-0401-5F

108E

-0017-5F
-0401-12

108G

-0101-5F
-0101-16

**Instrument and Photographic
Equipment**

112B

-0812-1

112C

-0007-2

112G

-0120-1
-0302-1
-0333-1
-0333-6
-0410-1
-0516-1
-0557-1
-0559-1
-0574-1
-0704-1
-0704-6

112G--cont

-0903-1
-1004-1
-1022-1
-1142-1
-1204-1
-1205-13A

112R

-0201-1

112T

-0202-1
-01209-1

Airborne Electrical Equipment

113B

-0202-16

113C

-0304-13A

113D

-0102-16
-0304-16A
-0305-16
-0307-1
-0309-16
-0410-1
-0411-1
-0416-1
-0704-16
-0705-16
-0706-2
-0706-16
-0708-16
-0709-16
-0720-2
-0720-16
-1108-1
-1109-1
-1111-1
-1115-1
-1302-16
-1305-6
-1310-1
-1311-1
-1312-1
-1313-1
-1318-1
-1319-16
-1320-16
-1321-16
-1322-16
-1325-16
-1338-16
-1361-16
-1363-16
-1367-1
-1397-16
-1403-1

113E

-0107-16
-0108-13A6
-0120-16
-0209-13A6
-0213-1

113E--cont

-0316-16
-0317-16
-0318-16
-0319-13A6
-0332-16
-0342-16
-0345-16
-0359-1
-0404-6
-0405-6
-0406-6
-0407-6
-0503-16
-0513-3A
-03162-1
-0701-5F

113F

-0201-16
-0205-1
-0209-1
-0306-1
-0607-13A
-0611-1
-0612-1
-0613-1
-0621-1
-0702-1
-0801-1
-0802-1
-0804-1
-0820-1

Airborne Radar Equipment

114E

-0200-4F
-0200-16

114F

-0100-3ACD

**Radio and Television (and
Associated Special-to-Type
Test Equipment)**

116N

-0101-2
-0101-4F
-0401)
)-2
-0404)
-0404-3ACD

116Z

-0402-3ACD

ANDOVER Mk 1-cont

Aircraft Environment Control
Equipment-cont

107B-cont

- 0216-1
- 0217-16
- 0218-16
- 0405-16A
- 0509-5F
- 0509-16A
- 0902-13A
- 0945-1
- 0954-1
- 1003-5F
- 1003-16A
- 1009-16A
- 1011-16A
- 1105-16A
- 1107-13A
- 1121-1

107C

- 0216-16

107D

- 0810-5F
- 0810-12
- 0903-16

107E

- 0104-1

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108C

- 0111-1
- 0401-5F

108E

- 0017-5F
- 0401-12

108G

- 0101-5F
- 0101-16

Instrument and Photographic
Equipment

112B

- 0812-1

112C

- 0007-2

112G

- 0120-1
- 0302-1
- 0333-1
- 0333-6
- 0410-1
- 0516-1
- 0557-1
- 0559-1
- 0574-1
- 0704-1
- 0704-6

112G-cont

- 0903-1
- 1004-1
- 1022-1
- 1142-1
- 1204-1
- 1205-13A

112R

- 0201-1

112T

- 0202-1
- 01209-1

Airborne Electrical Equipment

113B

- 0202-16

113C

- 0304-13A

113D

- 0102-16
- 0304-16A
- 0305-16
- 0307-1
- 0309-16
- 0410-1
- 0411-1
- 0416-1
- 0704-16
- 0705-16
- 0706-2
- 0706-16
- 0708-16
- 0709-16
- 0720-2
- 0720-16
- 1108-1
- 1109-1
- 1111-1
- 1115-1
- 1302-16
- 1305-6
- 1310-1
- 1311-1
- 1312-1
- 1313-1
- 1318-1
- 1319-16
- 1320-16
- 1321-16
- 1322-16
- 1325-16
- 1338-16
- 1361-16
- 1363-16
- 1367-1
- 1397-16
- 1403-1

113E

- 0107-16
- 0108-13A6
- 0120-16
- 0209-13A6
- 0213-1

113E-cont

- 0316-16
- 0317-16
- 0318-16
- 0319-13A6
- 0332-16
- 0342-16
- 0345-16
- 0359-1
- 0404-6
- 0405-6
- 0406-6
- 0407-6
- 0503-16
- 0513-3A
- 03162-1
- 0701-5F

113F

- 0201-16
- 0205-1
- 0209-1
- 0306-1
- 0607-13A
- 0611-1
- 0612-1
- 0613-1
- 0621-1
- 0702-1
- 0801-1
- 0802-1
- 0804-1
- 0820-1

Airborne Radar Equipment

114E

- 0200-4F
- 0200-16

114F

- 0100-3ACD

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116N

- 0101-2
- 0101-4F
- 0401)
-)-2
- 0404)
- 0404-3ACD

116Z

- 0402-3ACD

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F -2152-1

119H -0801-16
-0802-16

Electrical Equipment for Air-
craft Ground Servicing and Aero-
nautical Ground Installations

120F -0404-1

120N -0118-1
-0132-1

Aircraft

101B

-0300-13
-0301-4C3
-0301-4C4
-0302-2
-0302-4A1
-0302-4A2
-0302-4A3
-0302-4A4
-0302-4B1
-0302-4B2
-0302-4C1
-0302-4C2
-0302-4D
-0302-4F

101S

-0306-1

Aero-Engines (including AAPUs
and Propellers)

102C

-0505-2

102P

-1601-2

Aero-Engines Equipment

103C

-0102-2
-0301-1

Aircraft Landing Gear

104C

-1002-16

104E

-1003-16C
-1004-16C
-1005-16C

104F

-1002-1
-1030-1
-1030-5F

104G

-1003-1
-1006-1

104J

-1005-1

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B

-0202-1
-0206-1
-0310-1
-0411-1
-0412-1
-0413-1
-0414-13A
-0508-16C
-0510-1
-0511-1
-0512-1
-0513-1
-0514-1
-0606-16C
-0607-16C
-0714-16C
-0716-1
-0717-1
-0718-1
-0719-16C
-0720-16C
-0721-16C
-0722-1
-0723-16C
-0725-1
-0728-1
-0729-1
-0730-1
-0730-5F
-0743-1
-0750-1
-0751-1
-0752-1
-0753-1
-0754-1
-0755-16
-0913-16
-0914-16C
-0915-16C
-0916-16C
-0917-16C
-0918-16C
-1001-1
-1302-1
-1504-1
-1804-16AC
-1805-16C
-1806-16
-2201-5F
-2201-16C
-07192-1
-07225-1

105C

-0303-1
-0509-1
-0515-1
-0601-16C

105F

-0208-13A6

Aircraft Fuel, Oil and Water
Systems

106C

-0309-1
-0411-16A
-0412-1
-0502-1

106G

-0106-16
-0209-16A

Aircraft Environment Control
Equipment

107B

-0206-1
-0216-1
-0218-13A6
-0225-16
-0405-16A
-0406-1
-0409-1
-0509-6F
-0509-16A
-0902-13A
-0919-16
-0945-1
-0954-1
-1003-5F
-1003-16A
-1009-16A
-1105-16A
-1107-13A
-1112-1
-1420-1

107C

-0216-16

107D

-0812-12
-0903-16

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108C

-0401-5F

108E

-0017-5F
-0401-12

Instrument and Photographic
Equipment

112B

-0812-1

AP.113
AL.93

ANDOVER Mk 2 -cont

Instrument and Photographic
Equipment-cont

112G

- 0120-1
- 0201-1
- 0302-1
- 0333-1
- 0410-1
- 0516-1
- 0557-1
- 0559-1
- 0574-1
- 0704-1
- 0903-1
- 1004-1
- 1142-1
- 1204-1
- 1205-13A

112T

- 0202-1

Airborne Electrical Equipment

113B

- 0202-16

113C

- 0304-13A

113D

- 0102-16
- 0304-16A
- 0305-16
- 0309-16
- 0410-1
- 0411-1
- 0416-1
- 0704-16
- 0705-16
- 0706-2
- 0706-16
- 0708-16
- 0709-16
- 0720-16
- 0922-1
- 1108-1
- 1109-1
- 1111-1
- 1302-16
- 1305-6
- 1310-1
- 1311-1
- 1312-1
- 1312-1
- 1313-1
- 1318-1
- 1319-16
- 1320-16
- 1321-16
- 1323-16
- 1325-16
- 1338-16
- 1361-16
- 1363-16
- 1367-1
- 1397-16
- 1403-1

113E

- 0107-16
- 0108-13A6
- 0120-16
- 0209-13A6
- 0213-1
- 0316-16
- 0317-16
- 0318-16
- 0319-16
- 0332-16
- 0345-16
- 0359-1
- 0404-6
- 0405-6
- 0406-6
- 0407-6
- 0503-16
- 0513-3A

113F

- 0201-16
- 0205-1
- 0209-1
- 0613-1
- 0702-1
- 0801-1
- 0804-1
- 0820-1

113L

- 0102-1
- 0103-13A6

Airborne Radar Equipment

114E

- 0200-16

114F

- 0100-1
- 0100-2
- 0100-6

114J

- 1700-16

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

- 0609-3ACD
- 0610-4F

116N

- 0101-4F
- 0404-3ACD

116Z

- 0402-3ACD

Aircraft Ground Servicing
Information and General
Engineering Equipment

119K

- 0101-13A6

Electrical Equipment for Air-
craft Ground Servicing and Aero-
nautical Ground Installations

120N

- 0118-1

Aircraft

101B

-2400-5A1
-2400-5A2
-2400-5A3
-2400-5B1
-2400-5B2
-2400-5C
-2400-5D
-2400-5E
-2400-5F
-2400-5G
-2400-12A
-2401-1A
-2401-1B
-2401-1C
-2401-3C/3D
-2401-4M
-2401-11A1
-2401-11A2
-2401-11C1
-2401-11C2

101S

-0107-1

Aero-Engines (including AAPUs
and Propellers)

102P

-1301-6C
-1301-2
-1301-16A

Aero-Engine Equipment

103C

-0106-16AC

Aircraft Landing Gear

104C

-2401-1
-2401-5F
-2402-5F

104F

-1027-1
-1027-5F

104G

-1012-1
-1012-5F

104J

-1045-1

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B

-0122-16
-0206-1
-0374-1
-0407-1
-0573-16C
-07316-1
-0738-16
-09166-5F
-0926-16C
-0984-1

105D

-2400-16A

105E

-0601-16

105F

-0101-16A

Aircraft Fuel, Oil and Water
Systems

106B

-0200-1C6
-0211-16

106D

-0112-16C
-0504-1
-0507-1
-4400-13A
-4401-13A
-4701-1

106G

-0116-1
-0210-13A
-0213-1

Aircraft Environment Control
Equipment

107B

-0408-1
-0529-1
-0603-1
-0604-1
-1082-1

107C

-0221-1

107D

-0210-5F
-0213-5F
-0903-16

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108B

-0324-1

108C

-0425-1

Armament (Excluding Guided
Weapons—See Group 118)

110G

-0627-125F

Instrument and Photographic
Equipment

112B

-0208-16
-0311-13A
-0312-13A
-0315-13A
-0316-13A6
-0812-1

112C

-0800-1A
-0802-1
-0802-2

112G

-0513-1
-0527-13A6
-0713-16
-0723-1
-0744-1
-0745-1
-1125-16
-1139-1
-1211-16
-1230-1
-1233-1

112T

-0105-1
-01173-1
-01174-1
-01175-1
-01240-1

Airborne Electrical Equipment

113B

-0210-16

113D

-0114-16
-0412-1
-0723-16

Airborne Electrical Equipment—cont

113D—cont
 -0740-1
 -0772-13A6
 -0903-1
 -1113-1
 -1210-1
 -1305-1
 -1329-16
 -1350-16
 -1352-1
 -1354-1
 -1358-16
 -1401-1
 -1404-16
 -1412-1
 -1416-1
 -1416-6
 -1431-1
 -07100-1
 -13115-1
 -13117-1
 -13147-1

113E

-0112-16
 -0118-16
 -0120-16
 -0125-1
 -0209-16
 -0348-16
 -0353-16
 -03174-1
 -0377-16
 -0384-16
 -0387-16
 -0397-16
 -0398-16
 -03164-6
 -0407-16
 -0504-3A
 -0506-1
 -0506-3
 -0522-1

113F

-0209-1
 -0303-1
 -0608-16
 -0623-1
 -0643-1
 -0643-6
 -0702-1

113G

-0108-1

113L

-0113-1

Airborne Radar Equipment

114E

-0100-1
 -0100-3A(N)
 -0400-2
 -0400-3ACD

114F

-0300-1
 -0300-2
 -0300-6

114J

-0300-2

Radio and Television (and
Associated Special-to-Type
Test Equipment

116B

-0201-5F(N)
 -0203-3ACD
 -0203-5F(N)
 -0444-2
 -0444-3A2
 -0603-3ACD
 -0604-3ACD
 -0608-3ACD

116D

-0108-4F

116L

-0701-1

116N

-0403-2

116Z

-0402-3ACD

Aircraft Ground Servicing Infor-
mation and General Engineering
Equipment

119F

-2129-1

119H

-0801-16
 -0802-16

Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installation

120F

-0408-1

**Aero-Engines (including AAPUs
and Propellers)**

102P
-0301-3A

**Parachutes and Personnel
Safety and Survival Equipment
(Airborne)**

108E
-0422-1

**Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls**

105B
-0129-1
-0344-1
-0575-1
-07337-1
-07338-1
-09134-1
-09135-1
-09136-1
-1313-1
-1313-5F
-1825-1
-1826-1
-1827-1
-1828-1
-1829-1
-1830-1

**Instrument and Photographic
Equipment**

112B
-0331-1
-0344-16
112C
-1500-1
112G
-0333-1
-0333-6
-1005-16

Airborne Electrical Equipment

113D
-1109-1
113E
-0475-16
-03113-16

**Aircraft Fuel, Oil and Water
Systems**

106C
-0109-1
-1004-1

**Airborne and Marine Radar
Equipment**

114J
-1700-16

**Aircraft Environment Control
Equipment**

107E
-0122-1

Aircraft

- 101B
 -0100-6A
 -0101-1A
 -0101-1B
 -0101-1C
 -0101-1D
 -0101-1E
 -0101-1F
 -0101-1G
 -0101-1H
 -0101-2
 -0101-3B
 -0101-3C
 -0101-9
 -0101-10A
 -0101-10B
 -0101-11B
 -0101-11D
 -0101-14
 -0101-15
 -0101-16A
 -0101-16B

- 101S
 -0106-1
 -0201-1

Aero-Engines (including AAPUs and Propellers)

- 102C
 -0101-2
 -0101-3A
 -0101-7
 -0101-16A

Aero-Engine Equipment

- 103B
 -0101-16A7
 -0102-1
 -0302-16C
 -1101-1
- 103C
 -0101-3A
 -0101-2
 -0101-16C
 -0102-16AC
 -0302-1

Aircraft Landing Gear

- 104B
 -0201-5F
 -2001-1
 -2003-16

- 104C
 -0001-5F
 -0201-5F
 -0201-16C
 -0202-5F
 -0202-16
 -0203-16
 -2001-1

- 104E
 -0001-5F
 -0201-16C
 -1007-1
 -1008-1
 -1012-1
 -1028-16C

- 104F
 -1000-5F
 -1001-1
 -1001-5F
 -1003-16

- 104G
 -1001-1

- 104J
 -1001-1

Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls

- 105B
 -0001-5F
 -0101-1
 -0201-1
 -0301-5F
 -0301-16AC
 -0302-5F
 -0302-16AC
 -0304-5F
 -0304-16AC
 -0306-1
 -0501-16C
 -0502-1
 -0503-1
 -0504-16C
 -0505-16C
 -0507-1
 -0510-1
 -0515-1
 -0517-1
 -0601-16C
 -0602-16AC
 -0603-16C
 -0604-16C
 -0605-16C
 -0619-1
 -0620-1
 -0621-16C
 -0622-1
 -0624-13A
 -0625-13A
 -0626-13A
 -0701-1
 -0702-16C
 -0703-16AC
 -0706-16C
 -0707-1
 -0708-16AC

Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls-cont

- 105B-cont
 -0709-16AC
 -0710-16C
 -0711-16C
 -0712-16C
 -0713-16C
 -0715-1
 -0724-1
 -0726-1
 -0735-1
 -0736-1
 -0737-1
 -0742-1
 -0744-1
 -0745-1
 -0746-1
 -0756-16
 -0759-5F
 -0794-1
 -0796-16
 -0799-1
 -07155-1
 -07339-1
 -07431-16C
 -0801-16AC
 -0802-16AC
 -0803-16
 -0804-1
 -0901-16C
 -0902-16C
 -0903-16C
 -0904-16C
 -0905-16C
 -0906-16C
 -0907-16C
 -0908-16C
 -0909-16C
 -0911-5F
 -0923-1
 -0945-16C
 -0946-16C
 -0947-16
 -0948-5F
 -0948-16
 -0949-16AC
 -0969-5F
 -0969-16C
 -0970-5F
 -0970-16
 -0971-16
 -1506-1
 -1510-16
 -1701-16
 -1705-5F
 -1705-16C
 -1714-13A
 -1801-16C
 -1802-1
 -1803-1
 -1809-1
 -1810-1
 -1811-1

- 105C
 -0101-16A
 -0201-1
 -0301-1
 -0301-13A
 -0401-16A

BELFAST Mk 1-cont

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls - cont

- 105C-cont
 - 0404-1
 - 0501-16AC
 - 0502-16AC
 - 0503-1
 - 0505-16A
 - 0506-16A
 - 0507-16A
 - 0509-1
 - 0511-16A

- 105D
 - 0101-16A
 - 0102-16A
 - 0103-16A

- 105E
 - 0199-1
 - 0401-5F
 - 0501-5F
 - 0502-5F
 - 0503-5F
 - 0504-5F
 - 0505-5F
 - 0507-5F

- 105F
 - 0102-5F
 - 0202

Aircraft Fuel, Oil and Water
Systems

- 106B
 - 0601-16A

- 106C
 - 0201-1
 - 0202-1
 - 0304-16A
 - 0401-16A
 - 0601-16A

- 106D
 - 0101-1
 - 0501-1
 - 0601-1
 - 1101-1
 - 4302-13A6C

- 106G
 - 0201-16A
 - 0202-16A
 - 0203-16A
 - 0204-16A
 - 0205-16
 - 0207-16A
 - 0301-16A
 - 0503-5F

- 106H
 - 0210-1

Aircraft Environment Control
Equipment

- 107B
 - 0101-1
 - 0202-1
 - 0203-1

Aircraft Environment Control
Equipment - Cont

- 107B-cont
 - 0204-1
 - 0205-1
 - 0211-1
 - 0212-1
 - 0213-1
 - 0214-6
 - 0215-1
 - 0222-126
 - 0223-1
 - 0411-1
 - 0501-1
 - 0501-5F
 - 0502-1
 - 0503-1
 - 0504-3F
 - 0504-1
 - 0901-1
 - 0901-13A
 - 0902-13A
 - 0903-1
 - 0906-16A
 - 0930-16A
 - 0931-1
 - 09123-1
 - 09126-1
 - 1073-13A
 - 10114-1
 - 1101-1
 - 1102-1
 - 1401-13A
 - 1402-1
 - 5001-1

- 107C
 - 0200-1
 - 0215-16A
 - 0219-1
 - 0401-1

- 107D
 - 0814-12
 - 0901-12
 - 0902-1
 - 0903-5F
 - 0903-16

- 107E
 - 0101-1
 - 0101-6
 - 0102-1
 - 0104-1
 - 0105-1
 - 0107-1

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

- 108E
 - 0402-1

Armament (Excluding Guided
Weapons-See Group 118)

- 110H
 - 0125-2

Instrument and Photographic
Equipment

- 112B
 - 0201-13A
 - 0501-1
 - 0801-1
 - 0801-2
 - 0802-2
 - 0803-1
 - 1001-10

- 112C
 - 0007-1A
 - 2100-2
 - 2101-16
 - 2103-16
 - 2104-16
 - 2106-1
 - 2107-16
 - 2108-16
 - 2109-1B
 - 2109-16
 - 2110-16
 - 2111-1
 - 2112-1B
 - 2112-16
 - 2114-16
 - 2115-16
 - 2118-16
 - 2120-16
 - 2121-16
 - 2123-16
 - 2124-16
 - 2125-16
 - 2126-16
 - 2126-1A6
 - 2127-16
 - 2128-16
 - 2129-16
 - 2130-16
 - 2131-16
 - 2133-1
 - 2134-1
 - 2135-16
 - 2136-16
 - 2137-16
 - 2138-16
 - 2139-16
 - 2141-16
 - 2142-16
 - 2143-16
 - 2144-16
 - 2145-1
 - 2147-16
 - 2148-16
 - 2149-16
 - 2150-16
 - 2151-16
 - 2152-1A6
 - 2153-1A6
 - 2153-1B
 - 2154-1A6
 - 2155-1A6
 - 2156-1A6
 - 2157-1A6
 - 2157-1B
 - 2158-1B

- 112G
 - 0101-1
 - 0102-1
 - 0126-1

Instrument and Photographic
Equipment-cont

- 112G-cont
- 0126-2
 - 0203-1
 - 0301-1
 - 0303-1
 - 0303-6
 - 0501-1
 - 0504-16
 - 0506-1
 - 0507-1
 - 0508-1
 - 0510-1
 - 0511-1
 - 0514-1
 - 0517-16
 - 0518-1
 - 0518-6
 - 0519-1
 - 0520-1
 - 0521-1
 - 0526-1
 - 0558-1
 - 0601-1
 - 0613-1
 - 0701-1
 - 0702-1
 - 0703-16
 - 0901-1
 - 1001-1
 - 1002-1
 - 1002-16
 - 1101-16
 - 1102-1
 - 1103-1
 - 1104-1
 - 1105-16
 - 1107-1
 - 1111-13A
 - 1201-1
 - 1202-1
 - 1203-13A6
 - 1203-16

112R

- 0201-1

112T

- 0101-1
- 0103-1
- 0104-1
- 0212-1
- 0213-1
- 0214-1
- 0215-1
- 0216-1
- 0217-1
- 0218-1
- 0219-1
- 0220-1
- 0221-1
- 0222-1
- 0223-1
- 0224-1
- 0226-1
- 01147-1
- 01148-1
- 01157-1
- 01159-1
- 01160-1
- 01161-1
- 01162-1
- 01164-1

Instrument and Photographic
Equipment-cont

- 112T cont
- 01165-1
 - 01167-1
 - 01168-1
 - 01169-1
 - 01170-1
 - 01171-1
 - 01173-1
 - 01174-1
 - 01175-1
 - 01209-1
 - 01400-1
 - 01401-1
 - 01402-1
 - 01403-1
 - 01410-1
 - 01411-1
 - 01415-1
 - 01416-1
 - 01417-1
 - 01418-1
 - 01419-1
 - 01420-1
 - 01421-1
 - 01423-1
 - 01424-1
 - 01436-1
 - 01437-1
 - 01439-1
 - 01440-1
 - 01441-1
 - 01442-1
 - 01443-1
 - 01444-1
 - 01445-1
 - 01446-1
 - 01447-1
 - 01456-1
 - 01465-1
 - 01466-1
 - 01467-1
 - 01468-1
 - 01469-1
 - 01697-1

Airborne Electrical Equipment

113B

- 0101-1B

113D

- 0101-2
- 0302-1
- 0302-6
- 0303-1
- 0309-16
- 0401-1
- 0402-1
- 0403-1
- 0405-2
- 0405-16
- 0406-2
- 0406-16
- 0407-16
- 0408-1
- 0409-1
- 0702-2

Airborne Electrical Equipment-cont

- 113D-cont
- 0702-16
 - 0703-2
 - 0703-16
 - 0713-16
 - 0901-16
 - 0905-1
 - 0906-1
 - 0907-1
 - 0913-1
 - 1001-1
 - 1101-1
 - 1102-1
 - 1107-1
 - 1115-1
 - 1201-1
 - 1204-1
 - 1209-1
 - 1305-1
 - 1305-6
 - 1306-1
 - 1307-1
 - 1307-6
 - 1309-1
 - 1312-1
 - 1320-16
 - 1321-16
 - 1322-16
 - 1323-16
 - 1324-16
 - 1325-16
 - 1326-16
 - 1327-1
 - 1332-16
 - 1336-16
 - 1337-16
 - 1340-16
 - 1345-16
 - 1402-1
 - 1416-1
 - 1416-6
 - 1802-1

113E

- 0101-16
- 0102-16
- 0103-16
- 0104-1
- 0105-6
- 0106-16
- 0162-16
- 0201-1
- 0208-16
- 0210-1
- 0250-1
- 0250-6
- 0301-1
- 0301-6
- 0302-16
- 0304-16
- 0305-16
- 0306-1
- 0306-6
- 0307-16
- 0309-16
- 0311-1
- 0312-16
- 0313-16
- 0314-16
- 0315-16
- 0316-16

Airborne Electrical Equipment—cont

113E—cont
-0320-16
-0331-16
-0333-16
-0344-16
-0348-16
-0349-16
-03164-6
-0402-6
-0403-6
-0404-6
-0501-16
-0510-13A6

113F
-0101-16
-0102-13A
-0203-1
-0203-6
-0204-1
-0206-1
-0207-1
-0210-16
-0211-1
-0212-1
-0214-1
-0215-1
-0401-1
-0501-1
-0601-1
-0602-1
-0604-1
-0605-13A
-0606-1
-0607-13A
-0805-1
-0807-16
-0809-1

113L
-0114-13A6
-0302-1
-0303-1

Airborne Radar Equipment

114E
-0400-3ACD
114F
-0100-1
-0100-2
-0100-3ACD
-0100-6

Radio and Television (and Associated Special-to-Type Test Equipment)

116B
-0101-2
-0101-3ACD
-0304-2

Radio and Television (and Associated Special-to-Type Test Equipment)—cont

116B—cont
-0304-601
-0304-602
-0304-603
-0304-604
-0304-605
-0304-606
-0304-608
-0304-609
-0304-610
-0304-611
-0304-612
-0304-613
-0304-617
-0304-619
-0304-620
-0304-622
-0304-623
-0304-625
-0304-626
-0412-16
-0610-1
-0610-2
-0610-3CD

116D
-0105-1
-0105-3ACD
-0108-4F
-0133-1A
-1101-1
-1101-6

116N
-0101-4F
-0101-6
-0401)
)-2
-0404)
-0401-3ACD

116Z
-0402-3ACD
-0418-1

Electrical Equipment for Aircraft Ground Servicing and Aeronautical Ground Installations

120F
-0403-1
-0404-1
120N
-0104-15F

Aircraft Ground Servicing Information and General Engineering Equipment

119F
-2147-1
119H
-0801-16
-0802-16

Aircraft Environment Control
Equipment

107B

- 0241-1
- 0902-13A

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

110H

- 0125-2

Instrument and Photographic
Equipment

112C

- 2102-1A6
- 2112-1B

112T

- 01166-1
- 01171-2
- 01425-1
- 01426-1
- 01432-1
- 01433-1

Airborne Electrical Equipment

113D

- 0913-1

Aircraft

101B

-1202-1A
-1202-4A1
-1202-4A2
-1202-4A3
-1202-4B1A(R)
-1202-4B1B(R)
-1202-4B1(R)
-1202-4B2
(covers 1 & 2)
-1202-4C1
-1202-4C2
-1202-4D
-1202-4F
-1202-4M(R)
-1202-12

101S

-0130-1

Aero-Engine Equipment

103D

-0213-167
-0216-167

103E -0106-16A

Aircraft Landing Gear

104C

-2003-16

104E

-1011-16
-1013-16

104F

-3005-5F
-3007-1
-3007-5F

104G

-1009-1
-1009-5F

104J

-3002-5F
-3008-1
-3008-5F

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B

-0338-1
-0339-1
-0340-1
-0341-1
-0403-13A6

105B-cont

-0404-13A6
-0434-13A
-0438-1
-0559-1
-0615-16
-0616-16
-0681-1
-0682-1
-0684-1
-0685-1
-0686-1
-0687-1
-0688-1
-0689-1
-0696-1
-0699-1
-0726-1
-0741-5F
-0741-16
-0822-1
-0826-1
-0980-1
-0981-1
-0982-1
-0987-16
-0993-5F
-1007-1
-1009-1
-1012-1
-1101-1
-1102-1
-1107-16
-1119-16
-1133-1
-1134-1
-1135-1
-1136-1
-1137-1
-1139-1
-1140-1
-1204-1
-1703-1
-1816-16C
-1819-1
-1820-1
-1823-1
-05106-16C
-06109-1
-07127-1
-07115-1
-07201-1
-07215-1
-07216-1
-07217-1
-07219-1
-07222-1
-07223-1
-07224-1
-07226-1
-07229-1
-07239-1
-07240-1
-07241-1
-07244-1
-07245-1
-07246-1
-07247-1
-07269-1
-07274-1
-07275-1

105B-cont

-07278-1
-07279-1
-07281-1
-07282-1
-07283-1
-09109-16
-09110-16
-09112-1
-09113-1
-09114-1
-09115-1
-09116-1
-09117-1
-09118-1
-09119-1
-09120-1
-09121-1
-09122-16
-09123-1
-09156-16C
-09157-1

105C

-0112-1
-0210-1
-0314-1
-0315-1
-0316-1
-0403-16A
-0409-16A
-0417-16
-0418-1
-0446-1
-0547-1
-0596-1
-1203-1
-05103-1
-05160-16A

105D

-1202-16
-1203-16

Aircraft Fuel, Oil and Water
Systems

106C

-0801-16BC
-1101-16

106D

-0401-16C
-0504-1
-0602-1
-2202-1
-4204-16C
-4401-13A
-4402-13A
-4403-13A
-4701-1

106E

-0401-1

Aircraft Environment Control
Equipment

- 107B
 - 0105-1
 - 0105-5F
 - 0108-5F
 - 0139-5F
 - 0207-1
 - 0208-16
 - 0226-16
 - 0305-1
 - 0505-16
 - 0511-126
 - 0515-16
 - 0516-5F
 - 0629-1
 - 0905-16AD
 - 0928-16
 - 0943-16
 - 0963-126
 - 0990-5F
 - 0991-5F
 - 1005-126
 - 1007-16
 - 1013-16A
 - 1025-16A
 - 1026-16A
 - 1110-13A
 - 5004-16
- 107C
 - 0232-16
- 107D
 - 0503-1
 - 0811-12
 - 1002-12

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

- 108B
 - 0132-1D
- 108C
 - 0123-1
 - 0128-1J
 - 0128-5F9
 - 0135-12
 - 0135-5F
- 108E
 - 0035-126
 - 0537-12
 - 0537-5F
- 108F
 - 0809-12
 - 0809-5F
 - 0902-12

Aircraft Assisted — Escape
Systems

- 109B
 - 0132-1D
 - 0132-5F
- 109F
 - 0101-5F

Armament (Excluding Guided
Weapons — See Group 118)

- 110G
 - 0103-15F
 - 0123-15F
 - 0123-D1
 - 0124-15F
 - 0124-D1
 - 0125-15F
 - 0125-D1
 - 0127-15F
 - 0128-15F
 - 0129-15F
 - 0303-15F
 - 0504-125FNQ
 - 0506-125FNQ
 - 0609-15F

Instrument and Photographic
Equipment

- 112B
 - 0303-1
 - 0303-6
 - 0304-1
 - 0304-6
 - 0306-6
 - 0602-13A
- 112C
 - 0019-6
- 112E
 - 0403A-1
 - 0403B-1
 - 0403B-6
 - 0403D-16
 - 0403E-16
 - 0403F-16
- 112F
 - 0006-6
- 112G
 - 0113-1
- 112P
 - 0208-16
 - 0533-1
 - 0540-1
 - 0719-1B
 - 0815-1
 - 1216-1
 - 1217-1
- 112P
 - 0215-1
 - 0403-1
 - 1110-13A

112T

- 01192-1
- 01193-1
- 01202-2
- 01205-1
- 01214-1
- 01215-1
- 01216-1
- 01217-1
- 01218-1
- 01223-1
- 01224-1
- 01242-16
- 01564-1

Airborne Electrical Equipment

- 113B
 - 0115-16
- 113D
 - 0418-1
 - 0435-1
 - 07171-1
 - 1109-1
 - 1113-1
 - 1115-1
 - 1304-13A
 - 1351-16
 - 1379-2
 - 1394-1
 - 13135-13A
 - 13141-1
 - 13148-13A6
 - 1451-1
 - 1875-1
 - 1905-1
- 113E
 - 0109-16
 - 0135-16A
 - 0213-1
 - 0215-16
 - 0330-16
 - 0357-16
 - 0389-13A6
 - 03161-1
- 113F
 - 0107-1
 - 0109-1
 - 0110-1
 - 0244-1
 - 0403-13A
 - 0407-6
 - 0408-13A
 - 0408-6
 - 0424-13A6
 - 0662-1
 - 1203-16
 - 1204-1
- 113G
 - 0131-1
 - 0132-13A
 - 0134-13A
 - 0135-1
 - 0136-1
 - 0137-1
 - 0301-13A
 - 0601-1

Airborne Electrical Equipment—cont

113L
—0114—13A6
—0604—1

120G—cont
—0147—1
—0148—1
—0152—1
—0401—1D
—0701—1

Airborne Radar Equipment

114F
—0100—1

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B
—0443—2
116D
—0102—2
—0102—3ACD
—0102—4F
116N
—0101—5F(N)
116T
—0403—1

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F
—0303—5F
119K
—0701—2

Electrical Equipment for Aircraft
Ground Servicing and
Aeronautical Ground
Installations

120F
—0201—13A
120G
—0108—1
—0109—1
—0133—1
—0139—1
—0140—1
—0141—1
—0142—1
—0143—1
—0144—1

Aircraft

101B
-0400-6
-0400-13
-0402-1
-0402-12

101T
-0001-1

Aircraft Fuel, Oil and Water Systems

106B
-0200-1C6
-0213-16

106C
-1101-16

Armament (excluding Guided Weapons - see Group 118)

110G
-0148-125F
-0323-125F
-0614-125F
-0626-125F

110H
-0219-125F

Aero-Engines (including AAPUs and Propellers)

102C
-1522-1
-1522-2
-1522-6A

Aircraft Environment Control Equipment

107B
-0522-1
-0614-1
-0905-123A6AD
-0911-16
-0945-1
-1002-16A
-1027-16
-10109-1
-10112-2
-1109-16
-1111-16
-1203-1
-1415-1

Instrument and Photographic Equipment

112B
-0326-16
-0502-1
-0814-1

112C
-1800-1

112G
-0558-1
-1022-1
-1023-1
-1031-2
-1101-16
-1247-2

112K
-0200-16

112P
-0201-1
-0211-1

Aero-Engine Equipment

103C
-0107-16

103D
-0106-17
-0202-3A

107C
-0106-1

107D
-0211-1
-0211-5F
-0212-1
-1002-12

Aircraft Landing Gear

104B
-1401-16

104G
-1039-1

104J
-1039-5F
-1047-1

Parachutes, and Personnel Safety and Survival Equipment (Airborne)

108C
-0106-1
-0108-1

108E
-0507-1
-0538-1
-0538-5F
-0542-1

Airborne Electrical Equipment

113D
-0123-1
-0724-1
-0751-1
-0773-13A
-07101-16
-1002-1
-1374-16
-1377-1
-1397-16
-1404-16
-1612-1
-13147-1

113E
-0141-16
-0143-16
-0145-1
-0418-6
-0419-6
-0438-1
-0438-6

113F
-1103-1

Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls

105B
-0217-1
-0547-1
-0738-16
-07433-16C
-0986-16C
-09127-16C

105C
-0545-16A
-0587-1
-0595-1

105D
-0410-16A

Aircraft Assisted-Escape Systems

109C
-0201-1
-0201-5F
-0206-5F

109D
-0201-1

109E
-0201-1

Airborne Radar Equipment

114F

- 0300-4F
- 0500-2

Radio and Television (and
Associated Special-to-Type
Test Equipment

116B

- 0407-3A1
- 0407-3A2
- 0407-3CD
- 0408-3ACD
- 0601-3ACD

116D

- 0111-3ACD
- 0117-3ACD

Aircraft

101B

-0400-6
-0400-13
-0404-1
-0404-12
-0404-D1
-0413-D1
-0404-D12

Aero-Engines (including AAPUs
and Propellers)

102C

-1522-1
-1522-2
-1522-6A
-1522-D11

Aero-Engine Equipment

103D

-0106-17
-0201-16A
-0202-3A

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B

-0217-1
-0547-1
-0738-16
-0986-16C
-09127-16C

105C

-0545-16A
-0587-1

105D

-0410-16A

Aircraft Fuel, Oil and Water
Systems

106B

-0200-1C6
-0213-16

106C

-1101-16

Aircraft Environment Control
Equipment

107B

-0614-1
-0905-123A6AD
-0911-16
-0945-1
-1022-16A
-1027-16
-10109-1
-10112-1
-1109-16
-1111-16
-1415-1

107C

-0106-1

107D

-1002-12

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108B

-0115-1
-0116-1

108C

-0106-1
-0108-1
-0119-1

108E

-0032-5F
-0538-1
-0542-1

Aircraft Assisted-Escape
Systems

109B

-0115-1
-0116-1
-0116-5F

109C

-0201-1
-0201-5F
-0206-5F

109D

-0201-1

109E

-0201-1

Armament (Excluding Guided
Weapons - see Group 118)

110G

-0148-125F
-0626-125F

Instrument and Photographic
Equipment

112B

-0326-16
-0502-1
-0814-1

112C

-1800-1

112G

-0558-1
-1022-1
-1023-1
-1031-1
-1101-16

112K

-0200-16

112P

-0201-1
-0211-1

Airborne Electrical Equipment

113D

-0724-1
-0751-1
-0773-13A
-1210-1
-1374-16
-1377-1
-1397-16
-13147-1
-1404-16
-1612-1

113E

-0142-16
-0143-16
-0418-6
-0419-6
-0438-1
-0438-6

113F

-1103-1

Aircraft Radar Equipment

114F

-0300-4F

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

-0407-3A2
-0407-3CD
-0408-3ACD

Radio and Television (and
Associated Special-to-Type
Test Equipment)—cont

116D
-0111-3ACD
-0117-3ACD

Electrical Equipment for Aircraft
Ground Servicing — Aeronautical Ground
Installations

120F
-0401-1

Airborne Electrical Equipment—cont

113E

-0104-1
-0143-16
-0162-16
-0418-6
-0419-6
-0438-1
-0438-6
-0450-6

113F

-0410-1
-1103-1

113L

-0118-1

Airborne Radar Equipment

114E

-0300-4F

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116D

-0111-3ACD
-0117-3ACD

116F

-0407-3A2
-0407-3ACD
-0407-3CD

119F

-0216-16A

Aircraft

- 101B
-0400-6
-0400-13
-0417-1
-0417-2
-0417-10
-0417-12

Aircraft Fuel, Oil and Water Systems

- 106B
-0200-1C6
-0213-16
-1001-16
106C
-1101-16

Armament (Excluding Guided Weapons - See Group 118)

- 110G
-0148-125F
-0516-125F
110M
-0101-1D

Aero-Engines (including AAPUs and Propellers)

- 102C
-1522-1
-1522-2
-1522-6A
-1522-D11

Aircraft Environment Control Equipment

- 107B
-0614-1
-0905-16AD
-0911-16
-0945-1
-1002-16A
-1027-16
-10109-1
-10112-1
-1109-16
-1111-16
-1415-1

Instrument and Photographic Equipment

- 112B
-0326-1
-0502-1
-0814-1
112C
-1800-1
112G
-0558-1
-1022-1
-1023-1
-1101-1
112K
-0200-16
112P
-0201-1

Aero-Engine Equipment

- 103C
-0201-16A
103D
-0202-13A

- 107C
-0106-1
107D
-0201-1
-1002-1

Airborne Electrical Equipment

- 113D
-0724-1
-0751-1
-0756-1
-0773-13A
-1002-1
-1210-1
-1374-16
-1377-1
-1397-16
-1404-16
-1612-1
-13134-1
-13147-1
113E
-0141-16
-0143-16
-0380-16
-0418-6
-0438-1
-0438-6
113F
-1103-1
-1105-1

Aircraft Landing Gear

- 104B
-1401-16

Parachutes and Personnel Safety and Survival Equipment (Airborne)

- 108C
-0106-1
-0108-1
-0119-1
-0129-1
108E
-538-1
-542-1

Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls

- 105B
-0217-1
-0547-1
-0738-16
-0986-16C
-09127-16C
105C
-0545-16A
-0546-16
-0550-16
-0587-1
-05150-1
105D
-0410-16A

Aircraft Assisted - Escape Systems

- 109C
-0201-1
-0201-5F
-0206-5F
109D
-0201-1
109E
-0201-1

AP.113
AL.93

CANBERRA Mk 17—cont.

Airborne Radar Equipment

- 114E
-0300-4F
- 114J
-0102-2

● Radio and Television (and
Associated Special-to-Type
Test Equipment)

- 116B
 - 0407-3A2
 - 0407-3CD
 - 0408-3ACD
- 116D
 - 0111-3ACD
 - 0117-3ACD
- 116F
 - 0108-3ACD
 - 0206-3ACD

DOMINE Mk 1

Aircraft

101B

-2001-1A
-2001-1C
-2001-1D
-2001-1E
-2001-1F
-2001-2
-2001-4A1
-2001-4A3
-2001-4B1
-2001-4B2
-2001-4C1
-2001-4C2
-2001-4C3
-2001-4C4
-2001-4C5
-2001-4C6
-2001-4C7
-2001-4C8
-2001-4F
-2001-6A
-2001-10
-2001-12

Aero-Engines (including AAPUs
and Propellers)

102C

-0805-16A

Aero-Engine Equipment

103B

-0104-1
-0701-1
-1601-1

Aircraft Landing Gear

104B

-1001-16A

104C

-1001-16
-2101-5F

104F

-1044-1

104G

-1011-5F

104J

-1023-1

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B

-0219-1
-0303-16A
-0305-16A
-0363-1
-0465-1
-0583-1
-07321-1
-07323-1
-07324-1
-07325-1
-07326-1
-07327-1
-07328-1
-07329-1
-07436-1
-0830-1
-0831-1
-0919-16
-0920-16
-0921-16
-0923-1
-1406-1

105C

-0512-16A
-0513-16A

Aircraft Environment Control
Equipment

107B

-0102-1
-0201-1
-0224-1
-0241-1
-0605-1
-0606-1
-0620-1
-0904-1
-09122-1
-09126-1
-1001-1
-1014-16A
-1114-1
-1429-1
-5011-1

107C

-0229-1

107D

-0505-12
-0810-5F
-0816-12

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108E

-0204-5F
-0301-1
-0420-1

Instrument and Photographic
Equipment

112B

-0323-1
-0327-1
-0813-1

112C

-0007-1A
-0007-1B
-0007-2

112G

-0208-16
-0314-16
-0555-1
-0725-6
-1023-1
-1031-2
-1111-1
-1133-1
-1160-1

112T

-01225-1
-01272-1
-01272-2

Airborne Electrical Equipment

113B

-0106-16
-0201-16

113C

-0210-1

113D

-0103-16
-0105-16
-0114-16
-0319-1
-0423-16
-0710-16
-0720-2
-0720-16
-0748-16
-0782-6
-1002-1
-1109-1
-1115-1
-1305-6
-1330-1
-1362-16
-1366-16
-1377-1

AP. 113
AL. 93

DOMINE Mk 1—cont

Airborne Electrical Equipment—cont

113D—cont

-1395-1
-1602-1
-1901-1

113E

-0113-16
-0114-16
-0305-16
-0359-1
-0376-1
-03115-6
-0417-1
-0417-6
-0446-1
-0446-2
-0446-6
-0478-1

113F

-0208-13A
-0413-13A
-0414-1
-0603-16
-0623-1
-0628-13A
-0628-6

113K

-0601-1

116G

-0601-5F(N)

116N

-0101-6
-0304-3ACD

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120F

-0404-1

120N

-0131-1

Airborne Radar Equipment

114E

-0200-16

114F

-0100-1
-0100-2
-0100-6

114J

-0300-2

Radio and Television (and
Associated Special-to-Type
Test Equipment)

16B

-0408-3ACD
-0604-3ACD

116D

-0101-3ACD
-0102-3A
-0102-6D1
-0102-6D2
-0102-6D3
-0102-6D4
-0102-6D5
-0106-3A(N)
-0106-3ACD

GNAT

Aircraft		
101B	105B—cont	Parachutes, and Personnel Safety and Survival Equipment (Airborne)
-1800-6A	-0578-1	108C
-1800-13	-0579-1	-0004-1
-1801-1A	-0580-1	-0115-1
-1801-1B	-07161-1	-0115-6
-1801-5A1	-07162-1	-0503-1
-1801-5A2	-07163-1	-0503-5F
-1801-5A3	-07187-1	108D
-1801-5B1	-07188-1	-0004-1
-1801-5B2	-07203-1	108E
-1801-5C	-07298-1	-0032-5F
-1801-5D	-07299-1	-0515-5F
-1801-5F	-07336-5F	-0531-1
-1801-5G	-07392-1	-0531-5F
-1801-12	-07399-1	
101S	-0827-1	
-0112-1	-09125-1	
-0301-1	-1130-1	
	-1141-1	
	-1142-1	
	-1143-1	
	-1144-1	
	-1423-1	
	105C	
	-0316-1	
	-05106-1	
	-0595-1	
	105D	
	-1800-16A	
	-1802-1	
	-1803-1	
	-1804-1	
Aero-Engines (Including AAPUs and Propellers)		Aircraft Assisted - Escape Systems
102C		109B
-1402-6A		-0200-1
		-0200-5F
		109S
		-0200-1
		109T
		-0200-1
Aero-Engine Equipment		Armament (Excluding Guided Weapons - see Group 118)
103D	Aircraft Fuel, Oil and Water Systems	110N
-0216-167	106B	-0313-1
	-1410-1	
	106C	
	-0125-1	
	-0808-1	
Aircraft Landing Gear		Instrument and Photographic Equipment
104F	Aircraft Environment Control Equipment	112B
-1026-1	107B	-0302-1
-1026-5F	-0515-5F	-0302-6
104J	-0515-16	-0303-1
-1021-1	-0905-16AD	-0304-1
-1021-5F	-0939-16	-0304-6
	-1086-1	-0334-1
	107D	-0348-1
	-1002-1	-0349-1
	107E	-0903-1
	-0116-1	-0903-6
		112G
		-0208-16
		-0582-1
		-0930-1
		-1031-2
		-1111-13A
		-1136-1
Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls		
105B		
-0316-16		
-0366-1		
-0383-5F		
-0459-1		
-0460-1		
-0470-1		

AP.113
AL.93

GNAT - cont

**Instrument and Photographic
Equipment-cont**

- 112G-cont
- 1172-1
- 112T
- 01225-1
- 01226-1
- 01626-1

Airborne Electrical Equipment

- 113D
- 0741-16
- 0749-1
- 0758-1
- 1109-1
- 1116-1
- 1307-6
- 1378-1
- 1378-6
- 1613-1
- 113E
- 0126-16
- 113F
- 0211-1
- 0622-1
- 0654-16

Airborne Radar Equipment

- 114J
- 1200-2
- 1200-3ACD
- 1200-16

**Radio and Television (and
Associated Special-to-Type
Test Equipment)**

- 116B
- 0408-3ACD

**Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations**

- 120B
- 0103-1

HARRIER GR3

Aircraft

101A
-0600-6

101B
-0600-5A1
-0600-5A2
-0600-5A3
-0600-5A6
-0600-5B1
-0600-5C1
-0600-5D
-0600-5F
-0600-5G
-0600-5M
-0600-5W
-0600-6A
-0601-1

-0601-1A)
-0603-1A)

-0601-1B)
-0603-1B)

-0601-1C)
-0603-1C)

-0601-1D1)
-0603-1D1)

-0601-1D2)
-0603-1D2)

-0601-1E)
-0603-1E)

-0601-1F)
-0603-1F)

-0601-1G)
-0603-1G)

-0601-2)
-0603-2)

-0601-3A)
-0603-3A)
-Bks 1 & 2

-0601-3B)
-0603-3B)

-0601-10)
-0603-10)

-0601-12)
-0603-12)

-0601-14A)
-0602-14A)
-0603-14A)
-0604-14A)

-0601-15A)
-0602-15A)
-0603-15A)
-0604-15A)

101B-cont
-0601-15B)
-0602-15B)
-0603-15B)
-0604-15B)

101S
-0127-1

101X
†-0600-1B

Aero-Engines (including AAPUs
and Propellers)

102C
†-1001-3A
-1002-3A
-1003-1
-1003-2
-1003-3A
-1003-5F
-1003-7

Aero Engine Equipment

103C
-0105-13A
-0202-2
-0202-13A

103D
-0302-2
-0302-16A
-0304-1

103E
-0107-1

Aircraft Landing Gear

104B
-0101-13A6C

104C
-0101-13A6C
-0102-13A

104F
-1018-13A
-1023-5F
-1023-13A

104G
-1015-5F
-1015-13A6
-1016-13A
-1019-5F
-1019-13A

104H
-1001-1

104J
-1013-13A

104J-cont
-1015-5F
-1015-123A

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B
-0105-13A
-0205-13A
-0319-13A
-0320-5F
-0320-13A
-0321-13A6C
-0323-13A6C
-0324-13A6C
-0325-13A6C
-0423-13A
-0424-13A
-0425-13A6C
-0426-13A
-0429-13A
-0528-13A
-0529-13A
-0530-13A6C
-0531-13A
-0538-13A
-0555-13A
-0640-13A
-0642-13A6
-0643-13A
-0644-13A
-0645-13A
-0646-13A
-0648-13A
-0810-13A
-0811-13A
-0812-13A6C
-0814-13A
-0815-13A
-0816-13A
-0937-13A6C
-0958-13A
-0959-13A
-0960-13A6C
-0961-13A6C
-0963-13A
-0964-13A
-0965-5F
-0965-13A6C
-1004-13A
-1111-13A
-1112-13A
-1113-13A
-1114-13A
-1117-1
-1123-13A
-1124-13A
-1125-13A
-1411-13A
-1521-6
-07129-13A
-07130-13A
-07131-13A
-07132-13A

† Not for Harrier Mk 50

AP.113
AL.93

HARRIER GR3—cont

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls—cont

105B—cont

-07133-13A
 -07135-13A
 -07136-13A
 -07137-13A
 -07138-13A
 -07139-13A
 -07140-13A
 -07141-13A
 -07142-13A
 -07143-13A
 -07144-13A6C
 -07145-13A
 -07147-13A6C
 -07148-13A
 -07149-13A
 -07150-13A
 -07151-13A
 -07152-13A
 -07153-13A6C
 -07156-13A6C
 -07164-13A6
 -07165-13A
 †-07183-13A
 -07184-13A

105C

-0105-13A
 -0106-13A
 -0110-13A

105D

-0430-123A
 -0552-13A
 -0554-13A
 -0555-13A6C
 -0560-13A
 -0561-13A
 -0578-5F
 -1006-13A
 -1901-13A
 -0601-13A
 -0602-13A
 -0603-13A
 -0604-113A
 -0605-13A
 -0606-13A

105E

-01113-13A
 -01119-13A
 -0196-13A
 -0197-13A
 -0198-13A

Aircraft Fuel, Oil and Water
Systems

106B

-0303-16A
 -0306-5F
 -0306-13A

106C

-0112-1
 -0113-13A
 -0120-13A
 -0205-1
 -0207-13A
 -0310-13A
 -0311-13A
 -0503-13A
 -0805-13A

106D

-0906-13A
 -1501-1
 -1601-13A6
 -1802-13A6
 -4302-13A6C
 -4400-13A
 -4401-13A
 -4402-13A
 -4403-13A

106J

-0101-13A
 -0201-13A
 -0501-13A
 -0601-3A6
 -0602-6

Aircraft Environment Control
Equipment

107B

-0129-5F
 -0129-13A
 -0138-5F
 -0138-13A
 -0140-5F
 -0140-13A
 -0214-1
 -0214-6
 -0216-1
 -0217-16
 -0227-1
 -0235-13A
 -0518-5F
 -0518-13A
 -0520-13A
 -0600-1C6
 -0622-1
 -0905-123A6AD
 -0939-13A
 -0964-13A
 -0965-13A
 -0966-13A
 -0971-13A
 -0977-13A
 -0986-13A
 -0992-13A
 -1047-13A
 -1048-13A
 -1049-13A
 -1050-13A
 -1051-13A
 -1052-13A
 -1053-13A
 -1054-13A
 -1055-13A
 †-1066-13A

107B—cont

-1110-13A
 -1401-13A
 -1406-13A6
 -1413-13A6

107C

-0405-13A

107D

-0106-1
 -0205-12
 -0205-5F
 -0301-1
 -0324-1
 -0402-1
 -0500A-1
 -0502-1
 -0502-2
 -0505-2
 -0802-1
 -1001-1

107E

-0102-1
 -0110-1
 -0301-1
 -0400-1A
 -0400-1B

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108B

-0136-1

108C

-0131-5F

108D

-0102-1
 -0102-5F

108E

-0002-1
 -0534-1
 -0534-5F
 -0551-12

108F

-0103-1
 -0103-5F(R)
 -0103-6
 -0202-5F
 -0401-5F
 -0604-5F
 -0604-6
 -0809-5F
 -0905-5F
 -1101-1
 -1101-5F

Aircraft Assisted — Escape
Systems

109B

-0136-1
 -0136-3A
 -0136-5F

† Not for Harrier Mk 50

HARRIER GR3-cont

Aircraft Assisted-Escape
Systems-cont

- 109C
 - 0104-1
 - 0104-5F
- 109D
 - 0203-1
 - 0203-5F
- 109E
 - 0103-1
 - 0103-5F
- 109F
 - 0201-1
 - 0204-3A
- 109G
 - 0102-1
 - 0701-1
 - 0701-5F
- 109T
 - 0100-1

Armament(Excluding Guided
Weapons - see Group 118)

- 110G
 - 0113-15F
 - 0310-125F
 - 0401-1
 - †-0505-125NQ
 - †-0506-125FNQ
 - †-0602-1
- 110H
 - 0114-12
 - 0126-125F
 - 0129-12
 - 0132-12
- 110J
 - 0104-125F6
 - 0203-15F
- 110L
 - 0201-1
 - 0401-1
 - 0501-125F
- 110N
 - 0300-1
 - †-0303-1
 - †-0304-12
 - 0305-1
 - 0307-1
 - 0308-1
 - 0310-1
 - 0311-1
 - 0402-12
 - 0403-12
- 110T
 - 0809-1
 - 0819-12

Instrument and Photographic
Equipment

- 112B
 - 0200-1

† Not for Harrier Mk 50

Instrument and Photographic
Equipment-cont

- 112B-cont
 - 0201-13A
 - 0309-13A6
 - †-0324-1
- 112C
 - 1200-10
 - 1200-16
 - 1201-2
- 112G
 - 0102-1
 - 0132-1
 - 0203-1
 - 0203-6
 - 0220-16
 - 0221-1
 - 0305-1
 - 0320-16
 - 0321-16
 - 0400-1
 - 0501-1
 - 0508-1
 - 0521-1
 - 0533-1
 - 0555-1
 - 0602-1
 - 0614-1
 - 0617-1
 - 0619-1
 - 0620-1
 - 0701-1
 - 0701-6
 - 0753-1
 - 0753-2
 - 0754-13A6
 - 0815-2
 - 0922-16
 - 1008-16
 - 1022-1
 - 1026-16
 - 1101-16
 - 1110-1
 - 1111-13A
 - 1112-16
 - 1122-13A6
 - 1141-13A
 - 1150-1
 - 1151-16
 - 1155-1
 - 1167-1
 - 1174-16
 - 1203-13A6
 - 1209-13A6
- 112J
 - 0100-2
 - 0101-10
 - 0101-16
 - 0102-10
 - 0102-16
 - 0103-10
 - 0103-16
 - 0104-10
 - 0104-16
 - 0110-10
 - 0110-16
 - 0111-10
 - 0111-16
 - 0112-16
 - 0113-10
 - 0113-16

112J-cont

- 0114-10
- 0114-16
- 0115-10
- †-0115-16
- 0120-10
- 0120-16
- 0121-2
- 0121-16
- 0122-16
- 0123-1
- 0124-1
- 0125-1
- 0126-1
- 0130-10
- 0130-16
- 0132-16
- 0133-1
- 0134-16
- 0135-1
- 0136-1
- 0138-16
- †-0148-1
- †-0149-1
- 0150-1
- 0151-1
- 112P
 - †-0208-1
 - 0402-1
 - 0402-2
- 112R
 - 0201-1
 - 0201-2
- 112T
 - 01244-1
 - 01255-1
 - 01297-1
 - 01300-2
 - 01301-1
 - 01302-1
 - 01303-1
 - 01304-1
 - 01305-1
 - 01306-1
 - 01307-1
 - 01308-1
 - 01309-1
 - 01310-1
 - 01311-1
 - 01312-1
 - 01313-1
 - 01314-1
 - 01315-1
 - 01316-1
 - 01317-1
 - 01318-1
 - 01319-1
 - 01319-2
 - 01320-1
 - 01321-1
 - 01340-1
 - 01340-2
 - 01350-1
 - 01351-1
 - 01352-1
 - 01353-1
 - 01356-1
 - 01360-1
 - 01361-1
 - 01362-1
 - 01363-1

AP.113
AL.93

HARRIER GR3-cont

Instrument and Photographic
Equipment - cont

112T-cont

-01374-1
-01378-1
-01379-1
-01380-1
-01466-1
-01585-12
-01605-1
-01608-1
-01609-1
-01693-1
-01694-1
-01695-1
-01696-1

Airborne Electrical Equipment

113B

-0119-2
-0119-6
-0119-13A
-0121-1
-0135-1
-0138-13A6

113C

-0202-13A
-0208-1

113D

-0322-16
-0424-1
-0431-1
-0432-1
-0701-13A6
-07138-6
-0783-1
-0783-6
-0784-1
-0784-2
-0785-1
-0785-6
-0786-1
-0786-6
-0790-2
-0790-6
†-0791-13A
-0791-2
-0901-16
-0905-13A
-0905-6
-0913-1
-1102-1
-1108-1
-1108-1
-1115-1
-1116-1
-1117-1
-1123-1
-1123-1
-1124-1
-1125-1
-1129-1
-1130-1
-1136-1
-1201-1
-1206-13A
-1209-1

113D-cont

-1312-1
-1396-13A
-1399-1
-1417-1
-1425-1
-1437-13A6
-1604-2
-1604-13A
-1836-1
-1838-1
-2003-1
-07120-1
-07120-6
-07138-1
-07140-13A6
-13100-13A
-13101-13A
-13102-1
-13102-6
-13105-1
-13107-1

113E

-0152-13A
-0152-6
-0155-13A
-0204-126
-0240-1
-0240-6
-0245-6
-0245-13A
-0252-1
-0252-2
-0252-6
-0256-1
-0256-6
-0319-13A6
-0458-1
-0458-6
-0460-3A6
-0525-1
-0525-6
-0532-13A6
-03118-1
-03136-6
-03136-13A
-03137-6
-03137-13A
-03139-13A
-03139-6
-03141-1
-03141-6
-03172-1
-03172-6

113F

-0101-16
-0208-13A
-0208-6
-0235-1
-0236-1
-0422-13A
-0422-6
-0423-13A6
-0604-1
-0608-13A6
-0615-1
-0618-1
-0627-13A
-0635-1
-0640-1
-0641-1

113F-cont

-0644-13A
-0644-6
-0645-1
-0647-1
-0668-1
-0701-1
-0702-1
-0702-6
-1006-1
-1201-6
-1201-13A

113G

-0116-1
-0116-2
-0116-6
-0138-1
-0146-1
-0201-1
-0201-6

113L

-0115-1
-0115-6
-0117-1
-0117-6
-0124-13A6
-0601-1

Airborne Radar Equipment

114D

-0700-1

114J

-0101-2
-0101-3ACD
-0101-4F1
-0101-16
-0103-13D
-0103-2

114R

-0202-2A
-0202-2C

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

-0215-2
-0314-1A
-0314-1B
-0314-2
-0314-3A
-0314-6

116D

-0105-1
-0105-4F
†-0106-1
-0107-1
-0107-2
-0107-3ACD

† Not for Harrier Mk 50

HARRIER GR3--cont

Radio and Television (and
Associated Special-to-Type
Test Equipment)--cont

116D--cont

-0107-6
-0116-1
-0116-3ACD
-0116-4F
-0121-1A
-0121-2
-0133-1A
-0133-1B3D
-0133-2
-0133-6A
-0133-6B
-0135-1
-0135-3ACD
-0135-6
-1710-1

116L

-0113-2
-0113-16

116N

-0104-2
-0104-3ACD
-0104-16
-0301-1

Radio and Radar General
Test Equipment

117M

-0101-1
-0104-1
-0105-1
-0201-1

Aircraft Ground Servicing
Information and General
Engineering Equipment

119B

-0302-16

119C

-0401-16

119F

-0526-5F
-0529-5F
-0529-16
-0534-1
-1511-16
†-1704-16A
-2710-1
-2713-16
-3202-13A

119K

-0613-16A

119Q

-0200-126

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120B

-0103-1

120F

-0404-1
-0404-2

120G

-0102-15F
-0113-1
-0131-1
-0132-1
-0140-1
-0142-1
-0147-1
-0201-1
-0707-1
-0707-2
-0802-15F

120M

-0601-1

120N

-0121-1
-0121-2
-0124-1
-0125-1
-0138-2

† Not for Harrier Mk 50

HARRIER Mks TMK 4

Aircraft		
101B		
-0600		
-5G		
-0602		
-1A		
-0604		
-0602		
-1B		
-0604		
-0602		
-1C		
-0604		
-0602		
-1D1		
-0604		
-0602		
-1E		
-0604		
-0602		
-2		
-0604		
-0602		
-10		
-0604		
-0602		
-12		
-0604		
Aero-Engines (including AAPPs and Propellers)		
102C		
-1003-2		
-1003-5F		
103C		
-0202-2		
103E		
-0107-1		
Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls		
105B		
-1123-13A		
-1124-13A		
-1125-13A		
105C		
-0106-13A		
-0110-13A		
105D		
-0601-13A		
-0603-13A		
-0605-13A		
-0606-13A		
105E		
-01119-13A		
Aircraft Environment Control Equipment		
107B		
-0140-5F		
-0140-13A		
-0518-5F		
-0520-13A		
-0986-13A		
-0992-13A		
107D		
-0324-1		
Parachutes, and Personnel Safety and Survival Equipment (Airborne)		
108E		
-0035-126		
-0534-1		
108F		
-0103-5F		
-0809-12		
-0809-5F		
Aircraft Assisted - Escape Systems		
109B		
-0136-1		
109F		
-0204-13A		
Armament (excluding Guided Weapons - see Group 118)		
110G		
-0113-15F		
110H		
-0126-125F		
-0129-12		
-0132-12		
110J		
-0203-15F		
110N		
-0630-5F		
-0630-13A		
Instrument and Photographic Equipment		
112G		
-0113-2		
-0132-1		
112J		
-0101-10		
-0101-16		
-0102-16		
-0104-10		
-0104-16		
-0110-16		
-0113-16		
-0123-2		
-0125-1		
-0148-1		
-0149-1		
112T		
-01301-1		
-01303-1		
-01306-1		
-01307-1		
-01308-1		
-01309-1		
-01313-1		
-01314-1		
-01315-1		
-01317-1		
-01318-1		
-01319-1		
-01320-1		
-01353-1		
-01357-1		
-01360-1		
-01362-1		
-01374-1		
-01379-1		
-01695-1		
-01695-2		
-01696-1		
Airborne Electrical Equipment		
113B		
-0135-1		
-0135-6		
113D		
-07138-1		
-07138-6		
-1425-1		
-1604-2		
113E		
-0135-16A		
-0152-6		
-0155-6		
-0256-1		
-0256-6		

Airborne Electrical Equipment—cont

113E—cont

- 03137-6
- 03141-6
- 0423-13A6

113F

- 0644-13A
- 0668-1

113G

- 0201-1
- 0201-6
- 0146-1

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116L

- 0603-1

116N

- 0104-3ACD

116T

- 0108-1
- 0301-1
- 0304-1
- 1111-1B
- 1114-1
- 1201-1
- 1401-1

Radio and Radar General
Test Equipment

117E

- 0802-1

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F

- 2713-16

HERCULES

Aircraft

101B

-0701-1A
-0701-1B
-0701-1C
-0701-1D
-0701-1E
-0701-1F
-0701-1G
-0701-1H
-0701-1J
-0701-1K
-0701-1L
-0701-1M
-0701-2
-0701-3A
-0701-3B
-0701-3C
-0701-4A3
-0701-4B1-1
-0701-4B1
-0701-4B2
-0701-4B1B
-0701-4C3
-0701-4C4
-0701-4D1
-0701-4D2
-0701-4E
-0701-4G
-0701-11A
-0701-11C
-0701-14
-0701-15
-0701-16A
-0701-16B
-0702-1
(Covers 1 to 3)

101S

-0103-1

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105E

-0402-2
-0402-5F
-0402-16
-0501-5F
-0502-5F
-0503-5F
-0504-5F
-0505-5F
-0506-5F
-0507-5F
-0601-16
-0602-5F
-0602-16

Aircraft Environment Control
Equipment

107D

-0903-5F
-0903-16

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108B

-0307-1

108C

-0420-1
-0425-1

108E

-0424-1

108G

-0101-16

Armament

110G

-0105-13A5F

110K

-0801-13A5F

Instrument and Photographic
Equipment

112C

-0802-1
-2001-1

112G

-0806-1

112R

-0201-1

Airborne Electrical Equipment

113D

-0309-16

113E

-03164-1
-03164-6

113L

-0211-1

Airborne Radar Equipment

114E

-0200-4F

114F

-0400-16

114J

-1400-2

114S

-0102-16

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

-0304-602
-0304-603
-0304-604
-0304-605
-0304-606
-0304-608
-0304-609
-0304-610
-0304-611
-0304-612
-0304-613
-0312-1
-0312-3ACD
-0610-1
-0610-2
-0610-3CD
-0610-617
-0610-619
-0610-620
-0610-622
-0610-623
-0610-625
-0610-626

116D

-0105-1
-1103-2
-1103-3ACD
-1103-16

116M

-0355-13A6

116N

-0406-3ACD

116Z

-0402-3ACD
-0418-1

Aircraft Ground Servicing
Engineering Equipment
Information and General

119H

-0801-16
-0802-16

Aircraft

101B
-1301-1
-1301-12

101S
-0114-1

101T
-0001-1

Aero-Engine Equipment

103C
-0111-16

103D
-0208-16

Aircraft Landing Gear

104F
-1031-1
-1031-5F

104J
-1048-1

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B
-0421-16
-0738-16
-07238-5F
-07257-5F
-0988-16C
-1121-5F
-1122-5F
-09100-5F

105C
-0106-13A
-0109-1
-0554-13A
-05109-1
-05130-1
-05135-1
-05163-1

105D
-1301-5F
-1301-16C
-1302-1
-1302-5F
-1302-6
-1303-1
-1303-5F
-1303-6
-1304-1
-1304-5F

105D-cont

-1304-6
-1305-5F
-1306-5F
-1307-5F
-1309-5F
-1311-5F
-1314-5F

Aircraft Fuel, Oil and Water
Systems

106B
-0200-1C6
-0215-16

106C
-0128-1
-0135-1
-0802-16C

106D
-0131-1

Aircraft Environment Control
Equipment

107B
-0207-1
-0227-1
-0522-1
-0905-123A6AD
-1109-16
-1111-16

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108B
-0117-1

108C
-0123-1
-0123-5F
-0128-5F5
-0507-126

108E
-0505-5F
-0510-1
-0510-5F
-0543-1

Aircraft Assisted - Escape
Systems

109B
-0111-1
-0111-5F
-0117-1

109C
-0205-1
-0206-5F

109F
-0104-1
-0104-5F
-0105-5F

Armament (Excluding Guided
Weapons - See Group 118)

110G
-0330-125F
-0505-125NQ
-0506-125FNQ

Instrument and Photographic
Equipment

112B
-0303-6
-0304-1

112E
-0310-2

112F
-0006-6

112G
-0927-1
-1022-1
-1023-1
-1031-2
-1111-13A
-1230-1
-1233-1

112P
-0403-1

112T
-01207-1
-01208-1
-01215-1
-01220-1
-01222-1

AP.113
AL.93

HUNTER Mk 6—cont

Airborne Electrical Equipment

113B
-0222-6

113C
-0203-1
-07166-1

113D
-0747-1
-07178-1
-0802-16
-0903-1
-1007-1
-1109-1
-1329-16
-1379-2
-1404-16
-1609-1
-13148-16

113E
-0215-16
-0234-16
-0270-16
-0271-16
-0423-6
-0445-1

113F
-0405-1
-0411-1
-0681-1

113L
-0118-1

Electrical Equipment for
Aircraft Ground Servicing and
Aeronautical Ground
Installations

120G
-0701-1

HUNTER Mk 7 AND 7A

Aircraft	105D—cont	109C
101B	-1303-1	-0205-1
-1302-1	-1303-5F	109F
-1302-12	-1303-6	-0104-5F
101T	-1304-1	-0105-5F
-0001-1	-1304-6	
	-1309-5F	
	-1311-5F	
	-1314-5F	
		Armament (Excluding Guided Weapons — See Group 118)
Aero-Engines (including AAPUs and Propellers)	Aircraft Fuel, Oil and Water	110G
102C	106B	-0330-125F
-1516-2	-0200-1C6	-0505-125NQ
	-0215-16	-0506-125NQ
	106C	110J
	-0128-1	-0104-125F6
	-0135-1	
	-0802-16C	
Aero—Engine Equipment	106D	
103C	-0131-1	
-0111-16		Instrument and Photographic Equipment
103D		112B
-0203-3A		-0303-1
-0203-16		-0303-6
		-0304-1
		-0304-6
		112E
		-0310-2
Aircraft Landing Gear	Aircraft Environment Control Equipment	112G
104F	107B	-0927-1
-1031-1	-0207-1	-1022-1
	-0227-1	-1023-1
	-0522-1	-1111-13A
	-0905-123A6AD	-1230-1
	-1109-16	-1233-1
	-1111-16	112P
		-0403-1
		112T
		-01207-1
		-01208-1
		-01212-1
		-01213-1
		-01214-1
		-01215-1
		-01216-1
		-01217-1
		-01218-1
		-01223-1
		-01224-1
Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls	Parachutes and Personnel Safety and Survival Equipment (Airborne)	
105B	108B	
-0421-16	-0117-1	
-0738-16	108C	
-07238-5F	-0123-1	
-07257-5F	-0507-126	
-0988-16C	108F	
-1121-5F	-0902-12	
-07128-1		
105C		
-0106-13A		
-0554-13A		
-05109-1		
-05130-1		
-05135-1		
-05163-1		
105D	Aircraft Assisted — Escape Systems	
-1301-5F	109B	
-1301-16C	-0131-1	
-1302-1	-0131-5F	
-1302-5F		
-1302-6		
		Airborne Electrical Equipment
		113B
		-0212-13A6
		113C
		-1302-1

AP 113
AL 93

HUNTER Mk 7 AND 7A—cont

Airborne Electrical Equipment—cont

113D

- 0747-1
- 07187
- 0802-16
- 0903-1
- 1109-1
- 1329-16
- 1609-1
- 13148-13A6

113E

- 0171-1
- 0180-16
- 0182-16
- 0234-16
- 0445-1

Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations

120G

- 0701-1

HUNTER Mk 9

Aircraft	106C	Armament (Excluding Guided Weapons - See Group 118)
101B	-0128-1	110G
-1307-1	-0135-1	-0505-125NQ
-1307-12	-0802-16C	-0506-125FNQ
101T	106D	
-0001-1	-0131-1	
	-1501-1	
Aero-Engine Equipment	Aircraft Environment Control Equipment	Instrument and Photographic Equipment
103D	107B	112B
-0208-16	-0207-1	-0303-6
	-0227-1	-0304-1
	-0522-1	112E
	-0905-16AD	-0310-2
	-0965-13A	112F
	-1109-16	-0006-6
	-1111-16	112G
Aircraft Landing Gear	107E	-0927-1
104F	-0303-1	-1022-1
-1031-1		-1023-1
		-1111-13A
		-1230-1
		-1233-1
		112P
		-0403-1
		112T
		-01207-1
		-01208-1
		-01215-1
Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls	Parachutes, and Personnel Safety and Survival Equipment (Airborne)	
105B	108B	
-0421-16	-0117-1	
-0738-16	108C	
-07257-5F	-0123-5F	
-0988-16C	-0507-126	
-1121-5F	108E	
-09100-5F	-0505-5F	
105C	108F	
-0106-13A	-0902-12	
-0554-13A		
-05130-1		
-05163-1		
105D	Aircraft Assisted - Escape Systems	Airborne Radar Equipment
-1301-5F	109B	113B
-1301-16C	-0111-1	-0222-6
-1302-1	-0111-5F	113C
-1302-5F	-0117-1	-0203-1
-1302-6	109C	113D
-1303-1	-0205-1	-0747-1
-1303-5F	-0206-5F	-0751-1
-1303-6	109F	-0802-16
-1304-1	-0104-1	-0903-1
-1304-6	-0104-5F	-1007-16
	-0105-5F	-1109-1
		-1329-16
		-1404-16
		-1609-1
		113E
		-0171-1
		-0182-16
		-0215-16
		-0234-16
		-0423-6
		-0445-1
		113F
		-0405-13A
		-0411-1
		113L
		-0118-1
Aircraft Fuel, Oil and Water Systems		
106B		
-0200-1C6		
-0215-16		

AP.113
AL.93

HUNTER Mk 9—cont.

Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations

120G
—0701—1

JET PROVOST

Aircraft

101B
-2300-6
-2300-13
-2303-1
-2304-12
-2305-2
-2305-12

101S
-0117-1

Aero-Engines (Including AAPUs
and Propellers)

102C
-0803-1)
-0806-1)

-0803-7)
-0806-7)

-0803-D4
-0804-1

Aero-Engine Equipment

103C
-0109-16

Aircraft Landing Gear

104C
-2301-5F

104F
-1024-1
-1024-5F

104G
-1014-5F
-1014-16

104J
-1009-1
-1009-5F

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B
-0206-1
-0335-1
-0436-13A

105B-cont

-0553-1
-0770-1
-06106-1
-07189-1
-1314-1

105C

-0306-16A
-0311-1
-0324-1
-0542-16A

Aircraft Fuel, Oil and Water
Systems

106B
-0203-16

106D
-0801-1

106H
-0200-186
-0206-16
-0602-16

Aircraft Environment Control
Equipment

107B
-0232-1
-0234-1
-0236-1
-0240-13A
-0521-5F
-0521-123A
-0982-1
-0983-1
-0984-13A
-0985-13A
-1062-1
-1110-13A
-1115-13A

107C
-0222-1

107D
-0212-5F

107E
-0116-1

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108B
-0133-1A

108E

-0510-1
-0510-5F
-0536-1
-0536-5F

Aircraft Assisted - Escape
Systems

109B
-0133-1
-0133-D6
-0133-5F

109F
-0107-1
-0107-5F
-0116-1
-0116-5F

Instrument and Photographic
Equipment

112G
-1022-1
-1111-13A
-1191-1

Airborne Electrical Equipment

113B
-0208-1

113D
-0423-16
-0428-1
-0442-1
-0809-1
-0903-1
-1378-1
-1378-6
-1617-1
-07106-1
-07171-1
-13112-1
-13117-1
-13131-1

113E
-0239-1
-0251-1
-0251-6
-0405-6
-0407-6

113F
-0417-1
-0651-1
-0651-6

113L
-0106-16

AP.113
AL.93

JET PROVOST—cont.

Airborne Radar Equipment

114J

- 0102-2
- 1200-2
- 1200-3ACD
- 1200-16
- 1700-16

**Radio and Television (and
Associated Special-to-Type
Test Equipment)**

116D

- 0601-1

**Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations**

120F

- 0404-1

LIGHTNING Mk 1

Aircraft		
101B		
-1000-5A6		
101S		
-0202-1		
Aero-Engine Equipment		
103D		
-0208-16		
Aircraft Landing Gear		
104F		
-1005-1		
-1005-5F		
-1021-1		
-1021-5F		
104G		
-1023-1		
104J		
-1017-1		
-1017-5F		
Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls		
105B		
-0123-1		
-0124-126		
-0206-1		
-0329-5F		
-0396-16C		
-0397-16C		
-0477-16C		
-0556-5F		
-0585-16A		
-0593-1		
-0594-1		
-0672-5F		
-06114-1		
-07105-1		
-07105-5F		
-07248-5F		
-07304-1		
-07369-1		
-07370-1		
-07371-1		
-07372-1		
-07373-1		
-07374-1		
-07432-16C		
-07433-16C		
-07435-16C		
-0824-5F		
105B-cont		
-0837-16C		
-0907-5F		
-0907-16C		
-0925-5F		
-0925-16		
-0952-5F		
-0952-16C		
-0974-16C		
-09178-16C		
-09181-1		
-09182-1		
-1128-5F		
-1129-5F		
-1723-16C		
-2204-1		
105C		
-0112-1		
-0212-1		
-0314-1		
-0402-16		
-0434-1		
-0596-1		
-05108-1		
-05110-1		
-05131-1		
-05132-1		
-05133-1		
-05165-1		
-1201-16A		
105D		
-1001-16AC		
105B-cont		
-1016-1		
-1021-16		
-1101-16		
-1108-16		
-1110-13A		
107D		
-0208-1		
-0601-12		
-1002-12		
107B-cont		
Parachutes and Personnel Safety and Survival Equipment		
108B		
-0127-1		
108C		
-0502-1		
-0502-6		
108E		
-0411-1		
-0513-12		
-0513-5F		
108F		
-0902-12		
Aircraft Assisted - Escape Systems		
109B		
-0127-1		
-0127-5F		
109C		
-0206-5F		
-0208-13A		
109F		
-0108-1		
-0108-5F		
Armament (Excluding Guided Weapons - See Group 118)		
110J		
-0104-125F		
Aircraft Fuel, Oil and Water Systems		
106D		
-0103-1		
-0104-1		
-0106-1		
-0107-16C		
-0108-16C		
-0109-16C		
-0110-18C		
-0402-16C		
-1301-1		
-1302-1		
-4303-123A6C		
-4401-13A		
-4402-13A		
106H		
-0207-1		
Aircraft Environment Control Equipment		
107B		
-0145-1		
-0302-1		
-0606-1		
-0910-16A		

AP.113
AL.93

LIGHTNING Mk 1—cont.

Instrument and Photographic
Equipment

112B

-0303-6
-0304-6
-0305-1
-0305-6

112C

-0011-2
-1000-1
-1000-2
-1102-1
-1102-2
-1103-2

112G

-0318-2
-0552-1
-0914-1
-1118-1
-1247-2

112K

-0100-1

112P

-0219-1
-0403-1

112T

-01195-1
-01196-1
-01207-1
-01208-1
-01210-12
-01211-1
-01214-1
-01215-1
-01216-1
-01217-1
-01218-1
-01222-1
-01225-1
-01239-1

Airborne Electrical Equipment

113B

-0116-16
-0205-16

113D

-0734-1
-0735-16
-0736-1
-0738-16
-0795-13A
-07125-1
-1007-16
-1337-16
-1353-1
-1372-1
-1374-16
-1404-16
-1430-1
-1607-1
-13117-1
-13134-1

113E

-0208-16
-0482-6

113F

-0413-13A

113L

-0108-1
-0108-2
-0118-1Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

-0304-2
-0408-3ACD

116D

-0105-1

116N

-0304-3ACD

Guided — Weapon Systems

118C

-0601-1C1
-0601-1C1
-0701-1
-0703-1

118M

-0601-1AB
-0601-1C
-0602-1
-0701-1

118T

-0601-1AB
-0601-1C
-0602-1
-0603-1AB
-0603-1C
-0604-1
-0605-2
-0701-1AB
-0701-1C

118U

-0601-1
-0602-1
-0701-1Aircraft Ground Servicing
Information and General
Engineering Equipment

119K

-0701-2

119N

-0102-1

Electrical and Equipment for
Aircraft Ground Servicing and
Aeronautical Ground Installations

120B

-0201-1
-0204-1
-0206-1

120F

-0404-1

120N

-0105-16

Aircraft

101B

-1000-5A6
-1000-13
-1003-1A
-1003-1B

-1003-2)
-1006-2)

-1003-3B)
-1006-3B)

-1006-1A
-1006-1B

-1003-12)
-1006-12)

-1006-12

101S

-0102-1
-0202-1

Aircraft Landing Gear

104F

-1005-1
-1005-5F
-1021-1
-1021-5F

104G

-1023-1

104J

-1017-5F

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B

-0123-1
-0124-126
-0206-1
-0329-5F
-0397-16C
-0438-5F
-0477-16C
-0556-5F
-0585-16A
-0615-16
-0672-5F
-07105-1
-07105-5F
-07190-1
-07248-5F
-07304-1
-07432-16C
-07435-16C
-0824-5F
-0837-16C

105B-cont

-0907-16C
-0925-5F
-0952-16C
-09158-1
-09182-1
-1128-5F
-1129-5F
-2204-1

105C

-0314-1
-0402-16
-0423-1
-0549-16
-0551-16
-05110-1
-05131-1
-1201-16A

105D

-1001-16AC

Aircraft Fuel, Oil and Water
Systems

106D

-0106-16A
-0107-3A6
-0109-1
-0110-1
-0402-3A6
-1301-3A6
-1302-3A6
-4303-123A6C
-4400-13A
-4401-13A

106H

-0207-1

Aircraft Environment Control
Equipment

107B

-0145-1
-0302-1
-0606-1
-0910-16A
-0968-16
-1016-1
-1021-16
-1065-1
-1108-16
-1110-13A

107D

-0208-12
-0601-12
-1002-12

Parachutes and Personnel
Safety and Survival Equipment

108B

-0127-1

108C

-0128-1B
-0502-1
-0502-6

108E

-0411-1
-0513-12
-0513-5F

108F

-0902-12

Aircraft Assisted - Escape
Systems

109B

-0127-5F

109C

-0206-5F

109F

-0108-1
-0108-5F

Armament (excluding Guided
Weapons - See Group 118)

110J

-0104-125F6

Instrument and Photographic
Equipment

112B

-0303-1
-0303-6
-0304-1
-0304-6
-0306-1
-0306-1

112C

-0011-1
-0011-16
-1102-1
-1105-1

112G

-0208-16
-0701-1
-1023-1
-1111-13A
-1173-1

112K

-0100-1

112P

-0403-1

**Instrument and Photographic
Equipment—cont**

- 112T
 -01195-1
 -01196-1
 -01201-1
 -01204-1
 -01207-1
 -01208-1
 -01210-12
 -01212-1
 -01215-1
 -01218-1
 -01225-1
 -01228-1
 -01228-2
 -01229-1
 -01230-1
 -01239-1
 -01249-1
 -01560-1
 -01581-1
 -01588-1

Airborne Electrical Equipment

- 113B
 -0116-16
 -0204-1
 -0205-16
 113D
 -0734-1
 -0735-16
 -0736-1
 -0793-1
 -0794-1
 -0795-13A
 -07125-1
 -1007-16
 -1208-1
 -1337-16
 -1372-1
 -1404-16
 -1607-1
 -1608-1
 -13134-1
 113E
 -0110-1
 -0208-16
 -0250-1
 113F
 -0244-1
 -0415-1
 113L
 -0111-1
 -0118-1

Airborne Radar Equipment

- 114C
 -0200-1AB
 -0200-1C

114C—cont

- 0200-2
 -0200-3A
 -0200-3CD
 -0200-4F
 -0200-10
 -0300-3ACD

**Radio and Television (and
Associated Special-to-Type
Test Equipment)**

- 116B
 -0304-2
 -0408-3ACD
 116D
 -0133-1A
 -0134-1
 -0134-3ACD
 116N
 -0304-3ACD

Guided — Weapon Systems

- 118C
 -0601-1C1
 -0601-1C2
 -0701-1
 -0703-1
 118M
 -0601-1AB
 -0601-1C
 -0602-1
 -0701-1
 118T
 -0601-1AB
 -0601-1C
 -0602-1
 -0603-1AB
 -0603-1C
 -0604-1
 -0701-1AB
 -0701-1C
 118U
 -0601-1
 -0602-1
 -0701-1

**Aircraft Ground Servicing
Information and General
Engineering Equipment**

- 119F
 -0216-16A

**Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations**

- 120B
 -0204-1
 -0205-1
 -0206-1
 120F
 -0404-1
 120N
 -0105-16

AP.113
AL.93

LIGHTNING Mk 4—cont

Instrument and Photographic
Equipment—cont.

112T
-01195-1
-01196-1
-01207-1
-01208-1
-01210-1
-01215-1
-01225-1
-01239-1
-01249-1

Airborne Electrical Equipment

113B
-0110-16
-0205-16
-0734-1
-0735-16
-0736-16
-0738-16
-1337-16
-1404-16
-1607-1

113D
-0795-13A
-07172-1
-1372-1
-13134-1
-1607-2

113E
-0208-16

113F
-0413-1
-0658-6

113L
-0108-1
-0118-1

Airborne Radar Equipment

114C
-0200-1AB
-0200-1D
-0200-1L
-0200-3A
-0200-3CD
-0300-3ACD

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B
-0304-2

116B—cont

-0307-10
-0408-3ACD

116N
-0304-3ACD

116P
-0192-6

Guided — Weapon Systems

118C
-0601-1C1
-0601-1C2
-0701-1
-0703-1

118M
-0601-1AB
-0601-1C
-0602-1
-0701-1

118T
-0601-1AB
-0601-1C
-0602-1
-0603-1AB
-0603-1C
-0604-1
-0701-1AB
-0701-1C

118U
-0601-1
-0602-1
-0701-1

Electrical Equipment for Aircraft
Ground servicing and Aeronautical
Ground Installations

120B
-0201-1
-0204-1
-0206-1

120F
-0404-1

120N
-0105-16

LIGHTNING Mk 5

Aircraft

101B
 -1000-5A6
 -1000-13
 -1005-1A
 -1005-1B
 -1005-5A
 -1005-5A2
 -1005-5A3
 -1005-5A4
 -1005-5F
 -1005-5G
 -1005-10
 -1005-12

101S
 -0202-1

Aero-Engine Equipment

103D
 -0208-16

Aircraft Landing Gear

104E
 -1001-16AC
 -1027-16AC

104F
 -1005-1
 -1005-5F
 -1021-1
 -1021-5F

104J
 -1017-5F

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B
 -0123-1
 -0124-16
 -0206-1
 -0329-5F
 -0397-16C
 -0438-5F
 -0438-13A
 -0556-5F
 -0585-16A
 -0615-16
 -0672-5F
 -06114-1
 -07105-1
 -07105-5F
 -07248-5F
 -07304-1

105B-cont

-07430-16C
 -07432-16C
 -07435-16C
 -0824-5F
 -0837-16C
 -0907-16C
 -0952-16C
 -0974-16C
 -09158-1
 -09182-1
 -09178-1
 -1128-5F
 -1129-5F
 -2204-1
 -2401-1

105C

-0212-1
 -0215-16C
 -0402-16
 -0423-1
 -0551-16
 -05107-1
 -05110-1
 -05130-1
 -1201-16A

105S

-0405-16AC
 -1001-16AC

Aircraft Fuel, Oil and Water
Systems

106D

-0106-16C
 -0107-16C
 -0108-16C
 -0109-16C
 -0110-16C
 -0402-16
 -1301-1
 -1302-1
 -4303-16C
 -4400-1
 -4401-1

106H

-0207-1

Aircraft Environment Control
Equipment

107B

-0145-1
 -0606-1
 -0910-16A
 -0968-16
 -1016-1
 -1021-16
 -1065-1
 -1108-16
 -1110-13A

107D

-0208-1
 -0601-1
 -0808-1
 -0808-5F
 -1002-1

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108C

-0128-19
 -0502-1
 -0502-6
 -0505-5F

108E

-0411-1
 -0513-1
 -0513-5F

108F

-0401-1
 -0902-1

Aircraft Assisted - Escape
Systems

109C

-0206-5F

109F

-0108-5F
 -0109-1
 -0109-5F
 -0128-1

Armament (Excluding Guided
Weapons - See Group 118)

110J

-0104-125F6

Instrument and Photographic
Equipment

112B

-0303-6
 -0304-1
 -0306-1
 -0306-2
 -0306-6

LIGHTNING Mk 5—cont.

Instrument and Photographic
Equipment—cont

- 112C
 - 0011-1
 - 0011-6
 - 1102-1
 - 1105-1
- 112E
 - 0309-2
- 112G
 - 0208-16
 - 0552-1
 - 0701-1
 - 1023-1
 - 1111-13A
 - 1118-1
 - 1173-1
- 112P
 - 0403-1
- 112T
 - 01195-1
 - 01196-1
 - 01207-1
 - 01208-1
 - 01210-12
 - 01215-1
 - 01218-1
 - 01225-1
 - 01228-1
 - 01228-2
 - 01229-1
 - 01230-1
 - 01239-1
 - 01249-1
 - 01560-1

Airborne Electrical Equipment

- 113B
 - 0116-16
 - 0204-1
 - 0205-16
- 113D
 - 0734-1
 - 0735-16
 - 0736-1
 - 0738-16
 - 0793-1
 - 0794-1
 - 0795-13A
 - 07125-1
 - 1337-16
 - 1372-1
 - 1404-16
 - 1607-1
- 113E
 - 0208-16
 - 0110-1
 - 0250-1
- 113F
 - 0244-1
 - 0415-1
- 113L
 - 0118-1

Airborne Radar Equipment

- 114C
 - 0200-2
 - 0200-4F

Radio and Television (and
Associated Special-to-Type
Test Equipment)

- 116B
 - 0304-2
 - 0307-1
 - 0408-3ACD
- 116D
 - 0134-1
 - 0134-3ACD
- 116N
 - 0304-3ACD

Guided — Weapon System

- 118C
 - 0601-1C1
 - 0601-1C2
 - 0701-1
 - 0703-1
- 118M
 - 0601-1AB
 - 0601-1C
 - 0602-1
 - 0701-1
- 118T
 - 0601-1AB
 - 0601-1C
 - 0602-1
 - 0603-1AB
 - 0603-1C
 - 0604-1
 - 0701-1AB
 - 0701-1C
- 118U
 - 0601-1
 - 0602-1
 - 0701-1

Aircraft Ground Servicing
Information and General
Engineering Equipment

- 119F
 - 0216-16A

Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations

- 120B
 - 0204-1
 - 0205-1
 - 0206-1
- 120F
 - 0404-1
- 120N
 - 0105-16

LIGHTNING Mk 6

Aircraft

101B
 -1000-5A6
 -1000-13
 -1003-1A
 -1003-1B

 -1003-12)
 -1006-12)

 -1006-1A
 -1006-1B
 -1006-12
 -1006-10
 -1006-12
 -1006-15
 -1006-16

 101S
 -0202-1

Aircraft Landing Gear

104F
 -1005-1
 -1005-5F
 -1021-1
 -1021-5F

 104G
 -1023-1

 104J
 -1010-1
 -1010-5F

Aircraft Hydraulic, Pneumatic,
and Mechanical Equipment and
Powered Flying Controls

105B
 -0123-1
 -0124-126
 -0206-1
 -0329-5F
 -0397-16C
 -0438-5F
 -0556-5F
 -0672-5F
 -0824-5F
 -0837-16C
 -0907-16C
 -0952-16C
 -0974-16C
 -1128-5F
 -1129-5F
 -2204-1
 -2401-1
 -07181-1
 -07304-1
 -07430-16C
 -07432-16C

105B-cont

-07435-16C
 -09158-1
 -09178-16C
 -09182-1

105C

-0212-1
 -0402-16
 -0423-1
 -0551-16
 -05101-1
 -05110-1
 -05131-1
 -05132-1
 -05133-1
 -1201-16A

105D

-0405-16A

Aircraft Fuel, Oil and Water
Systems

106D

-0106-1
 -0107-16C
 -0108-16C
 -0109-16C
 -0110-16C
 -0402-16C
 -1301-1
 -1302-1
 -4400-13A
 -4401-13A

106H

-0207-1

Aircraft Environment Control
Equipment

107B

-0145-1
 -0302-1
 -0606-1
 -0624-1
 -0910-16A
 -0968-16
 -1016-1
 -1021-16
 -1065-1
 -1108-16
 -1110-13A

107D

-0208-12
 -0601-12
 -1002-12

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108B

-0127-1

108C

-0502-1
 -0502-6

108E

-0411-1

108F

-0902-12

Aircraft Assisted - Escape
Systems

109B

-0127-5F

109C

-0206-5F

109F

-0108-1
 -0108-5F

Armament (excluding Guided
Weapons - see Group 118)

110H

-0102-1
 -0210-1

110J

-0104-125F6
 -0301-125F
 -0301-125F

110N

-0406-12

Instrument and Photographic
Equipment

112B

-0303-6
 -0304-1
 -0306-1
 -0306-6

112C

-1102-1
 -1105-1

112E

-0309-2

112G

-0208-16
 -0552-1
 -0701-1
 -1023-1
 -1118-1
 -1173-1

AP.113
AL.93

LIGHTNING Mk 6—cont.

Instrument and Photographic
Equipment—cont

112P -0403-1
112T -01196-1
-01207-1
-01208-1
-01210-12
-01215-1
-01225-1
-01239-1
-01249-1
-01560-1
-01588-1

Airborne Electrical Equipment

113B -0116-16
-0204-1
-0205-16
113D -0734-1
-0735-16
-0736-1
-0793-1
-0794-1
-0795-13A
-1007-16
-1337-16
-1372-1
-1404-16
-1607-1
-07125-1
-13134-1
113E -0110-1
-0208-16
-0250-1
113L -0118-1

Airborne Radar Equipment

114C -0200-4F

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B -0304-2
-0408-3ACD

116D -0134-1
-0134-3ACD
116N -0304-3ACD

Guided - Weapon Equipment

118C -0601-1C1
-0601-1C2
-0701-1
-0703-1
118M -0601-1AB
-0601-1C
-0602-1
-0701-1
118T -0601-1AB
-0602-1C
-0602-1
-0603-1AB
-0603-1C
-0604-1
-0701-1AB
-0701-1C
118U -0601-1
-0602-1
-0701-1

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F -0216-16A

Electrical Equipment for Aircraft
Ground Servicing and Aeronautical
Ground Installations

120B -0204-1
-0205-1
-0206-1
120F -0404-1
120N -0105-16

NIMROD Mk 1

Aircraft		
101B		
-0500-4C1		
-0500-4A1		
-0500-4A2		
-0500-4B1B		
-0500-4C2		
-0500-4D		
-0500-4T		
-0501-1A		
-0501-1B		
-0501-1C		
-0501-1D		
-0501-1E		
-0501-1F		
-0501-1G		
-0501-1H		
-0501-2)		
-0502-2)		
-0501-3B2		
-0501-4A3		
-0501-4A6		
-0501-4M		
-0501-10 (Cover 1)		
-0501-10 (Cover 2)		
-0501-10 (Cover 3)		
-0502-6		
-0502-9		
101S		
-0113-4A1		
-0113-4A2		
-0113-4A3		
-0113-4B1		
-0113-4C		
-0208-1		
-0303-10		
-0311-1		
Aero-Engines (including AAPUs and Propellers)		
102F		
-0201-2		
Aero-Engine Equipment		
103E		
-0105-13A		
Aircraft Landing Gear		
104B		
-0501-13A		
-0502-13A		
104B-cont		
-0503-13A		
-0505-13A		
-0506-13A		
104C		
-0502-13A		
-0503-13A		
-0504-13A		
104J		
-1014-5F		
-1014-13A		
Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls		
105B		
-0107-13A		
-0108-13A		
-0109-13A		
-0204-13A6		
-0326-13A		
-0327-13A		
-0328-13A		
-0330-13A		
-0331-13A		
-0332-13A		
-0333-13A		
-0334-13A		
-0423-13A		
-0431-13A		
-0432-13A		
-0433-13A		
-0500-4C3		
-0536-1		
-0535-1		
-0543-13A		
-07171-13A		
-07154-13A		
-07159-13A		
-07175-13A		
-07177-1		
-07178-13A		
-07180-13A		
-07193-13A		
-07199-13A		
-07399-1		
-0817-1		
-0818-1		
-0819-5F		
-0966-13A		
-0967-13A		
-0973-13A		
-0975-13A		
-0976-13A		
-0977-13A		
-0978-13A		
-0979-13A		
-0983-13A		
-1006-13A		
-1115-13A		
-1415-13A		
-1416-13A		
-1418-13A		
-1525-123A		
105C		
-0421-13A		
-0424-13A		
-0426-13A		
-0428-13A		
-0563-13A		
105D		
-0502-13A		
-0503-13A		
-0504-13A		
-0505-13A		
-0506-13A		
-0507-13A		
-0508-13A		
-0509-13A		
-0510-5F		
-0510-13A		
-0511-13A		
-0512-13A		
-0513-5F		
-0513-13A		
-0514-13A		
-0515-13A		
-0516-13A		
-0517-13A		
-0518-13A		
-0519-13A		
-0520-13A		
-0521-5F		
-0521-13A		
-0522-13A		
-0523-13A		
-0524-13A		
-0525-13A		
-0526-13A		
-0527-13A		
-0528-13A		
-0529-13A		
-0530-13A		
-0532-13A		
105E		
-01101-13A		
-01167-3A		
105F		
-0102-5F)		
-0202-5F)		
105T		
-0301-1		
Aircraft Fuel, Oil and Water Systems		
106B		
-0901-13A		
-0902-13A		
-0903-13A		
-1405-13A		
-1412-13A		
-1413-13A		
-1414-13A		
-1415-13A		
106C		
-0114-13A		
-0116-1		
-0201-1		
-0202-1		
-0206-13A		

AP 113
AL 93

NIMROD Mk 1—cont

Aircraft Fuel, Oil and Water
Systems—cont

106C—cont

-0309-1
-0312-1
-0313-1
-0314-13A
-0413-13A
-0506-13A

106D

-0115-13A
-0116-13A
-0117-1
-0907-13A
-1501-1

106G

-0107-13A
-0108-13A
-0109-13A
-0110-13A
-0111-13A
-0114-13A
-0210-13A
-0406-13A
-0407-13A

Aircraft Environment Control
Equipment

107B

-0239-1
-0525-13A6
-0901-13A
-0902-13A
-0972-13A
-0973-13A
-0974-5F
-0974-13A
-0987-13A
-1022-1
-1028-13A
-1056-13A
-1058-13A
-1059-13A
-1107-13A
-5006-6
-5007-1
-5008-1
-5008-6

107C

-0234-13A
-0238-5F
-0238-13A
-0239-5F
-0239-13A

107D

-0104-1
-0105-1
-0108-12
-0206-12
-0206-5F
-0505-12
-0508-1

107E

-0101-6

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108E

-0104-5F

108F

-0103-5F(R)
-0810-5F
-0810-12
-0906-12
-0906-5F

Armament (excluding Guided
Weapons — see Group 118)

110D

-0103-5A1
-0103-5A2
-0103-5B1
-0103-5B2
-0103-5F
-0103-5J1
-0103-5J2
-0405-125F
-0410-12
-0411-125F

110E

-0305-125NQ
-0306-15NQ
-0312-15NQ

110G

-0107-125F
-0108-125F
-0109-125F
-0110-125F
-0201-15F
-0303-125F
-0312-15F
-0317-15F
-0402-123A5F
-0403-125F
-0508-125F
-0510-125F
-0607-125F

110H

-0106-12
-0107-12
-0108-12
-0209-123A5F
-0403-1
-0404-1

110M

-0102-1

Instrument and Photographic
Equipment

112B

-0102-1
-0103-1
-0104-1A6

112B—cont

-0104-1B
-0104-1C
-0105-16
-0325-2
-0336-16
-0337-16
-0338-16
-0345-1A6
-0345-1B
-0345-1C
-0346-1
-0347-1B
-0347-1C
-0347-16
-0503-1
-0604-10
-0605-10
-0606-16
-0607-16
-0711-10
-0711-16
-0712-1B
-0712-1C
-0712-2
-0712-10
-0713-1B
-0713-1C
-0713-10
-0714-1A6
-0715-2
-0715-10
-0715-16
-0716-1C
-0716-2
-0716-10
-0718-16
-0908-1B
-0908-1C

112C

-0802-6
-1701-1
-1713-16
-1714-16
-1715-16
-1716-1B
-1716-1C
-1717-1A6
-1717-1B
-1717-1C
-1718-1B
-1718-1C
-1719-16
-1720-16
-1721-16
-1722-16
-1723-1A6
-1723-1B
-1723-1C
-1724-1A6
-1724-1B
-1724-1C
-1725-1B
-1725-1C
-1726-1A6
-1726-1B
-1726-1C
-1727-1A6
-1728-16
-1729-1A6
-1729-1B

NIMROD Mk 1—cont

Instrument and Photographic
Equipment—cont

112C—cont	112J—cont	112T—cont
-1729-1C	-0305-10	-01441-1
-1730-16	-0306-10	-01442-1
-1731-16	-0306-16	-01444-1
-1732-2	-0307-2	-01449-1
-1732-16	-0307-10	-01538-1
-1733-2	-0307-16	-01539-1
-1733-16	-0308-2	-01539-2
-1734-1B	-0308-10	-01553-1
-1734-1C	-0308-16	-01554-1
-1735-1A6	-0309-10	-01556-1
-1735-1B	-0309-16	-01557-1
-1735-1C	-0311-1	-01559-1
-1736-1	-0315-1A6	-01562-2
-1737-1	-0315-1B	-01563-1
-1738-1	-0315-1C	-01566-1
-1741-16	-0315-2	-01567-1
112F	-0316-1A6	-01567-2
-0101-1	-0316-1B	-01568-1
-0102-1	-0316-1C	-01568-2
-0103-16	-0317-1A6	-01575-13A6
-0105-16	-0317-1C	-01587-1
-0106-2	-0318-1A6	-01601-1
-0106-10	-0318-1B	-01606-1
-0106-16	-0318-1C	-01613-1
-0108-16	-0319-16	-01636-1
112G	-0320-1B	-01637-1
-0128-1	-0320-1C	-0231-1A
-0145-1	-0321-16	-0231-1D
-0208-16	-0322-1A6	-0231-1E
-0316-1	-0322-1B	-0231-10A
-0332-16	-0322-1C	-0231-10C
-0411-13A	-0323-1A6	-0232-16
-0412-13A	-0324-16	-0233-1
-0555-1	-0325-16	-0233-10
-0561-1	-0326-16	-0235-16
-0573-1	-0327-1	-0236-1
-0576-1	112P	-0236-10
-0577-2	-0407-1	-0238-1
-0577-16	-0408-1	-0239-1
-0614-1	-1104-1	-0240-10
-0622-1	-1104-2	-0240-16
-0623-1	-1701-16	-0241-1
-0624-1	112R	-0241-10
-0922-16	-0202-1	-0242-16
-1026-16	-0203-10	-0243-10
-1030-1	-0204-2	-0243-1
-1135-1	-0204-10	-0244-1
-1145-1	-0205-16	-0244-10
-1160-1	-0206-16	-0245-1
-1162-1	-0209-1	-0245-10
-1164-1	112T	-0246-1A
-1166-1	-01209-1	-0246-1B
-1174-16	-01400-1	-0246-10
-1222-16	-01404-1	-0247-1
-1227-1	-01405-1	-0247-10
112H	-01406-1	-0248-16
-0301-1B	-01407-1	-0249-16
-0302-10	-01413-1	-0250-1A
-0302-1A6	-01414-1	-0250-1B6
112J	-01422-1	-0250-10
-0300-1	-01427-1	-0251-16
-0300-3ACD	-01428-1	-0252-1A
-0301-16	-01429-1	-0252-1B6
-0302-2	-01430-1	-0252-10
-0302-16	-01431-1	-0253-1
-0303-16	-01434-1	-0253-10A
-0304-16	-01435-1	-0255-1
	-01438-1	-0255-10
	-01439-1	-0256-1
	-01440-1	-0257-1

AP.113
AL.93

NIMROD Mk 1—cont

Airborne Electrical Equipment

113B
-0123-1
-0123-6

113D
-0308-1
-0308-6
-0436-1
-0440-1
-0440-6
-0441-1
-07105-1
-07108-1
-07108-6
-07109-1
-07109-6
-07110-1
-07111-1
-07112-1
-07112-6
-07136-1
-07136-6
-0914-1
-0915-1
-1008-1
-1116-1
-1117-1
-1118-1
-1124-1
-1133-1
-1134-1
-13103-1
-13104-1
-13108-1
-13108-6
-13115-1
-13126-1
-13132-1
-13132-6
-13137-1
-13138-1
-13138-6
-13139-1
-13139-6
-13169-1
-1420-6

13E
-0154-1
-0154-6
-0160-16
-0203-16
-0207-6
-0227-1
-0227-6
-0230-1
-0236-1
-0236-6
-0238-1
-0243-6
-03100-6
-03116-6
-03119-6
-03120-1
-03121-1
-03121-2
-03122-1
-03122-6
-03123-1
-03123-6
-03124-6
-03125-6

113E—cont

-03132-1
-03132-6
-03133-1
-03133-6
-03134-1
-03135-1
-03135-6
-03143-6
-03144-6
-03145-6
-03148-1
-03153-1
-03153-6
-0389-13A6
-0453-6
-0459-1
-0459-6
-0526-1
-0526-6

113F
-0105-1
-0239-13A
-0240-1
-0241-1A
-0408-13A
-0420-1
-0420-6
-0639-1
-0822-1
-0823-1
-0824-1
-1004-1
-1006-1

113G
-0115-1
-0115-6
-0117-1
-0117-2
-0123-1
-0124-1
-0126-1
-0130-1
-0133-1
-0138-1
-0139-1

113L
-0114-13A6

Airborne Radar Equipment

114E
-1100-1B
-1100-2

114J
-0400-3A
-0400-3CD

114P
-0300-2
-0300-3A1(Books 1 & 2)

Radio and Television (and
Associated Special-to-Type
Test Equipment

116B
-0110-1
-0208-1
-0208-1A601
-0211-1
-0211-2
-0304-602
-0304-603
-0304-604
-0304-605
-0304-606
-0304-608
-0304-609
-0304-610
-0304-611
-0304-612
-0304-613
-0316-3ACD
-0316-6
-0318-1
-0319-16
-0442-1
-0610-1
-0610-2
-0610-3CD
-0610-617
-0610-619
-0610-620
-0610-622
-0610-623
-0610-625
-0610-626

116D
-0120-1D624
-0120-2A
-0120-3ACD
-0902-4F
-0908-16
-1702-16

116F
-0205-1B
-0205-1C
-0205-1D
-0205-1E
-0205-1F
-0205-1G
-0205-1H
-0205-1J
-0205-1K
-0205-1L3D
-0205-1M3D
-0205-1N3D
-0205-1P

116G
-0101-6)
-0102-6)
-0104-6)

-0103-1C603
-0103-1D604
-0104-3ACD
-0105-3AD
-0105-16
-0106-4F
-0201-1
-0201-6
-0202-1

NIMROD Mk 1--cont

Radio and Television (and
Associated Special-to-Type
Test Equipment--cont

116G--cont

-0202-6
-0204-1
-0204-2
-0204-6
-0205-1
-0205-2
-0205-3ACD
-0205-6
-0303-2
-0303-3ACD
-0303-10
-0303-16

116L

-0125-2
-0604-1
-0604-2
-0604-3A1CD1
-0604-3A2D2

116M

-0902-16

116N

-0103-1B
-0103-1C
-0103-1D
-0103-1E
-0103-1F
-0103-1G
-0103-1H
-0103-1J
-0103-1K
-0103-1L
-0103-1M
-0103-1N
-0103-1P
-0103-2
-0103-601
-0103-602
-0103-603
-0103-604
-0103-605
-0103-606
-0103-607
-0103-608
-0103-609
-0103-610
-0103-611

116R

-0101-1
-0101-2
-0102-2

-0102-3A2)
-0104-3A2)

-0102-3ACD)
-0104-3ACD)

-0103-2
-0104-1
-0104-2
-0201-1
-0201-2
-0302-2

Radio and Radar and
Television General Test
Equipment

117X

-0506-1

Guided-Weapon Equipment

118

-1008
-1
-1108
-1009-16
-1014
-1
-1114

118S

-0303-2)
-0305-2)

118T

-0301-2
-1003-16

118U

-0301-2

118W

-0301-2

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F

-0401-1
-0402-1
-0601-1
-1103-1
-2330-1
-2331-1

119K

-0110-16A
-0111-16A
-0115-13A
-0201-16A
-0202-1
-0901-16A
-0902-1

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120F

-0407-1
-0701-1
-1301-1

120G

-0107-1
-0116-1
-0127-1
-0128-1
-0134-1
-0135-1
-0136-1
-0137-1
-0138-1
-0703-2
-0710-2
-0710-15F
-0720-1

120N

-0128-1
-0129-1
-0130-1

SIOUX

Aircraft

101C

-0201-1
-0201-2

-0201-3A)
-0202-3A)

-0201-3B)
-0202-3B)

-0201-5A1)
-0202-5A1)

-0201-5A2)
-0202-5A2)

-0201-5A3)
-0202-5A3)

-0201-5B1)
-0202-5B1)

-0201-5C)
-0202-5C)

-0201-5F)
-0202-5F)

-0201-5M

-0201-6A)
-0202-6A)

-0201-6B)
-0202-6B)

-0201-15

-0201-10)
-0202-10)

Aero-Engines (including AAPUs
and Propellers)

102B

-0101-2
-0101-3A

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105D

-2201-1

Instrument and Photographic
Equipment

112B

-0351-16

112G

-0337-1
-1005-16

Airborne Electrical Equipment

113B

-0209-16
-0210-16
-0213-1

113D

-0761-1
-0911-16

113E

-0435-16

113F

-0218-16
-1102-1

113L

-0303-1

Airborne Radar Equipment

114F

-0400-3ACD

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116D

-0101-4F
-0113-2
-0113-3ACD
-0113-4F
-0114-3ACD

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls—cont

105B—cont

-0781-16
-0782-16
-0783-16
-0784-5F
-0784-16
-0785-5F
-0785-16
-0786-13A
-0787-16
-0788-16
-0789-16
-0790-16
-0791-16
-0792-16
-0793-16
-0806-16C
-0807-16AC
-0808-13A6
-0809-16
-0910-16C
-0911-16C
-0913-16
-0928-16
-0929-16
-0930-16
-0934-16
-0935-16AC
-0943-16
-0944-16
-1003-16
-1109-13A
-1110-16
-1306-16
-1408-16
-1409-16
-1507-16
-1509-16
-1510-16
-1511-16
-1601-16
-1707-16
-1708-16
-1709-1
-1807-16
-1808-16
-1901-16
-1902-16
-1909-1
-2001-16
-2101-16
-2402-1

105C

-0102-16D
-0202-16
-0302-13A
-0304-16
-0305-16
-0405-16
-0406-16
-0407-16
-0408-16
-0410-16
-0411-16
-0416-16
-0517-16D
-0519-16C

105C—cont

-0520-16
-0523-16
-0524-16
-0525-16
-0526-16
-0535-16
-0541-16
-0544-16
-0701-16
-1002-16

105D

-0210-16A
-0211-16A

105E

-0101-16
-0102-16
-0103-16
-0104-16
-0105-1
-0106-16A
-0107-16C
-0108-16A
-0109-16A
-0110-16
-01102-16
-01103-16
-01104-16
-0111-16
-0112-16
-0113-16
-0114-16
-0115-16
-0116-16
-0117-16
-0118-16
-0119-16
-0120-16
-0121-16
-0122-16
-0123-16
-0124-16
-0125-16
-0126-16
-0127-16
-0128-16
-0129-16
-0130-16
-0131-16
-0132-16
-0133-16
-0134-16
-0135-16
-0137-16
-0138-16
-0139-16
-0140-16
-0141-16
-0142-16
-0143-16
-0144-16
-0145-16
-0146-16
-0147-16
-0148-16
-0149-16
-0150-16
-0151-16
-0152-16
-0153-16
-0154-16

105E—cont

-0155-16
-0156-16
-0157-16
-0158-16
-0159-16
-0160-16
-0161-16
-0162-16
-0163-16
-0164-16
-0165-16
-0166-16
-0167-16
-0168-16
-0169-16
-0170-16
-0171-16
-0172-16
-0173-16
-0174-16
-0175-16
-0176-16
-0177-16
-0178-16
-0179-5F
-0179-16
-0180-16
-0181-16
-0182-16
-0183-16
-0184-16
-0186-16
-0187-16
-0188-16
-0189-16
-0190-16
-0191-16
-0192-16
-0193-1
-0194-16
-0195-16
-0201-16A
-0202-16
-0203-1
-0204-16
-0206-16
-0207-16
-0208-16
-0209-16
-0210-16
-0211-16
-0212-16
-0213-16
-0214-16
-0402-2
-0402-16
-0401-5F
-0501-5F
-0502-5F
-0503-5F
-0504-5F
-0505-5F
-0506-5F
-0507-5F

105F

-0102-5F)
-0202-5F)

-0207-5F
-0207-13A6A
-0210-5F

Aircraft Fuel, Oil and Water Systems

- 106B
 - 0602-16
 - 0801-16
 - 0802-16
 - 1005-16
 - 1006-16
 - 1201-16
 - 1301-16
 - 1302-16
- 106C
 - 0110-1
 - 0301-1
 - 0302-1
 - 0307-16
 - 0404-1
 - 0405-1
 - 0406-1
 - 0703-16
 - 1301-3A6
- 106D
 - 0206-16C
 - 0211-16
 - 0509-1
 - 0902-16C
 - 1001-1
 - 4202-16C
 - 4203-1
 - 4301-16C
 - 4400-13A
- 106G
 - 0102-16
 - 0103-16
 - 0104-16
 - 0105-16
 - 0302-16
 - 0401-16
 - 0501-1
 - 0503-5C
 - 0701-16

Aircraft Environment Control Equipment

- 107B
 - 0107-16D
 - 0109-16D
 - 0110-16D
 - 0111-16D
 - 0112-16D
 - 0113-16D
 - 0114-16D
 - 0115-16D
 - 0116-16D
 - 0119-16D
 - 0121-16D
 - 0122-16D
 - 0123-16D
 - 0124-16D
 - 0125-16D
 - 0126-16D
 - 0127-16D
 - 0130-1
 - 0132-1
 - 0209-1

107B—cont

- 0210-16A
- 0233-1
- 0407-16
- 0412-16A
- 0506-16D
- 0507-16D
- 0508-16D
- 0623-16
- 0908-16
- 0947-1
- 0948-16
- 0950-16
- 0959-1
- 0960-12
- 1008-16
- 1023-16
- 1029-16
- 1030-1
- 1034-16
- 1035-16
- 1036-16
- 1417-16
- 1423-16
- 1427-16
- 1428-1

107C

- 0101-1
- 0204-16
- 0205-16
- 0211-16
- 0213-16
- 0223-16
- 0224-16
- 0225-16
- 0226-16
- 0227-16
- 0245-1
- 0403-16

107D

- 0101-12
- 0201-1
- 0202-12
- 0203-12
- 0403-1
- 0505-12
- 0903-5F
- 0909-16

107E

- 0101-6
- 0107-1
- 0128-1

Parachutes and Personnel Safety and Survival Equipment (Airborne)

108C

- 0601-1

108E

- 0022-5F
- 0037-16
- 0423-1
- 0703-16

108F

- 0801-5F

108T

- 0402-1

Instrument and Photographic Equipment

112B

- 0307-1B
- 0307-1C
- 0307-1D
- 0307-1A6
- 0802-2
- 0904-1C
- 0904-1D

112C

- 0200-2
- 0201-1A6
- 0201-1B
- 0201-1C
- 0201-1D
- 0201-1E
- 0201-1F
- 0201-1G
- 0201-1J
- 0201-1K
- 0201-16
- 0202-16
- 0203-16
- 0204-1A6
- 0205-1A6
- 0206-16
- 0207-1A6
- 0208-1A6
- 0209-1A6
- 0210-16
- 0211-1A6
- 0212-16
- 0213-1A6
- 0214-16
- 0215-1A6
- 0216-16
- 0217-16
- 0218-1A6
- 0219-16
- 0220-16
- 0221-1A6
- 0222-16
- 0223-16
- 0224-16
- 0225-16
- 0226-16
- 0227-1A6
- 0228-16
- 0229-1A6
- 0230-1A6
- 0231-16
- 0232-16
- 0233-1A6
- 0234-16

112G

- 0106-1
- 0111-16
- 0113-1
- 0131-1
- 0131-6
- 0205-1
- 0337-1

AP.113
AL.93

VC 10 Mk 1-cont

Instrument and Photographic
Equipment-cont

112G-cont

-0518-1
-0530-1
-0612-1
-0613-1
-1010-1C
-1022-1
-1119-16
-1125-16
-1137-1
-1138-1
-1141-13A
-1143-1
-1155-1
-1209-13A6
-1215-13A

112H

-0114-1T
-0114-1U
-0114-1Y

112P

-0402-1

112R

-0201-1

112T

-0212-1
-0212-1B
-0212-1C
-0212-1D
-0213-1
-0214-1
-0215-1
-0216-1
-0217-1
-0218-1
-0219-1
-0220-1
-0221-1
-0222-1
-0223-1
-0224-1
-0226-1
-01148-1
-01173-1
-01174-1
-01175-1
-01186-1
-01209-1
-01242-16
-01245-1
-01247-1

Airborne Electrical Equipment

113B

-0107-16
-0210-16

113D

-0105-16
-0305-16
-0309-16
-0417-16
-0420-16
-0719-16

113D-cont

-0722-1
-0744-1
-0745-1
-0764-1
-0764-6
-1102-1
-1103-1
-1105-1
-1109-1
-13115-1
-1334-16
-1339-16
-1341-16
-1342-16
-1343-16
-1346-16
-1347-16
-1348-16
-1373-16
-1374-16
-1406-16
-1408-1
-1410-16
-1417-1

113E

-0103-16
-0123-16
-0126-16
-0128-1
-0128-6
-0129-16
-0129-2
-0132-1
-0133-1
-0133-6
-0206-16
-0209-13A6
-0212-16
-0221-16
-0222-16
-0224-16
-0308-16
-03109-16
-03111-16
-0323-16
-0324-16
-0325-16
-0326-16
-0327-16
-0328-16
-0329-16
-0337-16
-0338-16
-0339-16
-0340-16
-0341-16
-0347-16
-0431-16
-0432-6
-0433-6
-0527-1
-0517-6

113F

-0216-16
-0217-16
-0242-1
-0409-1
-0603-16
-0610-1
-0616-16

113F-cont

-0617-1
-0619-16
-0620-1
-0628-13A
-0628-2
-0628-6
-0633-1
-0819-16
-0827-1
-0829-1

113L

-0301-1

Airborne Radar Equipment

114E

-0200-4F
-0200-16

114F

-0100-3ACD

Radio and Television (and
Associated Special-to-Type
Test Equipment

116B

-0101-2
-0101-3ACD
-0304-2
-0407-3A1
-0407-3CD
-0610-1
-0610-2
-0610-3CD
-0610-617
-0610-619
-0610-620
-0610-622
-0610-623
-0610-625
-0610-626

116D

-0102-4F
-0105-1
-0133-1A
-1101-1
-1101-6

116M

-0333-1

116N

-0304-3ACD
-0405-16

116Z

-0402-3ACD
-0418-1

Aircraft Ground Servicing
Information and General
Engineering Equipment

119F
-2147-1

119K
-0108-16A
-0110-16A
-0111-16A

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120F
-0206-1
-0403-1
-0404-1

VICTOR Mk 1-cont

Aircraft Assisted - Escape
Systems

- 109B
 - 0123-1
 - 0123-5F
- 109C
 - 0204-1
 - 0204-5F
- 109F
 - 0113-1
 - 0113-5F

Armament (Excluding Guided
Weapons - See Group 118)

- 110G
 - 0206-125F
 - 0624-15F

Instrument and Photographic
Equipment

- 112B
 - 0331-1
 - 0703-1
 - 0704-1
 - 0705-1
 - 0706-1
 - 0707-1
 - 0708-1
 - 0709-1
 - 0710-1
 - 0810-1
 - 0811-1
 - 0811-D1

- 112C
 - 0801-1A
 - 0801-2

- 112G
 - 0106-1
 - 0516-1
 - 0553-16
 - 0574-1
 - 0725-1
 - 0919-1
 - 1022-1
 - 1101-16
 - 1102-1
 - 1120-1
 - 1121-1
 - 1124-1
 - 1127-1
 - 1134-1
 - 1141-13A
 - 1196-1
 - 1197-1

- 112T
 - 01184-1
 - 01187-1
 - 01273-1
 - 01274-1

- 112T-cont
 - 01277-1
 - 01280-1

Airborne Electrical Equipment

- 113B
 - 0131-1
- 113D
 - 0128-1
 - 0203-1
 - 0404-1
 - 0419-1
 - 0443-1
 - 07144-1
 - 07144-2
 - 07146-1
 - 07148-1
 - 07168-1
 - 07172-1
 - 07179-1
 - 0743-1
 - 09146-1
 - 0923-1
 - 0927-1
 - 0928-1
 - 1113-1
 - 1210-1
 - 1212-1
 - 1301-16
 - 13106-1
 - 1321-16
 - 1337-16
 - 1355-16
 - 1357-16
 - 1359-16
 - 1360-16
 - 1361-16
 - 1368-16
 - 1369-16
 - 1371-16
 - 1393-1
 - 13127-1
 - 1412-16

- 113E
 - 0127-16
 - 0121-1
 - 0146-1
 - 0188-1
 - 0193-1
 - 03102-1
 - 0359-16
 - 0370-1
 - 0395-1
 - 0399-16
 - 0420-6
 - 0421-6
 - 0425-6
 - 0428-6
 - 0443-6
 - 0505-1
 - 0505-3A
 - 0505-6

- 113F
 - 0208-13A
 - 0406-1
 - 0701-1
 - 0702-1

- 113G
 - 0103-1
 - 0106-1
 - 0117-2
- 113L
 - 0120-1

Airborne Radar Equipment

- 114E
 - 0300-4F

Radio and Television (and
Associated Special-to-Type
Test Equipment

- 116B
 - 0312-1
- 116D
 - 0102-1B
 - 0117-3ACD
- 116F
 - 0204-3ACD

Radio and Radar General Test
Equipment

- 117E
 - 0442-16

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

- 120E
 - 0104-1
- 120F
 - 0206-1
 - 0404-1
- 120H
 - 1001-1
- 120N
 - 0102-1
 - 0107-1
 - 0108-1

VICTOR Mk 2

Aircraft		Aircraft Hydraulic, Pneumatic, and Mechanical Equipment and Powered Flying Controls		106C	
101B	-1102-1A	105B	-0395-16C		-0109-1
	-1102-1B		-0456-1		-0130-1
	-1102-1C		-0457-1		-0708-1
	-1102-1D		-0458-1		-0804-16C
	-1102-14		-0558-1		-0806-1
	-1104-3B		-0569-1		-1101-16
	-1104-4A1		-0570-1		-1304-1
	-1104-4A2		-0572-1		-1401-1
	-1104-4B1		-06102-1	106D	-0132-1
	-1104-4B1B		-06103-1		-4204-16C
	-1104-4C1		-06105-1	106E	-1103-16
	-1104-4C2		-06117-1	106H	
	-1104-4C3		-07195-1		-0302-1
	-1104-4C4		-07207-1		-0331-1
	-1105-4C5		-07269-1	Aircraft Environment Control Equipment	
	-1104-4C6		-07283-1	107B	
	-1104-4C7		-07286-1		-0149-1
	-1104-4C8		-07287-1		-0905-123A6AD
	-1104-4F		-07288-1		-0922-5F
	-1104-10		-07339-1		-0922-16A
101S	-0116-1A		-07341-1		-0933-1
			-07355-16C		-0937-1
			-07356-1		-1010-16A
			-07396-1		-1012-16A
			-07396-5F		-1015-16
			-0825-1		-1019-16
			-09137-1		-1021-16
			-09138-1		-1027-16
			-09184-1		-1045-16A
			-09195-1		-1064-1
			-09196-1		-1074-1
			-09199-1		-1076-1
			-1821-1		-1085-1
			-1822-1		-1087-1
					-1088-1
		105C			-1091-1
			-0209-1		-1093-1
			-0316-1		-1103-16A
			-0325-1		-1105-16A
			-0417-16		-1106-16A
			-0444-1		-1110-13A
			-0450-1		-1113-1
			-0453-1		-1418-1
			-0458-1		-1425-1
			-05103-1	107C	
			-05108-1		-0106-1
			-05109-1		-0250-1
			-05129-1		-0253-1
			-05155-1		-0259-1
			-0533-16A		-0264-1
			-0547-1		-0265-12
			-0721-1		
			-0722-16	107D	
			-1203-1		-0207-1
		105D			-6510-12
			-1100-5F	107E	
			-1100-16A		-0106-1
			-1101-1		-0116-1
					-0303-1
		Aircraft Fuel, Oil and Water Systems			
		106B			
			-0207-16		

AP.113
AL.93

VICTOR Mk 2—cont

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108C

-0116-1
-0117-1
-0501-1
-0501-5F

108E

-0416-1
-0511-5F
-0535-1
-0535-5F

108F

-0301-1
-0302-1Aircraft Assisted-Escape
Systems

109B

-0124-1
-0124-5F

109C

-0204-1
-0204-5F

109F

-0113-1
-0113-5FInstrument and Photographic
Equipment

112B

-0502-1
-0701-10
-0702-16
-0703-1
-0704-1
-0705-1
-0706-1
-0707-1
-0708-1
-0709-16
-0710-1
-0711-16
-0800-1
-0810-1
-0811-1
-0811-D1

112C

-0300-2
-0802-2
-2300-2

112G

-0106-1
-0516-1
-0553-16
-0613-1
-0725-1
-0745-1
-1022-1
-1101-16
-11103-1
-1120-1
-1121-1
-1124-1
-1127-1
-1134-1
-1141-13A
-1196-1
-1197-1

112T

-01184-1
-01187-1
-01228-2
-01275-1
-01276-1
-01278-1
-01279-1

Airborne Electrical Equipment

113D

-0419-1
-0426-1
-0449-1
-0455-1
-0456-1
-0601-1
-07135-1
-0752-1
-0762-1
-0796-1
-07124-1
-07127-1
-07134-1
-07172-1
-07192-1
-0923-1
-0928-1
-1006-1
-1013-1
-1113-1
-1210-1
-1301-16
-1308-16
-1321-16
-1337-16
-1355-16
-1356-16
-1357-16
-1359-16
-1360-16
-1361-16
-1368-16
-1369-16
-1371-16
-1393-1
-1394-1
-1412-16

113E

-0121-1
-0127-16
-0130-16
-0146-1
-0193-1
-0207-1
-0207-6
-0220-16
-0223-16
-0359-1
-0383-16
-0386-1
-0386-6
-0394-1
-0395-1
-0399-16
-03165-1
-0420-6
-0428-6
-0442-6
-0443-6
-0449-6
-0505-1
-0505-3A
-0505-6

113F

-0208-13A
-0404-1
-0624-1
-0701-1
-0702-1
-0826-1
-1101-2
-1105-1

113G

-0103-1
-0106-1

113L

-0106-16
-0120-1

Airborne Radar Equipment

114E

-0300-4F
-1001-1A
-1001-1C
-1001-10
-1002-1A
-1002-1B
-1002-601
-1003-1A
-1003-1B
-1003-601
-1004-1
-1005-1
-1005-10
-1006-1
-1300-1A
-1300-1B
-1300-601

114Z

-0401-1

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B -0203-3ACD
116D -0117-3ACD
116F -0103-3ACD
-0204-3ACD

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120F -0404-1
-0405-1
120H -1001-1
120N -0101-2
-0102-1
-0107-1

VULCAN

Aircraft

- 101B
 -1900-6A
 -1902-1A
 -1902-1B
 -1902-1C
 -1902-5A to F
 -1902-5A5
 -1902-5F
 -1902-5B1B
 -1902-5B1A
 -1902-5M
- 101S
 -0126-1
 -0202-1

Aero-Engines (Including AAPUs and Propellers)

- 102C
 -0402-1
 -0402-6A
 -0403-1
 -0403-6A

Aero-Engine Equipment

- 103B
 -0202-1
 -1201-1
 -1403-1
- 103D
 -0103-3A
 -0218-17
- 103E
 -0106-16A

Aircraft Landing Gear

- 104F
 -1017-1
 -1017-5F
 -1033-1
- 104G
 -1024-1
 -1024-5F
- 104J
 -1029-1
 -1029-5F

Aircraft Hydraulic, Pneumatic and Mechanical Equipment and Powered Flying Controls

- 105B
 -0221-1
 -0313-16C
 -0318-16C
 -0481-1
 -0671-16C
 -0678-1
 -0731-1
 -0731-5F
 -0738-16
 -07174-5F
 -07236-5F
 -07248-1
 -1161-1

- 105C
 -0111-1
 -0112-1
 -0313-1
 -0453-1
 -05103-1
 -0514-1
 -05113-1
 -05154-1
 -05161-5F
 -0550-16
 -0553-16
 -0583-1
 -0584-1
 -0585-1
 -0586-1
 -0605-1
 -0607-1
 -0705-5F
 -0708-1
 -07399-1
 -09194-1
 -1005-16A
 -0458-1
 -05164-1
 -05166-1

- 105D
 -1901-16A
 -1902-16A
 -1903-16A

Aircraft Fuel, Oil and Water Systems

- 106B
 -0206-16
- 106C
 -0409-1
 -0604-16A
 -1304-1
 -1305-1
- 106D
 -0125-1
 -0207-1
- 106H
 -0217-1D6A
 -0311-1

Aircraft Environment Control Equipment

- 107B
 -0103-1
 -0106-16A
 -0137-16A
 -0144-1
 -0152-1
 -0153-1
 -0155-1
 -0157-1
 -0215-1
 -0227-1
 -0306-1
 -0307-1
 -0413-1
 -0511-126
 -0905-123A6A
 -0912-1
 -0914-16
 -0919-16
 -0924-1
 -0933-1
 -0934-1
 -1006-16
 -1015-16
 -1017-16
 -1021-16
 -1027-16
 -1033-1
 -1064-1
 -1087-1
 -1087-1
 -1095-1
 -1096-1
 -10105-1
 -10122-1
 -10124-1
 -1103-16A
 -1105-16A
 -1106-16A
 -1108-16
 -1202-1
 -1202-1
 -1204-1
 -1205-1
 -1206-1
 -1418-1
 -1421-1
 -1425-1
 -5012
 -5013
 -5014
 -5015

- 107C
 -0104-13A
 -0210-16A
 -0244-1
 -0258-1
 -0261-1

- 107D
 -0503-1
 -0510-12

- 107E
 -0303

AP.113
AL.93

VULCAN-cont

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108C

-0117-12
-0128-12D
-0128-5F6
-0141-5F
-0504-5F

108D

-0141-5F
-0303-5F

108F

-0301-1
-0302-1
-0401-12
-0804-1
-0804-5F

108T

-0403-1

Aircraft Assisted-Escape
Systems

109C

-0203-1

109F

-0114-1
-0114-5FArmament (Excluding Guided
Weapons - See Group 118)

110B

-0101-4A

110G

-0122-125F
-0136-125F
-0319-125F
-0515-125F
-0608-12
-0613-125F
-0615-125F
-0616-125F

110M

-0106-15F

110T

-0201-1A
-0201-1B5F2Instrument and Photographic
Equipment

112B

-0306-1
-0306-2

112B-cont

-0318-1A
-0318-1B
-0318-2
-0331-1
-0502-1
-0701-10
-0702-16
-0703-1
-0704-1
-0705-1
-0706-1
-0707-1
-0708-1
-0709-16
-0710-1
-0811-1
-0811-D1

112G

-0113-2
-0117-1
-0516-1
-0553-16
-0556-1
-0557-1
-0579-1
-0719-1B
-0725-1
-0728-1
-0762-16
-0918-1
-0919-1
-1022-1
-1101-16
-1124-1
-1197-1
-11113-1

112T

-01184-1
-01187-1
-01227-10
-01249-1
-01273-1
-01274-1
-01275-1
-01276-1
-01277-1
-01278-1
-01280-1
-01564-1
-01604-1
-01625-1
-01679-1

Airborne Electrical Equipment

113B

-0122-2

113D

-0121-1
-0203-1
-0412-1
-0426-1
-0456-1
-0601-1
-0767-1

113D-cont

-07107-2
-07121-1
-07123-2
-07134-1
-07135-1
-07146-1
-07168-1
-07172-1
-07190-1
-07203-1
-0752-1
-0903-1
-1109-1
-1113-1
-1114-1
-1210-1
-1321-16
-1351-16
-1355-16
-1357-16
-1371-16
-1389-16
-1390-16
-1394-1
-1398-1
-13113-1
-13128-1
-13190-13A
-1412-16
-1415-1
-1611-1
-1611-2

113E

-0145-1
-0188-1
-0173-1
-0266-1
-0193-1
-0364-1
-0364-2
-0366-1
-0370-1
-0380-16
-0381-16
-0383-1
-0395-1
-0399-16
-0428-6
-0441-6
-0517-1
-0517-6
-0522-1

113F

-0208-13A
-0414-1
-0630-1
-0701-1
-0821-16
-0826-1
-1101-2
-1105-1

113G

-0101-125F
-0103-1
-0108-1
-0117-2
-0129-1

113L

-0120-1

VULCAN—cont

Airborne Radar Equipment

114B
-0100-1

114E
-0300-4F
-1001-1A
-1001-1C
-1001-10
-1002-1A
-1002-1B
-1002-601
-1003-1A
-1003-1B
-1003-601
-1004-1
-1005-1
-1005-10
-1006-1
-1300-1A
-1300-1B
-1300-601
-1600-3A1

114K
-0103-1

114M
-0100-4F
-0200-1

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B
-0203-3ACD

116D
-0117-3ACD

116F
-0103-3ACD
-0204-3ACD

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120F
-1101-1

120G
-0701-1

120N
-0101-2
-0102-1
-0110-1
-0150-1
-0151-1
-0152-1
-0153-1

WESSEX

Aircraft

101C

-0100-11A
-0100-11C
-0100-13

-0102-1A)
-0104-1A)

-0102-1B)
-0104-1B)

-0102-4M)
-0104-4M)

-0102-6A
-0105-6A
-0102-6B
-0105-6B

Aero-Engines (Including AAPUs)
and Propellers

102C

-0704-2

-0704-7)
-0705-7)

-0705-2
-0706-7

Aircraft Landing Gear

104B

-1002-16

104D

-1001-16

104F

-1004-5F(R)

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B

-0122-16
-0126-16C
-0309-16
-0435-1
-0452-16
-0454-16
-07195-1
-0738-16
-0747-1
-1008-1
-1502-16

105C

-0429-1

105D

-2001-5F
-2002-5F

105F

-0303-13A

Aircraft Fuel, Oil and Water
Systems

106B

-0202-16

106C

-0104-1
-0112-1
-1403-1

Aircraft Environment Control
Equipment

107B

-0929-16
-0944-16
-0993-13A6

Parachutes, and Personnel
Safety and Survival Equipment
(Airborne)

108D

-0405-5(F)R

108H

-0101-5F
-0101-16C

Armament (Excluding Guided
Weapons - see Group 118)

110G

-0308-125F

110J

-0109-125F

110N

-0204-1

Instrument and Photographic

112B

-0311-13A
-0312-13A
-0315-13A
-0316-13A6
-0344-16
-0910-13A

112C

-0302-1
-0311-13A6
-0313-13A6
-0316-1
-0321-13A6
-0322-16
-0323-16
-0324-16
-0325-16
-0326-13A6
-0327-13A6
-0328-13A6

112G

-0104-13A
-0324-1
-0513-1
-0527-13A6
-0705-16
-0706-2
-0713-16
-0745-1
-1211-16
-1225-1

112T

-0105-1
-01173-1
-01174-1
-01175-1
-01240-1
-01570-13A
-01589-13A
-01590-13A
-01591-13A
-01592-13A
-01593-13A
-01594-13A
-01595-13A
-01596-13A
-01597-1

Airborne Electrical Equipment

113B

-0210-16

113D

-0107-16
-0435-1
-07116-1
-0740-1
-0772-13A6
-0774-13A6
-1113-1
-1305-1
-13120-16
-1329-16
-1350-16
-1358-13A6
-1404-16

AP.113
AL.93

WESSEX—cont

Airborne Electrical Equipment—cont.

113D—cont

—1412—16
—1417—1
—1605—1
—1605—2
—13106—1

113E

—0145—1
—0209—13A6
—0348—13A
—0353—13A
—0377—16
—0384—1
—0398—16
—0506—13A6
—0506—2
—0506—13A6

113F

—0209—1
—0608—13A6
—0628—2
—0660—13A6

113L

—0101—13A6

118T

—1002—16)
—1102—16)

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120G

—0701—1
—0715—1

Airborne Radar Equipment

114E

—0100—1

114J

—0300—2
—1300—2
—1400—2

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116B

—0603—3A1C1D1
—0604—3ACD
—0610—4F

116D

—0102—2
—0102—3ACD
—0102—4F
—0106—2
—0107—1
—0108—4F

116N

—0101—6

Guided—Weapon Systems

118C

—1102—1

WHIRLWIND Mks 1 to 10

Aircraft

101C

-0300-11A
-0300-11C
-0300-13

-0301-6A)
-0308-6A)

-0310-1A)
-0312-1A)

-0310-1B)
-0312-1B)

Aero-Engines (including AAPUs
and Propellers)

102C

-0701-7
-0701-D4
-0702-D4
-0703-D4
-0703-1
-0703-7

Aircraft Hydraulic, Pneumatic
and Mechanical Equipment and
Powered Flying Controls

105B

-0119-16
-0217-1
-07256-5F
-07349-5F
-0931-16
-1307-1
-1531-16
-1720-16

Aircraft Fuel, Oil and Water
Systems

106B

-0208-16

106C

-0112-1

106H

-0601-16
-0602-16
-0603-16

Parachutes and Personnel
Safety and Survival Equipment
(Airborne)

108D

-0101-5F(R)

108E

-0419-1

108H

-0104-16C

Instrument and Photographic
Equipment

112B

-0349-1

112G

-0324-1
-0527-13A6
-0535-1
-0706-1
-0706-2
-1005-16
-1211-1
-1225-1
-1232-1

Airborne Electrical Equipment

113B

-0212-2
-0212-13A6

113D

-0772-13A6
-0777-2
-07188-1
-0802-16
-0903-1
-1113-1
-1305-6
-1358-13A6
-1412-16
-1610-1

113E

-0113-16
-0136-13A
-0144-1
-0145-2
-0209-13A6
-0348-16
-0360-1
-0408-13A6
-0445-1
-0445-6
-0506-13A6
-0506-13A6

113F

-0243-13A

113L

-0307-1

Airborne Radar Equipment

114J

-1300-2

Radio and Television (and
Associated Special-to-Type
Test Equipment)

116D

-0102-2
-0102-3ACD
-0102-4F
-0106-3ACD

Guided-Weapon Systems

118C

-1102-1

118T

-1002-16)
-1102-16)

Electrical Equipment for Aircraft
Ground Servicing and Aero-
nautical Ground Installations

120G

-0701-1
-0715-1

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

