

PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off						Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
			1	2	3	4	5	6			
	EA3.80.7001	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (MOD 4937) (PRE—MOD 5204)									
	EA3.80.8001	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (MOD 5204)									
	EA3.80.7015	Spares for:— ACCELEROMETER, INSTALLATION								GA1/1	
6A/4695406	—	Spares for:— ACCELEROMETER, MK.2							A	GA1/2	
28S/1012358	A43/B32	Attaching parts for Ref. 6A/4695406:— Screw, 4BA							C	GA1/3	
	—	BRACKET, mounting (Existing bracket EA3.80.6465 modified) (C/Mod Con/0516/STC—Mod 5180)						L59		GA1/4	
28M/4342710	AGS2001B4	Attaching parts for bracket:— Nut, 4BA							C	GA1/5	
28S/9150582	A43/B16	Screw, 4BA							C	GA1/6	
28W/1010006	SP22B	Washer, 4BA							C	GA1/7	
45842	EA3.80.6469	BRACKET, L.H. coaming tube						BS267		GA1/8	
45843	EA3.80.6471	BRACKET, R.H. coaming tube						BS267		GA1/9	
	EA3.83.95	BALLAST, UNDER BOMB AIMER'S RAMP, ASSEMBLY (MOD 5204)								GA2/1	
		Spares for:—									
32203	EA3.84.23 or	BLOCK, ballast, 18 $\frac{3}{4}$ lbs S.O.O.							B	GA2/2	
46393	EA3.84.27	BLOCK, wood, S.O.O.									
12997	EA3.84.25 or	BLOCK, ballast, 49 $\frac{1}{2}$ lbs S.O.O.							B	GA2/3	
	EA3.84.29	BLOCK, wood, S.O.O.									
32202	EA3.84.21 or	BLOCK, ballast, 106 $\frac{1}{2}$ lbs S.O.O.							B		
	EA3.83.113	BLOCK, hardwood, 19" x 7" x 2" Attaching parts for EA3.84.113:—								GA2/4	
28D/1013176	AS.1242/10E	Bolt, $\frac{1}{4}$ " BSF							C	GA2/5	
28D/1212828	AS.1242/11E	Bolt, $\frac{1}{4}$ " BSF							C	GA2/6	
28D/1212831	AS.1242/14E	Bolt, $\frac{1}{4}$ " BSF							C	GA2/7	
28M/1011475	A27/EP	Nut, $\frac{1}{4}$ " BSF							C	GA2/8	
28W/9418921	SP13E	Washer							C	GA2/9	
13044	EA3.83.97	BOX, ballast Attaching parts for EA3.83.97:—							B	GA2/10	
28D/1008151	A25/4E	Bolt, $\frac{1}{4}$ " BSF							C	GA2/11	
28D/1011245	A25/10E	Bolt, $\frac{1}{4}$ " BSF							C	GA2/12	
28M/9480017	AGS2001E1/66	Nut, $\frac{1}{4}$ " BSF							C	GA2/13	
26763	EA3.83.105	Packing							C	GA2/14	
26762	EA3.83.107	Packing							C	GA2/15	
26761	EA3.83.109	Plate, washer						S514	C	GA2/16	
24855	EA3.83.111	Plate, washer						S514	C	GA2/17	
28W/9418921	SP13E	Washer							C	GA2/18	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off						Matl. Spec.	Cl. of Equip M.R. L.M.	Plate No.
			1	2	3	4	5	6			
32204	EA3.83.99	STRAP, ballast box Attaching parts for EA3.83.99:—						1	—	B	GA2/19
28D/1011240	A25/5E	Bolt, 1/4" BSF						1	—	C	GA2/20
28M/9480017	AGS2001E1/66	Nut, 1/4" BSF						1	—	C	GA2/21
26760	EA3.83.101	STRAP, support Attaching parts per pair EA3.83.101:—						2	—	C	GA2/22
28D/1011238	A25/3E	Bolt, 1/4" BSF						1	—	C	GA2/23
28M/9480017	AGS2001E1/66	Nut, 1/4" BSF						1	—	C	GA2/24
28W/9418921	SP13E	Washer						1	—	C	GA2/25
	EA3.80.6541	BRACKET, PLUG BREAK, PILOT'S ALTIMETER INSTALLATION (MOD 4859) Spares for:—						—	—	—	
45825	EA3.80.6543	BRACKET, 18 SWG						1	L72	LM	
	EA3.80.2619	COMPASS, E2A ASSEMBLY (PRE—MOD 5204)						—	—	—	
	EA3.80.8043	COMPASS, E2B, ASSEMBLY (MOD 5204) Spares for:—						—	—	—	GA15/1
4626	EA3.80.2623	BRACKET, mounting, assembly						1	—	C	GA15/2
6B/4343605	—	COMPASS, type E2A (Pre—Mod 5076)						1	—	A	
6B/1048857	—	COMPASS, type E2B (Mod 5076)						1	—	A	GA15/3
28S/1012356	A43/B12	Attaching parts for Ref. 6B/4343605 or 6B/1048857:— Screw, 4BA						2	—	C	GA15/4
8631	EA3.80.2621	FLAP, assembly (Pre—Mod 4724)						1	—	C	
8633	EA3.80.1949	PIN, hinge (Pre—Mod 4724)						1	—	C	
8632	EA3.80.2627	SPRING (Pre—Mod 4724)						1	—	C	
8630	EA3.80.2633	TUBE, distance (Pre—Mod 4724)						2	—	C	
	EA3.80.7009	CONSOLE, PILOT'S, ASSEMBLY (MOD 4937) (PRE—MOD 5204)						—	—	—	
	EA3.80.8009	CONSOLE, PILOT'S ASSEMBLY (MOD 5204) Spares for:—						—	—	—	GA15/5
	EA3.80.7011	PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING (MOD 4937) (PRE—MOD 5204)						—	—	—	
	EA3.80.8011	PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING (MOD 5204) Spares for:—						—	—	—	GA15/6
5CW/4400995	EA3.81.2083	BRACKET, switch, bomb doors Attaching parts for EA3.81.2083:—						1	—	C	GA15/7
28S/9419435	A31/B12	Screw, 4BA						4	—	C	GA15/8
29C/1007776	AGS2034/B	Washer, shakeproof						4	—	C	GA15/9

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
41036-1SS5	CONSOLE, PILOT'S, ASSEMBLY (SRIM 3577)	—	—	
		Spares for:			
703-1-00416	BLOCK, fuse	2	—	GA15/10
		Attaching parts for 703-1-00416:			
A32/B8	Screw, 4BA	2	—	GA15/11
SP47B	Washer	2	—	GA15/12
41035	CONSOLE, SUB-ASSEMBLY (SRIM 3577)	1	—	GA16/1
		Spares for:			
13659	PANEL, access	1	—	GA16/2
		Attaching parts for 13659:			
AS1246½B	Bolt, 4BA	4	—	GA16/3
21970	PANEL, ACCESS, SUB-ASSEMBLY	1	—	GA16/4
		Spares for:			
13946	HOLDER, spare fuse	1	—	GA16/5
		Attaching parts for 21970:			
213	Stud	2	—	GA16/6
214	Washer	2	—	GA16/7
R WIS.10112-C-1	FUSE, 5 amp	7	—	GA16/8
R AS10	FUSE, 10 amp	8	—	GA16/9
R AS20	FUSE, 20 amp	2	—	GA16/10
Z1788	GROMMET	4	—	GA16/11
R 10H2073169	HOLDER, fuse	1	—	GA16/12
R H2702 RED	LAMP, bomb doors	1	—	GA16/13
EEAS71/2	LINK, 3-way	1	—	
EEAS71/3	LINK, 4-way	1	—	
508-1-06394	PLUG, 4-way	1	—	GA15/13
508-1-06399	PLUG, 9-way	2	—	GA15/14
508-1-06413	PLUG, 26-way	2	—	GA15/15
R H2704	SCREEN, night, bomb door lamp	1	—	GA16/14
AS10512A-2	SWITCH, canopy demist, vent valve, pressure head and windscreen	4	—	GA16/15
R AS10	FUSE, 10A, anti-collision lights (C/Mod/Con/0267/FC-Mod.5180)	1	—	GA16/16
EA3.81.2077	KNOB, switch, bomb doors	1	—	GA15/16
		Attaching parts for EA3.81.2077:			
A31/B28	Screw, 4BA	1	—	GA15/17
31936-ISS3	PANEL, SWITCH, SUB-ASSEMBLY (SRIM 3577)	1	—	GA16/17
		Spares for:			
13950	GLOVE, aileron trim switch	1	L85	GA16/18
13947	GLOVE, rudder trim switch (Pre Mod.3428)	1	—	
13951A	GLOVE, inboard rudder trim switch (Mod.3428)	1	L85	GA16/19
13951B	GLOVE, outboard rudder trim switch (Mod.3428)	1	L85	GA16/20
		Attaching part for glove:			
A55A2	Screw, grub, 6BA	1	—	GA16/21

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
22106		PANEL, switch, engraved	1	L72	GA16/22
AS10512C-1		SWITCH, external lights master	1	—	GA16/23
AS10512A-1		SWITCH, aileron and rudder trim	QR	—	
AS10512A-2		SWITCH, navigation, taxiing and anti-collision lights	3	—	GA16/25
AS10512E-1		SWITCH, landing and identification lights	3	—	GA16/26
D0523		SWITCH, push, type B, morse	1	—	GA16/27
—		PRESS TO TEST FOR CANOPY AND HATCH DETONATOR CIRCUIT (SEM/CAN/016/STC-Mod.5180)	—	—	
		Spares for:			
WB1110S1B		BLOCK, terminal	1	—	GA16/28
WB1110/1B		COVER, terminal block	1	—	GA16/29
10H0590107		FUSE, 250 mA	2	—	GA16/30
FL8		HOLDER, fuse	2	—	GA16/31
C500/C/7		LAMP, warning	2	—	GA16/32
WB1114/28		PILLAR, terminal block	2	—	GA16/33
EA3.81.5851		SWITCH ASSEMBLY, BOMB DOORS	1	—	GA15/18
		Spares for:			
A33A6		SCREW, 6BA	2	—	GA15/19
5CW1047697		SWITCH	1	—	GA15/20
EA3.81.2073		TOGGLE	1	—	GA15/21
2061		UNIT, control, type 7681/A	1	—	GA16/34
		Attaching parts for EA3.80.7011 or EA3.80.8011:			
AS1248/1C		Bolt, 2BA	17	—	GA16/35
EA3.80.669		STRUCTURE, PILOT'S CONSOLE, ASSEMBLY	—	—	GA17/1
		Spares for:			
EA3.80.2575		FAIRING, CONTROL, ASSEMBLY	1	—	GA17/2
		Spares for:			
EA3.80.2579		COVER, detachable	1	—	GA17/3
		Attaching parts for EA3.80.2579:			
AS1248/1/2C		Bolt, 2BA	5	—	GA17/4
AS1248/1C		Bolt, 2BA	3	—	GA17/5
EB7.80.365		PANEL, removable, forward (Pre Mod.5061)	1	L72	GA17/6
EA3.80.6641		PANEL, ASSEMBLY, FORWARD, ACCESS FOR EMERGENCY BATTERY (MOD.5061)	1	—	
		Spares for:			
DZUS		FASTENER	1	—	
A4-30		FLAP, 18 SWG	1	L72	
EA3.80.6649		FLAP, 18 SWG	1	L72	
DZUS		GROMMET	1	—	
GA4-250		HINGE (Make from AS1878 Ref.28N/9511950)	1	—	
EA3.80.6651		HINGE (Make from AS1878 Ref.28N/9511950)	1	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
BULGIN				
T102 TERMINAL, red	1	—	
T102 TERMINAL, black	1	—	
A31C24 Attaching parts for T102: Screw, 2BA	1	—	
EA3.80.2755 PANEL, removable centre	1	—	GA17/7
EA3.80.1177 PANEL, removable, rear intermediate	1	—	GA17/8
EA3.80.2849 PANEL, removable, rear	1	—	GA17/9
AS1248/1C Attaching parts for Panels, removable: Bolt, 2BA	QR	—	GA17/10
A25/1E Bolt, ¼" BSF	QR	—	GA17/11
EA3.80.1727	. CONTAINER, URINE, ASSEMBLY Spares for:	—	—	GA2/26
E20002	. . . CLIP, spring	1	—	GA2/27
HX11761	. . . CONTAINER, Mk.2	1	—	GA2/28
E20001	. . . FUNNEL	1	—	GA2/29
EB7.80.327	. CURTAIN, BLACKOUT, ASSEMBLY (MOD.1413) (MOD.4937) (PRE MOD.5204) Spares for:	—	—	
EB7.80.331	. . . CURTAIN, main	1	—	
EA3.80.1753	. . . CURTAIN, navigator's window	1	—	
CARR No.759	. . . FASTENER	3	—	
AGS2001C1/66	. . . NUT, 2BA	4	—	
AGS2002C1	. . . NUT, 2BA	2	—	
EB6.80.139	. . . PLATE, black-out, starboard	1	—	
EB6.80.183	. . . PLATE, black-out, port	1	—	
EEAS132/12	. . . STRAP, securing	2	—	
CARR No.882	. . . STUD, hex. base	6	—	
EEAS27/16ER	. . . WASHER, special	2	—	
EA3.80.8071	. CURTAIN, BLACKOUT, ASSEMBLY (MOD.5204) Spares for:	—	—	GA3/1
EH6.80.381	. . . BLACKOUT, NAVIGATOR'S WINDOW, ASSEMBLY (MOD.5204) Spares for:	—	—	
EH6.80.383	. . . CURTAIN, navigator's window	1	—	GA3/2
EA3.80.8069	. . . CURTAIN, MAIN, ASSEMBLY Spares for:	1	—	GA3/3
CARR				
GJ4.00671.00.000	. . . BUTTON, dome	3	—	GA3/4
EA3.80.8067	. . . CURTAIN, main	1	—	GA3/5
CARR				
GJ1.00708.00.000A	. . . PLATE, clinch	8	—	GA3/6
GJ1.00608.00.000	. . . SOCKET, fastener	8	—	GA3/7
GJ4.00548.00.000	. . . SOCKET	3	—	GA3/8

EQUIPMENT AIRCRAFT
PRESSURE CABIN AIRCRAFT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.80.6689	. . CURTAIN, UPPER, ASSEMBLY Spares for:	1	-	GA3/9
CARR				
GJ4.00671.00.000	. . . BUTTON, dome	8	-	GA3/10
EA3.80.8081	. . . CURTAIN, upper	1	-	GA3/11
CARR				
GJ4.00548.00.000	. . . SOCKET	8	-	GA3/12
AGS2001C1/66	. . NUT, 2BA	6	-	GA3/13
AGS2002C1	. . NUT, 2BA	2	-	GA3/14
EA3.80.6389	. . PLATE, BLACKOUT, ASSEMBLY, PORT Spares for:	1	-	GA3/15
EB6.80.177	. . . BRACKET	1	-	GA3/16
EA3.80.6391	. . . PLATE, assembly	1	L72	GA3/17
EA3.80.6395	. . . PLATE Attaching parts for EA3.80.6395:	1	L72	GA3/18
A25/1B	. . . Bolt, 4BA	4	-	GA3/19
SP13B	. . . Washer	4	-	GA3/20
EEAS132/12	. . . STRAP	2	-	GA3/21
CARR				
GJ1.00882.00.000	. . STUD	8	-	GA3/22
GJ4.00759.00.000	. . STUD	11	-	GA3/23
EEAS27/16ER	. . WASHER	2	-	GA3/24
EA3.85.15	. DESTRUCTOR, MOUNTING, ASSEMBLY Spares for:	-	-	GA14/1
EA3.85.17	. . BRACKET, MOUNTING, ASSEMBLY Spares for:	1	-	GA14/2
EA3.85.25	. . . BAND, wire	1	-	GA14/3
EA3.85.27	. . . BAND, wire	1	-	GA14/4
EA3.80.7005	. EQUIPMENT IN NAVIGATOR'S COMPARTMENT, ASSEMBLY (MOD.4937) (PRE MOD.5204)	-	-	
EA3.80.8005	. EQUIPMENT IN NAVIGATOR'S COMPARTMENT, ASSEMBLY (MOD.5204) Spares for:	-	-	GA5/1
EA3.80.2919	. . ATTACHMENT OF NAVIGATOR'S TABLE TO PILOT'S SEAT RAIL Spares for:	-	-	GA5/2
EA3.80.2921	. . . BRACKET, assembly Attaching parts for EA3.80.2921:	1	-	GA5/3
A25/1C	. . . Bolt, 2BA	4	-	GA5/4
A25/3C	. . . Bolt, 2BA	4	-	GA5/5
SP10C	. . . Washer	4	-	GA5/6
SP13C	. . . Washer	4	-	GA5/7

AP101B-0402-3A

EQUIPMENT AIRCRAFT

Page GA.7

PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.	
					1
	BOX, JUNCTION, MICROPHONE (FIG 3 and 4, SEM/CAN/015/STC-MOD 5180) Spares for:-	1	-	GA5/8	
R SP93B8	GROMMET	2	-		
R PO4A4X2-12/0	PLUG, fixed, size 2, 12-way	2	-	GA5/10	
KT95291/5	POST, terminal	2	-		
N314567-1	SOCKET, base	4	-	GA5/12	
SO4A4X1-4/1	SOCKET, fixed size, 4-way	1	-	GA5/13	
SO4AX2-12/0	SOCKET, fixed, size 2, 12-way	2	-	GA5/14	
N324362	SWITCH, magnetic relay	4	-	GA5/15	
HC302	TAG, RT	5	-		
EA3.80.2067	BRACKET, platform (For Aircraft WJ640) (Pre-Mod 5204)	1	-		
EA3.80.2069	BRACKET, platform (For Aircraft WJ640) (Pre-Mod 5204)	1	-		
	Attaching parts for EA3.80.2067 and EA3.80.2069:-				
A25/1C	Bolt, 2BA	4	-		
AGS2001C1/66	Nut, 2BA	4	-		
SP15C	Washer	4	-		
EA3.80.8041	BURCOSTAT, PORT WALL, INSTALLATION (MOD 5204) Spares for:-	-	-	GA6/1	
SP93B6	GROMMET, (C/Mod/Con/0539) (Mod 5180)	1	-	GA6/2	
22977	PLATE, mounting (SRIM 3867 or 3868) Attaching parts for 22977:-	1	-	GA6/3	
A25/1C	Bolt, 2BA	7	-	GA6/4	
SP15C	Washer	7	-	GA6/5	
L100CB	RHEOSTAT (C/Mod/Con/0539) (Mod 5180) Attaching parts for L100/CB:-	1	-	GA6/6	
A25/1/2C	Bolt, 2BA	3	-	GA6/7	
SP47C	Washer	3	-	GA6/8	
AS10512C-1	SWITCH (C/Mod/Con/0539) (Mod 5180)	1	-	GA6/9	
Z10129	DRIVE, flexible, repeater unit	1	-	GA5/16	
	EXTINGUISHER, FIRE, NAVIGATOR'S (C/MOD/0426/STC-MOD 5180) Spares for:-	-	-		
11B180	BRACKET, mounting	1	-	GA5/17	
34H	EXTINGUISHER, fire, 34H	1	-	GA5/18	
EA3.80.1203	PLATE, base	1	-	GA5/19	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Mati. Spec.	Plate No.
EA3.80.7025	PANEL, NAVIGATOR'S INSTRUMENT INSTALLATION Spares for:—	—	—	GA7/1
31076	CLAMP, panel top attachment (SRIM 3577) (Mod 4937) Attaching parts for 31076:—	2	—	GA7/2
A25/1/2C	Bolt, 2BA	2	—	GA7/3
AGS2001C1/66	Nut, 2BA	2	—	CA7/4
SP15C	Washer	2	—	GA7/5
AGS2097B6C	LEAD, bonding	1	—	GA7/6
AGS2097C3C	LEAD, bonding	1	—	GA7/7
14/511	MOUNT, resilient, 14 lb, lower Attaching parts for 14/511:—	3	—	GA7/8
A25/1C	Bolt, 2BA	4	—	GA7/9
AGS2001C1/66	Nut, 2BA	4	—	GA7/10
SP15C	Washer, forward bolts	2	—	GA7/11
SP18C	Washer, aft bolts	2	—	GA7/12
EA3.80.7027	PANEL, INSTRUMENT, ASSEMBLY Spares for:—	—	—	GA8/1
KOLLSMAN L83261-04-010	ALTIMETER, Mk. 30A Attaching parts for L83261-04-010:—	1	—	GA8/2
KOLLSMAN L84380-00-100	Plate, mooring	1	—	GA8/3
A219B36	Screw, 6UNC	4	—	GA8/4
703-2-00244	BLOCK, terminal, 10-way	1	—	GA8/5
—	CLIP	9	—	GA8/6
X16929	CONTROL, transponder	1	—	GA8/7
TYPE 9273	CONTROL, unit, type 9273	1	—	GA8/8
TYPE 7681A	CONTROL, unit, type 7681/A	1	—	GA8/9
640-1-12638	CONTROL, unit, type C1607/7 (Pre Mod 5409)	1	—	GA8/10
703-1-00265	COVER, terminal block	1	—	GA8/11
A259	FILAMENT	2	—	GA8/12
L1338	FILAMENT	9	—	GA8/13
SP40	GROMMET	4	—	GA8/14
AGS1696/6	GROMMET	3	—	GA8/15
SIS2465	HOLDER, correction card	1	—	GA8/16
SIS1128	HOLDER, ejection drill card (C/Mod/Con/0328/STC—Mod 5180)	1	—	GA8/17
TYPE 9M	INDICATOR, airspeed Mk. 9HP Attaching parts for TYPE 9M	1	—	GA8/18
AS1246/10C	Bolt, 2BA	2	—	GA8/19
AS1246/11C	Bolt, 2BA	2	—	GA8/20

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

	Part Number	Description						No. Off	Matl. Spec.	Plate No.	
		1	2	3	4	5	6				
R	6A2769	INDICATOR, air temperature	1	—	
R	or 6A1037475	INDICATOR, air temperature, type 'B' Attaching parts for 6A/2769 or 6A/1037475:	1	—	GA8/21
	AS1246/2B	Bolt, 4BA	2	—	GA8/22
	AS1246/5B	Bolt, 4BA	2	—	GA8/23
	6B4343585	INDICATOR, air mileage Attaching parts for 6B/4343585:	1	—	GA8/24
	AS1246/3C	Bolt, 2BA	3	—	GA8/25
	AGS2001C1/66	Nut, 2BA	3	—	GA8/26
	SP15C	Washer	3	—	GA8/27
	6B6349775	INDICATOR, air position, Mk.1A	1	—	GA8/28
R	or 6B458	INDICATOR, air position, Mk.1B	1	—	
R	6B1996	INDICATOR, master, type 'A'	1	—	GA8/29
	or 6B6341552	INDICATOR, master, type 'B' Attaching parts for 6B/1996 or 6B/6341552:	1	—	
	AS1246/5C	Bolt, 2BA	3	—	GA8/30
R	WT/D143473	INDICATOR, electrical, type 9547, tacan	1	—	GA8/31
	10Q4698518	INDICATOR, relative bearing, type 1630 Attaching parts for WT/D143473 and 10Q4698518	1	—	GA8/32
	AS1246/5B	Bolt, 4BA	2	—	GA8/33
	AS1246/8B	Bolt, 4BA	2	—	GA8/34
R	C5165Y	INDICATOR, electro magnetic, oxygen	1	—	GA8/35
	01-0460 RED	LAMP, bridge	2	—	GA8/36
	5CX1042173	LAMP, bridge	1	—	GA8/37
	01-0483 RED	LAMP, bridge	1	—	GA8/38
	80/10/0678	LAMP, pillar, red	2	—	GA8/39
R	01-0497 RED	LAMP, pillar	1	—	GA8/40
R	C1102/E/18	LAMP, warning	1	—	GA8/41
	703-2-00252	LINK, 3-way	2	—	
	703-2-00253	LINK, 4-way	1	—	
	EA3.80.7029	PANEL, INSTRUMENT, SUB-ASSEMBLY Spares for:	1	—	GA7/13
	14/531	MOUNT, resilient, 14 lb, upper Attaching parts for 14/531:	2	—	GA7/14
	AS1246/1B	Bolt, 4BA	4	—	GA7/15
	AGS2001B1	Nut, 4BA	4	—	GA7/16
	SP15B	Washer	4	—	GA7/17
	PRC3½	RECEPTACLE, for control unit attachment	12	—	GA7/18
	13668	SCREW, wing (SRIM 3577) (Mod 4937)	1	—	GA7/19

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.
21533	PANEL, shorting link, used when control unit type T1607/7 fitted (SRIM 3577) (Mod 4937) (Pre--Mod 5409)	1	—	
703-2-00267	PLUG, fixing	2	—	GA8/42
EA3.80.6593	PLATE, altimeter adapter Attaching parts for EA3.80.6593:	1	L73	GA8/43
AS1242/1C	Bolt, 2BA	4	—	GA8/44
EA3.80.6595	PLATE, blanking Attaching parts for EA3.80.6595:	1	L72	GA8/45
AS1248/1B	Bolt, 4BA	4	—	GA8/46
AGS2001B1	Nut, 4BA	4	—	GA8/47
AS10512A-7	SWITCH, transmit	1	—	GA8/48
909E1448-13	VOLTMETER, 0-40V Attaching parts for 5Q/4347793:	1	—	GA8/49
A33A16	Screw, 6BA Attaching parts for EA3.80.7027:	4	—	GA8/50
A25/8E	Bolt, 1/4" BSF	5	—	GA7/20
AGS2001E1/77	Nut, 1/4" BSF	3	—	GA7/21
10AC1053243	Washer, check	3	—	GA7/22
13611	STOP, hinged table (SRIM 3577) (Mod.4937) Attaching parts for 13611:	1	—	GA7/23
A25/1B	Bolt, 4BA	2	—	GA7/24
AGS2001B1	Nut, 4BA	2	—	GA7/25
SP15B	Washer	2	—	GA7/26
EA3.80.7033	PANEL, NAVIGATOR'S AUXILIARY, INSTALLATION Spares for:	—	—	GA6/10
AS2633	BLOCK, terminal, 2-way	1	—	GA6/11
AS2635	BLOCK, terminal, 5-way Attaching parts for AS2633 and AS2635:	3	—	GA6/12
AGS2001B1	Nut, 4BA	2	—	GA6/13
A33B16	Screw, 4BA	2	—	GA6/14
SP13B	Washer	2	—	GA6/15
AS3180/12B	CLIP, 4BA	1	—	GA6/16
AS3180/20B	CLIP, 4BA Attaching parts for AS3180/12B and AS3180/20B:	1	—	GA6/17
AGS2001B1	Nut, 4BA	1	—	GA6/18
A33B16	Screw, 4BA	1	—	GA6/19
SP13B	Washer	1	—	GA6/20
10J4306022	CONTROLLER, loop, type 1342	1	—	GA6/21

R

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.	
					1
41108	TABLE, NAVIGATOR'S INSTALLATION (SRIM 3577) (MOD 4937) (PRE-MOD 5204) (For Aircraft WJ640) Spares for:-	-	-		
13988	LINK, connecting	1	L72		
41098	PEDESTAL, TABLE, SUB-ASSEMBLY Spares for:-	-	-		
13994	ATTACHMENT, link, forward	1	-		
13993B	SPACER, link, forward attachment	1	-		
13993C	SPACER, link, forward attachment	1	-		
41109	TOP, TABLE, ASSEMBLY Spares for:-	-	-		
14010	SPACER, for hinge brackets	4	-		
EA3.80.181	SPRING	1	-		
41110	TOP, TABLE, AFT, SUB-ASSEMBLY Spares for:-	1	-		
14045	ATTACHMENT, link	1	-		
13989	BRACKET, link	1	-		
14026	BRACKET, hinge	2	-		
14028	BRACKET, spring	1	-		
13992	PLATE, spring attachment	1	-		
13993A	SPACER, link	1	-		
13996	SPACER, spring	1	-		
13990	SPIGOT	1	-		
41100	TOP, TABLE, CENTRE, SUB-ASSEMBLY Spares for:-	1	-		
14032	BRACKET, hinge	4	-		
41101	TOP, TABLE, FORWARD, SUB-ASSEMBLY Spares for:-	1	-		
14026	BRACKET, hinge	2	-		
14028	BRACKET, spring	1	-		
13992	PLATE, spring attachment	1	-		
13996	SPACER, spring	1	-		
EA3.80.7019	TABLE, NAVIGATOR'S INSTALLATION Spares for:-	-	-	GA9/5	
EA3.80.575	TABLE, NAVIGATOR'S ASSEMBLY Spares for:-	1	-	GA9/6	
EA3.80.183	LINK, connecting	1	-	GA9/7	
EA3.80.187	PLATE, spring connection	2	-	GA9/8	
EA3.80.181	SPRING	1	-	GA9/9	
EA3.80.519	TOP, centre portion, assembly	1	-	GA9/10	
EA3.80.579	TOP, front portion, assembly	1	-	GA9/11	
EA3.80.581	TOP, rear portion, assembly	1	-	GA9/12	
EA3.80.629	TRAY, mounting assembly, repeater unit and Tacan coupling unit	1	-	GA9/13	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.80.899	. . . EXTINGUISHER, FIRE, ASSEMBLY Spares for:	—	—	GA4/1
EA3.80.1211	. . . BRACKET, assembly	1	—	GA4/2
EA3.80.1213	. . . BRACKET, assembly	1	—	GA4/3
11B180	. . . BRACKET, extinguisher, fire	1	—	GA4/4
AS1248/7C	. . . Bolt, mush, head 2BA	2	—	GA4/5
AGS2001C1/66	. . . Nut, stiff, 2BA	2	—	GA4/6
AS2810/8/05	. . . Tube, distance	2	—	GA4/7
SP15C	. . . Washer, 2BA	2	—	GA4/8
34H	. . . EXTINGUISHER, fire	1	—	GA4/9
15420	. . . FAIRLEAD (SRIM 3868-Mod.5204)	1	—	GA9/14
EA3.80.1989	. . . HANDLE, EMERGENCY HYDRAULIC PUMP Spares for:	1	—	GA14/5
ROMAC B80	. . . HANDGRIP	1	—	GA14/6
or B79	. . . HANDGRIP	1	—	
or FLEET RUBBERS 1001	. . . HANDGRIP	1	—	
or AUTOMOTIVE PRODUCTS UMC529	. . . HANDGRIP	1	—	
—	. . . HOLDER, FREQUENCY CARD ON PILOT'S STARBOARD BLAST SHIELD, INSTALLATION (C/MOD/CAN/0563/STC) (MOD.5180) Spares for:			
SIS1564	. . . BLOCK, terminal type B, 2-way	1	—	
VITALITY 736	. . . FILAMENT	3	—	
—	. . . HOLDER, assembly (C/Mod/Con/0563STC, Fig.1, 2 and 3) (Mod.5180)	1	—	
01-0497	. . . LAMP, pillar	3	—	
6A1046812	. . . HOLDER, escape drill cards (C/Mod/Con/0328/STC) (Mod.5180)	1	—	
EA3.83.175	. . . LOCK, FLAP SWITCH, ASSEMBLY Spares for:	1	—	GA14/7
AVDEL A415	. . . PIN, quick release	1	—	GA14/8
EA3.83.299	. . . LOCK, undercarriage switch	1	—	GA14/9
EA3.80.901	. . . MOUNTING, FIRE AXE, ASSEMBLY Spares for:	—	—	GA4/10
27N4670513	. . . AXE, fire	1	—	GA4/11
AS2294/8	. . . CLIP, spring	1	—	GA4/12
NEWAY TYPE 7/7	. . . FASTENER	1	—	GA4/13
EA3.80.1829	. . . PLATE, doubling	1	L72	GA4/14
EA3.80.1831	. . . STRAP, 1/8" thick	1	Leather	GA4/15

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
				1 2 3 4 5 6
EA3.80.1833	. MOUNTING, FIRST AID CONTAINER, ASSEMBLY	—	—	GA14/10
EA1.80.881	Spares for: . CONTAINER, first aid box	1	—	GA14/11
AS1248/4C	Attaching parts for EA1.80.881:			
AGS2001C1/66	. Bolt, 2BA	2	—	GA14/12
EA3.80.1923	. Nut, 2BA	2	—	GA14/13
SP15C	. Pad, packing	1	—	GA14/14
	. Washer, 2BA	4	—	GA14/15
EA3.80.1835	. COVER	1	—	GA14/16
ODDIE 212	Attaching parts for EA3.80.1835:			
ODDIE 213/2	. Clip	2	—	GA14/17
ODDIE 214	. Stud	2	—	GA14/18
	. Washer	2	—	GA14/19
EA3.80.7003	. PANELS, PILOT'S INSTRUMENT, ASSEMBLY (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.8003	. PANELS, PILOT'S INSTRUMENT, ASSEMBLY (MOD.5204)	—	—	GA15/22
32000	Spares for: . BRACKET, upper AV mounting (SRIM.3577) (Mod.4937)	1	—	GA15/23
31999	. BRACKET, upper AV mounting (SRIM.3577) (Mod.4937)	1	—	GA15/24
A25/1B	Attaching parts for 32000 and 31999:			
AGS2001B1	. Bolt, 4BA	4	—	GA15/25
SP13B	. Nut, 4BA	4	—	GA15/26
	. Washer	8	—	GA15/27
22201	. BRACKET, on flying panel upper AV mount (SRIM.3577) (Mod.4937)	2	—	GA19/1
22202	. BRACKET, on flying panel lower AV mount (SRIM.3577) (Mod.4937)	2	—	GA19/2
14124	. BRACKET, snub	1	—	GA15/28
A25/1B	Attaching parts for 14124:—			
AGS2001B1	. Bolt, 4BA	2	—	GA15/29
SP13B	. Nut, 4BA	2	—	GA15/30
	. Washer	2	—	GA15/31
14125	. BRACKET, snub	2	—	GA15/32
14126	. BRACKET, snub	1	—	GA15/33
EA3.80.331	. CHANNEL	1	—	GA15/34
14123	. FITTING, support assembly (SRIM.3577) (Mod.4937)	2	—	GA17/12
AS1248/1C	Attaching parts for 14123:—			
AGS2001C1/66	. Bolt, 2BA	2	—	GA17/13
SP13C	. Nut, 2BA	2	—	GA17/14
	. Washer	2	—	GA17/15
EA1.81.401	. LEAD, bonding	1	—	GA17/16
AGS2097C4C	. LEAD, bonding	1	—	GA17/17
27H4605579	. MOUNTING, AV; 4 lbs engine panel	6	—	GA17/18
AGS2001B1	Attaching parts for 27H/4605579:			
A32B14	. Nut, 4BA	4	—	GA17/19
	. Screw, 4BA	4	—	GA17/20

AP101B-0402-3A

Page GA.15

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R IN13154G963GA 27H4605574	. . . MOUNT, AV, 10 lbs flying panel . . . MOUNT, AV, 12 lbs flying panel Attaching parts for IN13154G963GA and 27H4605574:	5 3	— —	GA17/21 GA17/22
A25/18	. . . Bolt, 4BA	AR	—	GA17/23
A25/2B	. . . Bolt, 4BA	AR	—	GA17/24
AGS2001B1	. . . Nut, 4BA	AR	—	GA17/25
R 14130	. . . Spacer (SRIM.3577) (Mod.4937)	AR	—	GA17/26
SP13B	. . . Washer	AR	—	GA17/27
EA3.80.6117	. . . PANEL, ENGINE INSTRUMENT, ASSEMBLY Spares for:	1	—	GA18/1
EA3.80.6115	. . . BRACKET, mounting, assembly Attaching parts for EA3.80.6115:	1	—	GA18/2
A25½A	. . . Bolt, 6BA	4	—	GA18/3
AGS2001A1	. . . Nut, 6BA	4	—	GA18/4
SP15A	. . . Washer	4	—	GA18/5
R Uninyvin 14	. . . CABLE, Uninyvin 14	AR	BSG 177	
R Uninyvin 20	. . . CABLE, Uninyvin 20	AR	BSG 177	
R Uninyvin 16	. . . CABLE, Uninyvin 16	AR	BSG 177	
HV3711	. . . CAP, Helvin, dolly	6	—	
5L9951110	. . . FILAMENT, 6V, 0.24W	2	—	GA18/6
EA3.81.5787	. . . GUARD, assembly	6	—	GA18/7
SMITH				
AG26	. . . INDICATOR, gauge, fuel contents (Mod.1271)	1	—	GA18/8
AG27	. . . INDICATOR, gauge, fuel contents (Mod.1271)	1	—	GA18/9
AG25	. . . INDICATOR, gauge, fuel contents (Pre Mod.3391)	1	—	GA18/10
AG144	. . . INDICATOR, gauge, fuel contents (Mod.3391)	1	—	
1ACR	. . . INDICATOR, gauge, oil pressure	2	—	GA18/11
SIS3596	. . . INDICATOR, engine speed (Mod.322) Attaching parts for indicators:	2	—	GA18/12
A44B24	. . . Screw, 4BA	AR	—	GA18/13
EA3.80.6121	. . . LABEL	1	L72	GA18/14
R H2702 RED	. . . LAMP, warning, type H2702, fuel pressure	2	—	GA18/15
R H2702 RED	. . . LAMP, warning, type H2702, generator fail (B/Com/Mod Con/15) (Mod.5180)	2	—	GA18/16
AGS1658/0	. . . NUT, gland	2	—	GA18/17
508-1-06407	. . . PLUG, assembly	2	—	GA18/18
508-1-06399	. . . PLUG, assembly, 9 pin, size B	2	—	GA18/19
508-1-06405	. . . PLUG, assembly, 12 pin, size C	2	—	GA18/20
EA3.81.2311	. . . REFLECTOR, fuel tank gauge	1	DTD339	GA18/21
EA3.81.2399	. . . REFLECTOR, fuel tank gauge	1	DTD339	GA18/22
EA3.81.2315	. . . SCREEN, fuel tank gauge reflector	1	L72	GA18/23
AGS1651/3	. . . SLEEVE	2	—	
508-2-11232-002	. . . SLEEVE, cable	38	—	
R XD776	. . . SWITCH, toggle Attaching parts for XD776	6	—	GA18/24
A44B20	. . . Screw, 4BA	2	—	GA18/25
EEAS28/2EP	. . . Washer	2	L16	GA18/26
SIS3652	. . . THERMOMETER, exhaust gas, type B Attaching parts for SIS3652:	1	—	GA18/27
AGS2001C4	. . . Nut	4	—	GA18/28
A44C14	. . . Screw	4	—	GA18/29

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EEAS28/2EP		WASHER, special Attaching parts for EA3.80.6117:	12	L16	GA18/31
A25/9B		Bolt, 4BA	3	—	GA17/28
AGS2001B1		Nut, 4BA	3	—	GA17/29
EA3.80.1789		Washer, 1" o/d	12	L72	GA17/30
SP13B		Washer	6	—	GA17/31
EA3.80.7007		PANEL, FLYING' ASSEMBLY Spares for:	—	—	GA19/3
KOLLSMAN L82621-04-010		ALTIMETER, Mk.29B (Mod.4859) Attaching parts for L82621-04-010:	1	—	GA20/1
KOLLSMAN L84380-00-100		Plate, mooring	1	—	GA20/2
A219B36		Screw, 6UNC	4	—	GA20/3
WB1110S2B		BLOCK, terminal (Mod.3922) Attaching parts for WB1110S2B:	1	—	GA19/4
AGS2001B1		Nut, 4BA	2	—	GA19/5
EB6.81.5349		Pillar, fixing	2	—	GA19/6
SP13B		Washer	2	—	GA19/7
6B4343640		COMPASS, Gyro Unit, Type A Attaching parts for Ref.6B4343640	1	—	GA20/4
A44C24		Screw, 2BA	4	—	GA20/5
WB1110B2		COVER, terminal block	1	—	GA19/8
VITALITY 736		FILAMENT, lamp, 28V, 1.1W	4	—	GA20/6
THORN. L1114		FILAMENT, lamp, 28V, 3.5W	1	—	GA20/7
HV3033		GROMMET	1	—	GA20/8
SP93B4		GROMMET	2	—	GA20/9
MRI-1AP-274		HOLDER, compass deviation card	1	—	GA20/10
6A1046811		HOLDER, frequency card	1	—	GA20/11
6A4338320		HORIZON, artificial Attaching parts for Ref.6A4338320	1	—	GA19/9
A44C20		Screw, 2BA	4	—	GA19/10
SMITH		INDICATOR, aileron trim	1	—	GA19/11
430FL		INDICATOR, flap position	1	—	GA19/12
218FL		INDICATOR, rudder trim	1	—	GA19/13
431FL		INDICATOR, tail trim	1	—	GA19/14
813FL		Attaching parts for indicators:			
A44B24		Screw, 4BA	4	—	GA19/15
6A4337742		INDICATOR, air speed, Mk.9M Attaching parts for Ref.6A/4337742:	1	—	GA20/12
AGS2001C4		Nut, 2BA	4	—	GA20/13
A44C20		Screw, 2BA	4	—	GA20/14
AS2809/5/070		Tube, distance	4	L62	GA20/15
5CZ4340430		INDICATOR, electro-magnetic, 24 volt, type A2	1	—	GA20/16
5CZ1031243		INDICATOR, electro-magnetic, 24 volt, type C1	1	—	GA20/17
10Q4280389		INDICATOR, electrical type 9547, Tacan Attaching parts for 10Q/4280389:	1	—	GA20/18
A32B20		Screw, 4BA	4	—	GA20/19

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
27-RC-PC	INDICATOR, rate of climb, Mk.3P (Pre Mod.5228)	1	—	GA20/20
KRA1001K	INDICATOR, rate of climb, Mk.3Q (Mod.5228) Attaching parts for Ref. 27-RC-PC or KRA1001K	1	—	
A44B28 BARBER & COLMAN 1906	Screw, 4BA	4	—	GA20/21
	Washer, shakeproof	4	—	GA20/22
10Q4698518	INDICATOR, relative bearing, type 1630 Attaching parts for 10Q4698518	1	—	GA20/35
A44B28	Screw, 4BA	4	—	GA20/36
RL7003-46A	INDICATOR, ILS, type 7 Attaching parts for RL7003-46A	1	—	GA19/18
A44B20	Screw, 4BA	4	—	GA19/19
ID95ISSUE2	INDICATOR, turn and slip, Mk.3 Attaching parts for ID95ISSUE2	1	—	GA20/23
A44B20	Screw, 4BA	2	—	GA20/24
A44B28 BARBER & COLMAN 1906	Screw, 4BA	2	—	GA20/25
	Washer, shakeproof	4	—	GA20/26
80/10/1192	LAMP, bridge, type C	1	—	GA20/27
80/10/0678	LAMP, pillar	2	—	GA20/28
H2705	LAMP, warning amber, ILS marker	1	—	GA20/29
M1684	MACHMETER, Mk.2 Attaching parts for M1684	1	—	GA20/30
A44B28	Screw, 4BA	4	—	GA20/31
EA3.80.6639	PANEL, SUB-ASSEMBLY (MOD.4859) Spares for:	1	—	GA19/20
EA3.80.6557	PLATE, adaptor, 10 SWG	1	L73	GA19/21
AS10512L-1	PLATE, adaptor, switch (Alt. R60/58-Mod.5097)	1	—	GA20/32
EA3.81.6247	PLATE, switch (Alt. R60/58-Mod.5097)	1	—	GA20/33
AS10512M-1	SHROUD, terminal (Alt. R60/58-Mod.5097)	1	—	
AS10512B-3	SWITCH (Alt. R60/58-Mod.5097) Attaching parts for EA3.80.7007:	1	—	GA20/34
A25/14E	Bolt, 1/4" BSF	4	—	GA17/32
AGS2001E1/77	Nut, 1/4" BSF	4	—	GA17/33
WT33047	Washer, check	12	—	GA17/34
EA3.80.2933	PANEL, FIXED, INSTRUMENT, STARBOARD INSTALLATION (MOD.4937) (PRE-MOD.5204)	—	—	
EA3.80.8023	PANEL, FIXED, INSTRUMENT, STARBOARD, INSTALLATION (MOD.5204) Spares for:	—	—	GA21/1
EA3.80.7013	PANEL, FIXED, INSTRUMENT, STARBOARD, ASSEMBLY (MOD.4937) (PRE-MOD.5204)	1	—	
EA3.80.8013	PANEL, FIXED, INSTRUMENT, STARBOARD ASSEMBLY (MOD.5204) (PRE-MOD.5)	1	—	GA21/2
EA3.80.8015	PANEL, FIXED, INSTRUMENT, STARBOARD, ASSEMBLY (MOD.5204) (Mod.5) For Aircraft WH667 only Spares for:	1	—	
6A4333072	ALTIMETER, Mk.18 Attaching parts for 6A/4333072:	1	—	GA21/3
A44B24	Screw, 4BA	4	—	GA21/4
AGS2037B	Washer, shakeproof	4	—	GA21/5

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
703-1-00238	BLOCK, terminal, 5-way Attaching parts for 703-1-00238:	1	—	GA21/6
A32B24	Screw, 4BA	2	—	GA21/7
14067	Spacer threaded (SRIM.3577) (Mod.4937)	2	—	GA21/8
AGS2037B	Washer, shakeproof	2	—	GA21/9
630/1/37854/010	CONTROLLER, V/UHF (Service supply) (Mod 5409)	1	—	
703-1-00264	COVER, terminal block	1	—	GA21/10
L1034	FILAMENT (Sem/Can/039/STC) (Mod.5180)	2	—	GA21/11
10069 N & Z or SIS3592	GAUGE, pressure	2	—	GA21/12
GE21552	GAUGE, pressure, Mk.14LL Attaching parts for SIS3592 and 10069 N & Z:	1	—	GA21/13
A44B24	Plate, adapter	4	—	GA21/14
AGS2037B	Screw, 4BA	4	—	GA21/15
KGA0463	Washer, shakeproof	2	—	GA21/16
289FL	GAUGE, pressure, oxygen	1	—	GA21/17
A44B24	INDICATOR, air mixer valve Attaching parts for KGA0463 and 289FL:	4	—	GA21/18
AGS2037B	Screw, 4BA	4	—	GA21/19
IN14343-2	Washer, shakeproof	2	—	GA21/20
EA3.81.6235	LABEL, hydraulic, pressure gauge	1	—	GA21/21
40925/36	LABEL, engine air to cabin (Alt. R60/58-Mod.5097)	1	—	
40925/34	LABEL, muting, CU nav and lower aerial (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
22111	LABEL, PTR175 (SRIM.3577) (Mod.4937) (Pre Mod.5204)	1	—	
R 5CX5361 X	LABEL, mute, CU pilot and upper aerial (SRIM.3577) (Mod.4937) (Pre Mod.5204)	2	—	
R 703-2-00251	LAMP, pillar (C/Mod/Con/0473/STC) (Mod.5180)	1	—	
EA3.80.6169	LINK, 2-way	1	—	
EB6.80.5645	PANEL, SUB-ASSEMBLY (PRE MOD.5204) Spares for:	1	—	
EB6.80.695	BRACKET, assembly, control unit	1	—	
A32A12	DOOR, assembly, switch Attaching parts for EB6.80.695:	2	—	
41181	Screw, 6BA	1	—	GA21/24
—	PANEL, sub-assembly (SRIM.3676) (Mod.5204)	1	L72	
R A32B12	PANEL, sub-assembly, fire switches (SEM/Con/039/STC) (Mod.5180) Attaching parts for panel:	4	—	
AS10512L-2	Screw, 4BA	1	—	
15417	PLATE, adapter, cabin pressure switch (Mod.4939) (Pre Mod.5204)	1	—	GA21/26
AS10512L-1	PLATE, switch, cabin pressure (SRIM.3867) (Mod.5204)	3	—	GA21/27
13615	PLATE, adaptor (Alt. R60/58-Mod.5097)	1	—	
AS10512M-1	PLATE, switch, PTR175 (SRIM.3577) (Mod.4937) (Pre Mod.5204)	3	—	
EL37711	SHROUD, terminal (Alt. R60/58-Mod.5097)	2	—	GA21/28
C5162Y Mk.3	SWITCH, push, fire (SEM/Con/039/STC) (Mod.5180)	1	—	GA21/29
AS10512C-4	SWITCH, push, fire warning and test (SEM/Con/039/STC) (Mod.5180)	1	—	GA21/30
	SWITCH, DP, cabin pressure on/off test (Mod.4939)	1	—	

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
AS10512A-2 SWITCH, engine air to cabin (Alt. R60/58-Mod.5097) (Mod.5)	2	—	
AS10512A-2 SWITCH, PTR 175, control unit and aerial (SRIM.3577) (Mod.4937)	2	—	GA21/31
AS10512A-7 SWITCH, PTR 175, muting (SRIM.3577) (Mod.4937)	1	—	GA21/32
AS10512A-1 SWITCH, cabin air hot/cold (Alt. R60/58-Mod.5097)	1	—	GA21/33
R 10L9455739 UNIT, control, T1607/4 (Pre Mod 5409)	1	—	GA21/34
5CW11817 WINDOW, F1 (SEM/Con/039/STC) (Mod.5180)	1	—	GA21/35
5CW11818 WINDOW, F2 (SEM/Con/039/STC) (Mod.5180)	1	—	GA21/36
EA3.81.8137 WIRING, STARBOARD, INSTRUMENT PANEL (MOD.5204) (Pre Mod.5)	—	—	
EA3.81.8139 WIRING, STARBOARD INSTRUMENT PANEL (MOD.5204) (MOD.5)	—	—	
	Spares for:			
Minyvin 16 CABLE, Minyvin 16	AR	BSG195	
Minyvin 20 CABLE, Minyvin 20	AR	BSG195	
508-1-06406 PLUG, 14 way	2	—	
EEAS146/16 SLEEVE, 1/4" long	AR	—	
EEAS146/16 SLEEVE, 3/8" long	AR	—	
EEAS146/20 SLEEVE, 1/4" long	AR	—	
EEAS146/20 SLEEVE, 3/8" long	AR	—	
508-2-11232-002 SLEEVE, inner	23	—	
508-2-11231-002 SLEEVE, inner	4	—	
HC294 TAG, RT	4	—	
HC294D TAG, RT	3	—	
HC295 TAG, RT	2	—	
HC296 TAG, RT	2	—	
HC304 TAG, RT	2	—	
HC306B TAG, RT	2	—	
HC490 TAG, QR	7	—	
HC1187RH TAG, cranked	3	—	
	Attaching parts for fixed panel:			
AS1248/1C Bolt, 2BA	9	—	GA21/37
EA3.04.11001 PANEL, FIXED, INSTRUMENT, STARBOARD INSTALLATION (EA3.04.9533) (MOD.2523-S.O.O.)	—	—	
	Spares for:			
6A4333072 ALTIMETER, cabin Attaching parts for 6A/4333072:	1	—	
R S1S6118 Adaptor	1	—	
A44B24 Screw, 4BA	4	—	
SIS1564 BLOCK, terminal, 2 way Attaching parts for SIS1564:	2	—	
AGS2001A1 Nut, 6BA	1	—	
A45A20 Screw, 6BA	1	—	
Unipren 6 CABLE, Unipren 6	AR	BSG177	
Unipren 12 CABLE, Unipren 12	AR	BS2E21	
EA3.04.1887 CABLE, assembly, N64, from starboard fixed panel to pressure bulkhead	1	—	
EA3.04.10749 CABLE, assembly, N65 from starboard fixed panel to electrical control panel	1	—	
AS491/15 CLIP, cable Attaching parts for AS491/15:	2	—	
AGS2001B1 Nut, 4BA	1	—	
A44B20 Screw, 4BA	1	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
AGS1765/2	. . . COVER, spring, assembly	2	—	
	. . . FILAMENT, lamp, 28V, 3.5W	3	—	
ZA2401-1	. . . GUARD, locking	1	—	
	Attaching parts for ZA2401-1:			
A44B10	. . . Screw, 4BA	2	—	
EEAS28/2HP	. . . Washer	2	—	
505FL	. . . INDICATOR, air valve	1	—	
	Attaching parts for 505FL:			
A44B24	. . . Screw, 4BA	4	—	
H2702 RED	. . . LAMP, warning, red	3	—	
EA3.04.10999	. . . PANEL, starboard, fixed	1	—	
EA3.83.827	. . . PIPE, assembly (Pre Mod.887)	1	—	
EA3.73.981	. . . PIPE, assembly (Mod.887)	1	—	
EA3.04.11031	. . . PLATE, blanking, assembly (Pre Mod.887)	1	—	
	Attaching parts for EA3.04.11031:			
AGS2001B1	. . . Nut, 4BA	4	—	
A441B14	. . . Screw, 4BA	4	—	
SP15B	. . . Washer	4	—	
508-1-06406	. . . PLUG, size C	2	—	
508-2-11231-002	. . . SLEEVE, cable	2	—	
508-2-11232-002	. . . SLEEVE, cable	22	—	
DO523	. . . SWITCH, button, push	2	—	
5CW1042625	. . . SWITCH, toggle	1	—	
XD778	. . . SWITCH, toggle	1	—	
D5404	. . . SWITCH, toggle	1	—	
	Attaching parts for D5404, XD778: and 5CW/1042625:			
A44B10	. . . Screw, 4BA	2	—	
EEAS28/2HP	. . . Washer	2	—	
5K4266	. . . SNUB, pilot's instrument panel (SRIM.3577)	4	—	GA15/35
EA3.80.383	. . . STAY, tubular	1	—	GA19/22
EA2.80.17	. . . PANEL, UNDERCARRIAGE INSTRUMENT, ASSEMBLY	1	—	GA22/1
	Spares for:			
EA3.81.2081	. . . BRACKET, assembly	1	—	GA22/2
	Attaching parts for EA3.81.2081:			
A31B12	. . . Screw, 4BA	4	—	GA22/3
AGS2035B	. . . Washer, shakeproof	4	—	GA22/4
DOWTY				
C2524Y	. . . BUTTON, push undercarriage	1	—	GA22/6
	Attaching parts for C2524Y:			
A40B14	. . . Screw, 4BA	2	—	GA22/7
Uninyvin 16	. . . CABLE, Uninyvin 16	AR	BSG177	
Uninyvin 20	. . . CABLE, Uninyvin 20	AR	BSG177	
THORN. L1114	. . . FILAMENT, lamp, 28V, 3.5W	9	—	GA22/8
5CX4330226	. . . INDICATOR, undercarriage	1	—	GA22/9
	Attaching parts for Ref. 5CX4330226			
A40B14	. . . Screw, 4BA	4	—	GA22/10

AP101B-0402-3A

EQUIPMENT AIRCRAFT

Page GA.21

PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Mati. Spec.	Plate No.
THERMOTANK DAR2		LOUVRE, punkah Attaching parts for DAR2:—	1	—	GA22/14
AS2922/4B		Bolt, 4BA	3	—	GA22/15
AGS2001B1		Nut, 4BA	3	—	GA22/16
SP14B		Washer	3	—	GA22/17
EA1.81.321		PANEL, removable	1	—	GA22/18
508-1-06406		PLUG, assembly, size C	1	—	GA22/19
508-2-11232-002		SLEEVE, cable, 4-7 amp	9	—	
508-2-11231-002		SLEEVE, cable 7-19 amp	2	—	
EA3.81.2071		SWITCH, FLAP SELECTOR, ASSEMBLY (PRE-MOD 4005)	1	—	
EA3.81.5851		SWITCH, FLAP SELECTOR, ASSEMBLY (MOD 4005) Spares for:—	1	—	GA22/20
R A33A6		SCREW, 6BA	2	—	GA22/21
5CW/6435		SWITCH (Pre-Mod 4005)	1	—	
XD789		SWITCH (Mod 4005)	1	—	GA22/22
EA3.81.2073		TOGGLE	1	—	GA22/23
EA3.80.2853		SWITCH, MASTER, UNDERCARRIAGE AND SWITCH FLAP ASSEMBLY (MOD 2392) Spares for:—	—	—	GA22/24
R AS10512L-2		ADAPTER, plate (Alt. R60/58-Mod 5097)	1	—	
EA2.80.271		BRACKET, switch mounting, assembly Attaching parts for EA2.80.271:—	1	—	GA22/26
R A25/1B		Bolt, 4BA	3	—	GA22/5
R AGS2001B1		Nut, 4BA	3	—	GA22/11
UNINYVIN16		CABLE, Uninyvin 16	AR	—	
ZA2402-2		GUARD, switch (Pre-Mod 5097) Attaching parts for ZA2402-2	1	—	
A32B6		Screw, 4BA	4	—	
R EH7.80.49		GUARD, switch (Alt. R60/58-Mod 5097)	1	—	GA22/12
AS10512M-2		SHROUD, terminal (Alt. R60/58-Mod 5097)	1	—	
EEAS146/16		SLEEVE, 3/4" long	2	—	
5CW/6435		SWITCH, D.P. changeover (Pre-Mod 3849)	1	—	
XD789		SWITCH, D.P. changeover (Mod 3849) (Pre-Mod 5097)	1	—	
R AS10512D-2		SWITCH, D.P. (Alt. R60/58-Mod 5097)	1	—	GA22/13
EB6.80.1017		PERISCOPE, STOWAGE AND ELECTRICAL WIRING, ASSEMBLY (MOD 2132— S.O.O.) (EA3.00.1) Spares for:—	—	—	
EA3.81.3009		BOX, junction, No. 14	1	—	
EA3.82.217		BRACKET, MOUNTING, P.F.C. TRANSFORMER, INSTALLATION Spares for:—	1	—	
EA3.82.215		BRACKET, assembly Attaching parts for EA3.82.215:—	1	—	
A25/1C		Bolt, 2BA	5	—	
AGS2001C1/66		Nut, 2BA	5	—	
SP13C		Washer, 2BA	5	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description						No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5	6			
EB6.81.2899	1	—	
AS3180/15B	1	—	
AS3180/4B	6	—	
			Attaching parts for AS3180/4B:—
AGS2001B1	1	—	
A31B16	1	—	
Z49431	1	—	
EB7.80.901	1	—	
			GROMMET
			MOUNTING, PERISCOPE, ASSEMBLY
			Spares for:—
R 6B3469	1	—	
			PERISCOPE, mounting, Mk. 1F
			Attaching parts for 6B/3469:—
AS2920/8E	8	—	
			Bolt, 1/4"
EA3.81.3013	1	—	
			PANEL, ELECTRICAL CONTROL, ASSEMBLY
			(PRE—MOD 76)
EA3.81.3011	1	—	
			PANEL, ELECTRICAL CONTROL, ASSEMBLY
			(MOD 76) (PRE—MOD 310)
EA3.81.3015	1	—	
			PANEL, ELECTRICAL CONTROL, ASSEMBLY
			(MOD 76) (MOD 310)
			Spares for:—
EA1.81.410	2	—	
			BAR, TERMINAL, ASSEMBLY
			Spares for:—
EA1.81.411	1	—	
			BAR, terminal, c/w studs
EA1.81.410A	1	LFS	
			BASE, 5/16" thick
EA1.81.410B	1	LFS	
			COVER, plate, 1/8" thick
BULGIN T5	2	—	
			HEAD, terminal moulded, 4BA
R UNINYVIN 20	AR	—	
			CABLE, Uninyvin 20
R UNINYVIN 16	AR	—	
			CABLE, Uninyvin 16
R UNINYVIN 12	AR	—	
			CABLE, Uninyvin 12
R UNINYVIN 8	AR	—	
			CABLE, Uninyvin 8
EA3.81.121	1	—	
			COVER, terminal block access
9225	2	—	
			GROMMET, Helsyn No. 1
EA3.81.167	1	—	
			LABEL, 'Fuel pumps and cocks circuit breakers
			port and starboard'
EA3.81.1573	1	—	
			LABEL, 'Control—1600~'
EA3.81.189	1	—	
			LABEL, 'Inverters No. 2, No. 3 and No. 4'
EA3.81.1449	1	—	
			LABEL, 'Pump cock, pump cock No. 1 tank'
EA3.81.1447	1	—	
			LABEL, 'Pump cock, pump cock No. 2 tank'
EA3.81.1445	1	—	
			LABEL, 'Pump cock, pump cock No. 3 tank'
EA3.81.1945	2	—	
			LANYARD, fuse panel check
703-2-00251	2	—	
			LINK, 2 way
703-2-00252	1	—	
			LINK, 3 way
703-2-00253	3	—	
			LINK, 4 way
703-2-00260	8	—	
			LINK, transverse
EEAS71/3	14	—	
			LINK, 4 way
EA3.83.285	1	—	
			LOCK, SAFETY, BOMB DOOR RELEASE AND
			STOWAGE, ASSEMBLY
			Spares for:—
R EA3.83.151	1	—	
			PIN, SAFETY, ASSEMBLY
			Spares for:—
AVIATION DEVELOPMENTS			
A415	1	—	
			PIN, 'pip'
Z2889-2	3	—	
			LUG, terminal
EA3.81.1427	1	—	
			PANEL, SWITCH, C/W EQUIPMENT,
			ASSEMBLY
			Spares for:—
EA3.81.1211	1	—	
			GUARD, switch, accumulator isolator
EA3.81.1213	1	—	
			GUARD, switch, No. 1 generator
EA3.81.1215	1	—	
			GUARD, switch, No. 2 generator

PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.
HV3254	. . . STRAP, Helvin	AR	—	
HV.3255	. . . STUD, Helvin	12	—	
EB6.80.945	. . . TUBE, ASSEMBLY Spares for:—	1	—	
EB6.80.985	. . . HANDLE	1	—	
EB6.80.979	. . . LOCK	1	—	
EB6.80.983	. . . NUT	1	—	
SP29E8	. . . PIN, taper	1	—	
EB6.80.981	. . . SPRING	1	—	
EB6.80.977	. . . TUBE	1	—	
EEAS28/42AR	. . . WASHER, packing Attaching parts for EB6.80.945:—	AR	—	
A25/16B	. . . Bolt, 4BA	2	—	
A27BP	. . . Nut, 4BA	2	—	
SP47B	. . . Washer, spring	2	—	
EA3.83.151	. . . PIN, SAFETY, BOMB DOOR LOCK, ASSEMBLY Spares for:—	1	—	GA14/20
AVIATION DEVELOPMENTS				
A415	. . . PIN, quick release	1	—	GA14/21
EA2.10.707	. . . RAMP ASSEMBLY, BOMB AIMER'S Spares for:—	1	—	
EA2.10.709	. . . SPIGOT, assembly	2	—	
EA3.80.1231	. . . SEAT, MAP READER'S, ASSEMBLY Spares for:—	1	—	GA10/1
EA3.80.1289	. . . CABLE, BOWDEN, ASSEMBLY Spares for:—	1	—	GA10/2
EA3.80.1293	. . . BRACKET	1	L72	GA10/3
P19/52A	. . . CABLE, 'Bowdenite' non-fray, inner	AR	—	GA10/4
B52	. . . CONDUIT, outer	AR	—	GA10/5
PN980	. . . FERRULE, plain	2	—	GA10/6
PN3341A	. . . NIPPLE, spherical	2	—	GA10/7
PN1159	. . . STOP, plain adjusting	1	—	GA10/8
EA3.80.1291	. . . WASHER, tapped, radiused	1	S11	GA10/9
EEAS112/6	. . . CLIP, pipe 1/4" single	4	L16	GA10/10
EA3.80.1237	. . . LOCK, BOTTOM, ASSEMBLY Spares for:—	1	—	GA10/11
EA3.80.1249	. . . BRACKET, bottom half	1	140	GA10/12
EA3.80.1250	. . . BRACKET, bottom half Attaching parts for EA3.80.1249 and 1250:—	1	L40	GA10/13
EA3.80.1255	. . . Bolt, special	2	S11	GA10/14
A27CP	. . . Nut, plain 2BA	2	—	GA10/15
SP47C	. . . Washer, spring 2BA	2	—	GA10/16
EA3.80.1251	. . . CATCH, bottom Attaching parts for EA3.80.1251:—	1	DTD124	GA10/17
A25/2C	. . . Bolt, 2BA	1	—	GA10/18
A27CS	. . . Nut, slotted 2BA	1	—	GA10/19
SP90C7	. . . Pin, split	1	—	GA10/20
EA3.80.1253	. . . SPRING	1	Spring Steel	GA10/21
EA3.80.1285	. . . SADDLE, special Attaching parts for EA3.80.1285:—	1	DTD124	GA10/22
A25/4B	. . . Bolt, 4BA	1	—	GA10/23
AGS2001B1	. . . Nut, stiff, 4BA	1	—	GA10/24

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EEAS28/6GR		WASHER, special Attaching parts for EA3.80.1237:	4	L72	GA10/25
A25/2C		Bolt, 2BA	6	—	GA10/26
AGS2001C1/66		Nut, stiff, 2BA	6	—	GA10/27
SP15C		Washer, 2BA	6	—	GA10/28
EA3.80.1231A		PAD, 2" x 1" (Make from 32C/4659939) or two of 32C/4659938)	1	—	GA10/29
EA3.80.1233		SEAT, assembly	1	—	GA10/30
EA3.80.1957		STOWAGE, MAP READER'S SEAT, ASSEMBLY Spares for:	1	—	GA10/31
—		BLOCK, mounting, terry clip (Make from 5F/9400958) (C/Mod/Con/0475/ STC) (Mod.5180)	1	—	
80X2		CLIP, terry 3/4" (C/Mod/Con/0475/STC) (Mod.5180)	1	—	
EA3.80.1961		PLATE, front (Pre Mod.5180)	1	L72	GA10/32
EA3.80.1963		PLATE, reinforcing (Pre Mod.5180)	1	L72	GA10/33
EA3.80.1959		STRAP Attaching parts for EA3.80.1957:	1	—	GA10/34
AS1242/4C		Bolt, 2BA	1	—	GA10/35
AGS2001C1/66		Nut, stiff, 2BA	1	—	GA10/36
EA3.80.1235		SUPPORT, MAP READER'S SEAT, ASSEMBLY Spares for:	1	—	GA10/37
EA3.80.1261		ROLLER, GUIDE, ASSEMBLY Spares for:	1	—	GA10/38
EA3.80.1259		BOLT, special	1	S11	GA10/39
EA3.80.1257		ROLLER	1	L40	GA10/40
AS2811/6/020		WASHER, distance Attaching parts for EA3.80.1261:	1	T4	GA10/41
A27EP		Nut, 1/2" BSF	1	—	GA10/42
SP47E		Washer, spring 1/4"	1	—	GA10/43
AS2811/6/025		WASHER, distance	1	T4	GA10/44
EA3.80.6475		SEATING, PRESSURE CABIN, ASSEMBLY Spares for:	—	—	GA23/1
EA1.80.867		BRACKET, top, pilot's seat rail attachment Attaching parts for EA1.80.867:	2	—	GA23/2
A25/5C		Bolt, 2BA	2	—	GA23/3
A27CP		Nut, 2BA	2	—	GA23/4
EA3.80.1569		Packing, fillet	2	—	GA23/5
EA2.80.5135		BRACKET, pipe clamp, assembly Attaching parts for EA2.80.5135:	1	—	GA23/6
A25/1C		Bolt, 2BA	2	—	GA23/7
SP13C		Washer, 2BA	2	—	GA23/8
MARTIN BAKER MBCJ2587		BREECH-UNIT, and time release (Mod.5244) Attaching parts for MBCJ2587:	1	—	GA23/9
AS1242/13E		Bolt, 1/4" BSF, csk. head	2	—	GA23/10
AS1242/17E		Bolt, 1/4" BSF, csk. head	1	—	GA23/11
AGS2001E1/77		Nut, 1/4" BSF	3	—	GA23/12
SP13E		Washer, 1/4" BSF	6	—	GA23/13

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
B/MBCJ/1110	. . . CARTRIDGE, No.3, Mk.1	1	—	GA23/14
12K9629465	. . . CARTRIDGE, set No.13, Mk.1	3	—	GA23/15
EG5.80.177	. . . CLAMP, pipe, assembly Attaching parts for EG5.80.177:	1	—	GA23/16
A25/10B	. . . Bolt, 4BA	2	—	GA23/17
AGS2001B1	. . . Nut, 4BA	2	—	GA23/18
SP13B	. . . Washer, 4BA	2	—	GA23/19
AS4525/8C	. . . CLIP, support Attaching parts for AS4525/8C:	4	—	GA23/20
A25/1C	. . . Bolt, 2BA	1	—	GA23/21
AGS2001C1/66	. . . Nut, 2BA	1	—	GA23/22
EEAS239/1A	. . . Washer, 'D'	1	L72	GA23/23
R MARTIN BAKER C76HC/MB	. . . COUPLING, ermeto	2	—	GA27/1
MARTIN BAKER MBEU34678	. . . GUN, ejection, type 12, Mk.1, navigator and passenger	2	—	GA23/24
MARTIN BAKER MBEU34679	. . . GUN, ejection, type 10, Mk.1 pilot's	1	—	GA23/25
EA3.80.2869	. . . LINE, LEG RESTRAINT AND BRACKETS, NAVIGATOR'S AND BOMB AIMER'S ASSEMBLY Spares for:	—	—	GA24/1
EA3.80.2887	. . . BRACKET, SHEAR PIN, NAVIGATOR AND BOMB AIMER, INSTALLATION Spares for:	—	—	GA24/2
EA3.80.2859	. . . BRACKET, SHEAR PIN, BOMB AIMER'S ASSEMBLY Spares for:	—	—	GA24/3
R MARTIN BAKER A/MBEU3666	. . . BRACKET, floor Attaching parts for A/MBEU3666:	2	—	GA24/4
A25/3C	. . . Bolt, 2BA	4	—	GA24/5
EA3.80.2889	. . . BRACKET, SHEAR PIN, NAVIGATOR'S ASSEMBLY Spares for:	—	—	GA24/6
MARTIN BAKER A/MBEU3666	. . . BRACKET, floor Attaching parts for A/MBEU3666:	2	—	GA24/7
A25/7C	. . . Bolt, 2BA	4	—	GA24/8
AGS2001C1/66	. . . Nut, 2BA	4	—	GA24/9
SP13C	. . . Washer, 2BA	4	—	GA24/10
AS2809/4/060	. . . TUBE, distance	2	—	GA24/11
MARTIN BAKER B/MBEU17353	. . . LINE, leg restraint	4	—	GA24/12
MARTIN BAKER MBEU8921	. . . PIN, QR	4	—	GA24/13
EA2.80.5143	. . . LINE, LEG RESTRAINT AND BRACKETS, PILOT'S. ASSEMBLY Spares for:	—	—	GA24/14
EG5.80.157	. . . BRACKETS, LEG RESTRAINT, ASSEMBLY Spares for:	—	—	GA24/15
MARTIN BAKER A/MBEU3666	. . . BRACKET, floor Attaching parts for A/MBEU3666:	2	—	GA24/16
A25/9C	. . . Bolt, 2BA	4	—	GA24/17

AP101B-0402-3A

Page GA.27

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
MARTIN BAKER B/MBEU17353 LINE, leg restraint	2	—	GA24/18
MARTIN BAKER MBEU8921 PIN, QR	2	—	GA24/19
EA3.80.6405 MECHANISM, SINGLE LEVER, EJECTION, INSTALLATION Spares for:	—	—	
R EA3.80.6411 BOLT, special Attaching parts for EA3.80.6411:	3	S95	GA25/1
AGS2001C1/66 Nut, stiff, 2BA	1	—	GA25/1A
SP16C Washer, thick, 2BA	1	—	GA25/1B
EA3.80.6409 BOX, sealing	1	S510	GA25/2
R EA3.80.6609 CABLE, assembly, secondary firing, port side (Pre Mod.5353) Attaching parts for EA3.80.6609:	1	—	
SP121G Collar	1	—	
SP4Z/B4 Pin, shackle	1	—	
SP113G5 Pin, shear	1	—	
SP90C3 Pin, split	1	—	
SP90E7 Pin, split	1	—	
SP13C Washer	1	—	
R EA3.80.6695 CABLE, secondary firing, port rear seat (Mod.5353) Spares for:			
MARTIN BAKER MBEU.56016 PIN, assembly Attaching parts for MBEU.56016:	1	—	
R SP121/G Collar	1	—	
R SP113/G5 Pin, shear	1	—	
R SP90/E7 Pin, split	1	—	
	Attaching parts for EA3.80.6695:			
R SP4Z/B4 Pin, shackle	1	—	
R SP90/C3 Pin, split	1	—	
R SP13/C Washer, 2BA, plain	1	—	
EA3.80.6691 CABLE, assembly, secondary firing, starboard side (Mod.5266) Attaching parts for EA3.80.6691:	1	—	GA25/3
SP121B Collar	1	—	GA25/4
SP11385½ Pin, shear	1	—	GA25/5
SP90C5 Pin, split	1	—	GA25/6
EA3.80.6425 CONDUIT, convoluted, assembly Attaching parts for EA3.80.6425:	1	—	GA25/7
A25/2B Bolt, 4BA	8	—	GA25/7A
AGS2001B1 Nut, stiff, 4BA	8	—	GA25/7B
SP15B Washer, 4BA	8	—	GA25/7C
EA3.80.6427 CONDUIT, convoluted, assembly	1	—	GA25/8
EA3.80.6407 COVER, assembly Attaching parts for EA3.80.6407:	2	S515	GA25/9
A25/2C Bolt, 2BA	10	—	GA25/10
SP15C Washer, 2BA	10	—	GA25/11
EA3.80.6417 LEVER, cocking, assembly	2	—	GA25/12
EA3.80.6413 LINK, cocking, assembly Attaching parts for EA3.80.6413:	1	—	GA25/13
SP90E3 Pin, split	3	—	GA25/13A
SP10E Washer	3	—	GA25/13B

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.81.6531	MECHANISM, SINGLE LEVER, EJECTION, PORT, ASSEMBLY	1	—	GA26/1
		Spares for:			
EA3.81.6553	ARM, cam follower, assembly	1	S61	GA26/2
EA3.81.6043	BODY	1	—	GA26/2A
A25/26C	BOLT, 2BA	3	—	GA26/3
A25/10B	BOLT, 4BA	2	—	GA26/4
AS1242/26C	BOLT, 2BA, csk. head	2	—	GA26/5
AS1242/10B	BOLT, 4BA, csk. head	1	—	GA26/6
EA3.81.6061	BLOCK, guide	1	L64	GA26/7
EA3.81.6063	BLOCK, guide	1	L64	GA26/8
EA3.81.6527	MASK, assembly	1	L16	GA26/9
AGS2002C1	NUT, 2BA	5	—	GA26/10
A27BT	NUT, 4BA	3	—	GA26/11
EA3.81.6067	PIN, locating	2	S1	GA26/12
EA3.81.6069	PIN, cocking	1	S1	GA26/13
SP4Z/A2	PIN, shackle	1	—	GA26/15
SP90C4	PIN, split	2	—	GA26/16
EA3.81.6039	PLATE, back	1	—	GA26/16A
EA3.81.6065	PLATE, mounting assembly	1	—	GA26/16B
EA3.81.6087	PLATE, sealing	1	L72	GA26/17
EA3.81.6551	PLUNGER, cam	1	L64	GA26/18
DOWTY					
1077Z136	RING, retaining micro switch	2	—	GA26/33
EA3.81.6051	ROLLER	1	S61	GA26/19
4104/4/3/16	SCREW, self tapping mush. head	2	—	GA26/19A
EA3.80.6485	SEAR	1	—	GA26/20
EA3.81.6085	SEAL	1	Neoprene	GA26/21
DOWTY					
1077Z138	SHROUD, micro switch cable entry	2	—	GA26/34
EA3.81.6529	SPINDLE, adjusting	1	S1	GA26/22
EA3.81.6041	SPRING	1	DTD5A	GA26/23
EA3.81.6053	SPRING, compression	1	DTD5A	GA26/24
DOWTY					
DN1241Z	SWITCH, microseal	2	—	GA26/25
AS2811/5/235	TUBE, distance	3	—	GA26/26
SP13C	WASHER, 2BA	5	—	GA26/27
SP13B	WASHER, 4BA	3	—	GA26/28
SP13E	WASHER, 1/4"	1	—	GA26/29
EA3.81.6523	MECHANISM, SINGLE LEVER EJECTION STARBOARD, ASSEMBLY	1	—	GA26/30
		Spares for:			
EA3.81.6553	ARM, cam follower, assembly	1	S61	GA26/2
EA3.81.6043	BODY	1	—	GA26/2A
A25/26C	BOLT, 2BA	3	—	GA26/3
A25/10B	BOLT, 4BA	2	—	GA26/4
AS1242/26C	BOLT, 2BA, csk. head	2	—	GA26/5
AS1242/10B	BOLT, 4BA, csk. head	1	—	GA26/6
EA3.81.6061	BLOCK, guide	1	L64	GA26/7
EA3.81.6063	BLOCK, guide	1	L64	GA26/8
EA3.81.6527	MASK, assembly	1	L64	GA26/9
AGS2002C1	NUT, 2BA	4	—	GA26/10
A27BT	NUT, 4BA	3	—	GA26/11
SP90C4	PIN, split	2	—	GA26/16
EA3.81.6067	PIN, locating	2	S1	GA26/12

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.
EA3.81.6069 PIN, cocking	1	S1	GA26/13
SP4Z/A2 PIN, shackle	1	—	GA26/15
EA3.81.6039 PLATE, back	1	—	GA26/16A
EA3.81.6329 PLATE, mounting assembly	1	—	GA26/16C
EA3.81.6087 PLATE, sealing	1	L72	GA26/17
EA3.81.6551 PLUNGER, cam	1	L64	GA26/18
DOWTY 1077Z136 RING, retaining micro switch	2	—	GA26/33
EA3.81.6051 ROLLER	1	S61	GA26/19
4104/4/3/16 SCREW, self tapping mush, head	2	—	GA26/19A
EA3.81.6086 SEAL	1	Neoprene	GA26/21
EA3.80.6486 SEAR	1	—	GA26/20
DOWTY 1077Z138 SHROUD, micro switch cable entry	2	—	GA26/34
EA3.81.6529 SPINDLE, adjusting	1	S1	GA26/22
EA3.81.6041 SPRING	1	DTD5A	GA26/23
EA3.81.6053 SPRING, compression	1	DTD5A	GA26/24
DOWTY DN1241Z SWITCH, microseal	2	—	GA26/25
AS2811.5.235 TUBE, distance	3	—	GA26/26
SP13C WASHER, 2BA	5	—	GA26/27
SP13B WASHER, 4BA	3	—	GA26/28
SP13E WASHER, 1/4" BSF	1	—	GA26/29
A27CT NUT, thin 2BA	4	—	GA25/14A
EA3.80.6463 PACKING	1	L72	GA25/14
EA3.80.6415 PLATE, peg	1	S510	GA25/15
	Attaching parts for EA3.80.6415:			
A27CT Nut, 2BA	3	—	GA25/16
EEAS1/2C Screw, 2BA, csk. head	3	S96	GA25/17
SP10C Washer, 2BA	3	—	GA25/18
EEAS1/2C SCREW, 2BA, csk. head	4	S96	GA25/19
EEAS1/3C SCREW, 2BA, csk. head	5	S96	GA25/20
EA3.80.6421 SEAL, for cover and mechanism	1	Neoprene	GA25/21
EA3.80.6429 SEAL, for conduit	1	Neoprene	GA25/22
EA3.80.6419 STOWAGE, COCKING LEVER, ASSEMBLY	1	—	GA25/23
	Spares for:			
AS1877/20 HINGE	1	—	GA25/24
EA3.80.6451 LID	1	L72	GA25/25
EA3.80.6453 SPRING	1	DTD187	GA25/26
	Attaching parts for EA3.80.6419:			
AS1248/1C Bolt, 2BA, mush. head	2	—	GA25/27
AGS2001C1/66 Nut, 2BA	2	—	GA25/28
SP15C Washer, 2BA	2	—	GA25/29
EA3.80.6431 WASHER, packing	2	L72	GA25/30
SP10C WASHER, 2BA	4	—	GA25/30A
MRI/RFD/400 PACK, personal survival, M, Mk.2 (Pre Mod.5204)	3	—	GA27/2
MRI/RFD/460 PACK, personal survival, 2M, Mk.1 (Mod.5204)	3	—	
15A4177659 PARACHUTE, Mk.19 (Pre Mod.5204)	3	—	GA27/3
MRI IRV646 PARACHUTE, S, Mk.18 (Mod.5204)	3	—	
MARTIN BAKER MBCJ1765 PIPE, assembly	1	—	GA27/4
MARTIN BAKER MBCJ1766 PIPE, assembly	1	—	GA27/5

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Mati. Spec.	Plate No.
MARTIN BAKER MBCJ1684	. . PIPE, assembly (Pre Mod.4868)	1	-	GA27/6
MBCJ2211/1	. . PIPE, assembly (SRIM.3479) (Mod.4868) For Aircraft WJ637 and WJ731	1	-	
R MARTIN BAKER MBEU1902EE	. . RAIL, guide, pilot's Attaching parts for MBEU1902EE:	1	-	GA27/7
A25/5G	. . Bolt, 5/16" BSF	2	-	GA27/8
A25/5J	. . Bolt, 3/8"	2	-	GA27/9
AGS2001G1	. . Nut, 5/16" BSF	2	-	GA27/10
AGS2001J1	. . Nut, stiff, 3/8" BSF	1	-	GA27/10A
SP15J	. . Washer, 3/8"	2	-	GA27/12
R MARTIN BAKER MBEU1963EE	. . RAIL, guide, navigator's Attaching parts for MBEU1963EE:	1	-	GA27/13
A25/5C	. . Bolt, 2BA	1	-	GA27/13A
A25/6E	. . Bolt, 1/4" BSF	12	-	GA27/14
A25/7E	. . Bolt, 1/4" BSF	10	-	GA27/15
A25/8E	. . Bolt, 1/4" BSF	1	-	GA27/16
A25/7G	. . Bolt, 5/16" BSF	4	-	GA27/17
A25/8G	. . Bolt, 5/16" BSF	1	-	GA27/18
A25/10G	. . Bolt, 5/16" BSF	2	-	GA27/19
A25/5L	. . Bolt, 7/16"	5	-	GA27/20
AS1242/6E	. . Bolt, 1/4" BSF, csk. head	1	-	GA27/21
A27CP	. . Nut, 2BA	1	-	GA27/21A
AGS2001E1/77	. . Nut, 1/4" BSF	24	-	GA27/22
AGS2001G1	. . Nut, 5/16" BSF	7	-	GA27/23
AGS2001L1	. . Nut, 7/16" BSF	5	-	GA27/24
EA3.80.1569	. . Packing, fillet	1	L72	GA27/24A
EA3.80.477	. . Packing, fillet	2	L72	GA27/25
EA3.80.479	. . Packing, fillet	5	L72	GA27/26
EA3.80.481	. . Packing, fillet	20	L72	GA27/27
EA3.80.1725	. . Packing	1	DTD683	GA27/28
EA3.10.2197	. . Packing	1	DTD683	GA27/29
EA3.10.571	. . Shim, laminated	1	Attewell	GA27/30
SP15E	. . Washer, 1/4" BSF	20	-	GA27/31
SP15G	. . Washer, 5/16" BSF	2	-	GA27/32
SP15L	. . Washer, 7/16" BSF	5	-	GA27/33
SP16E	. . Washer, 1/4" BSF	4	-	GA27/34
SP16G	. . Washer, 5/16"	4	-	GA27/35
R MARTIN BAKER MBEU1964EE	. . RAIL, guide, bomb aimer's Attaching parts for MBEU1964EE:	1	-	GA27/36
A25/5C	. . Bolt, 2BA	1	-	GA27/36A
A25/4E	. . Bolt, 1/4" BSF	9	-	GA27/37
A25/5E	. . Bolt, 1/4" BSF	8	-	GA27/38
A25/6E	. . Bolt, 1/4" BSF	6	-	GA27/39
A25/9G	. . Bolt, 5/16" BSF	2	-	GA27/40
A25/5L	. . Bolt, 7/16" BSF	5	-	GA27/41
AS1242/5E	. . Bolt, 1/4" BSF, csk. head	1	-	GA27/42
A27CP	. . Nut, 2BA	1	-	GA27/42A
AGS2001E1/77	. . Nut, 1/4" BSF	24	-	GA27/43
AGS2001G1	. . Nut, 5/16" BSF	2	-	GA27/44

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
AGS2001L1	. . Nut, 7/16" BSF	5	—	GA27/45
EA3.80.1569	. . Packing, fillet	1	L72	GA27/45A
EA3.80.477	. . Packing, fillet	2	L72	GA27/46
EA3.10.2197	. . Packing	1	L72	GA27/47
EA3.10.571	. . Shim, laminated	1	Attewell	GA27/48
SP15E	. . Washer, 1/4" BSF	20	—	GA27/49
SP15G	. . Washer, 5/16" BSF	2	—	GA27/50
SP15L	. . Washer, 7/16" BSF	5	—	GA27/51
SP16E	. . Washer, 1/4" BSF	4	—	GA27/52
27L1445204	. . SEAT, ejection, type 2CA1, Mk.2	1	—	GA27/53
27L1445205	. . SEAT, ejection, type 2CA2, Mk.4	2	—	GA27/54
EA3.80.1225	. STOWAGE, ASBESTOS GLOVES, ASSEMBLY Spares for:	1	—	GA12/1
NEWAY 7/7-101	. . FASTENER, snap	1	—	GA12/2
EA3.80.1795	. . STRAP, 2½" wide	1	Blue Webbing	GA12/3
EA3.80.6175	. STOWAGE, BLOCK, PILOT'S EJECTION SEAT SAFETY PINS, ASSEMBLY (MOD.4442) Spares for:	—	—	GA1/10
EA3.80.6547	. . BLOCK, stowage (Mod.4925)	1	—	GA1/11
AS1242/6C	. . Attaching parts for EA3.80.6547: . . Bolt, 2BA	2	—	GA1/12
EA3.80.6173	. . CLIP	1	—	GA1/13
EA3.80.6669	. STOWAGE, BLOCKS REAR CREW EJECTION SEAT SAFETY PINS, ASSEMBLY (MOD.5103) Spares for:	—	—	GA1/14
EA3.80.6667	. . BLOCK, stowage (Make from EA3.80.6547 Ref.6101183) Attaching parts for EA3.80.6667:	2	—	GA1/15
AS1246/6C	. . Bolt, 2BA	2	—	GA1/16
AGS2001C1/66	. . Nut, 2BA	2	—	GA1/17
SP15C	. . Washer	2	—	GA1/18
EA3.80.2893	. STOWAGE, FIRST AID, INSTALLATION (MOD.3228-S.O.O.) Spares for:	—	—	
EA3.80.2913	. . BRACKET, mounting assembly	1	—	
EA3.80.2899	. . CONTAINER, first aid stowage, assembly Attaching parts for EA3.80.2899:	1	—	
AS1248/4C	. . Bolt, 2BA	2	—	
SP13C	. . Washer	2	—	
EA3.80.6643	. STOWAGE, MAP, PILOT'S INSTALLATION (MOD.5061) Spares for:	—	—	GA13/1
EA3.80.6655	. . STOWAGE, map, pilot's (Make from AS432, Ref. No.25158) Attaching parts for EA3.80.6655:	1	—	GA13/2
AS1248/2C	. . Bolt, 2BA	2	—	GA13/3
AGS2002C1	. . Nut, 2BA	2	—	GA13/4
SP124D	. . Washer	6	—	GA13/5
EA3.83.1	. STOWAGE, PILOT'S PERSONAL EQUIPMENT (PRE Mod.76) Spares for:	—	—	
EA3.83.133	. . STOWAGE	1	—	
—	. STOWAGE, bag, key, flap and bomb door selector safety pins, on crew entrance door (C/Mod/Con/015-Mod.5180)	1	—	GA14/22

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.80.899	. STOWAGE, HANDLE, EMERGENCY U/C HAND PUMP (MOD.4937) Spares for:	—	—	GA13/10
TERRY No.257-7-8	. . CLIP	2	—	GA13/11
EA1.80.967	. STRAP, BACK, OCCASIONAL SEAT, ASSEMBLY Spares for:	1	—	GA11/1
EA1.80.987	. . LUG Attaching parts for EA1.80.987:	1	—	GA11/2
A25/3C	. . Bolt, 2BA	4	—	GA11/3
AGS2001C1/66	. . Nut, 2BA	4	—	GA11/4
EA1.80.985	. . Washer, radiused	2	—	GA11/5
EA3.80.2665	. . STRAP, BACK, ASSEMBLY Spares for:	1	—	GA11/6
AS2394	. . . COLLAR	1	—	GA11/7
EA1.80.971	. . . EYE-BOLT	1	L72	GA11/8
EA1.80.973	. . . PLATE, strap	1	L72	GA11/9
EA1.80.975	. . . PLATE, strap	1	L72	GA11/10
AS2385	. . . TRUNNION, 5/16" BSF	1	—	GA11/11
EA3.80.2681	. . . WEBBING, 40" long x 6½" wide (Proof-load) Attaching parts for EA3.80.2665:	1	—	GA11/12
AVDEL A405	. . PIN, 'pip'	1	HTS	GA11/13
EA2.83.6081	. SUNBLIND, PILOT'S, INSTALLATION (Pre Mod.5408) Spares for:	—	—	
EA3.83.195	. . BEARING, support, bottom	2	LFS26	GA12/4
EA3.83.197	. . BEARING, support, top Attaching parts for EA3.83.195 and 197:	2	LFS26	GA12/5
AS1242/13C	. . Bolt, 2BA	2	—	GA12/6
AGS2002C1	. . Nut, 2BA	2	—	GA12/7
SP13C	. . Washer, 2BA	2	—	GA12/8
EB7.83.5359	. . PLATE, stop, assembly Attaching parts for EG5.83.47:	1	—	GA12/9
A25/4C	. . Bolt, 2BA	6	—	GA12/10
AGS2002C1	. . Nut, 2BA	6	—	GA12/11
SP13C	. . Washer, 2BA	6	—	GA12/12
EA3.82.205	. . SPRING, compression	1	DTD215	GA12/13
EA2.83.6067	. . SUNBLIND, PILOT'S, ASSEMBLY Spares for:	1	—	GA12/14
EG5.83.51	. . . BRACKET, stop, port	1	—	GA12/15
EG5.83.53	. . . BRACKET, stop, starboard	1	—	GA12/16
EB7.83.7375	. . . COVER, sunblind	1	—	GA12/17
EA2.83.6079	. . . FRAME, flexible	1	—	GA12/18
EA2.83.6075	. . . FRAME, INNER, ASSEMBLY Spares for:	1	—	GA12/19
EA2.83.6071 FRAME, inner member	1	L65	GA12/20
EA2.83.6073 FRAME, wire	1	DTD215	GA12/21
EG5.83.33 SOCKET, frame, port	1	—	GA12/22
EG5.83.35 SOCKET, frame, starboard	1	—	GA12/23

R

AP101B-0402-3A

Page GA.33

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EG5.83.63	HANDLE, control	1	—	GA12/24
EG5.83.45	LEVER, assembly, compression spring	1	—	GA12/25
EG5.83.41	SHAFT, inner	1	—	GA12/26
EA2.83.6077	SOCKET, outer frame, port	1	—	GA12/27
EG5.83.39	SOCKET, outer frame, starboard	1	—	GA12/28
EA2.83.6069	STAY, outer, port	1	L65	GA12/29
EB7.83.5357	STAY, outer, starboard	1	L65	GA12/30
EA3.83.211	STIFFENER, 3.7" x 7/16" x 1/16" thick	2	Wovellon	GA12/31
EA3.83.213	STIFFENER, 2.8" x 7/16" x 1/16" thick	2	Wovellon	GA12/32
EA3.83.215	STIFFENER, 2.6" x 7/16" x 1/16" thick	2	Wovellon	GA12/33
EG5.83.43	TUBE, bearing	1	—	GA12/34
EA3.83.201	TUBE, spring, housing	1	—	GA12/35
EA3.83.203	TUBE, spring, housing	1	—	GA12/36
	Attaching parts for EA3.83.201 and 203:			
AGS899/1	Collar	1	—	GA12/37
SP4Y/A4	Pin, shackle	1	—	GA12/38
SP90C4	Pin, split	1	—	GA12/39
31709	SWITCH, FUEL TANK JETTISON, REPOSITIONED (SRIM.3577) (MOD.4937) Spares for:	—	—	
	COVER, spring	1	—	
AGS1765/2	SWITCH, push	1	—	
DO523	TRANSFER	1	—	
5K4329557	WALL, STARBOARD, INSTALLATION (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.7021	WALL, STARBOARD, INSTALLATION (MOD.5204) Spares for:	—	—	
EA3.80.8021	AMPLIFIER, type B, G4B compass	1	—	GA28/2
6B4343641	BRACKET, mounting assembly, warning horn	1	—	GA28/3
EA3.80.1035	BRACKET, assembly, inverter mounting, type 100B (Appendix D and E, C/Mod/Con/43) (Mod.4937)	1	—	GA28/4
EA3.80.929	FLOOR, assembly, second navigator	1	—	
6A1046812	HOLDER, escape drill card (C/Mod/Con/0328/STC) (Mod.5180)	1	—	
EA3.80.7023	MOUNTING PLATE FOR BURCOSTAT AND BLANKING PLATES, INSTALLATION (MOD.4937) (PRE MOD.5204)	—	—	
EA3.80.8039	MOUNTING BRACKET FOR BURCOSTAT AND BLANKING PLATE, INSTALLATION (MOD.5204) Spares for:	—	—	GA28/5
22943	BRACKET, mounting, for burcostat, 18 SWG (SRIM.3867 or 3868) (Mod.5204)	1	L72	GA28/6
	Attaching parts for 22943:			
AS1248/3C	Bolt, 2BA	10	—	GA28/7
31907	PANEL, blanking (SRIM.3577) (Mod.4937) Attaching parts for 31907:	1	L72	GA28/8
AS1248/3C	Bolt, 2BA	6	—	GA28/9
	PLATE, mounting for burcostat (C/Mod/0539/STC, Fig.9) (Mod.5180) (Pre Mod.5204) Attaching parts for plate:	1	—	
AS1248/3C	Bolt, 2BA	9	—	

R
R

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
31932		TRAY (SRIM.3577) (Mod.4937) Attaching parts for 31932:	1	L72	GA28/10
AS1242/6B		Bolt, 4BA	4	—	GA28/11
AGS2001B1		Nut, 4BA	4	—	GA28/12
WT33047/C7		Washer, check	8	—	GA28/13
EA3.81.6395		SWITCH, NAVIGATOR'S HATCH, DETONATOR, ASSEMBLY Spares for:	1	—	GA28/14
EA3.81.6519		FLAP, SPRING, ASSEMBLY, L.H. SWITCH Spares for:	1	—	GA28/15
EA3.81.6513		FLAP (5CW5514, modified)	1	—	GA28/16
EA4.81.1663		FLAP, support	1	—	GA28/17
EA4.81.1659		PIN	1	—	GA28/18
EA4.81.1661		SPRING	1	—	GA28/19
EA3.81.6517		FLAP, assembly, for R.H. switch	1	—	GA28/20
EA6.81.369		PIN, hinge, for R.H. switch flap	1	DTD683	GA28/21
EA1.81.929		SPRING, torsion, for R.H. switch flap	1	—	GA28/22
EA3.81.6497		SWITCH, unit, sub-assembly	1	—	GA28/23
DOWTY					
AS10512C-1		SWITCH, D.P.	2	—	GA28/24
DP1002A		WASHER, locking Attaching parts for EA3.81.6395:	8	—	GA28/25
EA3.81.6515		Packing	1	—	GA28/26
A32A17		Screw, 6BA	4	—	GA28/27
SP13A		Washer	4	—	GA28/28
15390/014		TRAY, mounting, G4B, amplifier Attaching parts for 15390/014:	1	—	GA28/29
AS1248/1E		Bolt, 1/2" BSF	4	—	GA28/30
SP13E		Washer	4	—	GA28/31
EA3.80.2007		EQUIPMENT IN PRESSURE CABIN, ASSEMBLY (PRE MOD.4937) Spares for:	—	—	
EA3.80.6473		ACCELEROMETER INSTALLATION (MOD.4158) Spares for:	—	—	
6A4695406		ACCELEROMETER, Mk.2 Attaching parts for Ref.6A/4695406:	1	—	
A43B32		Screw, 4BA	3	—	
EA3.80.6465		BRACKET, mounting Attaching parts for EA3.80.6465:	1	L59	
AGS2001B4		Nut, 4BA	6	—	
A43B16		Screw, 4BA	6	—	
SP22B		Washer	6	—	
EA3.80.6469		BRACKET, L.H., coaming tube	1	BS267	
EA3.80.6471		BRACKET, R.H., coaming tube	1	BS267	
EA3.83.95		BALLAST, UNDER BOMB AIMER'S RAMP, ASSEMBLY For spares breakdown see Page GA.1	—	—	

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
—	. BALLAST, ADDITIONAL, UNDER CHEST PLATFORM (EA3.84.5635) (MOD.3723-S.O.O.) Spares for:	—	—	
EA3.84.5659	. . . TRAY, BALLAST, ASSEMBLY Spares for:	—	—	
EB6.97.507	. . . BRACKET	1	—	
EB6.10.319	. . . SPIGOT	1	S92	
EB6.10.320	. . . SPIGOT Attaching parts for EB6.10.319 and EB6.10.320:	1	S92	
AS1242/1C	. . . Bolt, 2BA	2	—	
AS1242/7C	. . . Bolt, 2BA	1	—	
AGS2001C1/66	. . . Nut, 2BA	3	—	
EA3.84.5661	. . . TRAY, ballast, engraved	1	—	
EA3.84.5645	. . . WEIGHT, ballast	1	—	
EA3.84.5647	. . . WEIGHT, ballast	2	—	
EA3.84.5649	. . . WEIGHT, ballast Attaching parts for EA3.84.5645, EA3.84.5647 and EA3.84.5649:	1	—	
A59/32E	. . . Bolt, 1/4" BSF	3	—	
A59/38E	. . . Bolt, 1/4" BSF	3	—	
EA3.84.5665	. . . Strap	2	S510	
SP13E	. . . Washer	6	—	
SP16E	. . . Washer	4	—	
EA3.80.1839	. BRACKET, support, accumulator	1	—	
EA3.80.875	. CONSOLE, PILOT'S ASSEMBLY Spares for:	—	—	
EA3.81.1563	. . . PANEL, PILOT'S CONSOLE, EQUIPMENT AND WIRING ASSEMBLY Spares for:	1	—	
5CW4400976	. . . BAR, switch coupling	1	—	
EA2.81.359	. . . BRACKET, plug Attaching parts for EA2.81.359:	1	—	
AGS2001B1	. . . Nut, 4BA	6	—	
A32B12	. . . Screw, 4BA	6	—	
EA3.81.2083	. . . BRACKET, switch, bomb doors Attaching parts for EA3.81.2083:	1	—	
AGS2001A1	. . . Nut, 6BA	2	—	
A32A16	. . . Screw, 6BA	2	—	
EA3.81.1379	. . . BLOCK, fuse assembly (Make from Ref.5X/4491411)	1	—	
EA3.81.1381	. . . BLOCK, fuse, assembly	1	—	
EA3.81.6547	. . . CABLE, assembly, N49D, from jettison switch unit to snatch unit terminal block	1	—	
EA2.81.5907	. . . CABLE, assembly, earth rudder trim switch (Mod 4229)	1	—	
R Uninyvin 12	. . . CABLE, Uninyvin 12	AR	BSG177	
R Uninyvin 16	. . . CABLE, Uninyvin 16	AR	BSG177	
R Uninyvin 20	. . . CABLE, Uninyvin 20	AR	BSG177	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
AGS1600A	. . .	CABLE, end, eye	5	—	
HV3711	. . .	CAP, dolly	7	—	
EA1.81.542	. . .	CARRIER, spare fuse	1	—	
		Attaching parts for EA1.81.542:			
AGS2001A1	. . .	Nut, 6BA	2	—	
A32A16	. . .	Screw, 6BA	2	—	
EA3.04.15147	. . .	COVER, assembly (Mod.3796-S.O.O.)	1	—	
EA3.81.375	. . .	COVER, fuse, compartment	1	—	
		Attaching parts for EA3.81.375:			
ODDIE					
213	. . .	Stud	2	—	
214	. . .	Washer	2	—	
EA3.81.377	. . .	COVER, SPRING, BOMB JETTISON SWITCH (PRE MOD.5081)	1	—	
		Spares for:			
EA3.81.383	. . .	SPRING, tension	1	DTD215	
5K9573173	. . .	COVER, spring, fuel tank jettison switch	1	—	
THORN. L1114	. . .	FILAMENT, 2V, 3.5W	1	—	
AS5	. . .	FUSE, type S, 5 amp	6	—	
TDA-62-10A	. . .	FUSE, type S, 10 amp	8	—	
AS20	. . .	FUSE, type S, 20 amp	2	—	
Z1719	. . .	GROMMET	4	—	
Z1840	. . .	GROMMET	1	—	
HV2420A	. . .	GROMMET, dummy	2	—	
EA3.81.787	. . .	KNOB, switch, aileron trim	1	DTD683	
		Attaching parts for EA3.81.787:			
EA3.81.1089	. . .	Screw, grub	1	S1	
or					
A55A4	. . .	Screw, grub	1	—	
EA3.81.2077	. . .	KNOB, switch, bomb doors	1	—	
		Attaching parts for EA3.81.2077:			
A31B28	. . .	Screw, 4BA	1	—	
H2702 RED	. . .	LAMP, warning, red	1	—	
EEAS71/3	. . .	LINK, connecting	2	—	
EA3.80.673	. . .	PANEL, console, bare	1	—	
EA3.04.15143	. . .	PANEL, mounting, assembly (Mod.3796-S.O.O.)	1	—	
		Attaching parts for EA3.04.15143:			
AS1248/1B	. . .	Bolt, 4BA	6	—	
508-1-06394	. . .	PLUG, 4 way	2	—	
508-1-06399	. . .	PLUG, 9 way	1	—	
508-1-06413	. . .	PLUG, 26 way	2	—	
508-2-11232-002	. . .	SLEEVE	21	—	
EEAS146/6	. . .	SLEEVE	10	—	
EEAS146/16	. . .	SLEEVE	70	—	
HV3254	. . .	STRAP (Mod.4229)	AR	—	
NY3255	. . .	STUD (Mod.4229)	12	—	
XD779	. . .	SWITCH	1	—	
		Attaching parts for XD779:			
A32B12	. . .	Screw, 4BA	2	—	
EEAS28/2HP	. . .	Washer, packing	2	L16	

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.81.2071	. . .	SWITCH, BOMB DOORS (PRE MOD.3728)	1	—	
EA3.81.5851	. . .	SWITCH, BOMB DOORS (MOD.3728)	1	—	
		For spares breakdown see Page GA.4			
		Attaching parts for EA3.81.2071 or EA3.81.5851:			
A31B12	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer, shakeproof	4	—	
EEAS28/2FP	. . .	Washer, spring	4	L16	
R D2710	. . .	SWITCH	1	—	
R XD777	. . .	SWITCH (Mod.4003)	1	—	
		Attaching parts for D2710 and XD777:			
A32B8	. . .	Screw, 4BA	2	—	
SP47B	. . .	Washer	2	—	
EA3.81.6375	. . .	SWITCH, ASSEMBLY, RUDDER TRIM (MOD.4229)	1	—	
		Spares for:			
EA4.81.6801	. . .	KNOB, switch	2	—	
C.W.C.					
EQUIPMENT	. . .	SWITCH, special (XD787 with modified dolly XD827)	1	—	
THOS. HADDON & STOKES					
DP1003	. . .	WASHER, crinkle, 4BA	6	—	
		Attaching parts for EA3.81.6375:			
A32B10	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer	4	—	
SIS3629	. . .	SWITCH	8	—	
		Attaching parts for SIS3629:			
AGS2001A1	. . .	Nut, 6BA	2	—	
A32A16	. . .	Screw, 6BA	2	—	
R SIS3630	. . .	SWITCH	1	—	
D0523	. . .	SWITCH	2	—	
		Attaching parts for SIS3630 and D0523:			
AGS2001A1	. . .	Nut, 6BA	4	—	
A32A16	. . .	Screw, 6BA	4	—	
R D10001 TYPE 8B No.1	. . .	SWITCH	3	—	
		Attaching parts for D10001 TYPE 8B No1			
A32B8	. . .	Screw, 4BA	4	—	
SP47B	. . .	Washer	4	—	
R HC1187RH	. . .	TAG (Mod.4229)	1	—	
HC490	. . .	TAG	3	—	
HC500	. . .	TAG	4	—	
HC510	. . .	TAG	5	—	
R WTD140835	. . .	UNIT, control type 7681 (Mod.3796-S.O.O.)	1	—	
		Attaching parts for WTD140835			
AS1246/1B	. . .	Bolt, 4BA	4	—	
SP15B	. . .	Washer	4	—	
		Attaching parts for EA3.81.1563:			
AS1248/1C	. . .	Bolt, 2BA	17	—	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.	
					1
EA3.81.3083	. . . PANEL, PILOT'S CONSOLE EQUIPMENT AND WIRING ASSEMBLY (MOD.3352-S.O.O. WITH MOD.3428-S.O.O.) Spares for this assembly are identical with those for assembly Part No. EA3.81.1563 on Page GA40, except for the following additions: Add:	1	—		
Unitersil 20 CABLE, Unitersil 20	AR	BSG189		
TD.A62-5A FUSE, 5 amp	1	—		
10H2071369 HOLDER, fuse	1	—		
508-2-11232-002 SLEEVE	1	—		
EEAS146/20 SLEEVE	6	—		
XD778 SWITCH	1	—		
A32B12 Screw, 4BA	2	—		
AGS2035B Washer	2	—		
HC294 TAG	3	—		
HC490 TAG	1	—		
EA3.80.669	. . . STRUCTURE, PILOT'S CONSOLE ASSEMBLY For spares breakdown see Page GA.4	—	—		
41008	. . . CONSOLE, NAVIGATOR'S, ASSEMBLY (SRIM.3479) (MOD.4868-S.O.O.) For Aircraft WJ637 and WJ731 Spares for:	—	—		
40980	. . . TABLE, NAVIGATOR'S, ASSEMBLY Spares for:	—	—		
22020 CATCH, SUB-ASSEMBLY FOR RAISED POSITION OF FOLDING TABLE Spares for:	1	—		
1A11668 SPRING, compression	1	—		
40979 TABLE, FOLDING SUB-ASSEMBLY Spares for:	1	—		
13780 PIN, table rest	1	—		
EA3.80.2057	. . . CONTAINER, URINE, ASSEMBLY Spares for:	1	—		
HX11761	. . . CONTAINER, Mk.2	1	—		
E20001	. . . FUNNEL	1	—		
EB7.80.327	. . . CURTAIN, BLACK-OUT, ASSEMBLY (MOD.1413) For spares breakdown see Page GA.5	—	—		
EA3.85.15	. . . DESTRUCTOR, MOUNTING, ASSEMBLY For spares breakdown see Page GA.6	1	—		
EA3.80.2009	. . . EQUIPMENT IN NAVIGATOR'S COMPARTMENT, ASSEMBLY Spares for:	—	—		
EB7.80.723	. . . BRACKET, FILTER MOUNTING, INSTALLATION (PRE MOD.861) Spares for:	—	—		
EB7.80.725 BRACKET, mounting, assembly Attaching parts for EB7.80.725:	1	—		
A25/1B Bolt, 4BA	4	—		
EB7.80.815	. . . BRACKET, FILTER MOUNTING, INSTALLATION (MOD.861) Spares for:	—	—		
EB7.80.817 BRACKET, mounting Attaching parts for EB7.80.817:	1	—		
A25/1B Bolt, 4BA	4	—		

R

AP101B-0402-3A

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.	
					1
EB7.80.807	BRACKET, support	1	—		
A25/1B	Attaching parts for EB7.80.807: Bolt, 4BA	2	—		
EB7.80.811	BRACKET, support	1	—		
A25/1B	Attaching parts for EB7.80.811: Bolt, 4BA	2	—		
EA3.80.2025	EQUIPMENT FORWARD OF TABLE	1	—		
EEAS143/8	Spares for: CLIP, 'P'	1	—		
A25/1B	Attaching parts for EEAS143/8: Bolt, 4BA	1	—		
AGS2001B1	Nut, 4BA	1	—		
SP15B	Washer	1	—		
Z10129	DRIVE, flexible, for A.P.I. repeater unit	1	—		
EEAS132/7	STRAP, cable	2	—		
AS1248/2B	Attaching parts for EEAS132/7: Bolt, 4BA	2	—		
AGS2001B1	Nut, 4BA	2	—		
EEAS73	Plate, clamp	2	—		
SP15B	Washer	2	—		
IN8501	UNIT, repeater, for A.P.I.	1	—		
A25/1C	Attaching parts for IN8501: Bolt, 2BA	3	—		
AGS2001C1/66	Nut, 2BA	3	—		
EA3.80.49	FRAME, receiver, assembly	1	—		
AGS2001E1/77	Attaching parts for EA3.80.49: Nut, 1/4" BSF	4	—		
EA3.80.133	Washer, special	4	—		
EA3.80.2017	INDICATOR, GEE-H AND CONTROL CABLE, ASSEMBLY (PRE MOD.4868)	1	—		
EA3.80.2461	Spares for: BOLT, special	2	—		
EA3.80.2463	CLAMP, toggle assembly	2	—		
A. WELLS CO. H.D.F.M.35	MOUNTING, Equiflex	4	—		
AGS2001J1	Attaching parts for H.D.F.M. 35: Nut, 3/8" BSF	2	—		
SP15J	Washer	2	—		
EA3.80.107	NUT, knurled	2	—		
159/3	MOUNTING, for drive unit, assembly (Pre Mod.4868)	1	—		
A25/10E	Attaching parts for 159/3: Bolt, 1/4" BSF	4	—		
AGS2001E1/77	Nut, 1/4" BSF	4	—		
EA3.80.1323	Washer, special	4	—		
375B2	MOUNTING, for Gee-H transmitter unit, assembly (Pre Mod.1282)	1	—		
A25/1E	Attaching parts for 375/B2: Bolt, 1/4" BSF	16	—		
AGS2001E1/77	Nut, 1/4" BSF	16	—		
EA3.80.411	Washer, special	4	—		

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EA3.80.2023		MOUNTING, A.M.U. CONTROLLER, ASSEMBLY (PRE MOD.4868) Spares for:	1	—	
6B6361962		CONTROL, A.M.U. Mk.4 Attaching parts for Ref.6B/6361962:	1	—	
AS1248/1/4B		Bolt, 4BA	4	—	
EA3.80.2685		MOUNTING, R.F. UNIT, INSTALLATION Spares for:	1	—	
EA3.80.2709		BRACKET, assembly (Pre Mod.4868) Attaching parts for EA3.80.2709:	4	—	
A25/1C		Bolt, 2BA	4	—	
SP13C		Washer	4	—	
EA3.80.2687		MOUNTING, assembly (Pre Mod.4868)	1	—	
EA3.80.6637		PANEL, NAVIGATOR'S INSTRUMENT, ASSEMBLY (MOD.4859) (Ref. Dwgs. EB6.80.5937 and EA3.80.6623) Spares for:	—	—	
KOLLSMAN L83261-04-010		ALTIMETER, Mk.30A (Mod.4859) Attaching parts for L83261-04-010:	1	—	
KOLLSMAN L84380-00-100		Plate, mooring (Mod.4859)	1	—	
A219B36		Screw, 6UNC	4	—	
EA3.80.551		BRACKET, attachment of panel to frame 5 Attaching parts for EA3.80.551:	1	—	
A25/7E		Bolt, 1/4" BSF	1	—	
AGS2001E3		Nut, 1/4" BSF	1	—	
EA3.80.2325		CLIP, assembly	1	—	
EA3.80.2327		CLIP, assembly Attaching parts for EA3.80.2325 and EA3.80.2327:	1	—	
A25/10C		Bolt, 2BA	2	—	
AGS2001C1/66		Nut, 2BA	2	—	
SP13C		Washer	2	—	
6B6341552		COMPASS, indicator, gyro-magnetic, G4B Attaching parts for Ref.6B/6341552:	1	—	
AGS2001C3		Nut, 2BA	3	—	
A40C32		Screw, 2BA	3	—	
5L9959118		FILAMENT (Mod.4859)	2	—	
MRI-1AP-274		HOLDER, deviation card, Mk.4	1	—	
6B6349775		INDICATOR, air position, Mk.1B Attaching parts for Ref.6B/6349775	1	—	
AS4565/9E		Bolt, 1/4" BSF	2	—	
AS4565/31E		Bolt, 1/4" BSF	1	—	
AGS2001E3		Nut, 1/4" BSF	3	—	
SP15E		Washer	3	—	
6A4337742		INDICATOR, air speed, Mk.9HP Attaching parts for Ref.6A/4337742	1	—	
AS4565/1C		Bolt, 2BA	2	—	
AGS2001C3		Nut, 2BA	2	—	

AP101B-0402-3A		EQUIPMENT AIRCRAFT			PRESSURE CABIN EQUIPMENT					
Part Number	Description	No. Off	Matl. Spec.	Plate No.						
					1	2	3	4	5	6
5CZ1031243	INDICATOR, electro-magnetic	1	—							
10QB4698523	INDICATOR, unit type 208	1	—							
A40B12	Attaching parts for Ref. 10QB4698523: Screw, 4BA	2	—							
80/10/0678	LAMP, pillar, red (Mod.4859)	2	—							
EA3.80.6599	PANEL, NAVIGATOR'S INSTRUMENT, SUB- ASSEMBLY (MOD.4859) (Ref. Dwg. EA3.80.2301) Spares for:	1	—							
EA3.80.2333	BRACKET, mounting, for altimeter	1	—							
EA3.80.2305	BRACKET, mounting, for A.P.I. Attaching parts for EA3.80.2305:	1	—							
AS1246/1C	Bolt, 2BA	7	—							
AGS2001C1/66	Nut, 2BA	7	—							
SP15C	Washer	7	—							
EA3.80.533	BRACKET, attachment	1	—							
EA3.80.2309	BRACKET, mounting, for cathode ray tube	1	—							
EA3.80.2313	BRACKET, mounting, for G4B compass	1	—							
WELLS & CO. M.D.S.M.10	MOUNTING, Equiflex	4	—							
CARR 882	STUD	2	—							
EA3.80.6559	PLATE, adaptor, altimeter, 10SWG (Mod.4859) (For aircraft embodying SRIM.3479)	1	L73							
EA3.80.6593	PLATE, adaptor, altimeter, 10SWG (Mod.4859) (For aircraft embodying SRIMS.3577 and 3676) Attaching parts for EA3.80.6593:	1	L73							
AS1242/1C	Bolt, 2BA	4	—							
EA3.80.6595	PLATE, blanking, 18 SWG (Mod.4859) (For aircraft embodying SRIMS.3577 and 3676) Attaching parts for EA3.80.6595:	1	L72							
AS1248/1B	Bolt, 4BA	4	—							
AGS2001B1	Nut, 4BA	4	—							
6A1037475	THERMOMETER, air temperature, S63/112, Form 4 Attaching parts for Ref.6A/1037475	1	—							
A44B16	Screw, 4BA Attaching parts for EA3.80.6637:	2	—							
A25/7E	Bolt, 1/4" BSF	1	—							
A25/9E	Bolt, 1/4" BSF	1	—							
A25/10E	Bolt, 1/4" BSF	1	—							
A25/11E	Bolt, 1/4" BSF	1	—							
AGS2001E3	Nut, 1/4" BSF	1	—							
AGS2002E1-66	Nut, 1/4" BSF	3	—							
EA3.80.2331	Piece, distance	4	—							
SP16E	Washer	1	—							
EA3.80.2013	TABLE, NAVIGATOR'S, ASSEMBLY (PRE MOD.4868) Spares for:	1	—							
EA3.80.2119	EYE-BOLT	1	—							
EA3.80.2173	TABLE, folding, section Attaching parts for EA3.80.2173:	1	—							
EA3.80.2133	Bolt, pivot	2	—							
AGS2001C1/66	Nut, 2BA	2	—							
AS2808/5/012	Piece, distance	2	T35							
EEAS28/36CU	Washer	2	—							

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EB7.80.685	. . . TRAY, MOUNTING, TRANSMITTER, GEE-H, ASSEMBLY (MOD.1282) Spares for:	1	—	
WELLS & CO. H.D.P.M.15	. . . MOUNTING, Equiflex	4	—	
EB7.80.705	. . . NUT, knurled Attaching parts for EB7.80.685:	2	—	
A25/12J	. . . Bolt	4	—	
A27JP	. . . Nut, 3/8" BSF	4	—	
SP13J	. . . Washer	4	—	
EA3.80.647	. . . WASHER, special	1	—	
EA3.80.651	. . . WASHER, special	2	—	
EEAS28/2CP	. . . WASHER	2	L16	
EA3.80.2741	. . . EQUIPMENT, BOMB AIMER'S, ASSEMBLY Spares for:	—	—	
EA3.80.1035	. . . BRACKET, mounting, assembly	1	—	
EA3.80.929	. . . FLOOR, assembly, bomb aimer's	1	—	
EA3.10.2799	. . . RAMP, for strobe unit	1	—	
EA3.81.6395	. . . SWITCH, HATCH, DETONATOR, ASSEMBLY (MOD.3960) For spares breakdown see Page GA.37	1	—	
EA3.82.9	. . . TRAY, mounting, strobe unit	1	—	
EEAS28/2CP	. . . WASHER, special	1	L16	
EA3.80.2619	. . . E2A, COMPASS, ASSEMBLY For spares breakdown see Page GA.2	1	—	
EA3.80.899	. . . EXTINGUISHER, FIRE, STARBOARD SIDE, ASSEMBLY For spares breakdown see Page GA.13	—	—	
EA3.83.179	. . . FLAP, SWITCH AND UNDERCARRIAGE SWITCH, LOCK, STOWAGE, ASSEMBLY (MOD.1724) Spares for:	1	—	
EA3.83.173	. . . BAG, stowage, for flap switch locking pin (Pre Mod.5081)	1	—	
EA3.83.295	. . . BAG, stowage, for undercarriage switch locking pin	1	—	
EA3.83.175	. . . LOCK, FLAP SWITCH, ASSEMBLY Spares for:	1	—	
AVIATION DEVELOPMENTS A415	. . . PIN, 'pip', quick release	1	—	
EA3.83.299	. . . LOCK, undercarriage switch	1	—	
EA3.80.1989	. . . HANDLE, EMERGENCY HYDRAULIC PUMP, ASSEMBLY For spares breakdown see Page GA.13	1	—	
EA3.80.901	. . . MOUNTING, FIRE-AXE, ASSEMBLY For spares breakdown see Page GA.13	1	—	
EA3.80.1833	. . . MOUNTING, FIRST AID CONTAINER, ASSEMBLY For spares breakdown see Page GA.14	1	—	
EA3.80.317	. . . PANELS, INSTRUMENT, ASSEMBLY Spares for:	—	—	
27H/4605579	. . . MOUNTING, anti-vibration, rubber, 4 lbs (light duty)	6	—	
27H/4605574	. . . MOUNTING, anti-vibration, rubber, 12lbs (medium duty)	6	—	

AP101B-0402-3A		EQUIPMENT AIRCRAFT			Page GA.43			
PRESSURE CABIN EQUIPMENT								
Part Number	Description					No. Off	Matl. Spec.	Plate No.
	1	2	3	4	5			
EA3.80.6635	PANEL, FLYING, ASSEMBLY (MOD 4859) (EA3.80.6155 and EA3.80.2931) Spares for:—	—	—	
KOLLSMAN L82621-04-010	ALTIMETER, Mk. 29B (Mod 4859) Attaching parts for L82621-04-010:—	1	—	
KOLLSMAN L84380-00-100 A219B36	Plate, mooring Screw, 6UNC	1 4	— —	
WB1110S2B EA3.80.361	BLOCK, terminal (Mod 3922) BRACKET, shock absorber Attaching parts for EA3.80.361:—	1 1	— L72	
A25/1B AGS2001B4 SP15B	Bolt, 4BA Nut, 4BA Washer	4 4 4	— — —	
EA3.80.357 EA3.80.359	BRACKET, shock absorber BRACKET, shock absorber Attaching parts for EA3.80.357 and EA3.80.359:—	1 1	L72 L72	
A25/1B AGS2001B4 SP15B	Bolt, 4BA Nut, 4BA Washer	6 6 6	— — —	
SIS2802 or 4B	CLOCK, Mk. 4 CLOCK, Mk. 4B	1 1	— —	
SMITH CHX2104	CLOCK, Mk. 5 Attaching parts for CHX2104	1	—	
A44B24	Screw, 4BA	4	—	
16382-0 A44C24	COMPASS, Gyro Unit Attaching parts for 16382-0 Screw, 2BA	1 4	— —	
WB1110/2 A259 SP93C6	COVER, terminal block (Mod 3922) FILAMENT, for bridge lamp GROMMET	1 2 2	— — —	
ZA2401-1 18846-0	GUARD, switch HORIZON, artificial	1 1	— —	
SMITH 430FL 9M	INDICATOR, aileron trim INDICATOR, air speed, Mk. 9M Attaching parts for 9M:—	1 1	— —	
AGS2001C4 A44C40 AS2809/5/070	Nut, 4BA Screw, 2BA Tube, distance	4 4 4	— — L62	
DN1245Z-MK1 DN1245 MK14 SMITH 218FL	INDICATOR, electro-magnetic, 24 volt, type A2 INDICATOR, electro-magnetic, 24 volt, type C1 INDICATOR, flap position	1 1 1	— — —	
KRA1001K or KAB2004	INDICATOR, rate of climb, Mk. 3Q INDICATOR, rate of climb, Mk. 3P	1 1	— —	

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

Part Number	1 2 3 4 5 6	Description	No. Off	Mati. Spec.	Plate No.
SMITH 431FL	. . .	INDICATOR, rudder trim	1	—	
EA3.90.26/1	. . .	INDICATOR, special, pilot's (GEE-H)	1	—	
SMITH 813FL	. . .	INDICATOR, tail trim	1	—	
R 2A	. . .	INDICATOR, turn and slip, Mk. 2A	1	—	
80/10/1192	. . .	LAMP, bridge, type C (Mod 3922)	1	—	
A114/4B or	. . .	Attaching parts for 80/10/1192:— Bolt, 6-32 UNC	2	—	
A44B36	. . .	Screw, 4BA	2	—	
R MI684	. . .	MACHMETER, Mk. 2	1	—	
EA3.80.6639	. . .	PANEL, SUB-ASSEMBLY (MOD 4859) Spares for:—	1	—	
EA3.80.6557	. . .	PLATE, adaptor, 10 SWG	1	L73	
EB6.81.5349	. . .	PILLAR, fixing, terminal block (Mod 3922)	2	—	
R XD778	. . .	SWITCH, type D5406	1	—	
EA3.80.329	. . .	PANEL, FIXED, STARBOARD, ASSEMBLY (WITHOUT MOD 5, MOD 3905 AND MOD 4135) Spares for:—	—	—	
R 6A/4333072	. . .	ALTIMETER, cabin, Mk. 18 Attaching parts for Ref. 6A/4333072:—	1	—	
A44B20	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer	4	—	
R 1240	. . .	BLOCK, terminal, type B, 2 way Attaching parts for 1240:—	2	—	
R AGS2002A4	. . .	Nut, 6BA	2	—	
A45A32	. . .	Screw, 6BA	2	—	
R UNINYVIN	. . .	CABLE, Uninyvin 20	AR	—	
R AGS1765-2	. . .	COVER, push button, switch	2	—	
R L1034	. . .	FILAMENT, lamp, 28 volt, 3.5 watt	2	—	
R 6A/2237916	. . .	GAUGE, hydraulic pressure, Mk. 14LL Attaching parts for Ref. 6A/2237916:—	2	—	
A44B20	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer	4	—	
R ZA2401-1	. . .	GUARD, locking	1	—	
DN1320Z2	. . .	GROMMET (Mod 4939)	1	—	
SMITH 289FL	. . .	INDICATOR, air mixer valve Attaching parts for 289FL:—	1	—	
A44B20	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer	4	—	
EA3.81.437	. . .	LABEL, 'cold and hot'	1	L72	
R H2702	. . .	LAMP, type H2702, red	2	—	
EA3.80.323	. . .	PANEL, fixed (Pre-Mod 292)	1	L72	
EA3.80.1919	. . .	PANEL, fixed (Mod 292)	1	L72	
AS10512L2	. . .	PLATE, adaptor (Mod 4939)	1	—	
508-1-06399	. . .	PLUG, size B, 9-way	1	—	
508-1-06406	. . .	PLUG, size C, 14-way	1	—	
ROTAX N64799/2	. . .	SWITCH, toggle D5403 Attaching parts for N64799/2:—	1	—	
A32B12	. . .	Screw, 4BA	4	—	
AGS2035B	. . .	Washer	4	—	

AP101B-0402-3A

Page GA.45

EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT

	Part Number	Description	No. Off	Matl. Spec.	Plate No.
R	D0523	. . . SWITCH, push button, type B	2	—	
R	A44B12	. . . Attaching parts for D0523:	4	—	
	AGS2035B	. . . Screw, 4BA	4	—	
		. . . Washer	4	—	
R	XD779	. . . SWITCH, S.P. (Pre Mod.4939)	1	—	
	A32A12	. . . Attaching parts for XD779:	2	—	
	AGS2035A	. . . Screw, 6BA	2	—	
		. . . Washer	2	—	
	DN1320ZIC-4	. . . SWITCH, toggle D.P. (Mod.4939)	1	—	
	AS10512.M2	. . . TERMINAL, shroud (Mod.4939)	1	—	
	EA3.80.6157	. . . PANEL, FIXED, STARBOARD, INSTRUMENT, ASSEMBLY (MOD.4135 WITH MOD.5- S.O.O. AND MOD.3905-S.O.O.)	1	—	
	6A/4333072	. . . Spares for: ALTIMETER, Mk.18	1	—	
	A44B24	. . . Attaching parts for Ref.6A/4333072:	4	—	
	AGS2037B	. . . Screw, 4BA	4	—	
		. . . Washer, shakeproof	4	—	
	703-1-00238	. . . BLOCK, terminal, 5 way	1	—	
	A44B32	. . . Attaching parts for 703-1-00238:	2	—	
	EB6.80.615	. . . Screw, 4BA	2	—	
	AGS2037B	. . . Spacer, threaded	2	—	
		. . . Washer, shakeproof	2	—	
R	Unifersil 20	. . . CABLE, Unifersil 20	AR	BSG189	
	HV3711	. . . CAP, Helvin	1	—	
	508-1-07776-003	. . . CLAMP, cable	1	—	
	32A/0119481	. . . CORD, nylon covered	AR	—	
R	AGS1765/2	. . . COVER, spring, fire button switch	2	—	
R	THORN. L1114	. . . FILAMENT (Pre Mod.5180)	2	—	
	5L/9951284	. . . FILAMENT (SEM/Can/039/STC) (Mod.5180)	2	—	
	EA4.81.1687	. . . FLAP, spring, assembly	1	—	
	508-2-07705-200	. . . GASKET, outlet	1	—	
	508-2-07719-200	. . . GASKET, union	1	—	
R	10069 N & Z	. . . GAUGE, pressure	2	—	
	or				
R	SIS 3592	. . . GAUGE, pressure, Mk.14LL			
	AGS2002C4	. . . Attaching parts for SIS3592:	4	—	
	6A2710	. . . Nut, 2BA (Pre Mod.292)	1	—	
	A44B24	. . . Plate, mask	4	—	
	A44C40	. . . Screw, 4BA (Post Mod.292)	4	—	
	AS2811/5/065	. . . Screw, 2BA (Pre Mod.292)	4	—	
	AGS2037B	. . . Tube, distance (Pre Mod.292)	4	L62	
		. . . Washer, shakeproof	4	—	
R	6D/2244063	. . . GAUGE, pressure, oxygen	2	—	
	A44B24	. . . Attaching parts for Ref.6D/2244063:	4	—	
	AGS2037B	. . . Screw, 4BA	4	—	
		. . . Washer, shakeproof	4	—	
	DN1320Z2	. . . GROMMET (Mod.4939)	1	—	
	6A/4333073	. . . INDICATOR, air mixer valve	1	—	
	A44B24	. . . Attaching parts for Ref.6A/4333073:	4	—	
	AGS2037B	. . . Screw, 4BA	4	—	
		. . . Washer, shakeproof	4	—	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

