

FLYING CONTROLS IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.45.385	CONTROLS, FLYING IN REAR FUSELAGE, ASSEMBLY Spares for:	—	—	
EA1.45.601	. LEVERS, CONTROL AND MOUNTING OF BRACKETS AT FRAME 42, ASSEMBLY Spares for:	1	—	
EA1.45.1193	. . LEVER, CONTROL, ELEVATOR ASSEMBLY Spares for:	1	—	DC1/1
HOFFMANN CS1	. . . BEARING, ballrace	2	—	DC1/2
SKEFKO CBA2	. . . BEARING, ballrace	3	—	DC1/3
EA1.45.573	. . . BOBBIN	1	L40	DC1/4
EA1.45.577	. . . BUSH, distance	1	L40	DC1/5
EEAS3D	. . . HOUSING, ballrace	3	L40	DC1/6
EA1.45.1191	. . . LEVER Attaching parts for EA1.45.1191:	1	—	DC1/7
A25/4C	. . . Bolt, 2BA	4	—	DC1/8
A27CP	. . . Nut, 2BA	4	—	DC1/9
SP16C	. . . Washer	4	—	DC1/10
EEAS4/20C	. . . WASHER, packing Attaching parts for EA1.45.1193:	6	L72	DC1/11
EEAS13/6	. . Bolt, special	1	—	DC1/12
A58ES	. . Nut, slotted ¼" BSF	1	—	DC1/12A
SP90C7	. . Pin, split, 1/16" dia	1	—	DC1/12B
SP15E	. . Washer	1	—	DC1/46
EA1.45.561	. . LEVER, CONTROL, RUDDER, ASSEMBLY Spares for:	1	—	DC1/13
HOFFMANN CS1	. . . BEARING, ballrace	2	—	DC1/14
EA1.45.575	. . . BOBBIN Attaching parts for EA1.45.575:	1	L40	DC1/15
A25/5C	. . . Bolt, 2BA	4	—	DC1/15A
A27CT	. . . Nut, 2BA	4	—	DC1/15B
SP16C	. . . Washer	4	—	DC1/15C
EA1.45.577	. . . BUSH, distance	1	L40	DC1/16
EA1.45.569	. . . LUG, c/w ballraces Attaching parts for EA1.45.561:	1	—	DC1/17
EEAS13/7	. . Bolt, special	1	S96	DC1/18
A58ES	. . Nut, thin, slotted, ¼" BSF	1	—	DC1/18A
SP90C7	. . Pin, split, 1/16" dia	1	—	DC1/18B
SP15E	. . Washer	1	—	DC1/18C
EA1.45.499	. SUPPORT, CONTROL TUBES, AT FRAME 35, ASSEMBLY Spares for:	1	—	DC1/19
FAIREY AVIATION FS515	. . BEARING, roller	2	—	DC1/20
EA1.45.501	. SUPPORT, CONTROL TUBES, AT FRAME 37, ASSEMBLY Spares for:	1	—	DC1/21
FAIREY AVIATION FS515	. . BEARING, roller	2	—	DC1/22

CONTROLS
FLYING CONTROLS IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.45.267	. TUBE, CONTROL, LETTERED, ELEVATOR AND RUDDER, ASSEMBLY (PRE MOD.4930)	2	—	DC1/23
EA3.45.649	. TUBE, CONTROL, LETTERED, ELEVATOR AND RUDDER, ASSEMBLY (MOD.4930)	2	—	
EA3.45.297	. . TRANSFER, 'DO NOT HANDLE', waterslide (PRE MOD.4930)	1	—	DC1/23A
EA3.45.375	. . TUBE, control (Pre Mod.4930)	1	—	DC1/24
EA3.45.681	. . TUBE, control (Mod.4930)	1	—	
EA3.45.375	. TUBE, control, elevator and rudder (Pre Mod.4930)	2	—	DC1/25
EA3.45.681	. TUBE, control, elevator and rudder (Mod.4930)	2	—	
EA3.45.317	. TUBE, CONTROL, ELEVATOR, FROM CONTROL ARM TO ELEVATOR, ASSEMBLY (PRE MOD.4930)	1	—	DC1/26
EA3.45.653	. TUBE, CONTROL, ELEVATOR, FROM CONTROL ARM TO ELEVATOR, ASSEMBLY (MOD.4930)	1	—	
EA3.45.315	. . END-FITTING Attaching parts for EA3.45.315:	1	—	DC1/26A
EEAS37/13A	. . Nipple	6	—	DC1/26B
EEAS38/1A	. . Spoke	3	—	DC1/26C
EEAS47/2	. . FORK-END, adjusting	1	DTD683	DC1/27
EA3.45.313	. . FORK-END Attaching parts for EA3.45.313:	1	—	DC1/28
EEAS37/13A	. . Nipple	8	—	DC1/28A
EEAS38/1A	. . Spoke	4	—	DC1/28B
A29NP	. . NUT, 1/2" BSF	1	—	DC1/29
EA3.45.319	. . TUBE	1	—	DC1/29A
EA3.45.387	. TUBE, CONTROL, ELEVATOR, ASSEMBLY (PRE MOD.4930)	1	—	DC1/30
EA3.45.683	. TUBE, CONTROL, ELEVATOR, ASSEMBLY (MOD.4930)	1	—	
EEAS128	. . END-FITTING Attaching parts for EEAS128:	1	—	DC1/30A
EEAS37/13A	. . Nipple	4	—	DC1/30B
EEAS38/1A	. . Spoke	2	—	DC1/30C
EEAS47/2	. . FORK-END, adjusting	1	DTD683	DC1/31
EEAS131/2	. . FORK-END Attaching parts for EEAS131/2:	1	—	DC1/32
EEAS37/13A	. . Nipple	6	—	DC1/32A
EEAS38/1A	. . Spoke	3	—	DC1/32B
A29NP	. . NUT, 1/2" BSF	1	—	DC1/33
EA3.45.373	. . TUBE	1	—	DC1/33A
EA3.45.115	. TUBE, CONTROL, RUDDER, FROM CONTROL ARM TO RUDDER, ASSEMBLY (PRE MOD.4930)	1	—	DC1/34
EA3.45.647	. TUBE, CONTROL, RUDDER, FROM CONTROL ARM TO RUDDER, ASSEMBLY (MOD.4930)	1	—	
EEAS128	. . END-FITTING Attaching parts for EEAS128:	1	—	DC1/34A
EEAS37/13A	. . Nipple	4	—	DC1/34B
EEAS38/1A	. . Spoke	2	—	DC1/34C

FLYING CONTROLS IN REAR FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EEAS47/2	. . FORK-END, adjusting	1	DTD683	DC1/35
EEAS131/2	. . FORK-END Attaching parts for EEAS131/2:	1	-	DC1/36
EEAS37/13A	. . Nipple	6	-	DC1/36A
EEAS38/1A	. . Spoke	3	-	DC1/36B
A29NP	. . NUT, 1/2" BSF	1	-	DC1/37
EA3.45.113	. . TUBE	1	-	DC1/37A
EA3.45.393	. TUBE, CONTROL, RUDDER, FROM CONTROL ARM, ASSEMBLY (PRE MOD.4930)	1	-	DC1/38
EA3.45.685	. TUBE, CONTROL, RUDDER, FROM CONTROL ARM, ASSEMBLY (MOD.4930) Spares for:	1	-	
EEAS128	. . END-FITTING Attaching parts for EEAS128:	1	-	DC1/38A
EEAS37/13A	. . Nipple	4	-	DC1/38B
EEAS38/1A	. . Spoke	2	-	DC1/38C
EEAS47/2	. . FORK-END, adjusting	1	DTD683	DC1/39
EEAS131/2	. . FORK-END Attaching parts for EEAS131/2:	1	-	DC1/40
EEAS37/13A	. . Nipple	6	-	DC1/40A
EEAS38/1A	. . Spoke	3	-	DC1/40B
A29NP	. . NUT, 1/2" BSF	1	-	DC1/41
EA3.45.395	. . TUBE Attaching parts for control tubes:	1	-	DC1/41A
EEAS13/1	. Bolt, special	2	S11	DC1/42
EEAS14	. Bush	2	S11	DC1/43
EEAS63E	. Nut, special	2	S96	DC1/44
EEAS127	. Piece, distance	2	S96	DC1/45
SP90C7	. Pin, split, 1/16" dia	2	-	DC1/45A

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.



LIGHTNING MK. 1
COVER PITOT HEAD
EB2-88-511