

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	ENGINE COWLING INSTALLATION PORT (EB8.50.1)	-	-	-	
	Spares for:				
EA1.50.103	CLIP, hook retaining	2	DTD390	C	J2/1
EA1.50.105	CLIP, hook retaining	2	DTD390	C	J2/2
EB8.50.5	COWL, Front Group (Pre Mod 4967)	1	-	P	J1/3
EB8.50.5x7	COWL, Front Group (Mod 3967) (Spares supplied to Drg EB8.00.467)	1	-	P	J1/4 J3/4
	Spares for:				
EB8.50.155	AIR INTAKE, complete (Pre Mod 4967)	1	-	P	J3/5
EB8.50.1643	AIR INTAKE, complete (Mod 4967) #(Spares supplied to Drg EB8.00.746 - 26FZ/44916)	1	-	P	J3/6
	Spares for:				
EB8.50.1643/D	COVER, (Make from 30B/9611218)	3	-	LM	-
EB8.50.191	RING, support (Pre Mod 4967)	1	L72	MR	-
EB8.50.1657	RING, support (Mod 4967)	1	L72	MR	-
EA6.50.551	SEAL, (Make from 26FZ/20518 EAS 140)	2	-	LM	-
EB8.50.133	BAFFLE, (supplied undrilled)	2	L72	C	J3/7
	Attachment of baffle to cowl				
AS2230/404	Rivet, 1/8 in. c/sunk	6	-	C	J3/8
EB8.50.1097	DUCT, bleed valve	1	-	C	J3/9
	Attachment of duct to cowl				
AS1242/2C	Bolt, 2BA	16	-	C	J3/10
EB8.50.1325	DUCT extractor	1	-	C	J3/11
	Attachment of duct to cowl				
EB8.50.1331	Bolt, 2BA	4	S95	C	J3/12
AS1242/2C	Bolt, 2BA	12	-	C	J3/13
A27/CP	Nut, 2BA	12	-	C	J3/14
A27/CS	Nut, 2BA	2	-	C	J3/15
SP90/C8	Pin, split	2	-	C	J3/16
SP15/C	Washer	14	-	C	J3/17
EB8.00.438	EXHAUST OUTLET, starter	1	-	C	J3/18
	Attachment of outlet to cowl				
AS1242/1C	Bolt, 2BA	8	-	C	J3/19
EB8.50.1541	FERRULE, (Mod 3566) frame 2	1	S966	C	-
EB8.50.1111	GASKET, anti-icing attachment	1	Bestobell	C	J3/21
EB8.50.919	PACKING, anti-corrosive, bleed valve attachment	1	DTD124	C	J3/22
EB8.50.913	PACKING, anti-corrosive, extractor duct	1	DTD124	C	J3/23
EB8.50.915	PACKING, anti-corrosive, extractor duct bracket	2	DTD124		J3/24
EB8.50.971	PACKING, asbestos, exhaust tube	1	DTD278A	C	J3/25
EB8.50.929	PANEL, access, low pressure filter	1	-	C	J3/26
EB8.50.985	PANEL, access, low pressure filter	1	-	C	J3/27

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate							
						1	2	3	4	5	6	
	Attachment of panels to cowl											
EEAS1/2C	Screw, csk, 2BA	12	S96	C	J3/28							
EB8.50.1105	PIPE, anti-icing	1	-	C	J3/29							R
	Attachment of pipe to cowling											
A25/7C	Bolt, 2BA	2	-	C	J3/30							
A25/8C	Bolt, 2BA	4	-	C	J3/31							
SP14/C	Washer, 2BA	6	-	C	J3/32							
EB8.50.1329	PLATE, shim, extractor duct	2	Lam.Alum	C	J3/33							
EB8.50.1327	PLATE, slide, extractor duct bracket	2	L72	C	J3/34							
EB8.50.777	RECEIVER, spigot complete	1	-	C/MR	J3/35							
EB8.50.129	Rim, air duct	2	L59	C	J3/36							
	Attachment of rim to air duct											
AS2230/303	Rivet, csk, 5/32 in. dia.	8	-	C	J3/37							
AS2230/405	Rivet, csk, 1/8 in. dia.	2	-	C	J3/38							
EB8.50.13	COWL, Top Rear Group (Spares supplied to Drg. EB8.00.471)	1	-	P	J1/39							
	Spares for:											
EAL.50.281	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/40							
EAL.50.282	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/41							
	Spares for:											
EAL.50.95	HANDLE, Toggle Fastener Group	1	-	L	J4/42							
	Spares for:											
Terry 169-1	RING, split	1	-	C	J4/43							R
EAL.50.49	SPRING (19 SWG)	1	DTD215	C	J4/44							
	Attachment of handle to fastener											
EAL.50.155	Pin	2	S11	C	J4/45							
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/46							
EAL.50.283	FASTENER, Toggle, Light Duty Group	2	-	C/MR	J4/47							
EAL.50.284	FASTENER, Toggle, Light Duty Group	2	-	C/MR	J4/48							
	Spares for:											
EAL.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/49							
	Spares for:											
Terry 169-1	RING, split	1	-	C	J4/50							R
EAL.50.49	SPRING (19 SWG)	1	DTD215	C	J4/51							
	Attachment of handle to fastener											
EAL.50.157	Pin	2	S11	C	J4/52							
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/53							
Dzus FJ5/70	FASTENER	5	-	C	J4/54							

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate						
						1	2	3	4	5	6
Dzus FJ5/80	FASTENER	2	-	C	J4/55						
Dzus FJ5/90	FASTENER	3	-	C	J4/56						
EA1.50.161	PANEL, toggle fastener housing	8	-	C	J4/57						
EA1.50.1793	WASHER, cup retaining	10	DTD124A	C	J4/58						
EB8.50.15	COWL, Bottom Rear, Group (Pre-Mod.2800) (Spares supplied to Drg. EB8.00.473)	1	-	P	J1/59 J5/59						
EB8.50.15/1	COWL, Bottom Rear, Group (Mod.2800) (Pre Mod 5282) (Spares supplied to Drg. EB8.00.473)	1	-	P	-						R
EB8.50.15/1x9	COWL, Bottom Rear, Group (Mod 5282) (Spares supplied to Drg EB8.00.473)	1	-	P	J1/60						R
	Spares for:										
EB8.50.1385	BOLT, duct spring	6	S95	C	J6/61						
EA1.50.65	BRACKET, forward hinge u/c cowl	1	DTD683	C	J5/62						
	Attachment of bracket to cowl										
A25/20C	Bolt, 2BA	4	-	C	J5/63						
A27/CT	Locknut, 2BA	4	-	C	J5/64						
SP15/C	Washer, 2BA	4	-	C	J5/65						
EA1.50.67	BRACKET, aft hinge u/c cowl door	1	DTD683	C	J5/66						
	Attachment of bracket to cowl										
A25/20C	Bolt, 2BA	2	-	C	J5/67						
A25/21C	Bolt, 2BA	2	-	C	J5/68						
A27/CT	Locknut, 2BA	4	-	C	J5/69						
SP16/C	Washer, 2BA	2	-	C	J5/70						
SP15/C	Washer, 2BA	2	-	C	J5/71						
EB8.50.1367	CABLE, Check and Tension Rod Assy.	1	-	C	J5/72						
	Spares for:										
EB8.50.1365	CABLE	1	-	C	J5/73						
EB8.00.441	ROD, tension c/w ends	1	-	C	J5/74						
EB8.50.1381	COLLAR, duct spring	6	L65	C	J6/75						
EA1.50.317	DOOR, access u/c cowl linkage	1	-	C	J5/76						
EB8.00.475	DOOR, Undercarriage Cowl Group (Not supplied with Bottom Rear Cowl Ref. Nos. 13269 or 32892)	1	-	P	J5/77						
	Spares for:										
EB8.50.1333	BUSH, aft hinge	1	L65	C	J5/78						
EB8.50.1335	BUSH, aft hinge	1	L65	C	J5/79						
EB8.50.1265	HINGE, half, aft	1	-	C/MR	J5/80						
EB8.50.1267	HINGE, half, aft	1	-	C/MR	J5/81						
	Attachment of half hinge to door										
A25/2C	Bolt, 2BA	4	-	C	J5/82						
SP15/C	Washer, 2BA	4	-	C	J5/83						
EA1.50.321	HINGE, forward	1	-	C	J5/84						
	Attachment of hinge to door										
A25/2C	Bolt, 2BA	6	-	C	J5/85						
SP15/C	Washer, 2BA	6	-	C	J5/86						

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	Attachment of door to cowl				
AGS899/6	Collar	2	-	C	J5/87
SP4/Z/F10	Pin, shackle	1	-	C	J5/88
SP4/Z/F18	Pin, shackle	1	-	C	J5/89
SP90/E6	Pin, split	2	-	C	J5/90
EA1.50.365	Washer	2	Lam.Alum.	C	J5/91
EB8.50.1637	DUCT, Inboard (Mod.2800) (Supplied to Pt. No. EB8.00.673 for spares purposes)	1	-	C	J6/92
EB8.50.1635	DUCT, Outboard (Mod.2800) (Supplied to Pt. No. EB8.00.671 for spares purposes)	1	-	C	J6/93
EB8.50.991	DUCT, Inboard (Pre-Mod.2800)	1	-	C	J6/94
EB8.50.993	DUCT, Outboard (Pre-Mod.2800)	1	-	C	J6/95
EB8.50.1375	DUCT, connecting	2	-	C	J6/96
EB8.04.6851	DUCT, air scoop	2	-	C	-
	Spares for:				
EB8.50.1575	DUCT, inlet	1	-	C	-
EB8.50.1605	DUCT, inlet	1	-	C	-
EA1.50.281	FASTENER, Toggle, Inboard Group	2	-	C/MR	J4/97 J5/97
EA1.50.282	FASTENER, Toggle, Outboard Group	2	-	C/MR	J4/98 J5/98
	Spares for:				
EA1.50.95	HANDLE, Toggle Fastener Group	2	-	C	J4/99
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/100
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/101
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/102
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/103
EA1.50.283	FASTENER, Toggle, Inboard Group	1	-	C/MR	J4/104 J5/104
EA1.50.284	FASTENER, Toggle, Outboard Group	1	-	C/MR	J4/105 J5/105 J5/105
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/106
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/107
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/108
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/109
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/110
Dzus FJ5/70	FASTENER	5	-	C	J5/111

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
Dzus FJ5/80	FASTENER	2	-	C	J5/112
Dzus FJ5/90	FASTENER	3	-	C	J5/113
EB8.50.1607	PANEL, access (Mod. 3160/B)	1	-	C	J5/114
	Spares for:				
Dzus F5/35DS	FASTENER	2	-	C	J5/115
Dzus GF5/175	GROMMET	2	-	C	J5/116
EB8.50.941	PANEL, fire	1	-	C	J5/117
	Attachment of panel to cowl				
AS1242/1B	Bolt, 4BA csk	8	-	C	J5/118
A27/BP	Nut, 4BA	8	-	C	J5/119
EB8.50.949	Tab	4	L72	C	J5/120
SP15/B	Washer, 4BA	8	-	C	J5/121
EA1.50.161	PANEL, toggle housing	6	-	C	J4/122
EEAS120	SEAL, rubber 6 in long (Pre Mod 5282)	2	EEAS120	LM	-
EB8.50.1675	SEAL, P 6 in long (Mod 5282) (Made from Ref.6147759)	2	EEAS842	LM	J5/122
EEAS157	SEAL, top plate	AR	-	C	J5/123
EB8.50.1383	SPRING, duct	6	DTD215	C	J6/124
EA1.50.1793	WASHER, cup retaining for fasteners	10	DTD124A	C	J5/125
EB8.50.1387	WASHER, duct spring	6	L72	C	J6/126
EA1.50.109	FORK-END, toggle hook	2	S11	C	J2/127
EA1.50.135	FORK-END, toggle hook	8	DTD683	C	J2/128
EA1.50.137	FORK-END, toggle hook	8	DTD683	C	J2/129
EA1.50.29	HOOK, toggle	8	S11	C	J2/130
EA1.50.45	HOOK, toggle	10	S11	C	J2/131
EB8.50.19	HOOP, upper cowling, complete	1	-	C	J1/132
EB8.50.21	HOOP, lower cowling, complete	1	-	C	J1/133
EB8.50.9	PANEL, Service Group (Spares supplied to Drg. EB8.00.469)	1	-	L	J1/134 J6/134
	Spares for:				
EB8.50.133	BAFFLE, (supplied undrilled)	1	L72	C	J6/135
	Attachment of baffle to cowl				
AS2230/303	Rivet, 3/32 in. csk.	6	-	C	J6/136
EA1.50.283	FASTENER, Toggle Group	2	-	L/MR	J4/137 J6/137
EA1.50.284	FASTENER, Toggle Group	2	-	L/MR	J4/138 J6/138
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/139
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/140
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/141

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	Attachment of handle to fastener				
EAL.50.157	Pin	2	S11	C	J4/142
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/143
EB8.50.963	PACKING, anti-corrosive for balance piston vent	1	DTD124	C	J6/144
EAL.50.161	PANEL, toggle, housing	4	-	C	J4/145 J6/145
EB8.50.941	PANEL, fire	1	-	C	J5/146 J6/146
	Attachment of panel to cowling				
AS1242/1B	Bolt, 4BA	8	-	C	J5/147 J6/147
A27/BP	Nut, 4BA	8	-	C	J5/148 J6/148
EB8.50.949	Tab	4	L52	C	J5/149 J6/149
SP15/B	Washer, 4BA	8	-	C	J5/150 J6/150
EB8.50.129	RIM, air duct	1	L59	C	J6/151
	Attachment of rim to air duct				
AS2230/303	Rivet, csk, 3/32 in. dia.	8	-	C	J6/152
AS2230/405	Rivet, csk, 1/8 in. dia.	2	-	C	J6/153
EB8.50.951	VENT, balance piston	2	-	C	J6/154
	Attachment of vent to panel				
AS2230/303	Rivet, 3/32 c/sunk	20	-	C	J6/155
AS2051/419BH	Rivet	6	-	C	J6/156
AS2051/413BH	Rivet	6	-	C	J6/157
EAL.50.119	ROD, hook	4	S11	C	J2/158
EAL.50.121	ROD, hook	1	S11	C	J2/159
EAL.50.129	ROD, hook	4	S11	C	J2/160
EAL.50.131	ROD, hook, top cowl	2	S11	C	J2/161
EAL.50.133	ROD, hook, bottom cowl	2	S11	C	J2/162
EB8.50.503	ROD, hook	1	S11	C	J2/163
EB8.50.505	ROD, hook	1	S11	C	J2/164
EB8.50.507	ROD, hook	1	S11	C	J2/165
EB8.50.195	SCREW, cowl attachment	54	S96	C	J3/166
EAL.50.101	SPRING, toggle hook tension	4	DTD215	C	J2/167
	ENGINE COWLING INSTALLATION STARBOARD (EB8.50.3)	-	-	-	
	Spares for:				
EAL.50.103	CLIP, hook retaining	2	DTD390	C	J2/168
EAL.50.105	CLIP, hook retaining	2	DTD390	C	J2/169
EB8.50.7	COWL, Front Group (Pre Mod 4967)	1	-	L	J1/170 J3/171



POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	Attachment of pipe to cowling				
A25/7C	Bolt, 2BA	2	-	C	J3/196
A25/8C	Bolt, 2BA	4	-	C	J3/197
SP14/C	Washer, 2BA	6	-	C	J3/198
EB8.50.1329	PLATE, shim, extractor duct attachment	2	Lam.Alum.	C	J3/199
EB8.50.1327	PLATE, slide, extractor duct bracket	2	L72	C	J3/200
EB8.50.777	RECEIVER, spigot, complete	1	-	C/MR	J3/201
EB8.50.129	RIM, air duct	2	L59	C	J3/202
	Attachment of rim to air duct				
AS2230/303	Rivet, csk, 3/32 in. dia.	8	-	C	J3/203
AS2230/405	Rivet, csk, 1/8 in. dia.	2	-	C	J3/204
EB8.50.25	COWL, Top Rear Group (Spares supplied to Drg. SC7.00.472)	1	-	L	J1/205
	Spares for:				J4/205
EA1.50.281	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/206
EA1.50.282	FASTENER, Toggle, Heavy Duty Group	2	-	C/MR	J4/207
	Spares for:				
EA1.50.95	HANDLE, Toggle Fastener Group	1	-	L	J4/208
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/209
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/210
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/211
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/212
EA1.50.283	FASTENER, Toggle, Light Duty Group	2	-	C/MR	J4/213
EA1.50.284	FASTENER, Toggle Light Duty Group	2	-	C/MR	J4/214
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/215
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/216
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/217
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/218
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/219
Dzus FJ5/70	FASTENER	5	-	C	J4/220
Dzus FJ5/80	FASTENER	2	-	C	J4/221
Dzus FJ5/90	FASTENER	3	-	C	J4/222
EA1.50.161	PANEL, toggle fastener housing	8	-	C	J4/223

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
EA1.50.1793	WASHER, cup retaining for fasteners	10	DTD124	C	J4/224
EB8.50.16	COWL, Bottom Rear, Group (Pre-Mod.2800) (Spares supplied to Drg. EB8.00.474)	1	-	L	J1/225 J5/225
EB8.50.16/1	COWL, Bottom Rear, Group (Mod 2800) (Pre Mod 5282) (Spares supplied to Drg.EB8.00.474)	1	-	L	-
EB8.50.16/1x9	COWL, Bottom Rear, Group. (Mod 5282) (Spares supplied to Drg. EB8.00.474)	1	-	L	J1/226
	Spares for:				
EB8.50.1640	ANGLE	1	L59	C	-
EB8.50.1642	ANGLE	1	L59	C	-
EB8.50.1385	BOLT, duct spring	6	S95	C	J6/227
EA1.50.66	BRACKET, forward hinge u/c cowl door	1	DTD683	C	J5/228
	Attachment of bracket to cowl				
A25/20C	Bolt, 2BA	4	-	C	J5/229
A27/CT	Locknut, 2BA	4	-	C	J5/230
SP15/C	Washer, 2BA	4	-	C	J5/231
EA1.50.68	BRACKET, aft hinge, u/c cowl door	1	DTD683	C	J5/232
	Attachment of bracket to cowl				
A25/20C	Bolt, 2BA	2	-	C	J5/229
A25/21C	Bolt, 2BA	2	-	C	J5/234
A27/CT	Locknut, 2BA	4	-	C	J5/235
SP16/C	Washer, 2BA	2	-	C	J5/236
SP15/C	Washer, 2BA	2	-	C	J5/237
EB8.50.1367	CABLE, Check, and Tension Rod Assembly	1	-	C	J5/238
	Spares for:				
EB8.50.1365	CABLE	1	-	C	J5/239
EB8.00.441	ROD, tension, c/w ends	1	-	C	J5/240
EB8.50.1381	COLLAR, duct spring	6	L65	C	J6/241
EA1.50.318	DOOR, access, u/c cowl linkage	1	-	C	J5/242
EB8.00.476	DOOR, Undercarriage Cowl Group (Not supplied with Bottom Rear Cowl Ref. Nos. 13270 or 32893)	1	-	P	J5/243
	Spares for:				
EB8.50.1333	BUSH, aft hinge	1	L65	C	J5/244
EB8.50.1335	BUSH, aft hinge	1	L65	C	J5/245
EB8.50.1266	HINGE, half, aft	1	-	C/MR	J5/247
EB8.50.1268	HINGE, half, aft	1	-	C/MR	J5/248
	Attachment of half hinge to door				
A25/2C	Bolt, 2BA	4	-	C	J5/249
SP15/C	Washer 2BA	4	-	C	J5/250
EA1.50.321	HINGE, forward	1	-	C	J5/251

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
	Attachment of hinge to door				
A25/2C	Bolt, 2BA	6	-	C	J5/252
SP15/C	Washer, 2BA	6	-	C	J5/253
	Attachment of door to cowl				
AGS899/6	Collar	2	-	C	J5/254
SP4/Z/F10	Pin, shackle	1	-	C	J5/255
SP4/Z/F18	Pin, shackle	1	-	C	J5/256
SP90/E6	Pin, split	2	-	C	J5/257
EA1.50.365	Washer	2	Lam.Alum.	C	J5/258
EB8.50.992	DUCT, inboard (Pre Mod.2800)	1	-	C	J6/259
EB8.50.994	DUCT, outboard (Pre Mod.2800)	1	-	C	J6/260
EB8.50.1638	DUCT, inboard (Supplied to Pt. No. EB8.00.674 for spares purposes) (Mod 2800)	1	-	C	J6/261
EB8.50.1636	DUCT, outboard (Supplied to Pt. No. EB8.00.672 for spares purposes) (Mod 2800)	1	-	C	J6/262
EB8.50.1375	DUCT, connecting	2	-	C	J6/263
EA1.50.281	FASTENER, Toggle, Inboard Group	2	-	C/MR	J4/264
EA1.50.282	FASTENER, Toggle, Outboard Group	2	-	C/MR	J5/264
	Spares for:				J4/265
EA1.50.95	HANDLE, Toggle Fastener Group	1	-	L	J4/266
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/267
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/268
	Attachment of handle to fastener				
EA1.50.155	Pin	2	S11	C	J4/269
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/270
EA1.50.283	FASTENER, Toggle, Inboard Group	1	-	C/MR	J4/271
EA1.50.284	FASTENER, Toggle, Outboard Group	1	-	C/MR	J5/271
	Spares for:				J4/272
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J5/272
	Spares for:				
Terry 169-1	RING, split	1	-	C	J4/274
EA1.50.49	SPRING (19 SWG)	1	DTD215	C	J4/275
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/276
SP90/C8	Pin, split, 1/16 in. dia.	2	-	C	J4/277
Dzus FJ5/70	FASTENER	5	-	C	J5/278
Dzus FJ5/80	FASTENER	2	-	C	J5/279

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
Dzus FJ5/90 EB8.50.1607	FASTENER PANEL, Access (Mod.3160/B)	3 1	- -	C C	J5/280 J5/281
	Spares for:				
Dzus F5/35DS Dzus GF5/175 EB8.50.941	FASTENER GROMMET PANEL, fire	2 2 1	- - -	C C C	J5/282 J5/283 J5/284
	Attachment of panel to cowl				
AS1242/1B A27/BP EB8.50.949 SP15/B EA1.50.161	Bolt, 4BA csk. Nut, 4BA Tab Washer, 4BA PANEL, toggle housing	8 8 4 8 6	- - L72 - -	C C C C C	J5/285 J5/286 J5/287 J5/288 J4/289
EEAS120 EB8.50.1675	SEAL, rubber 6 in long (Pre Mod 5282) SEAL, P 6 in long (Mod 5282) (Made from Ref.6147759)	2 2	EEAS120 EEAS842	LM LM	- J5/289
EEAS157 EB8.50.1383 EA1.50.1793 EB8.50.1387 EA1.50.109 EA1.50.135 EA1.50.137 EA1.50.29 EA1.50.45 EB8.50.20 EB8.50.21 EB8.50.11	SEAL, top plate SPRING, duct WASHER, cup retaining for fasteners WASHER, duct spring FORK-END, toggle hook FORK-END, toggle hook FORK-END, toggle hook HOOK, toggle HOOK, toggle HOOP, upper cowling, complete HOOP, lower cowling, complete PANEL, Service Group (Spares supplied to Drg. EB8.00.470)	AR 6 10 6 2 8 8 8 8 1 1 1	- DTD215 DTD124A L72 S11 DTD683 DTD683 S11 S11 - - -	C C C C C C C C C C C P	J5/290 J6/291 J5/292 J6/293 J2/294 J2/295 J2/296 J2/297 J2/298 J1/299 J1/300 J1/301 J6/301
	Spares for:				
EB8.50.133	BAFFLE, (Supplied undrilled)	1	L72	C	J6/302
	Attachment of baffle to cowl				
AS2230/303 EA1.50.283 EA1.50.284	Rivet, csk. FASTENER, Toggle Group FASTENER, Toggle Group	6 2 2	- - -	C C/MR C/MR	J6/303 J4/304 J6/304 J4/305 J6/305
	Spares for:				
EA1.50.97	HANDLE, Toggle Fastener Group	1	-	L	J4/306
	Spares for:				
Terry 169-1 EA1.50.49	RING, split SPRING (19 SWG)	1 1	- DTD215	C C	J4/307 J4/308
	Attachment of handle to fastener				
EA1.50.157	Pin	2	S11	C	J4/309

POWER INSTALLATION  
COWLINGS

Part No.	Description	No. off	Material Specification	Class of Eqpt M.R. or L.M.	Plate
SP90/C8	Pin split, 1/16 in. dia.	2	-	C	J4/310
EB8.50.963	PACKING anti-corrosive, for balance piston vent	1	DTD124	C	J6/311
EA1.50.161	PANEL, toggle, housing	4	-	C	J4/312
EB8.50.941	PANEL, fire	1	-	C	J6/312
	Attachment of panel to cowling				J5/313
					J6/313
AS1242/1B	Bolt, 4BA	8	-	C	J5/314
A27/BP	Nut, 4BA	8	-	C	J6/314
EB8.50.949	Tab	4	L72	C	J5/315
SP15/B	Washer, 4BA	8	-	C	J6/315
EB8.50.129	RIM, air duct	1	L59	C	J5/316
	Attachment of rim to air duct				J6/316
AS2230/303	Rivet, csk. 3/32 in. dia.	8	-	C	J5/317
AS2230/405	Rivet, csk. 1/8 in. dia.	2	-	C	J6/317
EB8.50.951	VENT, balance piston	2	-	C	J6/318
	Attachment of vent to panel				
AS2230/303	Rivet, 3/32 in.	20	-	C	J6/319
AS2051/419BH	Rivet	6	-	C	J6/320
AS2051/413BH	Rivet	6	-	C	J6/321
EA1.50.119	ROD, hook	4	S11	C	J6/322
EA1.50.121	ROD, hook	1	S11	C	J2/323
EA1.50.129	ROD, hook	4	S11	C	J2/324
EA1.50.131	ROD, hook, top cowl	2	S11	C	J2/325
EA1.50.133	ROD, hook, bottom cowl	2	S11	C	J2/326
EB8.50.503	ROD, hook	1	S11	C	J2/327
EB8.50.505	ROD, hook	1	S11	C	J2/328
EB8.50.507	ROD, hook	1	S11	C	J2/329
EB8.50.195	SCREW, cowl attachment	54	S96	C	J2/330
EA1.50.101	SPRING, toggle hook tension	4	DTD215	C	J2/331
					J2/332
					J2/333
					J2/334

This file was downloaded  
from the RTFM Library:

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

