

UNDERCARRIAGE

MAIN UNDERCARRIAGE, STARBOARD

Part Number	Description	No. Off	Mati. Spec.	Plate No.
EA1.40.101	Attaching parts for EA1.40.89 :- Bush, bearing	1	DTD412	WB2/5
EA1.40.96	Ring, lower, retaining ball joint	1	DTD412	WB2/77
EA1.40.98	Ring, upper, retaining ball joint	1	DTD412	WB2/78
EA1.40.99	Stud, for retaining rings at ball joint	12	S11	WB2/8
EA9.40.63	BUSH, pivot	2	DTD412	WB2/9
EA1.40.111	BUSH, torque link leg	2	DTD412	WB2/10
EA1.40.679	Attaching parts for EA1.40.111 :- Plug, pivot, bearing, bush retaining	2	L40	WB2/11
EA1.40.133	DISC, sealing, piston dowel plug	2	L40	WB2/12
EA1.40.625	Attaching parts for EA1.40.133 :- Screw, retaining, plug, dowel seal	2	L40	WB2/13
EA1.40.131	DOWEL, piston	2	S11	WB2/14
EA9.40.56	HEAD, oleo, forging	1	DTD5094	WB2/79
or EA9.07.36	HEAD, oleo, forging c/w bushes (Spares conditioned)	1	-	
EA1.40.103	HOOK, 'S' shaped, 16 SWG	2	MS Wire	WB2/16
EA1.40.127	PIPE, stack assembly	1	-	WB2/17
AGS1138B	Attaching parts for EA1.40.127 :- Washer, jointing	1	Alum	WB2/18
EA6.40.6	PISTON, OPERATING, ASSEMBLY	1	-	WB2/80
EEAS37/22A	Consisting of :- NIPPLE, 2BA	2	S11	WB2/20
EA1.40.647	PISTON	1	DTD197	WB2/21
EA6.40.33	PLATE, orifice enclosure control	1	S11	WB2/22
EA1.40.61	Attaching parts for EA6.40.33 :- Bolt, attachment, enclosure orifice plate	3	S11	WB2/23
EA1.40.651	RING, piston	1	-	WB2/24
EEAS38/3A	SPOKE, 2BA	1	S11	WB2/25
EA1.40.118	STRUT, piston, main	1	T4	WB2/81
EA1.40.155	RING, sealing, at dowel	2	Synthetic Rubber	WB2/27
EA1.40.105	TUBE, distance, packing for locking washer	1	L40	WB2/30
AGS2096A	VALVE, charging, hydraulic	1	-	WB2/28
AS1246/5C	Attaching parts for GYP.A58 :- Bolt, 2BA, round head	1	-	WB2/29
SP47C	Washer, spring	1	-	WB2/31
AGS1138B	Washer, jointing	1	Alum	WB2/32
EA1.40.149	Washer, locking, 14 SWG	1	DTD124	WB2/33
EA9.40.62	LEG, SLIDING, COMPRESSION, ASSEMBLY	1	-	WB3/36
EA3.40.201	Spares for :- BOLT, clamp, locking	1	S95 or S96	WB3/3
EA1.40.161	BUSH, bearing, in lug	2	DTD124	WB3/5
EA3.40.45	BUSH, bearing	1	-	WB3/4
EA3.40.217	CLAMP, AXLE, ASSEMBLY	1	-	WB3/6
EA3.40.23	Spares for :- BUSH	1	L16	WB3/7
EA3.40.183	CLAMP, axle, body	1	-	WB3/8
EA3.40.19	LINK, towing	1	-	WB3/9
A27JS	Attaching parts for EA3.40.19 :- Nut, slotted, 3/8" BSF	1	-	WB3/9A
SP90CB	Pin, split	1	-	WB3/9B
SP10J	Washer	1	-	WB3/9C

UNDERCARRIAGE

MAIN UNDERCARRIAGE, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.40.21	WASHER, tow link	1	—	WB3/10
EA3.40.209	HOUSING, seal	1	L56	WB3/11
EA3.40.10	LEG, sliding, c/w integral axle	1	—	WB3/12
EA1.40.41	NUT, stop	1	S11	WB3/13
EA3.40.221	PIN, locking, piston	3	S97	WB3/14
EA3.40.219	PISTON, sliding leg	1	DTD197	WB3/15
EA1.40.175	PLATE, orifice	1	S65	WB3/16
EA1.40.61	Attaching parts for EA1.40.175:— Bolt, stud	6	S11	WB3/17
EA1.40.677	PLUG, pivot, bearing, bush retaining	2	L40	WB3/19
EA3.40.203	PLUG, sealing	1	DTD683	WB3/18
EA3.40.215	RING, backing	2	Fabric CX18	WB3/27
EA3.40.207	RING, distance, between sealing and backing rings	1	L64	WB3/24
EA1.40.57	RING, piston	1	—	WB3/22
EA1.40.45	RING, retaining felt washer 12 SWG	1	MS	WB3/20
AS1242/1B	Attaching parts for EA1.40.45:— Bolt, 4BA	8	—	WB3/21
EA3.40.213	RING, sealing seal housing	2	Soft Rubber	WB3/26
EA3.40.205	RING, sealing	1	Soft Rubber	WB3/23
EA3.40.211	RING, sealing seal housing	1	Soft Rubber	WB3/25
EA1.40.659	RING, shock absorber stop	1	DTD683	WB3/29
EA1.40.657	RING, spacer, between sealing rings	1	DTD683	WB3/28
EA1.40.167	SCREW, grub, stop nut locking	1	S1	WB3/30
EA1.40.39	WASHER, fibre, between retaining ring and stop nut	1	BS216	WB3/31
EA1.40.43	WASHER, packing $\frac{3}{16}$ " thick	1	Hard Felt	WB3/32
EA1.40.28	LINK, torque, top	1	DTD5024	WB2/40
EA1.40.153	Attaching parts for EA1.40.28:— Bush, bearing	2	DTD412	WB2/2
SP21	Nipple, lubricating	1	—	WB2/41A
A27SS	Nut, $\frac{3}{4}$ " BSF	1	—	WB2/41
EA1.40.69	Pin, bearing, top torque link	1	S11	WB2/42
EA3.40.27	Pin, bearing, torque link joint	1	S97	WB2/43
SP90H11	Pin, split	1	—	WB2/41B
EA1.40.139	Screw, grub, locking, top bearing pin	1	MS	WB2/45
EA1.40.77	Screw, retaining, bearing pin	1	S11	WB2/44
EA1.40.619	Shim, bearing pin sleeve	1	LA	WB2/58
EA1.40.73	Sleeve, bearing, for torque link	1	S11	WB2/47
EA1.40.147	Washer, bearing, thrust	1	DTD412	WB2/51
EA1.40.75	Washer, bearing thrust	1	DTD412	WB2/48
EA1.40.79	Washer, locking, bearing, pin retaining screw, 16 SWG	1	MS	WB2/49
EA1.40.83	Washer, spacing, at torque link joint between link bearings	1	S11	WB2/50
EA3.40.29	Washer, at torque link joint	1	S96	WB2/52
EA3.40.31	Washer, at torque link joint	1	S96	WB2/53

UNDERCARRIAGE

MAIN UNDERCARRIAGE, STARBOARD

Part Number	Description	No. Off	Mati. Spec.	Plate No.
R EA1.40.27	. . . LINK, torque bottom Attaching parts for EA1.40.27:-	1	DTD5024	WB2/54
EA1.40.153	. . . Bush, bearing	2	DTD412	WB2/2
EA1.40.67	. . . Pin, bearing bottom torque link	1	S11	WB2/55
EA1.40.139	. . . Screw, grub bottom, locking, bottom bearing pin	1	MS	WB2/57
EA1.40.77	. . . Screw, retaining, bearing pinn	1	S11	WB2/56
EA1.40.619	. . . Shim, bearing, pin sleeve	1	LA	WB2/58
EA1.40.71	. . . Sleeve, bearing, for torque link	1	S11	WB2/59
EA1.40.75	. . . Washer, bearing, thrust	1	DTD412	WB2/60
EA1.40.147	. . . Washer, bearing, thrust	1	DTD412	WB2/62
EA1.40.79	. . . Washer, locking, bearing, pin retaining screw, 16 SWG	1	MS	WB2/61
SP21	. . . NIPPLE, lubricating 1/4" BSF	5	LA	WB2/63
EA1.40.137	. . . TAB, locking 16 SWG Attaching parts for EA1.40.137:-	1	MS	WB2/64
A31B16	. . . Screw, 4BA	1	-	WB2/65
SP47B	. . . Washer, spring	1	-	WB2/66
EA1.40.467	. . . LEVER, COWL DOOR MECHANISM, ASSEMBLY Spares for:-	1	-	WB2/36
EA1.40.465	. . . BUSH, bearing Attaching parts for EA1.40.465:-	2	L40	WB2/37
A25/15C	. . . Bolt, 2BA	1	-	WB2/37A
AGS2001C1/66	. . . Nut, 2BA	1	-	WB2/37B
EA1.40.529	. . . LEVER, operating Attaching parts for EA1.40.467:-	1	-	WB2/38
EA1.40.517	. . . Bolt, securing, cowl door mechanism to leg (Make from A25/5E)	4	HTS	WB2/39
DUNLOP AHM5656	. . . PIPE, feed, for maxaret unit	1	-	
DUNLOP AHM5657	. . . PIPE, feed for maxaret unit	1	-	
DUNLOP DT1606	. . . TUBE, 43" x 12.5" x 21" (Pre-Mod 4481)	1	-	WB1/11
DUNLOP DT1609	. . . TUBE, 43" x 12" x 21" (Mod 4481)	1	-	WB1/11
DUNLOP DR1623	. . . TYRE, 43" x 21.5" x 21"	1	-	WB1/3
or GOODYEAR GA1266	. . . TYRE, 43" x 12.5" x 21"	1	-	WB1/3
or FIRESTONE ZA303	. . . TYRE, 43" x 12.5" x 21"	1	-	WB1/3

MAIN UNDERCARRIAGE, STARBOARD

Part Number	Description	No. Off	Mati. Spec.	Plate No.
DUNLOP AC11514 DUNLOP AH51337 AH52692 EA1.40.30	. . UNIT, maxaret automatic brake control . . WHEEL, undercarriage (Pre-Mod 4481) . . WHEEL, undercarriage (Mod 4481) . STAY, SIDE, UNDERCARRIAGE, ASSEMBLY (PRE-MOD 3585)	1 1 1 1	- - - -	WB1/12 WB1/12 WB4/45
EA9.40.44 EA9.40.74	. STAY, SIDE, UNDERCARRIAGE, ASSEMBLY (MOD 3585) (PRE-MOD 5051) . STAY, SIDE, UNDERCARRIAGE, ASSEMBLY (MOD 5051)	1 1	- -	WB4/45 WB4/45
EA1.40.221 EA1.40.239	Spares for :- . . BOLT, connecting, undercarriage operating jack . . BOLT, stop link stay Attaching parts for EA1.40.239 :-	1 1	S65 or S81 S65 or S81	WB4/2 WB4/3
EA1.40.353	. . Nut, lock	1	S11	WB4/4
EA1.40.405 EA1.40.229	. . BOLT, sequence, valve operating . . BRACKET, stop bolt Attaching parts for EA1.40.229 :-	1 1	S11 S11	WB4/5 WB4/6
A25/15L A25/8L A27LS SP90E8	. . Bolt, 7/16" BSF . . Bolt, 7/16" BSF . . Nut, 7/16" BSF . . Pin, split	1 2 3 3	HTS HTS - -	WB4/7 WB4/8 WB4/9 WB4/9A
EA1.40.404 A25/18L A25/2C A27LS SP90E8 AGS2035C	. . BRACKET, sequence, valve operating stud Attaching parts for EA1.40.404 :- . . Bolt, 7/16" BSF . . Bolt, 2BA . . Nut, 7/16" BSF . . Pin, split . . Washer, shakeproof	1 1 1 1 1 1	L40 HTS - - - -	WB4/46 WB4/11 WB4/10A WB4/12 WB4/12A WB4/10B
EA1.40.199	. . LEVER, UNDERCARRIAGE LOCK, ASSEMBLY Consisting of :-	1	-	WB4/13
EA1.40.213 EA1.40.201 EA1.40.200	. . . BUSH . . . LEVER . . LEVER, UNDERCARRIAGE LOCK, ASSEMBLY Consisting of :-	1 1 1	DTD197 S11 -	WB4/14 WB4/15 WB4/16
EA1.40.213 EA1.40.202	. . . BUSH . . . LEVER Attaching parts for EA1.40.199 and EA1.40.200 :-	1 1	DTD197 S11	WB4/17 WB4/18
EA1.40.195 EA1.40.351 SP90G10 EA1.40.219	. . Bolt, hook catch . . Nut, slotted, for hook catch pin bolt . . Pin, split . . Tube, distance, for undercarriage 'Down' switch operating bracket	1 1 1 1	S65 or S81 MS - L40	WB4/19 WB4/20 WB4/20A WB4/21
SP15Q EA1.40.291	. . Washer, 5/8" . . Washer, tab at undercarriage hook catch bolt, 20 SWG	1 1	- S3	WB4/22 WB4/23
EA1.40.417	. . Washer, under tab and connecting bolts, 24 SWG	1	L72	WB4/24

UNDERCARRIAGE
MAIN UNDERCARRIAGE, STARBOARD

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.40.192	. . LEVER, UNDERCARRIAGE 'DOWN' MICRO SWITCH ASSEMBLY Spares for :-	1	-	WB4/47
A27ET	. . . NUT, thin 1/4" BSF	1	-	WB4/26A
EA1.40.569	. . . SCREW, tappet	1	S11	WB4/26
EA1.40.225	. . LINK, SIDE STAY, ASSEMBLY Spares for :-	1	-	WB4/27
EA1.40.227	. . . BUSH, bearing Attaching parts for EA1.40.225 :-	2	DTD197	WB4/28
EA1.40.197	. . Bolt, connecting stay and link	1	S65 or S81	WB4/29
EA1.40.347	. . Nut, slotted	1	MS	WB4/30
SP90K17	. . Pin, split	1	-	WB4/30A
EA1.40.223	. . Plug, adaptor	1	L40	WB4/31
EA1.40.765	. . Washer, link and link stay connecting bolt	1	-	WB4/32
SP21	. . NIPPLE, lubricating, 1/4" BSF	3	LA	WB4/33
A27GT	. . NUT, 5/16" BSF, sequence, valve operating bolt	1	-	WB4/5A
EA3.40.193	. . NUT, slotted, for undercarriage operating jack bolt	1	-	WB4/34
EA3.40.199	. . PLATE	1	DTD124	WB4/35
EA1.40.205	. . ROLLER, stop lever, assembly Attaching parts for EA1.40.205 :-	1	-	WB4/36
EA1.40.203	. . Bolt	1	S11	WB4/37
EA1.40.349	. . Nut, slotted	1	MS	WB4/38
SP90C7	. . Pin, split	1	-	WB4/38A
EA1.40.233	. . SLEEVE, operating spring, for undercarriage lock stop	1	DTD197	WB4/39
EA1.40.237	. . SPRING, compression at lock stop	1	Spring Steel	WB4/40
EA1.40.32	. . STAY, side (Pre-Mod 3585)	1	DTD683	WB4/48
EA9.40.40	. . STAY, side (Mod 3585) (Pre-Mod 5051)	1	-	WB4/48
EA9.40.80	. . STAY, side (Mod 5051)	1	-	WB4/48
EA1.40.235	. . STOP, undercarriage lock	1	S11	WB4/42
EA1.40.217	. . TUBE, distance, undercarriage jack bolt undercarriage 'Down' switch	1	L40	WB4/43
EA1.40.355	. . WASHER, link and link stay connecting bolt	1	L72	WB4/44

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

