

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.G4.81.2807	ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE, ASSEMBLY (MOD. 4799)	—	—	—	
	E.B6.81.389	BOX, JUNCTION NO. 1, INSTALLATION ...	—	—	—	
	E.G4.81.893	BOX, JUNCTION NO. 1, ASSEMBLY ...	1	—	—	
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way ...	2	—	C	
28S/1200033	A31/B24	Attaching parts for CZ.23212/1:— Screw, 4 BA ...	2	—	C	
	E.A1.81.583	BOX, JUNCTION, 40-WAY ...	1	—	—	
5E/4183	†	CABLE, Uninyvin 20 ...	QR	—	C	
5E/4185	†	CABLE, Uninyvin 16 ...	QR	—	C	
5E/4187	†	CABLE, Uninyvin 12 ...	QR	—	C	
	E.B6.81.387	COVER, ASSEMBLY ...	1	—	—	
32C/614	†	RUBBER, synthetic, 0"14 dia. ...	QR	DTD.552	C	
32368	E.A9.81.4357	SCREW, cover ...	6	—	C	
1066	EEAS.28/2CU	WASHER ...	12	S.514	C	
1108	EEAS.42	WASHER, leather ...	6	—	C	
5X/6168	Z.23197	GASKET, plug moulding ...	2	—	C	
5X/6169	Z.23198	GASKET, plug moulding ...	2	—	C	
5X/1004082	Z.50210	LINK, connecting, 2-way ...	1	—	C	
5X/6174	703/2/00257	LINK, connecting, 8-way ...	1	—	C	
5X/6185	CZ.50361	PLUG, 26-way ...	1	—	C	
5K/4346879	EEAS.146/12	SLEEVE, 1" long ...	18	—	C	
5K/4346878	EEAS.146/12	SLEEVE, 3/4" long ...	28	—	C	
5K/4346875	EEAS.146/6	SLEEVE, 1" long ...	2	—	C	
5X/1005131	Z.49428	SLEEVE, adaptor ...	12	—	C	
5X/9450396	HC.490	TAG, Q.R. ...	12	—	C	
5X/9482491	HC.500	TAG, Q.R. ...	6	—	C	
5X/9450224	HC.510	TAG, Q.R. ...	2	—	C	
		Attaching parts for E.G4.81.893:—				
28D/9436920	A25/1C	Bolt, 2 BA ...	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA ...	4	—	C	
28W/9419475	SP.15/C	Washer ...	4	—	C	
7724	EEAS.28/2EPH	WASHER, for earth bolt ...	2	—	C	
	E.G4.81.2995	BOX, JUNCTION NO. 2, INSTALLATION (MOD. 4799)	—	—	—	
	E.G4.81.2987	BOX, JUNCTION NO. 2, ASSEMBLY (MOD. 4799)	1	—	—	
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way ...	1	—	C	
28S/1200033	A31/B24	Attaching parts for CZ.23212/1:— Screw, 4 BA ...	2	—	C	
	E.A1.81.589	BOX, JUNCTION, 20-WAY ...	1	—	—	
5X/6168	Z.23197	GASKET, plug moulding ...	1	—	C	
5X/2790	Z.22634	GROMMET, dummy ...	4	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.598/E	LID, ASSEMBLY (Use Ref. 16782) 1						—		LM	
		Spares for:—									
32C/614	†	RUBBER , synthetic, 0"14 dia. QR						DTD.552		C	
32368	E.A9.81.4357	SCREW , cover 4						—		C	
1066	EEAS.28/2CU	WASHER 8						S.514		C	
1108	EEAS.42	WASHER , leather 4						—		C	
5X/1004082	Z.50210	LINK , 2-way 3						—		C	
5X/4491423	703/2/00253	LINK , 4-way 1						—		C	
5K/4346878	EEAS.146/12	SLEEVE , 3/4" long 20						—		C	
		Attaching parts for E.G4.81.2987:—									
28D/9436920	A25/1C	Bolt , 2 BA 4						—		C	
28M/1278190	AGS.2001/C/1	Nut , 2 BA 4						—		C	
28W/9419475	SP.15/C	Washer 4						—		C	
	7724	WASHER , for earth bolt 2						—		C	
	EEAS.28/2EPH	BOX, JUNCTION, NO. 3, INSTALLATION —						—		—	
	E.B6.81.10063	Spares for:—									
	E.B6.81.343	BOX, JUNCTION, NO. 3, ASSEMBLY 1						—		—	
		Spares for:—									
5X/1002695	CZ.23212/1	BLOCK , terminal, 20-way 2						—		C	
		Attaching parts for CZ.23212/1:—									
28S/9130752	A43/B24	Screw , 4 BA 2						—		C	
	E.A1.81.583	BOX , junction, 40-way 1						—		—	
5E/4183	†	CABLE , Uninyvin 20 QR						—		C	
5E/4185	†	CABLE , Uninyvin 16 QR						—		C	
5E/4187	†	CABLE , Uninyvin 12 QR						—		C	
	E.B6.81.341	COVER, ASSEMBLY (Use Ref. 16781) 1						—		LM	
		Spares for:—									
20457	EEAS.117/1	SCREW 6						S.92		C	
1066	EEAS.28/2CU	WASHER 12						S.514		C	
1108	EEAS.42	WASHER , leather, 0"05 thick 6						—		C	
5X/6168	Z.23197	GASKET , size "C" 2						—		C	
5X/6169	Z.23198	GASKET , size "D" 2						—		C	
5X/6174	703/2/00257	LINK , commoning, 8-way 1						—		C	
5X/1004082	Z.50210	LINK , connecting, 2-way 2						—		C	
5X/6185	CZ.50361	PLUG , size "D" (Pre-Mod. 3879) 1						—		B	
5X/7159	2CZ.111229	PLUG , size "D" (Mod. 3879) 1						—		B	
5K/4346879	EEAS.146/12	SLEEVE , 1" long 21						—		C	
5K/4346877	EEAS.146/6	SLEEVE , 1" long 34						—		C	
5X/1005131	Z.49428	SLEEVE 17						—		C	
5X/9450396	HC.490	TAG , Q.R. 17						—		C	
5X/9482491	HC.500	TAG , Q.R. 4						—		C	
5X/9450224	HC.510	TAG , Q.R. 2						—		C	
		Attaching parts for E.B6.81.343:—									
28D/1212401	A25/30C	Bolt , 2 BA 2						—		C	
28D/1212405	A25/36C	Bolt , 2 BA 2						—		C	
28M/1278190	AGS.2001/C/1	Nut , 2 BA 4						—		C	
	AS.2811/5/280	Tube , distance 2						L.62		LM	
	AS.2811/5/340	Tube , distance 2						L.62		LM	
28W/9419475	SP.15/C	Washer 4						—		C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.G4.81.2993	BOX, JUNCTION, NO. 5, INSTALLATION (MOD. 4799)	—	—	—	
	E.G4.81.2989	BOX, JUNCTION, NO. 5, ASSEMBLY (MOD. 4799)	1	—	—	
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way ...	1	—	C	
28S/1200033	A31/B24	Attaching parts for CZ.23212/1:— Screw, 4 BA ...	2	—	C	
	E.A1.81.589	BOX, junction, 20-way ...	1	—	—	
5X/6168	Z.23197	GASKET, plug moulding ...	1	—	C	
5X/2790	Z.22634	GROMMET, dummy ...	2	—	C	
	E.A1.81.598/B	LID; ASSEMBLY (Use Ref. 16782)	1	—	LM	
	32C/614	RUBBER, synthetic, 0"14 dia. ...	QR	DTD.552	C	
	32368	SCREW, cover ...	4	—	C	
	1066	WASHER ...	8	S.514	C	
	1108	WASHER, leather ...	4	—	C	
5X/1004083	703/2/00252	LINK, commoning, 3-way ...	2	—	C	
5K/4346878	EEAS.146/12	SLEEVE, 3/4" long ...	20	—	C	
28D/9436920	A25/1C	Attaching parts for E.G4.81.2989:— Bolt, 2 BA ...	2	—	C	
28D/9133011	A25/2C	Bolt, 2 BA ...	2	—	C	
28W/9419402	SP.13/C	Washer ...	4	—	C	
	7724	WASHER, for earth bolt ...	2	—	C	
	EEAS.28/2EPH	ELECTRICAL EQUIPMENT, REAR BOMB BAY	—	—	—	
	E.G4.81.2887	BULKHEAD, FRAME 29, ASSEMBLY (MOD. 4799)	—	—	—	
	AMPHENOL	Spares for:—				
10AD/9321715	UG.30.U	ADAPTOR ...	1	—	C	
10H/9560042	†	ADAPTOR, bulkhead plug ...	2	—	C	
	7791	BAG, cable stowage ...	1	—	C	
28M/1278190	AGS.2001/C/1	Attaching parts for E.A3.81.1829:— Nut, 2 BA ...	3	—	C	
28S/9131095	A31/C14	Screw, 2 BA ...	3	—	C	
28W/9419402	SP.13/C	Washer ...	3	—	C	
	E.A9.81.4005	FAIRLEAD, half ...	2	—	—	
28D/1010029	A25/68	Attaching parts for E.A9.81.4005:— Bolt, 4 BA ...	3	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...	3	—	C	
28W/9419474	SP.15/B	Washer ...	3	—	C	
5X/6007	CZ.28181	PLUG, bulkhead, size "A" (Pre-Mod. 3879) ...	1	—	C	
5X/7022	2CZ.84865	PLUG, bulkhead, size "A" (Mod. 3879) ...	1	—	C	
5X/6092	CZ.28198	PLUG, bulkhead, size "C" (Pre-Mod. 3879) ...	1	—	C	
5X/7169	2CZ.111426	PLUG, bulkhead, size "C" (Mod. 3879) ...	1	—	C	
5X/6102	CZ.28200	PLUG, bulkhead, size "C" (Pre-Mod. 3879) ...	1	—	C	
5X/7170	2CZ.111428	PLUG, bulkhead, size "C" (Mod. 3879) ...	1	—	C	
5X/6347	CZ.50371	PLUG, bulkhead, size "E" (Pre-Mod. 3879) ...	1	—	C	
5X/7633	2CZ.111435	PLUG, bulkhead, size "E" (Mod. 3879) ...	1	—	C	
5X/6042	CZ.28183	PLUG, bulkhead, size "Z" (Pre-Mod. 3879) ...	1	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/7120	2CZ.108926	PLUG, bulkhead, size "Z" (Mod. 3879) ...						1	—	C	
5X/6027	CZ.28185	PLUG, bulkhead, size "Z" (Pre-Mod. 3879) ...						1	—	C	
5X/7164	2CZ.111417	PLUG, bulkhead, size "Z" (Mod. 3879) ...						1	—	C	
10H/19445	CZ.62269	PLUG/SOCKET, bulkhead, 3-way ...						1	—	C	
10H/19492	CZ.62276/5	PLUG/SOCKET, bulkhead, 18-way ...						1	—	C	
10H/19493	CZ.62277	PLUG/SOCKET, bulkhead, 25-way ...						3	—	C	
10H/19494	CZ.62277/1	PLUG/SOCKET, bulkhead, 25-way ...						1	—	C	
10H/20423	CZ.61882	SOCKET/PLUG, bulkhead, 4-way ...						1	—	C	
10H/20422	CZ.61884	SOCKET/PLUG, bulkhead, 4-way ...						2	—	C	
3416	EEAS.132/7	STRAP, cable ...						4	—	C	
		Attaching parts for EEAS.132/7:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...						1	—	C	
28S/9992525	A32/B12	Screw, 4 BA ...						1	—	C	
4910	EEAS.28/18DR	Washer ...						1	L.72	C	
	E.G4.81.1149	FAIRLEAD, BOMB BAY, INSTALLATION (MOD. 4079)						—	—	—	
		Spares for:—									
41945	E.C3.11.207	FAIRLEAD, half ...						2	—	C	
		Attaching parts for E.C3.11.207:—									
28D/1200119	A25/4C	Bolt, 2 BA ...						3	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA ...						3	—	C	
28V/9419402	SP.13/C	Washer ...						3	—	C	
	E.G4.81.2835	LOOMS, CABLE, ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
	E.A1.81.738/2	CABLE ASSEMBLY, C33, from front transport joint to plug at bomb bay bulkhead						1	—	—	
	E.A3.81.706/2	CABLE ASSEMBLY, C2A, from pressure bulkhead to JB.2						1	—	—	
	E.A3.81.708/2	CABLE ASSEMBLY, C5, from pressure bulkhead to JB.5						1	—	—	
	E.A3.81.710/2	CABLE ASSEMBLY, 1D, from JB.1 to undercarriage actuator valve						1	—	—	
5427	E.A3.81.714/1	CABLE ASSEMBLY, 1G, from JB.1 to undercarriage actuator valve						1	—	B	
	E.A3.81.718/2	CABLE ASSEMBLY, 1H3, from No. 1 fuel tank terminal board to fuel cock, port						1	—	—	
	E.A3.81.722/2	CABLE ASSEMBLY, 1J3, from No. 2 fuel tank terminal board to fuel cock, port						1	—	—	
	E.A3.81.726/2	CABLE ASSEMBLY, 1K3, from No. 3 fuel tank terminal board to fuel cock, port						1	—	—	
7667	E.A3.81.727/1	CABLE ASSEMBLY, 2D, and 2C, from JB2 to port and starboard bomb door micro switches						1	—	B	
7670	E.A3.81.734/1	CABLE ASSEMBLY, 3D, from JB3 to bomb door valve actuator terminal board						1	—	B	
	E.A3.81.739/2	CABLE ASSEMBLY, 3D1, from terminal board to bomb door valve actuator						1	—	—	
	E.A3.81.740/2	CABLE ASSEMBLY, 3F, from JB3 to flap valve actuator						1	—	—	
	E.A3.81.748/2	CABLE ASSEMBLY, 3J3, from No. 2 fuel tank terminal board to fuel cock, starboard						1	—	—	
	E.A3.81.752/2	CABLE ASSEMBLY, 3K3, from fuel tank terminal board to fuel tank						1	—	—	
		(See Cable Chart for Breakdown Spares)									

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description						No off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
7674	E.A3.81.753/1	CABLE, ASSEMBLY, 3L from JB3, to fuel contents unit transformer No. 1 fuel tank						1	—	B	
7675	E.A3.81.754/1	CABLE, ASSEMBLY, 3M, from JB3, to fuel contents unit transformer, No. 2 fuel tank						1	—	B	
7676	E.A3.81.755/1	CABLE, ASSEMBLY, 3N, from JB3 to No. 3 tank, fuel gauge transmitter						1	—	B	
7678	E.A3.81.762/1	CABLE, ASSEMBLY, 5B, from JB5 to bomb door valve actuator						1	—	B	
7679	E.A3.81.763/1	CABLE, ASSEMBLY, 5C and 5D, from JB5 to bomb door microswitch						1	—	B	
7680	E.A3.81.767/2	CABLE, ASSEMBLY, C94, from 400 cycle distribution box to aft bomb bay bulkhead						1	—	B	
41568	E.A3.81.768/2	CABLE, ASSEMBLY, C96, from 1600~ distribution box to aft bomb bay bulkhead						1	—	C	
	E.A3.81.2359/2	CABLE, ASSEMBLY, CI, from pressure bulkhead to JB1						1	—	—	
7691	E.A3.81.2363	CABLE, ASSEMBLY, IH, from JB1 to No. 1 fuel tank terminal board, port						1	—	B	
7692	E.A3.81.2365	CABLE, ASSEMBLY, IH1, from No. 1 fuel tank terminal board to fuel pump suppressor, port						1	—	B	
	E.A3.81.2367/2	CABLE, ASSEMBLY, IH2, from No. 1 fuel tank suppressor to fuel pump, port						1	—	—	
7695	E.A3.81.2371	CABLE, ASSEMBLY, IJ1, from No. 2 fuel tank terminal board to fuel pump suppressor, port						1	—	B	
	E.A3.81.2373/2	CABLE, ASSEMBLY, IJ2, from No. 2 fuel tank suppressor to fuel pump, port						1	—	—	
7698	E.A3.81.2377	CABLE, ASSEMBLY, IK1, from No. 3 fuel tank terminal board to fuel pump suppressor						1	—	B	
	E.A3.81.2379/2	CABLE, ASSEMBLY, IK2, from No. 3 fuel tank suppressor to fuel tank, port						1	—	—	
7700	E.A3.81.2381	CABLE, ASSEMBLY, 3H, from JB3 to No. 1 fuel tank terminal board, starboard						1	—	B	
7701	E.A3.81.2383	CABLE, ASSEMBLY, 3H1, from No. 1 fuel tank terminal board to fuel pump suppressor, starboard						1	—	B	
7702	E.A3.81.2385/2	CABLE, ASSEMBLY, 3H2, from No. 1 fuel suppressor to fuel pump, starboard						1	—	B	
7703	E.A3.81.2387	CABLE, ASSEMBLY, 3J, from JB3 to No. 2 fuel tank terminal board						1	—	B	
7704	E.A3.81.2389	CABLE, ASSEMBLY, 3J1, from No. 2 fuel tank terminal board to fuel pump suppressor, starboard						1	—	B	
	E.A3.81.2391/2	CABLE, ASSEMBLY, 3J2, from fuel pump suppressor to fuel pump, starboard						1	—	—	
7706	E.A3.81.2393	CABLE, ASSEMBLY, 3K, from JB3 to No. 3 fuel tank terminal board, starboard						1	—	B	
7707	E.A3.81.2395	CABLE, ASSEMBLY, 3K1, from No. 3 fuel tank terminal board to fuel pump suppressor, starboard						1	—	B	
	E.A3.81.2397/2	CABLE, ASSEMBLY, 3K2, from fuel pump suppressor to fuel pump, starboard						1	—	—	
	E.A3.81.2427/2	CABLE, ASSEMBLY, 1F, from junction box 1 to dive brake valve actuator						1	—	—	

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.							Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
	E.A3.81.2429/2							CABLE ASSEMBLY, 1L, from JB1 to solenoid valve	1	—	—	
	E.A3.81.2539/2							CABLE ASSEMBLY, GS2, from pressure bulkhead to earth stud and plug at frame 24, also port and starboard fuel cocks	1	—	—	
	E.A3.81.2541/2							CABLE ASSEMBLY, 3H3, from No. 1 fuel tank terminal board to fuel cock, starboard	1	—	—	
7712	E.A3.81.2553/2							CABLE ASSEMBLY, C7, from pressure bulkhead to JB7, port wing	1	—	B	
	E.B6.81.291/2							CABLE ASSEMBLY, C3, from DC distribution box plug at pressure bulkhead to JB3	1	—	—	
	E.B6.81.541/2							CABLE ASSEMBLY, C9, from distribution box plug at pressure bulkhead to port wing break	1	—	—	
	E.B6.81.543/2							CABLE ASSEMBLY, C10, from distribution box plug at pressure bulkhead to starboard wing break	1	—	—	
	E.B6.81.545							CABLE ASSEMBLY, 1B, from JB1 to downward identification light	1	—	—	
	E.B6.81.567/2							CABLE ASSEMBLY, C7X, from pressure bulkhead to junction box 7	1	—	—	
	E.B6.81.631/2							CABLE ASSEMBLY, 3A, 3B and 3C, from JB3 to 5-way terminal board for vent valve heaters 3A, fire extinguisher bottle 3B and flame switch 3C (Pre-Mod. 2614)	1	—	—	
	E.B6.81.713/2							CABLE ASSEMBLY, C8X, from JB8 to connection at pressure bulkhead	1	—	—	
	E.B6.81.715/2							CABLE ASSEMBLY, C8, from JB8 to connection at pressure bulkhead	1	—	—	
	E.B6.81.731							CABLE ASSEMBLY, 1J, from JB1 to No. 2 fuel tank terminal board	1	—	—	
	E.B6.81.733							CABLE ASSEMBLY, 1K, from JB1 to No. 3 fuel tank terminal board	1	—	—	
15366	E.B6.81.783							CABLE ASSEMBLY, EB, battery earth connection	1	—	C	
	E.B6.81.1483							CABLE ASSEMBLY, E2, from JB2 to earth ...	1	—	—	
	E.B6.81.3661							CABLE ASSEMBLY, C6, from DC distribution box to rear bulkhead	1	—	—	
	E.B6.81.4055							CABLE ASSEMBLY, C37, from main electrical panel to port voltage regulator	1	—	—	
	E.B6.81.4057							CABLE ASSEMBLY, C38, from main electrical panel to starboard voltage regulator	1	—	—	
	E.B6.81.4059							CABLE ASSEMBLY, C31, from main electrical panel to port wing break	1	—	—	
	E.B6.81.4061							CABLE ASSEMBLY, C32, from main electrical panel to starboard wing break	1	—	—	
	E.B6.81.4103							CABLE ASSEMBLY, C35, from main electrical panel to voltage regulator and No. 1 generator	1	—	—	
	E.B6.81.4105							CABLE ASSEMBLY, C36, from main electrical panel to voltage regulator and No. 2 generator	1	—	—	
	E.B6.81.4927							CABLE ASSEMBLY, C71, from plug bracket frame 11 (starboard) above door frame to I.F.F. junction box	1	—	—	
	E.G4.81.2647							CABLE ASSEMBLY, C567, from pressure bulkhead and 1600 distribution box to I.F.F. tray (Mod. 4864)	1	—	—	

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B7.81.553/2	CABLE ASSEMBLY, 3A1, from terminal board to vent valve heater, starboard						1	—	—	
	E.B7.81.555/2	CABLE ASSEMBLY, 3A2, from terminal board to vent valve heater, port						1	—	—	
	E.B7.81.1119	CABLE ASSEMBLY, E1, earth connection from JB1						1	—	—	
	E.B7.81.1121	CABLE ASSEMBLY, E3, earth connection from JB3						1	—	—	
		(See Cable Chart for Breakdown Spares)									
43130	M.L. AVIATION YT.3740/9C	CABLE ASSEMBLY, F300, from junction box carrier to frame 12						1	—	B	
6A/2767	SMITH WAYMOUTH CA.14	CONNECTOR						3	—	C	
6A/4333102	CA.26	CONNECTOR						3	—	C	
5X/2790	Z.22634	GROMMET						4	—	C	
	E.G4.81.2847	LOOMS, CABLE, INSTRUMENT, ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
7734	E.A3.81.936	CABLE ASSEMBLY, DIC-DIB, detector unit from pressure bulkhead to wing root connection						1	—	B	
	E.B6.81.10613	CABLE ASSEMBLY, 1M, from JB1 to fatigue meter						1	—	—	
	E.G4.80.1003	METER FATIGUE INSTALLATION (MOD. 4223)						—	—	—	
		Spares for:—									
6A/5029	R.A.E. Type 3C	METER, fatigue (Pre-Mod. 3245)						1	—	A	
6A/6486	R.A.E. Type 13	METER, fatigue, (Mod. 3245) (Pre-Mod. 4223)						1	—	A	
6A/9657	—	METER, fatigue, Mk. 16 (Mod. 4223)						1	—	A	
		Attaching parts for fatigue meter:—									
28D/9436920	A25/1C	Bolt, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
31529	E.A9.80.1387	MOUNTING, meter channel						1	L.72	C	
		Attaching parts for E.A9.80.1387:—									
28D/9133011	A25/2C	Bolt, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	E.A9.80.1383	MOUNTING, bracket, fatigue meter, assembly						1	L.72	C	
		Attaching parts for E.A9.80.1383:—									
28D/9133012	A25/3C	Bolt, 2 BA						6	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						6	—	C	
	E.A9.80.1389	Packing						1	L.72	C	
28W/9419402	SP.13/C	Washer, 2 BA						6	—	C	
	E.G4.81.271	PANEL, CONTROL, TYPE 15, INSTALLATION						—	—	—	
		Spares for:—									
SUC/5759	†	PANEL, control, type 15						1	—	A	
		Attaching parts for Ref. SUC/5759:—									
28D/1008151	A25/4E	Bolt, 1" BSF						4	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No	Description	No. off	Matl Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
34329	E.B6.81.1767	STOWAGE, PLUG, ASSEMBLY Spares for:—	2	—		B	
10H/0970055	CZ.51538	CAP , protective	6	—		C	
10H/0970209	Z.62225	GASKET	6	—		C	
10H/	Z.67012	PANEL , mounting	6	—		C	
10H/19069	Z.49011	RING , locking	6	—		C	
10H/0970124	Z.49013	RING , mounting	6	—		C	
		Attaching parts for E.B6.81.1767:—					
28D/9435711	A25/10B	Bolt, 4 BA	4	—		C	
28W/9403519	A27/BP	Nut, 4 BA	4	—		C	
	AS.2810/4/090	Tube, distance	4	L.62		LM	
28W/9419474	SP.15/B	Washer	8	—		C	
3417	EEAS.132/9	STRAP , c/w buckle Attaching parts for EEAS.132/9:—	1	—		C	
28D/1218385	AS.1248/2B	Bolt, 4 BA	1	—		C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—		C	
	E.B6.81.901	Piece, packing, radiused, 10 SWG	1	L.72		C	
3420	EEAS.73	Plate, clamp	1	—		C	
5315	E.A1.81.222	SUPPORT AND ROLLERS, ACCUMULATOR TRAY, ASSEMBLY Spares for:—	1	—		B	
12002	E.A1.81.223	BEAM , support, outer, L.H.	1	—		C	
12003	E.A1.81.224	BEAM , support, outer, R.H.	1	—		C	
		Attaching parts for E.A1.81.223 or E.A1.81.224:—					
28D/9133013	A25/5C	Bolt, 2 BA	3	—		C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	3	—		C	
	E.A1.81.222A	Tube, distance, $\frac{1}{8}$ " o/d. x 0"45 long x 20 SWG	3	L.62		LM	
20794	E.A1.81.225	BEAM , support, inner Attaching parts for E.A1.81.225:—	1	—		C	
28D/9133013	A25/5C	Bolt, 2 BA	2	—		C	
28M/9403520	A27/CP	Nut, 2 BA	2	—		C	
	E.A1.81.222B	Packing, 10 SWG	1	L.72		LM	
28W/9416643	SP.47/C	Washer	2	—		C	
21494	E.A1.81.226	PLATE , attachment	1	—		C	
22274	E.A1.81.228	ROLLER , assembly Attaching parts for E.A1.81.228:—	6	—		C	
28D/9133011	A25/2C	Bolt, 2 BA	4	—		C	
28M/9403520	A27/CP	Nut, 2 BA	4	—		C	
28W/9416643	SP.47/C	Washer	4	—		C	
21083	E.A1.81.227	STOP, CHANNEL MOUNTING, ASSEMBLY Spares for:—	1	—		C	
20716	E.A3.81.2183	PIN , locking	2	S.92		C	
2727	E.A1.81.232	TRAY, ACCUMULATOR, ASSEMBLY Spares for:—	1	—		B	
	E.A3.81.2177	ANGLE , assembly, for locking accumulator tray L.H.	1	—		—	
	E.A3.81.2178	ANGLE , assembly, for locking accumulator tray R.H.	1	—		—	
		Attaching parts for E.A3.81.2177 or E.A3.81.2178:—					
28D/1013173	AS.1242/10C	Bolt, 2 BA	2	—		C	
28M/9403520	A27/CP	Nut, 2 BA	2	—		C	
28W/9416643	SP.47/C	Washer	2	—		C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
2743	E.A1.81.232E	BUFFER , rubber, 1/2" o/d. x 0"85 long ...	2	Shore 55	C	
2744	E.A1.81.236	FERRULE , accumulator securing nut ...	8	—	C	
		Attaching parts for E.A1.81.236:—				
28D/9709461	AS.1242/3C	Bolt, 2 BA ...	2	—	C	
28M/9403520	A27/CP	Nut, 2 BA ...	2	—	C	
28W/9416643	SP.47/C	Washer ...	2	—	C	
	E.A1.81.273	Washer, packing 14 SWG (as required) ...	2	L.72	LM	
	E.A1.81.274	Washer, packing 14 SWG (as required) ...	2	L.72	LM	
2745	E.A1.81.235	NUT , wing accumulator securing ...	8	—	C	
	E.G4.81.119	WIRING, IDENT LIGHT AND FLAME SWITCH FRAMES 12-13, ASSEMBLY	—	—	—	
		Spares for:—				
5CZ/1947	†	BLOCK , terminal, dummy, type J ...	1	—	C	
		Attaching parts for Ref. 5CZ/1947:—				
28D/1200119	A25/4C	Bolt, 2 BA ...	2	—	C	
28M/9433473	AGS.2002/C/1	Nut, 2 BA ...	2	—	C	
28W/9419402	SP.13/C	Washer ...	2	—	C	
32A/9429657	†	CORD , nylon, P.V.C. ...	QR	—	C	
5L/9952604	†	FILAMENT ...	1	—	C	
5CX/557	†	LAMP , downward ident, type C ...	1	—	C	
3416	EEAS.132/7	STRAP , cable, c/w buckle ...	2	—	C	
		Attaching parts for EEAS.132/7:—				
28D/1218384	AS.1248/1B	Bolt, 4 BA ...	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...	1	—	C	
3420	EEAS.73	Plate, clamp ...	1	—	C	
3419	EEAS.132/15	STRAP , cable, c/w buckle ...	1	—	C	
3614	EEAS.132/18	STRAP , cable, c/w buckle ...	2	—	C	
		Attaching parts for EEAS.132/18:—				
28D/1218384	AS.1248/1B	Bolt, 4 BA ...	4	—	C	
4966	E.A1.81.251	Guide, cable strap ...	2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...	4	—	C	
28W/9419474	SP.15/B	Washer ...	4	—	C	
5F/9434858	HV.3254	STRAP , Helvin ...	QR	—	C	
5F/9138823	NY.3255	STUD ...	QR	—	C	
	E.G4.81.121	WIRING, FRAMES 12-13, PORT AND STARBOARD, ASSEMBLY	—	—	—	
		Spares for:—				
32A/9429657	†	CORD , nylon, P.V.C. ...	QR	—	C	
3418	EEAS.132/12	STRAP , cable, c/w buckle ...	5	—	C	
		Attaching parts for EEAS.132/12:—				
28D/1218384	AS.1248/1B	Bolt, 4 BA ...	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...	1	—	C	
3420	EEAS.73	Plate, clamp ...	1	—	C	
3614	EEAS.132/18	STRAP , cable, c/w buckle ...	4	—	C	
5F/9434858	HV.3254	STRAP , Helvin ...	QR	—	C	
5F/9138823	NY.3255	STUD ...	16	—	C	
	E.B6.81.1757	WIRING, FRAMES 13-14, ASSEMBLY	—	—	—	
		Spares for:—				
5X/9402147	CWC.50450	BOARD , terminal ...	2	—	C	
		Attaching parts for CWC.50450:—				
28S/9419453	A31/B14	Screw, 4 BA ...	2	—	C	
28W/9419465	SP.13/B	Washer ...	2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
7729	E.A3.81.1279	BOLT, attachment for cocking indicator plug ...	1	S.1	C	
37505	E.A9.81.2285	BRACKET, microswitch, L.H. ...	1	L.72	C	
37506	E.A9.81.2286	BRACKET, microswitch, R.H. ...	1	L.72	C	
5X/9402795	A.52602	COVER, terminal board ...	2	—	C	
5X/9400053	CWC.50926	FERRULE, No. 4 ...	18	—	C	
5X/9994577	AS.2605	SOCKET, terminal ...	4	—	C	
3419	EEAS.132/15	STRAP, cable, c/w buckle ...	1	—	C	
5F/9434858	HV.3254	STRAP, Helvin ...	QR	—	C	
5F/9138823	NY.3255	STUD, Helvin ...	QR	—	C	
	DOWTY					
SCW/4742	C.1831.Y	SWITCH, micro ...	4	—	B	
		Attaching parts for C.1831.Y:—				
28D/1011025	A25/24C	Bolt, 2 BA ...	3	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA ...	3	—	C	
28W/9419402	SP.13/C	Washer ...	3	—	C	
		WASHER ...	6	—	C	
7724	EEAS.28/2EPH E.G4.81.123	WIRING AND SUPPRESSOR, FRAMES 14-15, ASSEMBLY Spares for:—	—	—	—	
5CZ/4350489	†	BLOCK, terminal, type B, No. 1 ...	2	—	C	
		Attaching parts for Ref. 5CZ/4350489:—				
28M/9403518	A27/AP	Nut, 6 BA ...	2	—	C	
28S/1200062	A33/A20	Screw, 6 BA ...	2	—	C	
28W/9416641	SP.47/A	Washer ...	2	—	C	
		STRAP, cable, c/w buckle ...	1	—	C	
3416	EEAS.132/7	STRAP, cable, c/w buckle ...	1	—	C	
3614	EEAS.132/18	Attaching parts for EEAS.132/7 or EEAS.132/18:—				
28D/1218386	AS.1248/3B	Bolt, 4 BA ...	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...	1	—	C	
3420	EEAS.73	Plate, clamp ...	1	—	C	

Pages EA.11 to EA.16 Not Issued

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5F/9434858 5F/9138823 5CY/4376390	HV.3254 NY.3255 †	STRAP , Helvin STUD SUPPRESSOR , type O, No. 2 Attaching parts for Ref. 5CY/4376390:—						QR QR 2	— — —	C C B	
28D/1008149 28M/9403519 28W/9416642	A25/2B A27/8P SP.47/B	Bolt, 4 BA Nut, 4 BA Washer						4 4 4	— — —	C C C	
12030	EEAS.21/2ER E.G.4.81.125	WASHER , "D" WIRING, FRAMES 15-16, ASSEMBLY Spares for:—						1 —	L.72 —	C —	
5CZ/4350489	†	BLOCK , terminal, type B, No. 1 Attaching parts for Ref. 5CZ/4350489						1	—	C	
28M/9403518 28S/1200062 28W/9416641	A27/AP A33/A20 SP.47/A	Nut, 6 BA Screw, 6 BA Washer						2 2 2	— — —	C C C	
3416 3614	EEAS.132/7 EEAS.132/18	STRAP , cable, c/w buckle, port STRAP , cable, c/w buckle, starboard Attaching parts for EEAS.132/7 or EEAS.132/18:—						1 1	— —	C C	
28D/1218386 28M/1278189 3420	AS.1248/3B AGS.2001/B/1 EEAS.73	Bolt, 4 BA Nut, 4 BA Plate, clamp						1 1 1	— — —	C C C	
5F/9434858 5F/9138823	HV.3254 NY.3255 E.G.4.81.127	STRAP , Helvin STUD WIRING, FRAMES 16-17, ASSEMBLY Spares for:—						QR QR —	— — —	C C —	
28M/1278189 28S/9992525 28W/9419474	AGS.2001/B/1 A32/B12 SP.15/B	BRACKET , assembly, cable support Attaching parts for E.B6.81.1859:—						1 2 2 2	— — — —	— C C C	
3416 3614	EEAS.132/7 EEAS.132/18	STRAP , cable, c/w buckle, port STRAP , cable, c/w buckle, starboard Attaching parts for EEAS.132/7 or EEAS.132/18:—						1 1	— —	C C	
28D/1218386 28M/1278189 3420	AS.1248/3B AGS.2001/B/1 EEAS.73	Bolt, 4 BA Nut, 4 BA Plate, clamp						1 1 1	— — —	C C C	
5F/9434858 5F/9138823	HV.3254 NY.3255 E.G.4.81.131	STRAP , Helvin STUD WIRING, FRAMES 17-18, ASSEMBLY Spares for:—						QR QR —	— — —	C C —	
28M/9403520 28S/9435713 28W/9419475 28W/9416643	A27/CP A31/C20 SP.15/C SP.47/C	FAIRLEAD , port wing to fuselage FAIRLEAD , starboard wing to fuselage FAIRLEAD , port wing to fuselage FAIRLEAD , starboard wing to fuselage Attaching parts for E.B6.81.1737, E.B6.81.1739, E.B6.81.1741 or E.B6.81.1743:—						1 1 1 1	L.F.S. L.F.S. L.F.S. L.F.S.	— — — —	
		Nut, 2 BA Screw, 2 BA Washer Washer						6 6 6 6	— — — —	C C C C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
3419	EEAS.132/15	STRAP, cable, c/w buckle						1	—	C	
28D/1218386	AS.1248/3B	Attaching parts for EEAS.132/15:—						1	—	C	
28M/1278189	AGS.2001/B/1	Bolt, 4 BA						1	—	C	
3420	EEAS.73	Nut, 4 BA						1	—	C	
5F/9434858	HV.3254	Plate, clamp						1	—	C	
5F/9138823	NY.3255	STRAP						QR	—	C	
28488	E.B7.81.1477	STUD						QR	—	C	
	E.G4.81.133	STUD, earth						2	—	C	
		WIRING AND SUPPRESSORS, FRAME 18-19, ASSEMBLY						—	—	—	
		Spares for:—									
5CZ/4350489	†	BLOCK, terminal, type B, No. 1						2	—	C	
		Attaching parts for Ref. 5CZ/4350489:—									
28M/9403518	A27/AP	Nut, 6 BA						2	—	C	
28S/1200062	A33/A20	Screw, 6 BA						1	—	C	
28S/9133018	A33/A28	Screw, 6 BA						1	—	C	
28W/9419485	SP.16/A	Washer						2	—	C	
28W/9416641	SP.47/A	Washer						2	—	C	
5X/4491469	Z.24933	SHELL, plug, size C						1	—	C	
5X/4491471	Z.49252	SHELL, plug, size Z						1	—	C	
		Attaching parts for Z.24933 and Z.49252:—									
28M/9403518	A27/AP	Nut, 6 BA						4	—	C	
28S/9419437	A31/A16	Screw, 6 BA						4	—	C	
28W/9416641	SP.47/A	Washer						4	—	C	
3417	EEAS.132/9	STRAP, cable, c/w buckle, port						1	—	C	
3419	EEAS.132/15	STRAP, cable, c/w buckle, starboard						1	—	C	
		Attaching parts for EEAS.132/9 and EEAS.132/15:—									
28D/1218385	AS.1248/2B	Bolt, 4 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
7735	E.B6.81.745	Plate, clamp, port						1	—	C	
3420	EEAS.73	Plate, clamp, starboard						1	—	C	
5F/9434858	HV.3254	STRAP						QR	—	C	
5F/9138823	NY.3255	STUD						QR	—	C	
5CY/4376390	†	SUPPRESSOR, type O, No. 2						2	—	B	
		Attaching parts for Ref. 5CY/4376390:—									
28D/1008149	A25/2B	Bolt, 4 BA (As required)						4	—	C	
28D/1010029	A25/6B	Bolt, 4 BA (As required)						4	—	C	
28M/9403519	A27/BP	Nut, 4 BA						4	—	C	
	AS.2806/4/02	Piece, distance (As required)						4	T.35	LM	
28W/9416642	SP.47/B	Washer						4	—	C	
	E.G4.81.235	WIRING, FRAME 19-20, ASSEMBLY						—	—	—	
		Spares for:—									
5X/3276	CZ.50205	BLOCK, terminal, type G						2	—	C	
		Attaching parts for CZ.50205:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
5X/9450403	Z.28426	Pillar, fixing						2	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
6A/2764	SMITH WAYMOUTH JLA/103/61							1	—	B	
28D/9436920	A25/1C							2	—	C	
28M/9433473	AGS.2002/C/1							2	—	C	
7725	EEAS.133							2	—	C	
28M/1278189	AGS.2001/B/1							1	—	C	
28S/9419435	A31/B12							1	—	C	
5X/3272	703/1/00262							2	—	B	
3417	EEAS.132/9							1	—	C	
3419	EEAS.132/15							1	—	C	
28D/8337	AS.1248/1B							1	—	C	
28M/1278189	AGS.2001/B/1							1	—	C	
7735	E.B6.81.745							1	—	C	
3420	EEAS.73							1	—	C	
5F/9434858	HV.3254							QR	—	C	
5F/9138823	NY.3255							QR	—	C	
	E.G4.81.253							—	—	—	
	E.B6.81.737							1	—	—	
28D/1007971	A25/1B							3	—	C	
28M/9403519	A27/BP							3	—	C	
	EEAS.28/6DU							3	—	—	
	E.B6.81.747							1	—	—	
28S/9419435	A31/B12							1	—	C	
28S/9419453	A31/B14							1	—	C	
28W/9416642	SP.47/B							2	—	C	
3416	EEAS.132/7							1	—	C	
3419	EEAS.132/15							1	—	C	
28D/8337	AS.1248/1B							1	—	C	
28M/1278189	AGS.2001/B/1							1	—	C	
7735	E.B6.81.745							1	—	C	
3420	EEAS.73							1	—	C	
5F/9434858	HV.3254							QR	—	C	
5F/9138823	NY.3255							QR	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.G4.81.255	WIRING, FRAMES 21-22, ASSEMBLY	—	—	—	
		Spares for:—				
7731	E.A3.81.1715	BRACKET	1	—	C	
		Attaching parts for E.A3.81.1715:—				
28D/1008149	A25/2B	Bolt, 4 BA	2	—	C	
28W/9416642	SP.47/B	Washer	2	—	C	
	7725	BRACKET	4	—	C	
		Attaching parts for EEAS.133:—				
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
28S/1200034	A31/B16	Screw	1	—	C	
	5X/6265	PLUG, size "D" (Pre-Mod. 3879)	2	—	B	
	5X/7171	PLUG, size "D" (Mod. 3879)	2	—	B	
	10H/19610	PLUG, type 757	2	—	B	
	10H/19481	PLUG/SOCKET, type 47	1	—	B	
	10H/19493	PLUG/SOCKET, type 59	1	—	B	
	5X/6493	SHELL, plug, size "C"	1	—	C	
	5X/6495	SHELL, plug, size "Z"	1	—	C	
		Attaching parts for 508/2/11335 and Z.49252:—				
28M/10286	AGS.2001/A/1	Nut, 6 BA	4	—	C	
28S/9419437	A31/A16	Screw, 6 BA	4	—	C	
	3419	STRAP, cable, c/w buckle	2	—	C	
		Attaching parts for EEAS.132/15:—				
28D/1218385	AS.1248/2B	Bolt, 4 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
	3420	Plate, clamp	1	—	C	
	7724	Washer	3	—	C	
	E.B6.81.1999	WIRING, FRAMES, 22-23, ASSEMBLY	—	—	—	
		Spares for:—				
28G/3812	AGS.797/C	EYE-BOLT	1	—	C	
		Attaching parts for AGS.797/C:—				
28M/1278190	AGS.2001/C/1	Nut, 2 BA	1	—	C	
28W/9419402	SP.13/C	Washer	1	—	C	
	E.A9.81.3975	STRAP, cable, complete, starboard	1	—	—	
38761	E.B6.81.4411	STRAP, cable, weapon loom, starboard	1	—	C	
33337	E.B6.81.4413	STRAP, cable, weapon loom, port	1	—	C	
28FP/9424331	ODDIE P.T. 325W	STUD	2	—	C	
28FP/9424332	ODDIE P.T. 326	WASHER	2	—	C	
	E.G4.81.257	WIRING AND SUPPRESSORS, FRAME, 23-24, ASSEMBLY	—	—	—	
		Spares for:—				
5CZ/868	†	BLOCK, terminal, type "B", No. 1	2	—	B	
		Attaching parts for 5CZ/868:—				
28M/9403518	A27/AP	Nut, 6 BA	2	—	C	
28S/1200062	A33/A20	Screw, 6 BA	2	—	C	
28W/9416641	SP.47/A	Washer	2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
38761	E.B6.81.4411	STRAP, cable	1	—	C	
3418	EEAS.132/12	STRAP, cable, c/w buckle	1	—	C	
		Attaching parts for EEAS.132/12:—				
28D/1218385	AS.1248/2B	Bolt, 2 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 2 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	—	C	
5CY/4376390	†	SUPPRESSOR, type "O", No. 2	2	—	B	
		Attaching parts for Ref. 5CY/4376390:—				
28D/1008149	A25/2B	Bolt, 4 BA	4	—	C	
28M/9403519	A27/BP	Nut, 4 BA	4	—	C	
28W/9416642	SP.47/B	Washer	4	—	C	
	E.G4.81.267	WIRING, FRAMES 24-25, ASSEMBLY	—	—	—	
		Spares for:—				
	SMITH					
	WAYMOUTH					
6A/2765	JLA/103/J	BOX, cable, connection (Pre-Mod. 3391)	1	—	C	
6A/7515	JY/86	BOX, cable, connection (Mod. 3391)	1	—	C	
		Attaching parts for JLA/103/J or JY/86:—				
28D/9436920	A25/1C	Bolt, 2 BA	2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	2	—	C	
20494	E.A3.81.1807	BRACKET, plug	1	L.72	C	
10H/0970056	CZ.51539	CAP, protective	2	—	C	
26902	E.A9.81.2105	COVER, assembly	1	—	C	
10H/0560140	CZ.50143/1	PLUG, fixed	1	—	C	
10H/0560541	CZ.50143	PLUG, fixed	1	—	C	
	CANNON					
	ELECTRIC					
10H/9454299	2182/8	RECEPTACLE, dummy	1	—	C	
		Attaching parts for 2182/8:—				
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28S/1007817	A32/B24	Screw, 4 BA	4	—	C	
	AS.2810/4/0500	Tube, distance	4	L.62	LM	
28W/9419474	SP.15/B	Washer	4	—	C	
3418	EEAS.132/12	STRAP, cable, c/w buckle	2	—	C	
		Attaching parts for EEAS.132/12:—				
28D/1218385	AS.1248/2B	Bolt, 2 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 2 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	—	C	
17519	EEAS.28/4DPH	Washer	2	L.16	C	
	E.G4.81.269	WIRING, FRAMES 25-26, ASSEMBLY	—	—	—	
		Spares for:—				
3418	EEAS.132/12	STRAP, cable, c/w buckle	1	—	C	
		Attaching parts for EEAS.132/12:—				
28D/1218385	AS.1248/2B	Bolt, 4 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN CENTRE FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.G4.81.117	WIRING, TO FLAP TRANSMITTER, ASSEMBLY	—	—	—	
		Spares for:—				
341B	EEAS.132/12	STRAP, cable, c/w buckle	1	—	C	
		Attaching parts for EEAS.132/12:—				
28D/1218386	AS.1248/3B	Bolt, 4 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	—	C	
	E.A3.81.387	WIRING, No. 1 FUEL TANK TRANSMITTER, ASSEMBLY	—	—	—	
		Spares for:—				
	SMITH WAYMOUTH JLA/103/60	BOX, cable, connection	1	—	C	
		Attaching parts for JLA/103/60:—				
28D/1200119	A25/4C	Bolt, 2 BA	2	—	C	
28M/9433473	AGS.2002/C/1	Nut, 2 BA	2	—	C	
	AS.2809/4/030	Tube, distance, 3/4" o/d x 0"30 x 22 SWG ...	2	L.62	LM	
7725	EEAS.133	BRACKET	1	—	C	
		Attaching parts for EEAS.133:—				
29M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
28S/9419435	A31/B12	Screw, 4 BA	1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
	E.G4.81.2805	ELECTRICAL EQUIPMENT IN FRONT FUSELAGE (MOD. 4799)	—	—	—	
9/4612	†	Spares for:— ACCELEROMETER	1	—	A	
	E.G5.80.443	BLOCK, TERMINAL, INSTALLATION	—	—	—	
5CZ/1053794	†	Spares for:— BLOCK, terminal, type B	1	—	C	
28M/1987493	AGS.2001/A/1	Attaching parts for Ref. 5CZ/1053794:—				
28S/1200062	A33/A20	Nut, 6 BA	2	—	C	
		Screw, 6 BA	2	—	C	
5CZ/4350495	†	BLOCK, terminal, type J	1	—	C	
28D/9133012	A25/3C	Attaching parts for Ref. 5CZ/4350495:—				
28M/1278190	AGS.2001/C/1	Bolt, 2 BA	2	—	C	
		Nut, 2 BA	2	—	C	
	E.B6.81.4873	BLOCK, TERMINAL AND PLUG BREAK, INSTALLATION	—	—	—	
		Spares for:—				
5X/1002694	703/1/00238	BLOCK, terminal, 5-way	1	—	C	
		Attaching parts for 703/1/00238:—				
28M/1278189	AGS.2001/B/1	Nut, 4 BA	2	—	C	
5X/9450403	703/2/00267	Pillar, fixing	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
5X/9149641	CZ.26805	COVER, terminal block	1	—	C	
5X/1004082	703/2/00251	LINK, commoning, 2-way	1	—	C	
5K/4346876	EEAS.146/6	SLEEVE	5	—	C	
5CZ/5063	E.A3.81.2665	BOX, CONTROL, WINDSCREEN HEATER, ASSEMBLY (PRE-MOD. 4420)	1	—	A	
		Spares for:—				
10H/3780	†	BLOCK, terminal	3	—	C	
		Attaching parts for Ref. 10H/3780:—				
28M/9403519	A27/BP	Nut, 4 BA	1	—	C	
28S/9435715	A33/B16	Screw, 4 BA	1	—	C	
28W/9416642	SP.47/B	Washer	1	—	C	
	E.A3.81.2671	BRACKET, mounting, potentiometer	1	—	—	
		Attaching parts for E.A3.81.2671:—				
28M/9403518	A27/AP	Nut, 6 BA	2	—	C	
28S/9436892	A31/A8	Screw, 6 BA	1	—	C	
28S/1200045	A31/A10	Screw, 6 BA	2	—	C	
28W/9416641	SP.47/A	Washer	3	—	C	
10C/0115252	Z.115252	CAPACITOR, type dielectric 2 micro-farad	1	—	C	
	E.A3.81.1443	COVER, box	1	—	—	
17045	E.A3.81.2157	PANEL, tag, assembly, C/W 5X/6627	1	—	C	
		Attaching parts for E.A3.81.2157:—				
28S/1200044	A31/A14	Screw, 6 BA	2	—	C	
28W/9419464	SP.13/A	Washer	2	—	C	
28W/9416641	SP.47/A	Washer	2	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CZ/5555	PAINTON C.V2	POTENTIOMETER, 25 ohms, preset type ...						1	—	C	
5CW/9729122	†	RELAY, type S1 ...						1	—	C	
5CW/4302	†	RELAY, type 415 ...						1	—	A	
10W/	PAINTON										
10W/0243125	P.301/15	RESISTOR, 15 ohms ...						1	—	—	
10W/	P.301/200	RESISTOR, 200 ohms ...						1	—	C	
10W/	P.406/100	RESISTOR, 100 ohms ...						1	—	—	
10W/	P.406/8000	RESISTOR, 8000 ohms ...						1	—	—	
28S/1200034	A31/B16	Attaching parts for E.A3.81.2665:— Screw, 4 BA ...						3	—	C	
	E.G4.81.2983	BOX, JUNCTION, NO. 13 (MOD. 4799) ... Spares for:—						—	—	—	
5X/1002695	703/1/00249	BLOCK, terminal, 20-way ...						1	—	C	
28S/9130752	A43/B24	Attaching parts for 703/1/00249:— Screw, 4 BA ...						2	—	C	
	E.A1.81.589	BOX, shell ...						1	—	—	
	E.B7.81.361	COVER, ASSEMBLY ... Spares for:—						1	—	—	
32C/614	†	RUBBER, synthetic, 0"14 dia. ...						QR	DTD.552	C	
20457	EEAS.117/1	SCREW ...						4	S.92	C	
1066	EEAS.28/2CU	WASHER ...						8	S.514	C	
1108	EEAS.42	WASHER ...						4	—	C	
5X/6177	CZ.24644	FERRULE, plate, "C" size ... Attaching parts for CZ.24644:—						1	—	C	
28M/10326	AGS.2002/A/1	Nut, 6 BA ...						4	—	C	
28S/1006948	A32/A12	Screw, 6 BA ...						4	—	C	
5X/6168	Z.23197 or 2Z.84912/C	GASKET, for plate, ferrule ...						1	—	C	
5X/4491423	703/2/00253	GASKET ...						1	—	—	
5X/1058004	CZ.23144/C	LINK, commoning, 4-way ...						1	—	C	
5K/4346875	EEAS.146/6	RING, clamp, for plate, ferrule ...						1	—	C	
		SLEEVE, 1/2" long ...						17	—	C	
28D/9436920	A25/1C	Attaching parts for E.G4.81.2983:— Bolt, 2 BA ...						4	—	C	
	E.G4.81.2985	BOX, JUNCTION, NO. 14, ASSEMBLY (MOD. 4799) Spares for:—						1	—	—	
	EEAS.281/D	ADAPTOR, outlet ... Attaching parts for EEAS.281/D:—						1	—	—	
28M/9418829	AGS.2002/A/1	Nut, 6 BA ...						4	—	C	
28S/1006948	A32/A12	Screw, 6 BA ...						4	—	C	
28W/9419464	SP.13/A	Washer ...						4	—	C	
5X/1002695	703/1/00249	BLOCK, terminal, 20-way ...						2	—	C	
28S/9130752	A43/B24	Attaching parts for 703/1/00249:— Screw, 4 BA ...						2	—	C	
	E.B6.81.1517	BOX, junction, 40-way ...						1	—	C	
10H/0970296	CZ.69738	CLAMP, cable ...						1	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
13237	E.B6.81.427	COVER ASSEMBLY						1	—	B	
		Spares for:—									
6171	E.A3.81.1259	CLIP, spring						6	—	C	
32C/614	†	RUBBER, synthetic, 0"14 dia.						QR	DTD.552	C	
20457	EEAS.117/1	SCREW, cover						6	S.92	C	
1066	EEAS.28/2CU	WASHER						12	S.514	C	
1108	EEAS.42	WASHER, leather						6	—	C	
5X/2790	Z.22634	GROMMET, dummy						6	—	C	
5X/1004082	703/2/00251	LINK, commoning, 2-way						4	—	C	
5X/6174	703/2/00257	LINK, commoning, 8-way						1	—	C	
5K/9107067	EEAS.146/C	SLEEVE, 3/8" long						40	—	C	
		Attaching parts for E.G4.81.2985:—									
28D/9436920	A25/1C	Bolt, 2 BA						4	—	C	
	E.G4.81.3125	BOX, JUNCTION, NO. 16, INSTALLATION (MOD. 4799)						—	—	—	
		Spares for:—									
	E.G4.81.3123	BOX, JUNCTION, NO. 16, ASSEMBLY (MOD. 4799)						1	—	—	
		Spares for:—									
5X/1002695	703/1/00249	BLOCK, terminal, 20-way						1	—	—	
		Attaching parts for 703/1/00249:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
285/1005622	A31/B28	Screw, 4 BA						2	—	C	
	E.B6.81.4093	BOX, JUNCTION, NO. 16						1	—	—	
		Spares for:—									
	E.B7.81.89	PANEL, access						1	—	—	
		Attaching parts for E.B7.81.89:—									
28S/1200034	A31/B16	Screw, 4 BA						6	—	C	
	E.B7.81.87	SEAL, access, strip panel, 1/8" thick						1	Rubber	LM	
5E/4187	†	CABLE, Uninyvin 12						QR	—	C	
5X/2790	Z.22634	GROMMET, dummy						5	—	C	
	E.B7.81.79	LID, ASSEMBLY						1	—	—	
		Spares for:—									
6171	E.A3.81.1259	CLIP, spring						6	—	C	
20457	EEAS.117/1	SCREW, cover						6	S.92	C	
1066	EEAS.28/2CU	WASHER						12	S.514	C	
1108	EEAS.42	WASHER						6	—	C	
5X/1004082	703/2/00251	LINK, commoning, 2-way						1	—	C	
5X/4491423	703/2/00253	LINK, commoning, 4-way						1	—	C	
5X/1012212	703/2/00259	LINK, commoning, 10-way						1	—	C	
5X/1004086	703/2/00260	LINK, commoning, transverse						1	—	C	
10H/0560050	CZ.48992	PLUG, Mk. 4, 2-way						1	—	C	
		Attaching parts for CZ.48992:—									
1109	EEAS.43/1	Washer, panel						1	L.72	C	
10H/0560200	CZ.49061	PLUG, Mk. 4, 25-way						6	—	C	
		Attaching parts for CZ.49061:—									
17524	EEAS.43/3	Washer, panel						1	L.72	C	
10H/0560150	CZ.49112	PLUG, Mk. 4, 12-way						2	—	C	
		Attaching parts for CZ.49112:—									
1110	EEAS.43/2	Washer, panel						1	L.72	C	
5X/6185	CZ.50361	PLUG, size "D" (Pre-Mod. 3879)						6	—	C	
5X/7159	2CZ.111229	PLUG, size "D" (Mod. 3879)						6	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5K/4346878	EEAS.146/12	SLEEVE, 1/2" long						44	—	C	
5K/4346878	EEAS.146/12	SLEEVE, 1/2" long						8	—	C	
5K/4346879	EEAS.146/10	SLEEVE, 1/2" long						8	—	C	
5K/4346879	EEAS.146/10	SLEEVE, 1" long						12	—	C	
5K/4346876	EEAS.146/6	SLEEVE, 1/2" long						265	—	C	
5K/1107826	EEAS.146/100	SLEEVE, 1" long						3	—	C	
5X/9525146	Z.49397	SLEEVE, adaptor						6	—	C	
5X/1005131	Z.49428	SLEEVE, adaptor						99	—	C	
	HELLERMANN										
5F/9434858	HV.3254	STRAPPING, Helsyn						QR	—	C	
5F/9138823	NY.3255	STUD, Helsyn						16	—	C	
5CW/6453	†	SWITCH, magnetic, type 9B, No. 2A						1	—	C	
		Attaching parts for Ref. 5CW/6453:—									
28D/1008149	A25/2B	Bolt, 4 BA						2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
5X/9462951	HC.294	TAG, RT (Mod. 4222)						2	—	C	
5X/9450396	HC.490	TAG, crimping						38	—	C	
5X/9482491	HC.500	TAG, crimping						5	—	C	
5X/9450224	HC.510	TAG, crimping						2	—	C	
5E/9424113	†	WIRE, 23/0-0076, black, type 3						QR	—	C	
5E/9424124	†	WIRE, 40/0-0076, black, type 3						QR	—	C	
5E/9424131	†	WIRE, 70/0-0076, black, type 3						QR	—	C	
		Attaching parts for E.G.4.81.3123:—									
28S/9419435	A31/B12	Screw, 4 BA						6	—	C	
	E.G.4.81.2865	BOX, DISTRIBUTION, 400 CYCLE AND DC, ASSEMBLY (MOD. 4799)						1	—	—	
		Spares for:—									
5X/4491411	CZ.52815	BLOCK, fuse						4	—	C	
		Attaching parts for CZ.52815:—									
28S/9435712	A31/B8	Screw, 4 BA						2	—	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						2	—	C	
5X/9402793	AS.2652	BLOCK, terminal, 37 amp.						2	—	C	
		Attaching parts for AS.2652:—									
28S/1200034	A31/B16	Screw, 4 BA						6	—	C	
5X/1004088	CZ.24285	BLOCK, terminal, 10-way						2	—	C	
		Attaching parts for CZ.24285:—									
28S/1005622	A31/B28	Screw, 4 BA						2	—	C	
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way						7	—	C	
		Attaching parts for CZ.23212/1:—									
28S/1200039	A31/B32	Screw, 4 BA						2	—	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						2	—	C	
	E.G.4.81.2077	BOX, distribution						1	—	—	
	E.B.6.81.549	CABLE ASSEMBLY, F18						1	—	—	
	E.B.7.81.461	CABLE ASSEMBLY, EW						1	—	—	
5E/3900	†	CABLE, unifersil 8						QR	—	C	
5E/3898	†	CABLE, unifersil 12						QR	—	C	
	CZ.51538	CAP, blanking						3	—	—	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
16922	E.A2.81.795	CARRIER , fuse						1	—	B	
28M/1987493	AGS.2001/A/1	Attaching parts for E.A2.81.795:—									
28S/1006948	A32/A12	Nut, 6 BA						2	—	C	
		Screw, 6 BA						2	—	C	
10C/0115565	†	CONDENSER , 0.25 ohms, 350v.						2	—	C	
10C/0115567	†	CONDENSER , 0.5 ohms, 250v.						3	—	C	
	E.G4.81.2075	COVER, ASSEMBLY (MOD. 4799)						1	—	—	
		(Make from Part No. E.B6.81.1177, Ref. 32526)									
		Spares for:—									
32C/614	†	RUBBER , 0"14 dia.						QR	DTD.552	C	
20457	EEAS.117/1	SCREW , cover						8	—	C	
1066	EEAS.28/2CU	WASHER						16	—	C	
1108	EEAS.42	WASHER						8	—	C	
5X/9402797	AS.2639	COVER , terminal board						2	—	C	
8337	E.A1.81.488	DISC , blanking						3	—	C	
		Attaching parts for E.A1.81.488:—									
10H/19073	Z.49035	Nut, union						1	—	C	
10H/0970088	Z.62229	Ring, sealing						1	—	C	
5X/9400055	AS.2674	FERRULE						1	—	C	
5X/9400056	AS.2675	FERRULE						2	—	C	
10H/21791	†	FUSE , dummy						4	—	C	
10H/21797	†	FUSE , type S, 2.5 amp.						2	—	C	
5X/1103756	Z.84912/A	GASKET , plug						1	—	C	
	E.A6.81.199	LINK						1	—	—	
5X/6237	EEAS.71/1	LINK , 2-way						2	—	C	
5X/1004082	Z.50210	LINK , 2-way						15	—	C	
5X/1004083	703/2/00252	LINK , 3-way						2	—	C	
5X/6174	703/2/00257	LINK , 8-way						1	—	C	
5X/1012212	703/2/00259	LINK , 10-way						1	—	C	
	E.A6.81.227	MOUNTING , fuse block						2	L.72	—	
		Attaching parts for E.A6.81.227:—									
28S/9419435	A31/B12	Screw, 4 BA						4	—	C	
16907	E.A2.81.721	MOUNTING , relay						2	—	C	
		Attaching parts for E.A2.81.721:—									
28S/9419435	A31/B12	Screw, 4 BA						2	—	C	
	E.A6.81.221	MOUNTING , relay						4	—	—	
		Attaching parts for E.A6.81.221:—									
28S/9419435	A31/B12	Screw, 4 BA						3	—	C	
29C/1206041	AGS.2035/B	Washer						3	—	C	
	E.A6.81.225	MOUNTING , transformer						1	L.72	—	
		Attaching parts for E.A6.81.225:—									
28S/9436892	A31/A8	Screw, 6 BA						4	—	C	
28VV/1007778	AGS.2035/A	Washer						4	—	C	
17317	E.A6.81.229	PILLAR , relay, mounting						12	—	C	
8545	E.A3.81.247	PLATE , blanking						1	—	C	
	E.B6.81.3631	PLATE , blanking						1	—	—	
	E.B6.81.3633	PLATE , blanking						1	—	—	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/6179	CZ.50355	PLUG, size A (Pre-Mod. 3879)	2	—	C		
5X/7140	2CZ.111399	PLUG, size A (Mod. 3879)	2	—	C		
5X/7147	2CZ.111299	PLUG, size B	1	—	C		
5X/6091	CZ.28108	PLUG, size C (Pre-Mod. 3879)	1	—	C		
5X/7152	2CZ.111227	PLUG, size C (Mod. 3879)	1	—	C		
5X/6333	CZ.28112	PLUG, size D (Pre-Mod. 3879)	2	—	C		
5X/7156	2CZ.111408	PLUG, size D (Mod. 3879)	2	—	C		
5X/6185	CZ.50361	PLUG, size D (Pre-Mod. 3879)	12	—	C		
5X/7159	2CZ.111229	PLUG, size D (Mod. 3879)	12	—	C		
5X/5805563	2CZ.111412	PLUG, size E	1	—	C		
10H/0560200	CZ.49061	PLUG, Mk. 4, 25-way	1	—	C		
5K/4346875	EEAS.146/6	SLEEVE, 1/2" long	101	—	C		
5K/4346876	EEAS.146/6	SLEEVE, 1/2" long	45	—	C		
5K/4346878	EEAS.146/12	SLEEVE, 3/4" long	435	—	C		
5K/4346882	EEAS.146/16	SLEEVE, 1/2" long	71	—	C		
5X/9525146	Z.49397	SLEEVE, 7-19 amp.	3	—	C		
5X/1005131	Z.49428	SLEEVE, 4-7 amp.	204	—	C		
5X/5806535	AS.2640	SOCKET, assembly	6	—	C		
5X/	CZ.49618	SOCKET, double tier, 50 amp.	1	—	C		
10H/0560240	CZ.49219	SOCKET, Mk. 4, 3-way	1	—	C		
10H/0560241	CZ.49219/1	SOCKET, Mk. 4, 3-way	1	—	C		
10H/0560260	CZ.49223	SOCKET, fixed, Mk. 4	1	—	C		
	HELLERMANN										
5F/9434858	HV.3254	STRAPPING	QR	—	C		
5F/9138823	NY.3255	STUD	12	—	C		
33420	E.B7.81.347	SUPPORT, terminal block	9	—	C		
		Attaching parts for E.B7.81.347:—									
28S/1005622	A31/B28	Screw, 4 BA	2	—	C		
5CW/9729122	†	SWITCH, magnetic relay, type S.1	3	—	C		
5CW/9729123	†	SWITCH, magnetic relay, type S.3	2	—	C		
5X/9462745	HC.304	TAG	2	—	C		
5X/9482491	HC.500	TAG	30	—	C		
5X/9450224	HC.510	TAG	18	—	C		
5X/9450396	HC.490	TAG	131	—	C		
	SMITHS										
6A/4333075	213MV	TRANSFORMER	2	—	C		
		Attaching parts for 213 MV:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA	2	—	C		
28S/9419435	A31/B12	Screw, 4 BA	2	—	C		
	1109	WASHER, panel	3	—	C		
	17524	WASHER, panel	1	—	C		
5E/9424113	†	WIRE, equipment, type 3, 23/0076, black	QR	—	C		
5E/9424124	†	WIRE, equipment, type 3, 40/0076, black	QR	—	C		
	E.G.4.81.2863	BOX, DISTRIBUTION, 1600 CYCLE, ASSEMBLY (MOD. 4799)	1	—	C		
		Spares for:—									
5X/4491411	CZ.52815	BLOCK, fuse	4	—	C		
		Attaching parts for CZ.52815:—									
28S/9435712	A31/B8	Screw, 4 BA	2	—	C		
28W/9416642	SP.47/B	Washer, spring	2	—	C		
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way	2	—	C		
		Attaching parts for CZ.23212/1:—									
28S/1200093	A31/B24	Screw, 4 BA	2	—	C		

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Mtrl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/1004088	CZ.24285	BLOCK, terminal, 10-way						1	—	C	
		Attaching parts for CZ.24285:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
28S/1200033	A31/B24	Screw, 4 BA						2	—	C	
	E.B7.81.941	BOX, distribution						1	—	—	
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
5E/1934440	†	CABLE, Uniminyvin 20						QR	—	C	
5E/4199	†	CABLE, Uninyvinmetsheath 20						QR	—	C	
16922	E.A2.81.795	CARRIER, fuse, spare, 4-way						1	—	B	
		Attaching parts for E.A2.81.795:—									
28M/1987493	AGS.2001/A/1	Nut, 4 BA						2	—	C	
28S/9995324	A32/A16	Screw, 6 BA						2	—	C	
8368	E.B7.81.943	COVER, ASSEMBLY						1	—	B/MR	
		Spares for:—									
6171	E.A3.81.1259	CLIP, spring						4	—	C	
32C/614	†	RUBBER, synthetic, 0"14 dia.						QR	DTD.552	C	
20457	EEAS.117/1	SCREW, cover						4	S.92	C	
1066	EEAS.28/2CU	WASHER						8	S.514	C	
1108	EEAS.42	WASHER, leather						4	—	C	
	E.B6.81.4807	DISC, blanking						1	—	—	
		Attaching parts for E.B6.81.4807:—									
10H/0970130	†	Nut, union						1	—	C	
8375	E.A1.81.487	DISC, blanking						4	—	C	
		Attaching parts for E.A1.81.487:—									
10H/0970127	†	Nut, union						1	—	C	
8337	E.A1.81.488	DISC, blanking						4	—	C	
		Attaching parts for E.A1.81.488:—									
10H/0970128	†	Nut, union						1	—	C	
10H/21791	†	FUSE, dummy						5	—	C	
10H/23864	†	FUSE, 5 amp.						15	—	C	
5X/9434277	†	GROMMET						10	—	C	
	E.A3.81.577	LABEL						1	—	—	
	E.A3.81.581	LABEL						1	—	—	
	E.A3.81.585	LABEL						1	—	—	
	E.G4.81.3149	LABEL						1	—	—	
	E.B7.81.945	LABEL						1	—	—	
	E.B7.81.953	LABEL						1	—	—	
5X/4491430	EEAS.71/1	LINK, commoning, 2-way						2	—	C	
5X/4491436	EEAS.71/2	LINK, commoning, 3-way						1	—	C	
5X/1004082	Z.50210	LINK, 2-way						1	—	C	
5X/1004083	703/2/00252	LINK, 3-way						2	—	C	
5X/6314	703/2/00255	LINK, 6-way						1	—	C	
5X/1004086	703/2/00260	LINK, transverse						1	—	C	
8353	E.A3.81.243	MOUNTING, fuse block						1	—	C	
		Attaching parts for E.A3.81.243:—									
28S/9419435	A31/B12	Screw, 4 BA						6	—	C	
8369	E.A3.81.241	MOUNTING, relay						1	—	C	
		Attaching parts for E.A3.81.241:—									
28S/9419435	A31/B12	Screw, 4 BA						5	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
10H/0560050	†	PLUG , fixed. Mk. 4						3	—	C	
1109	EEAS.43/1	Attaching parts for Ref. 10H/0560050:— Washer						1	L.72	C	
5CW/6717	†	RELAY , type S7						4	—	C	
28M/1987493	AGS.2001/A/1	Attaching parts for Ref. 5CW/6717:— Net. 6 BA						4	—	C	
8370	E.A3.81.245	SCREEN						1	—	C	
28M/1987493	AGS.2001/A/1	Attaching parts for E.A3.81.245:— Net. 6 BA						5	—	C	
28S/9436892	A31/A8	Screw. 6 BA						5	—	C	
5K/4346878	EEAS.146/10	SLEEVE , 1/2" long						QR	—	C	
5K/4346878	EEAS.146/12	SLEEVE , 1/2" long, Green						60	—	C	
5K/4346878	EEAS.146/10	SLEEVE , 1/2" long, Yellow						QR	—	C	
10H/0560332	†	SOCKET , fixed						1	—	C	
1110	EEAS.43/2	Attaching parts for Ref. 10H/0560332:— Washer						1	L.72	C	
5F/9434858	HV.3254	STRAP , Helvin						QR	—	C	
5F/9138823	NY.3255	STUD , Helvin						QR	—	C	
5X/9450396	HC.490	TAG , Q.R.						41	—	C	
5X/9709513	HC.294D	TAG						5	—	C	
28D/9436920	A25/1C	Attaching parts for E.G4.81.2863:— Bolt, 1 BA						4	—	C	
	E.G4.81.3073	BOX, FUSE, 400 CYCLE, ASSEMBLY (MOD. 4799)						1	—	—	
5X/4491411	CZ.52815	Spares for:— BLOCK , fuse						6	—	C	
28S/9992525	A32/B12	Attaching parts for CZ.52815:— Screw, 4 BA						2	—	C	
28W/9416642	SP.47/B	Washer, spring						2	—	C	
5E/4183	E.G4.81.957	BOX , shell						1	—	—	
5E/3894	†	CABLE , Uninyvin 20						QR	—	C	
	†	CABLE , Unisersil 20						QR	—	C	
	E.G4.81.3075	COVER, ASSEMBLY (MOD. 4799)						1	—	—	
	E.A1.81.542	Spares for:— CARRIER , spare fuse						1	—	—	
	E.G4.81.3093	LID , assembly (Mod. 4799)						1	—	—	
6171	E.A3.81.1259	Attaching parts for E.G4.81.3093:— Clip, spring						4	—	C	
32C/614	†	Rubber, 0"14 o/d.						QR	DTD.552	C	
20457	EEAS.117/1	Screw, 4 BA						4	5.92	C	
1066	EEAS.28/2CU	Washer						8	—	C	
1108	EEAS.42	Washer, leather						4	—	C	
10H/23864	†	FUSE , type AS, 5 amp.						2	—	C	
10H/23865	†	FUSE , type AS, 2.5 amp.						10	—	C	
10H/21791	†	FUSE , dummy						12	—	C	
	E.G4.81.953	GLAND , assembly						1	—	—	
1120	EEAS.62/2	GLAND						7	—	C	
1121	EEAS.62/3	GLAND						2	—	C	
5X/4491430	EEAS.71/1	LINK , 2-way						3	—	C	
5X/4491436	EEAS.71/2	LINK , 3-way						2	—	C	
5X/4491431	EEAS.71/3	LINK , 4-way						2	—	C	
5K/4346887	EEAS.146/20	SLEEVE , 1/2" long						8	—	C	
5X/9450396	HC.490	TAG , Q.R.						8	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
34349	E.G4.81.965	TERMINAL, ASSEMBLY						1	—	C		
		Spares for:—										
	E.G4.81.967	BLOCK , insulating						1	—	—		
	E.G4.81.951	LINK , connecting						1	—	—		
28M/4095821	AGS.2002/B/4	NUT , 4 BA						2	—	C		
28M/9136152	A54/B	NUT , 4 BA						2	—	C		
28S/1012364	A45/B32	SCREW , 4 BA						2	—	C		
28W/9437455	SP.25/B	WASHER						4	—	C		
34348	E.G4.81.947	TERMINAL, DOUBLE EARTH, ASSEMBLY						1	—	C		
		Spares for:—										
	E.G4.81.949	BLOCK , insulating						1	—	—		
	E.G4.81.951	LINK , commoning						1	—	—		
28M/4095821	AGS.2002/B/4	NUT , 4 BA						4	—	C		
28M/9136152	A54/B	NUT , 4 BA						2	—	C		
	EEAS.144	STUD , terminal						2	—	—		
	EEAS.28/7EW	WASHER						8	—	—		
27400	E.A9.81.3471	BRACKET , mounting, accelerometer						1	—	C		
		Attaching parts for E.A9.81.3471:—										
28D/1010658	A25/1B	Bolt; 4; BA						4	—	C		
28W/9419401	SP.10/B	Washer						QR	—	C		
28W/9419465	SP.13/B	Washer						4	—	C		
	E.G4.80.1187	BRACKET , plug break, master altimeter, frame 5, port (Mod. 4864) 18 SWG						1	L72	LM		
		Attaching parts for E.G4.80.1187:—										
28D/9436920	A25/1C	Bolt; 2; BA						4	—	C		
28M/1278190	AGS.2001/C/1	Nut; 2; BA						4	—	C		
28W/9419475	SP.15/C	Washer						4	—	C		

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.B6.81.5291	BRACKET, PLUG INSTALLATION, FRAME 11 ...	—	—	—		
	E.B6.81.5289	Spares for:— BRACKET, plug	1	L.72	—		
		Attaching parts for E.B6.81.5289:—					
28D/9133011	A25/2C	Bolt, 2 BA	1	—	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	1	—	—	C	
28S/9992522	A32/B16	Screw, 4 BA	4	—	—	C	
28W/9419465	SP.13/B	Washer	4	—	—	C	
28W/9419402	SP.13/C	Washer	1	—	—	C	
5UC/8770	506/1/07360	CONTROLLER, type 34 Mk. 1, windscreen heater (Mod. 4420)	1	—	—	A	
		Attaching parts for Ref. 5UC/8770:—					
28D/1214269	AS.1246/6B	Bolt, 4 BA	4	—	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	—	C	
28W/9419474	SP.15/B	Washer	4	—	—	C	
6A/4332835	†	COMPENSATOR, voltage, type A No. 1	1	—	—	A	
		Attaching parts for Ref. 6A/4332835:—					
28D/9140202	AS.1246/1C	Bolt, 2 BA	3	—	—	C	
4438	E.A3.81.2245	COVER, torque, switch	1	—	—	C	
		Attaching parts for E.A3.81.2245:—					
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	—	C	
28S/1200034	A31/B16	Screw, 4 BA	4	—	—	C	
	E.A9.81.10869	EARTH POINT, E80, GROUND SERVICE IN STARBOARD HATCH, INSTALLATION (MOD. 3976)	—	—	—		
		Spares for:—					
41316	E.A9.81.10865	BOLT, 5/8" UNF	1	S.96	—	C	
41317	E.A9.81.10867	LABEL, engraved	1	L.72	—	C	
28M/9416047	A103/GT	NUT, 5/8" UNF	2	—	—	C	
28M/9573834	AGS.3413/G	NUT, wing, 5/8" UNF	1	—	—	C	
28P/9486478	SP.90/C5	PIN, split	1	—	—	C	
41347	EEAS.28/31ERH	WASHER	1	—	—	C	
28W/9128199	SP.55/G	WASHER, double spring	1	—	—	C	
28W/9459071	SP.126/G	WASHER	1	—	—	C	
	SCD.78595	EQUIPMENT, INSTALLATION IN PORT LOWER EQUIPMENT BAY (SRIM.3533) (MOD. 4799)	—	—	—		
		Spares for:—					
5CY/4376384	†	CIRCUIT-BREAKER, type B1	2	—	—	C	
		Attaching parts for Ref. 5CY/4376384:—					
28D/1011238	A25/3E	Bolt, 1/2" BSF	4	—	—	C	
28M/1201610	AGS.2001/E1/77	Nut, 1/2" BSF	2	—	—	C	
28M/9435560	AGS.2007/E/1	Nut, anchor, 1/2" BSF	2	—	—	C	
28W/9418921	SP.13/E	Washer	4	—	—	C	
5UC/4395975	†	PANEL, control, type 26B	2	—	—	A	
	SCD.78599	PLATE, mounting assembly, for equipment (SRIM.3533) (Mod. 4799)	1	—	—	—	
		Attaching parts for SCD.78599:—					
28D/9140202	AS.1246/1C	Bolt, 2 BA	13	—	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	7	—	—	C	
28W/9419402	SP.13/C	Washer	13	—	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CZ/2742	†	RESISTOR unit, type A						2	—	C	
28S/1200060	A33/A16	Attaching parts for Ref. 5CZ/2742:— Screw, 6 BA						2	—	C	
5CW/5016	U.2005/1	SWITCH , magnetic starting, type 1A, No. 5 ...						2	—	A	
28D/1215079	AS.1246/6C	Attaching parts for U.2005/1:— Bolt, 2 BA						4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						2	—	C	
28M/11957	AGS.2007/C/1	Nut, anchor, 2 BA						2	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
33680	E.A9.81.3661	TRAY, MOUNTING, ASSEMBLY						2	—	B	
33410	E.A9.81.3675	Spares for:— BRACKET , catch, securing						2	L.72	C	
33411	E.A9.81.3677	CATCH , panel control, securing						2	L.72	C	
33408	E.A9.81.3671	Attaching parts for E.A9.81.3677:— Circlip						1	—	C	
33409	E.A9.81.3673	Nut, cylindrical						1	S.1	C	
33406	E.A9.81.3667	Screw, knurled, finger						1	S.92	C	
28W/9994791	AGS.160/A	Washer						1	—	C	
28W/9703147	AGS.163/D	Washer						1	—	C	
28W/9418921	SP.13/E	Washer						1	—	C	
33407	E.A9.81.3669	DOWEL , locating, control						2	L.64	C	
28M/1278190	AGS.2001/C/1	Attaching parts for E.A9.81.3669:— Nut, 2 BA						1	—	C	
10AJ/158		MOUNTING , AV, 4 lbs.						2	—	C	
10AJ/159		MOUNTING , AV, 6 lbs.						2	—	C	
28M/1278190	AGS.2001/C/1	Attaching parts for mountings:— Nut, 2 BA						4	—	C	
28S/9435713	A31/C20	Screw, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
33412	E.A9.81.3683	PILLAR						2	L.64	C	
28D/1010031	A25/8E	Attaching parts for E.A9.81.3683:— Bolt, 1/2" BSF						4	—	C	
28M/1201610	AGS.2001/E1/77	Nut, 1/2" BSF						4	—	C	
28W/9418921	SP.13/E	Washer						4	—	C	
SK/ 5UB/5083	STANDARD INSULATOR S.I.C.664.4133 †	GROMMET						1	—	—	
28D/1011029	A25/1E	INVERTER , type 200						1	—	A	
28M/9480017	AGS.2001/E1/66	Attaching parts for Ref. 5UB/5083:— Bolt, 1/2" BSF						6	—	C	
	E.G4.81.2861	Nut, 1/2" BSF						1	—	C	
	E.B6.81.1033	INVERTER, BAY LAYOUT, LOWER (MOD. 4799)						—	—	—	
	E.B6.81.1231	Spares for:— ANGLE , foot (Made from EEDX.127, Ref. 3570)						1	—	LM	
		ANGLE , foot (Made from EEDX.127, Ref. 3570)						1	—	LM	
28D/1011238	A25/3E	Attaching parts for E.B6.81.1033 and E.B6.81.1231:— Bolt, 1/2" BSF						2	—	C	
28D/1212749	AS.1242/9G	Bolt, 3/8" BSF						2	—	C	
28M/9480017	AGS.2001/E1/66	Nut, 1/2" BSF						2	—	C	
28M/4095807	AGS.2001/G/1	Nut, 3/8" BSF						2	—	C	
28W/9418920	SP.10/E	Washer						2	—	C	
28W/9419476	SP.15/G	Washer						2	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.1083	ANGLE , mounting						1	—	—	
28D/9436920	A25/1C	Attaching parts for E.B6.81.1083:—									
28W/9419475	SP.15/C	Bolt, 2 BA						3	—	C	
		Washer						3	—	C	
	E.G4.81.867	BLOCK, FUSE, ASSEMBLY (MOD. 3856) (Make from E.B6.81.1041 Ref. No. 32333) Consisting of:—						1	—	—	
	E.B6.81.1049	BASE						1	—	—	
32334	E.B6.81.1043	BOLT						2	—	C	
28D/1215164	AS.4565/7C	BOLT, 2 BA						2	—	C	
	E.B6.81.1045	COVER						1	—	—	
	E.B6.81.1047	END						2	—	—	
28M/1010994	A14/GB	NUT, 1/8" BSF (Electro tinned DTD.924) ...						2	—	C	
28M/10312	AGS.2002/G/4	NUT, 1/8" BSF brass						2	—	C	
28S/9435715	A33/B16	SCREW, 4 BA						2	—	C	
28S/1008075	A41/B16	SCREW, 4 BA						2	—	C	
28S/1213960	A41/B20	SCREW, 4 BA						2	—	C	
28W/19544	AS.2721	WASHER, contact						5	—	C	
		Attaching parts for E.G4.81.867:—									
28D/9133012	A25/3C	Bolt, 2 BA						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
	E.B6.81.1073	BRACKET						2	—	—	
	E.B6.81.1074	BRACKET						2	—	—	
		Attaching parts for E.B6.81.1073 or E.B6.81.1074:—									
28D/9133011	A25/2C	Bolt, 2 BA						3	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						3	—	C	
28W/9419475	SP.15/C	Washer						1	—	C	
28W/9419404	SP.16/C	Washer						2	—	C	
	SCB.76943/1	CHANNEL , mounting, inverter type 108 (SRIM.3533) (Mod. 4799) 16 SWG						1	L.72	—	
	SCB.76943/2	CHANNEL , mounting, inverter type 108 (SRIM.3533) (Mod. 4799) 16 SWG						1	L.72	—	
		Attaching parts for SCB.76943/1 or SCB.76943/2:—									
28D/9133012	A25/3C	Bolt, 2 BA						8	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						8	—	C	
	SCD.76956/6	Washer, contour, 10 SWG						8	L.72	—	
	34523	CLIP , hose						2	—	C	
	30165	CLIP , hose						2	—	C	
28E/9488798	AS.3181/6B	CLIP, P						1	—	C	
28E/1012847	AS.3181/18B	CLIP, P						1	—	C	
	SCB.76958	CONNECTION , air cooling, inverter type 108 (SRIM.3533) (Mod. 4799) 20 SWG						1	L.59	—	
		Attaching parts for SCB.76958:—									
28E/2027591	SP.91/L	Clip						1	—	C	
10H/0119128	†	FUSE , H.R.C. 115 amp.						1	—	C	
5UB/4357516	†	INVERTER , type 108 (SRIM.3533) (Mod. 4799)						1	—	A	
		Attaching parts for Ref. 5UB/4357518:—									
28D/1202771	A25/4G	Bolt, 1/8" BSF						4	—	C	
28W/9419403	SP.13/G	Washer						4	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
SUB/4938	†	INVERTER, Type 100A						1	—	A	
28D/1202334	AS.1242/3E	Attaching parts for Ref. SUB/4938:—									
28M/9480017	AGS.2001/E1/66	Bolt, 1/2" BSF						4	—	C	
28W/9419405	SP.15/E	Nut, 1/2" BSF						4	—	C	
		Washer						4	—	C	
SUB/6731	†	INVERTER, Type 103A (Mod. 2643)						1	—	A	
28D/1212747	AS.1242/6G	Attaching parts for Ref. SUB/6731:—									
28M/4095807	AGS.2001/G/1	Bolt, 3/8" BSF						4	—	C	
28W/9419476	SP.15/G	Nut, 3/8" BSF						4	—	C	
		Washer						4	—	C	
32535	E.B6.81.1013	LINK, MI						1	—	C	
SUC/4939	†	PANEL, control, Type 12						1	—	A	
28D/9480017	AS.1242/3E	Attaching parts for Ref. SUC/4939:—									
28M/9480017	AGS.2001/E1/66	Bolt, 1/2" BSF						4	—	C	
28W/9419405	SP.15/E	Nut, 1/2" BSF						4	—	C	
		Washer						4	—	C	
32537	E.B6.81.1059	PLATE, mounting, assembly						1	—	C	
32536	E.B6.81.1037	PLATE, MOUNTING, ASSEMBLY						1	—	C	
		Consisting of:—									
32332	E.A3.81.2885	PIN, locating						2	—	C	
28M/7002430	AGS.2002/E/1	Attaching parts for E.A3.81.2885:—									
28W/9418921	SP.13/E	Nut, 1/2" BSF						2	—	C	
		Washer						2	—	C	
	E.B6.81.1039	PLATE, mounting						1	—	—	
32538	E.B6.74.87	SLEEVE, connecting						1	—	C	
32539	E.B6.74.89	SLEEVE, connecting						1	—	C	
5CW/4620	†	SWITCH, magnetic relay, Type T, No. 1						1	—	B	
28D/9133012	A25/3C	Attaching parts for Ref. 5CW/4620:—									
28W/9419475	SP.15/C	Bolt, 2 BA						2	—	C	
		Washer						2	—	C	
5CW/5016	†	SWITCH, magnetic, starting, Type 1A, No. 5						1	—	A	
	E.B6.81.5275	INVERTER, UPPER INSTALLATION						—	—	—	
		Spares for:—									
34371	E.B6.81.3415	BOX, RELAY, ASSEMBLY						1	—	B	
	E.B6.81.4141	Spares for:—									
		BLOCK, FUSE, ASSEMBLY						1	—	—	
		Consisting of:—									
5X/3271	CZ.52815	BLOCK, fuse, 4-way						1	—	C	
	E.B6.81.4143	LABEL						1	—	—	
28S/9992525	A32/B12	Attaching parts for E.B6.81.4141:—									
29C/1206041	AGS.2035/B	Screw, 4 BA						2	—	C	
		Washer, shakeproof						2	—	C	
	E.B6.81.3417	BOX, SHELL, sub assembly						1	—	—	
	E.B6.81.3423	CHANNEL, mounting						1	—	—	
28S/1008327	A32/B14	Attaching parts for E.B6.81.3423:—									
		Screw, 4 BA						4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
10H/23863 33506	† E.B6.81.3421	FUSE , 7.5 amp.						3	—	C	
		LID , assembly						1	—	C	
		Attaching parts for E.B6.81.3421:—									
28S/1011490	A32/C16	Screw , 2 BA						4	—	C	
10H/0560565	Z.48993/5	PLUG , fixed						1	—	C	
10H/0560660	Z.48993	PLUG , fixed						1	—	C	
5CW/6698	7CZ.107791	RELAY , assembly						1	—	B	
5K/4346888	EEAS.146/20	SLEEVE						23	—	C	
10H/	7CZ.107794	SOCKET , assembly						1	—	—	
10H/0560240	Z.49219	SOCKET , fixed						1	—	C	
5X/1010324	HC.490	TAG						6	—	C	
5E/9100188	†	WIRE , equipment, Type 2 23/0076, black ...						QR	—	C	
		Attaching parts for E.B6.81.3415:—									
28D/9133011	A25/2C	Bolt , 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	E.B6.81.5267	BRACKET , inverter, mounting, assembly ...						1	—	—	
		Attaching parts for E.B6.81.5267:—									
28D/9436920	A25/1C	Bolt , 2 BA						4	—	C	
28M/1278190	AGS.2001/C/1	Nut , 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	33710	CLIP , bonding						5	—	C	
	39861	CLIP , bonding						1	—	C	
		Attaching parts for E.B6.81.4391 and E.B6.81.4419:—									
28D/1010658	A25/1B	Bolt , 4 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut , 4 BA						1	—	C	
28W/9419465	SP.13/B	Washer						1	—	C	
	12206	HOSE , rubber						3	—	C	
		Attaching parts for E.B7.57.181:—									
28E/9129562	AGS.605/3	Clip						2	—	C	
	SUB/6731	INVERTER , type 103A						1	—	A	
		Attaching parts for Ref. SUB/6731:—									
28D/1202771	A25/4G	Bolt , 1/8" BSF						4	—	C	
28W/9419403	SP.13/G	Washer						4	—	C	
	5K/7000206	LEAD , bonding						3	—	C	
	38447	PIPE , assembly						1	—	C	
	33504	PIPE , assembly						1	—	C	
	E.B6.81.3049	PLATE , packing, scoop						1	—	—	
	38448	SCOOP , assembly						1	—	C	
	E.G4.81.2885	INVERTER , TYPE 108 IN UPPER EQUIPMENT BAY, INSTALLATION (MOD. 4799) Spares for:—						—	—	—	
	SCB.79234	ADAPTOR , hose (SR1M.3533) (Mod. 4799) 18 SWG Attaching parts for SCB.79234:—						1	L.59	—	
28E/2027591	SP.91/L	Clip						1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCB.79245/1	BRACKET , clip support (SRIM.3533) (Mod. 4799) 18 SWG						1	L.72	—	
28M/1278190	AGS.2001/C/1	Attaching parts for SCB.79245/1:—									
28S/9435713	A31/C20	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Screw, 2 BA						4	—	C	
		Washer						4	—	C	
	SCB.79245/2	CLAMP , pipe (SRIM.3533) (Mod. 4799) 18 SWG						1	L.72	—	
28M/1278190	AGS.2001/C/1	Attaching parts for SCB.79245/2:—									
28S/9435713	A31/C20	Nut, 2 BA						1	—	C	
28W/9419402	SP.13/C	Screw, 2 BA						1	—	C	
		Washer						1	—	C	
28E/9712166	SP.91/H	CLIP , hose						2	—	C	
	BELLS ASBESTOS	HOSE , flexible, 1 1/4" i/d. Bestobell Airlight, type D (SRIM.3533) (Mod. 4799)						QR	—	—	
5UB/4357518	†	INVERTER , type 108 (SRIM.3533) (Mod. 4799) ...						1	—	A	
28D/1011257	A25/7G	Attaching parts for Ref. 5UB/4357518:—									
23W/9419403	SP.13/G	Bolt, 3/8" BSF						4	—	C	
		Washer						4	—	C	
	E.G4.10.337	SCOOP, AIR, INSTALLATION						—	—	—	
	E.G4.10.553	Spares for:—									
	E.G4.81.2833	SCOOP , air						1	—	—	
	4868	LOOMS, CABLE, ASSEMBLY (MOD. 4799)						—	—	—	
	5419	Spares for:—									
	E.A1.675/1	CABLE, ASSEMBLY , 4C4, from undercarriage terminal board to nosewheel door switch						1	—	B	
	E.A1.81.684/1	CABLE, ASSEMBLY , N74, from windscreen heater thermostatic control box to coupe break						1	—	B	
	E.G4.81.2093	CABLE, ASSEMBLY , F170, from windscreen heater controller to 400 cycle fuse box (Mod. 4420)						1	—	—	
	E.A3.81.669/1	CABLE, ASSEMBLY , F44, from DC distribution box to undercarriage terminal board						1	—	—	
8302	E.A3.81.670/1	CABLE, ASSEMBLY , F45, from DC distribution box to pyrometer voltage compensator						1	—	B	
	E.A3.81.679/1	CABLE, ASSEMBLY , F59, from 1600 cycle distribution box to inverter No. 4, Type 200 (Pre-Mod. 5195)						1	—	—	
8307	E.A3.81.681/1	CABLE, ASSEMBLY , F83, from suppressor to DC distribution box						1	—	B	
8308	E.A3.81.682/1	CABLE, ASSEMBLY , F83A, from 1600 cycle distribution box to suppressor						1	—	B	
8309	E.A3.81.683	CABLE, ASSEMBLY , F88, from 1600 cycle distribution box to Rebecca T.R. blower (Pre-Mod. 5195)						1	—	B	
8310	E.A3.81.695	CABLE, ASSEMBLY , F90, from 1600 cycle distribution box to Rebecca T.R. unit (Pre-Mod. 5195)						1	—	B	
8314	E.A3.81.689/1	CABLE, ASSEMBLY , F54, from D.C. distribution box to inverter type 200 (Pre-Mod. 5195)						1	—	B	
4193	E.A3.81.811/1	CABLE, ASSEMBLY , F92, from 1600 cycle distribution box to 500 VA transformer (Pre-Mod. 5195)						1	—	B	
8312	E.A3.81.852/1	CABLE, ASSEMBLY , E28, earth connection for D.C. distribution box (Pre-Mod.5100)						1	—	B	
	E.A3.81.6215	CABLE, ASSEMBLY , E28 (Alt. R60/68—Mod. 5100)						1	—	LM	
		(See Cable Chart for Breakdown Spares)									

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
8313	E.A3.81.853/1	CABLE ASSEMBLY, E29, earth connection for 1600 cycle distribution box (Pre-Mod. 5100)						1	—	B	
8328	E.A3.81.6217	CABLE ASSEMBLY, E29 (Alt. R60/68—Mod. 5100)						1	—	LM	
	E.A3.81.1969	CABLE ASSEMBLY, E34, earth connection for inverter No. 4, type 200 (Pre-Mod. 5195)						1	—	B	
	E.B6.81.10047	CABLE ASSEMBLY, NS1, from E.C.P. to fuel pump cocks and switches (Mod. 3577 with Mod. 715)						1	—	—	
	E.A3.81.2537/2	CABLE ASSEMBLY, NS2, from pressure bulkhead to fuel pump cocks and switches (Modified by SRIM.3533) (Mod. 4799)						1	—	—	
8542	E.A3.81.2561	CABLE ASSEMBLY, F93, from 1600 cycle distribution box to rear warning waveform generator blower						1	—	B	
43122	E.A3.81.2931/2	CABLE ASSEMBLY, F52E, from inverter No. 2 type 100A, to control panel, type 12						1	—	C	
	E.A3.81.2961	CABLE ASSEMBLY, 13K, from JB13, to terminal block, frame 7, port side						1	—	—	
	E.B6.81.563/2	CABLE ASSEMBLY, F72, from D.C. distribution box to connection at pressure bulkhead						1	—	—	
	E.B6.81.565/2	CABLE ASSEMBLY, N5, from pilot's console to connection at pressure bulkhead						1	—	—	
	E.B6.81.581/2	CABLE ASSEMBLY, N72, from pilots console to connection at pressure bulkhead						1	—	—	
	E.G4.81.929	CABLE ASSEMBLY, E14, earth connection for JB4 and 400 cycle fuse box (Pre-Mod. 5100)						1	—	—	
	E.G4.81.3203	CABLE ASSEMBLY, E14 (Alt. R60/68—Mod. 5100)						1	—	LM	
	E.B6.81.761	CABLE ASSEMBLY, 16Y, from JB16 to regulator oxygen demand, prone position						1	—	—	
	E.B6.81.763	CABLE ASSEMBLY, 13J, from oxygen demand regulator, pilots position to junction box 13						1	—	—	
	E.B6.81.775	CABLE ASSEMBLY, 16P, from JB16 to pitot head terminal board						1	—	—	
	E.B6.81.1129	CABLE ASSEMBLY, F68, from 400 cycle distribution box, to 5-way block						1	—	—	
	E.B6.81.1133	CABLE ASSEMBLY, F68A, from 5-way block to voltage regulator						1	—	—	
	E.B6.81.1153/2	CABLE ASSEMBLY, F58, from 400 cycle distribution box to inverter No. 1, type 103						1	—	—	
38583	E.B6.81.1155	CABLE ASSEMBLY, E100A, from earth pillar to control panel, type 12						1	—	C	
	E.B6.81.1157	CABLE ASSEMBLY, M13, from switch magnetic starting, type 1A, No. 5, to switch magnetic starting type 1A, No. 5						1	—	—	
	E.B6.81.1159/2	CABLE ASSEMBLY, F52, from distribution box to control panel type 12, "T" type relay, switch magnetic starter type 1A No. 5 and M.E.P. bus-bar panel (Used on a/c WH957 only)						1	—	—	
	E.G5.81.523	CABLE ASSEMBLY, F52, from distribution box to control panel type 12 and "T" type relay, switch magnetic starter type 1A, No. 5 and M.E.P. bus-bar panel (Mod. 4075 and 4227) (Not required for a/c WH957)						1	—	—	
(See Cable Chart for Breakdown Spares)											

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
33135	E.B6.81.1161	CABLE,	ASSEMBLY,	F52C,	from control panel			1	—	C	
	E.B6.81.1163/2	CABLE,	ASSEMBLY,	F57,	from 400 cycle dis-			1	—	—	
	E.B6.81.1165	CABLE,	ASSEMBLY,	M11,	from magnetic relay			1	—	—	
					type T1 to switch magnetic starting,						
					type A1 No. 5						
38588	E.B6.81.1167	CABLE,	ASSEMBLY,	E103,	from earth stud frame			1	—	C	
					10 to inverter type 103						
	E.B6.81.1171	CABLE,	ASSEMBLY,	P10,	from bus-bar to fuse			1	—	—	
					block						
40522	E.B6.81.1525/2	CABLE,	ASSEMBLY,	F70/F71,	from block terminal			1	—	C	
					and DC distribution box to plug bracket						
					at frame 11, and 1600 cycle distribution						
					box						
	E.B6.81.1867	CABLE,	ASSEMBLY,	F42,	from D.C. distribution			1	—	—	
					box to torque switch						
	E.G4.81.931	CABLE,	ASSEMBLY,	N18,	from 400 cycle fuse box			1	—	—	
					to connection at pressure bulkhead						
	E.B6.81.2847	CABLE,	ASSEMBLY,	F41,	from 400 cycle dis-			1	—	—	
					tribution box to torque switch						
	E.B6.81.2947	CABLE,	ASSEMBLY,	F131,	from M.E.P. to relay			1	—	—	
					type T1						
	E.B6.81.2949	CABLE,	ASSEMBLY,	F132,	from magnetic start			1	—	—	
					switch to relay T1						
	E.B6.81.2951	CABLE,	ASSEMBLY,	F133,	from magnetic start			1	—	—	
					switch to inverter type 103A						
	E.B6.81.2953	CABLE,	ASSEMBLY,	F134,	from fuse and relay			1	—	—	
					box to inverter type 103A						
	E.B6.81.2955	CABLE,	ASSEMBLY,	F135,	from fuse and relay			1	—	—	
					box to control panel, type 24						
	E.B6.81.2957	CABLE,	ASSEMBLY,	F136,	from control panel			1	—	—	
					type 24, to inverter type 103A						
	E.B6.81.2959	CABLE,	ASSEMBLY,	F137,	from control panel			1	—	—	
					type 15 to control panel type 24						
	E.B6.81.2961	CABLE,	ASSEMBLY,	earth E.B.,	from magnetic			1	—	—	
					starting switch to earth point battery						
					bay						
	E.B6.81.2963	CABLE,	ASSEMBLY,	earth E34,	from inverter type			1	—	—	
					103A, to earth point equipment bay						
	E.B6.81.3003	CABLE,	ASSEMBLY,	M83,	from magnetic start			1	—	—	
					switch type 1A, No. 5 to magnetic start						
					switch type 1A, No. 5						
	E.B6.81.3137	CABLE,	ASSEMBLY,	14S,	from oxygen regulator			1	—	—	
					bomb aimer's position to JB14						
	E.B6.81.3139	CABLE,	ASSEMBLY,	13L,	from oxygen demand			1	—	—	
					regulator navigator's position to JB13						
	E.B6.81.3141	CABLE,	ASSEMBLY,	13M,	from navigator's mag-			1	—	—	
					netic indicator and pilot's magnetic in-						
					indicator to JB13						
	E.B6.81.3373	CABLE,	ASSEMBLY,	F160,	from D.C. distribution			1	—	—	
					box to relay T inv. and fuse and relay						
					box						
	E.B6.81.3429	CABLE,	ASSEMBLY,	16X,	from ON/OFF switch			1	—	—	
					pilot's station, port side to JB16						
	or										
	E.G4.81.3233	CABLE,	ASSEMBLY,	16X (Alt. R60/61—Mod. 5100)				1	—	LM	

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.							Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
	E.B6.81.3471							CABLE ASSEMBLY, N28/N29, from E.C.P. to D.C. distribution box	1	—	—	
	E.B6.81.3617							CABLE ASSEMBLY, N16A, from JB16 to E.C.P.	1	—	—	
	E.B6.81.3627							CABLE ASSEMBLY, N157, from pilot's take-off panel to pressure bulkhead	1	—	—	
	E.B6.81.3629							CABLE ASSEMBLY, F157, from pressure bulkhead to M.E.P.	1	—	—	
	E.B6.81.3831							CABLE ASSEMBLY, N156, from E.C.P. to radio junction box (Used on a/c WH957 only)	1	—	—	
	E.G5.81.521							CABLE ASSEMBLY, N156, from E.C.P. to radio junction box (Mod. 4075 and 4227) (Not required for a/c WH957)	1	—	—	
	E.B6.81.3945							CABLE ASSEMBLY, M82, and M12, from magnetic starting switch and relay type T1 to inverter type 103A	1	—	—	
	E.B6.81.4063							CABLE ASSEMBLY, F46, from port and starboard inverter switches to M.E.P.	1	—	—	
	E.B6.81.4065							CABLE ASSEMBLY, N16B, from JB16 to E.C.P.	1	—	—	
	E.B6.81.4077							CABLE ASSEMBLY, N150, from E.C.P. to M.E.P.	1	—	—	
	E.B6.81.4137							CABLE ASSEMBLY, N19, N22, N26, N27, from E.C.P. to D.C. distribution box and M.E.P.	1	—	—	
	E.G4.81.1791							CABLE ASSEMBLY, N76, from coaming panel jettison relay and JB16 to JB14, pilot's console and anti-icing indicator's (Mod. 3963 and 4155)	1	—	—	
	E.B6.81.4235							CABLE ASSEMBLY, N165, from control column TB to control column switch	1	—	—	
	E.B6.81.4237							CABLE ASSEMBLY, 13H1, from canopy de-mist blower motor to suppressor	1	—	—	
	E.B6.81.4239							CABLE ASSEMBLY, 14N, 14M, 14L, from JB14 to relay switch and relay coil	1	—	—	
	E.B6.81.4241							CABLE ASSEMBLY, 13D, from air thermo indicator to JB13	1	—	—	
	E.B6.81.4277							CABLE ASSEMBLY, 14A, from suppressor (unscreened end) to JB14	1	—	—	
	E.B6.81.4279							CABLE ASSEMBLY, 14A1, from 400 cycle fuse box to suppressor (screened end)	1	—	—	
	E.B6.81.4287							CABLE ASSEMBLY, E25, from E.C.P. to earth point E25	1	—	—	
	E.G4.81.1869							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel, starboard to E.C.P. (Mod. 3479) (Pre-Mods. 3833 and 4154) (Pre-Mod. 4415)	1	—	—	
	E.G4.81.2287							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel to E.C.P. (Mod. 4415) (Pre-Mods. 3833 and 5023)	1	—	—	
	E.G4.81.2715							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel, port and starboard, to E.C.P. (Mod. 5023) (Pre-Mod. 3833)	1	—	—	
								(See Cable Chart for Breakdown Spares)				

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.							Description	No. off	Matl Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6				M.R.	L.M.	
	E.G4.81.1847							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel, starboard to E.C.P. (Post-Mod. 3833 and 4154) (Pre-Mod. 4415)	1	—	—		
	E.G4.81.2121							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel, starboard to E.C.P. (Mod. 4415) (Post-Mod. 3833) (Pre-Mod. 5023)	1	—	—		
	E.G4.81.2717							CABLE ASSEMBLY, N69, from control column base TB and pilot's coaming panel, port and starboard, to E.C.P. (Mod. 5023) (Post-Mod. 3833)	1	—	—		
	E.B6.81.4687							CABLE ASSEMBLY, N14, from E.C.P. to JB14 (Pre-Mod. 3963 and 4155)	1	—	—		
	E.G4.81.1845							CABLE ASSEMBLY, N14, from E.C.P. to JB14 (Mod. 3963 and 4155)	1	—	—		
	E.B6.81.4689							CABLE ASSEMBLY, N2A, from pressure bulkhead to JB14	1	—	—		
	E.B6.81.4743							CABLE ASSEMBLY, 14J, 14Q, from JB14, to pressure bulkhead and Westland valve	1	—	—		
	E.G4.81.937							CABLE ASSEMBLY, N87, from G4B amplifier to 400 cycle fuse box (Mod. 3845)	1	—	—		
	E.B6.81.4941							CABLE ASSEMBLY, 16Q, from pilot's TB to JB16	1	—	—		
	E.B6.81.5421							CABLE ASSEMBLY, N70, from E.C.P. to aileron trim actuator and aileron trim transmitter	1	—	—		
	E.B6.81.5423							CABLE ASSEMBLY, N57, from pilot's switch panel to E.C.P.	1	—	—		
	E.B6.81.5425							CABLE ASSEMBLY, N8X, from E.C.P. to pressure bulkhead	1	—	—		
	E.B6.81.5427							CABLE ASSEMBLY, N30, from pilot's console anti-icing indicator's switches to E.C.P.	1	—	—		
	or												
	E.G4.81.3223							CABLE ASSEMBLY, N30 (Alt. R60/61—Mod. 5100)	1	—	LM		
	E.G5.81.151							CABLE ASSEMBLY, N13, from E.C.P. to JB13	1	—	—		
	E.G4.81.815							CABLE ASSEMBLY, 13P from JB13 to navigator's coaming panel	1	—	—		
	E.G4.81.817							CABLE ASSEMBLY, N176, from navigator's coaming panel to pilot's starboard instrument panel (Modified by SRIM.3533) (Mod. 4799)	1	—	—		
	E.B6.81.5433							CABLE ASSEMBLY, N16C, from JB16 to E.C.P.	1	—	—		
	E.B6.81.5435							CABLE ASSEMBLY, N71, from E.C.P. to pilot's console	1	—	—		
	E.B6.81.5437							CABLE ASSEMBLY, N7X, from E.C.P. to pressure bulkhead	1	—	—		
	E.B6.81.10439/2							CABLE ASSEMBLY, F24, from distribution box to main electrical panel (Mod. 3773)	1	—	—		
	E.B7.81.445							CABLE ASSEMBLY, 13H, from JB13 to suppressor type B4	1	—	—		
33894	E.B7.81.457/2							CABLE ASSEMBLY, N16D, N16E, N16F and N58, from JB16 and pilot switch panel to D.C. distribution box	1	—	C		
	E.B7.81.463							CABLE ASSEMBLY, 16J, from windscreen heater control box to JB16 (Mod. 4420)	1	—	—		
(See Cable Chart for Breakdown Spares)													

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B7.81.465	CABLE	ASSEMBLY	13C1	from suppressor to JB for A.M.U. and A.P.I.		1	—	—		
	E.B7.81.479/2	CABLE	ASSEMBLY	16S	from JB16 to starter panel		1	—	—		
	E.B7.81.481	CABLE	ASSEMBLY	16T	from JB16 to throttle box		1	—	—		
	E.B7.81.483	CABLE	ASSEMBLY	16U	from JB16 to under-carriage, fixed panel		1	—	—		
	E.B7.81.491	CABLE	ASSEMBLY	N51	from engine instrument panel to E.C.P.		1	—	—		
	E.B7.81.493	CABLE	ASSEMBLY	N52	from engine instrument panel to E.C.P.		1	—	—		
8541	E.B7.81.523	CABLE	ASSEMBLY	F95	from 400 cycle distribution box to 1600 cycle distribution box		1	—	B		
	E.B7.81.549/2	CABLE	ASSEMBLY	N55	from time switch to starter panel		1	—	—		
	E.B7.81.551/2	CABLE	ASSEMBLY	N56	from time switch to starter panel		1	—	—		
	E.B7.81.591/2	CABLE	ASSEMBLY	N49	from connection at pressure bulkhead to jettison relay panel and emergency detonator accumulator		1	—	—		
	E.B7.81.1235/2	CABLE	ASSEMBLY	F49	from main electrical panel to connection at pressure bulkhead		1	—	—		
22538	E.B7.81.1783	CABLE	ASSEMBLY	4C1	nosewheel "up" from terminal board to indicator control switch (Pre-Mod. 5091)		1	—	C		
	E.A1.81.1225	CABLE	ASSEMBLY	4C1	nosewheel "up" from terminal board to indicator control switch (Mod. 5091)		1	—	LM		
22539	E.B7.81.1785	CABLE	ASSEMBLY	4C2	nosewheel "down" from terminal board to indicator control switch (Pre-Mod. 5091)		1	—	C		
	E.A1.81.1227	CABLE	ASSEMBLY	4C2	nosewheel "down" from terminal board to indicator control switch (Mod. 5091)		1	—	LM		
21777	E.B7.81.1787	CABLE	ASSEMBLY	4C3	nosewheel "down" from terminal board to indicator control switch (Pre-Mod. 5091)		1	—	C		
	E.A1.81.1229	CABLE	ASSEMBLY	4C3	nosewheel "down" from terminal board to indicator control switch (Mod. 5091)		1	—	LM		
	E.B7.81.2015	CABLE	ASSEMBLY	N102	from control column terminal block and pilot's console to limit switch upper and lower, and isolating relay		1	—	—		
	E.B7.81.6549	CABLE	ASSEMBLY	N104	from console switch panel to crimping connector above junction box 16 (Mod. 4009)		1	—	—		
	or E.B7.81.6721	CABLE	ASSEMBLY	N104	(Alt. R60/61—Mod. 5100)		1	—	LM		
	E.G4.81.2691	CABLE	ASSEMBLY	F567	from pressure bulkhead to P.E.C. transducer and 1600 cycle distribution box (Mod. 4864)		1	—	—		
	E.G4.81.2681	CABLE	ASSEMBLY	N567	from pilot's and navigator's panel breaks and E.C.P. to pressure bulkhead (Mod. 4864)		1	—	—		

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.81.3241	CABLE, ASSEMBLY, N59, from canopy jettison switch to relay panel (Alt. R60/61—Mod. 5100)						1	—	LM	
	E.G4.81.3243	CABLE, ASSEMBLY, N48A-5, from canopy jettison switch to resistance unit (Alt. R60/61—Mod. 5100)						1	—	LM	
	SCA.78015/29	CABLE, ASSEMBLY, from H.F. distribution box to 1600 cycle distribution box and E.C.P. (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/71	CABLE, ASSEMBLY, from E.C.P. to power unit blower relay (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/86	CABLE, ASSEMBLY, from E.C.P. and control unit to pressure bulkhead (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/92	CABLE, ASSEMBLY, between inverter No. 5 and control panel (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/93	CABLE, ASSEMBLY, between inverter No. 5 and control panel (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/94	CABLE, ASSEMBLY, between inverter No. 6 and control panel (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/95	CABLE, ASSEMBLY, between inverter No. 6 and control panel (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/151	CABLE, ASSEMBLY, from No. 5 inverter control panel to 1600 cycle distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/152	CABLE, ASSEMBLY, from No. 6 inverter control panel to terminal block, D.C. distribution box and 1600 cycle distribution box (SRIM.3533) (Mod. 4799)						1	—	—	
	SCA.78015/153	CABLE, ASSEMBLY, from No. 5 inverter control panel to 1600 cycle distribution box (SRIM 3808) (Mod. 4799)						1	—	—	
	SCA.78015/154	CABLE, ASSEMBLY, from No. 6 inverter control panel to terminal block, D.C. distribution box and 1600 cycle distribution box (SRIM 3808) (Mod. 4799)						1	—	—	
	E.G4.81.2843	LOOMS, INSTRUMENT, CABLE, ASSEMBLY (MOD. 4799) Spares for:—						—	—	—	
	E.B6.81.807	CABLE, ASSEMBLY, G1-C3, from control panel to gyro unit						1	—	—	
	E.B6.81.1139	CABLE, ASSEMBLY, from computer (Zero reader flight director) to I.L.S. junction box						1	—	—	
	E.B6.81.1141	CABLE, ASSEMBLY, from indicator (Zero reader flight direction) to junction box (Zero reader flight director)						1	—	—	
26444	E.B6.81.1143	CABLE, ASSEMBLY, from coarse selector (Zero reader flight director) to computer						1	—	C	
	E.B6.81.1145	CABLE, ASSEMBLY, from computer (Zero reader flight director) to GM. compass, Mk. 4B						1	—	—	
	E.B6.81.1149	CABLE, ASSEMBLY, from computer (Zero reader flight director) to control panel						1	—	—	
(See Cable Chart for Breakdown Spares)											

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.1151							1	—	—	
	E.B6.81.4041							1	—	—	
	E.B6.81.4045							1	—	—	
	E.B6.81.4813							1	—	—	
	E.G4.81.933							1	—	—	
	E.G4.81.941							1	—	—	
	E.B6.81.4819							1	—	—	
	E.B6.81.4825							1	—	—	
	or E.G4.81.3239							1	—	LM	
											(See Cable Chart for Breakdown Spares)
	E.B6.81.4821							1	—	—	
	E.B6.81.4823							1	—	—	
	E.B6.81.1503							1	—	—	
	E.B6.81.1445							2	—	—	
28D/9436920	A25/1C							8	—	C	
28D/7002428	A25/6C							8	—	C	
	E.B6.81.1469							1	—	—	
	E.B6.81.1509							2	—	—	
28S/9435715	A33/B16							1	—	C	
	E.B6.81.1505							2	BS.2572	—	
28D/1212399	A25/28C							3	—	C	
28W/9419475	SP.15/C							3	—	C	
	E.B6.81.1511							1	—	—	
28D/1011030	A25/2E							4	—	C	
28W/9419405	SP.15/E							4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.F. L.M.	
		1 2 3 4 5 6				
	E.A2.81.1241	MOUNTING, SLAVE RELAY BOX, INSTALLATION	—	—	—	
13050	E.A3.81.2843	Spares for:— BOX, RELAY, ASSEMBLY	1	—	A	
	E.A3.81.2847	Spares for:— LID, ASSEMBLY	1	—	—	
10H/3780	†	Spares for:— BLOCK, terminal	4	—	B	
28M/9403519	A27/BP	Attaching parts for Ref. 10H/3780:— Nut, 4 BA	1	—	C	
28S/9435715	A33/B16	Screw, 4 BA	1	—	C	
29C/1206041	AGS.2035/B	Washer	1	—	C	
22485	E.A3.81.3101	LID, box	1	—	B	
22488	E.A3.81.3107	Attaching parts for E.A3.81.3101:— Screw, special	2	—	C	
22489	E.A3.81.3113	LINK, connecting	2	—	C	
22486	E.A3.81.3103	PANEL, relay mounting	1	—	B	
28M/1278189	AGS.2001/B/1	Attaching parts for E.A3.81.3103:— Nut, 4 BA	8	—	C	
22487	E.A3.81.3105	Stud, mounting	4	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	
5945-99-053-0463	S.T.C.SM.5A-H.19	RELAY	2	—	B	
28M/9418829	AGS.2002/A/1	Attaching parts for SM5A-H19:— Nut, 6 BA	2	—	C	
28W/9419464	SP.13/A	Washer	2	—	C	
	E.A3.81.3115	BRACKET, mounting relay box	1	—	—	
	E.B6.81.3071	PANEL, CONTROL AND STARTER SWITCHES FOR INVERTER, INSTALLATION	—	—	—	
		Spares for:—				
5CW/4620	†	SWITCH, magnetic relay, Type T.1	1	—	B	
5CW/5016	†	SWITCH, magnetic starting, Type 1A No. 5	1	—	A	
28D/9133012	A25/3C	Attaching parts for Ref. 5CW/4620 and 5CW/5016:— Bolt, 2 BA (For Ref. 5CW/4620)	2	—	C	
28D/1010030	A25/7C	Bolt, 2 BA (For Ref. 5CW/5016)	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA (As required)	6	—	C	
28W/9419475	SP.15/C	Washer	6	—	C	
39614	E.B6.81.3067	TRAY, mounting, assembly	1	L72	LM	
28D/9436920	A25/1C	Attaching parts for E.B6.81.3067:— Bolt, 2 BA	8	—	C	
28W/9419475	SP.15/C	Washer	8	—	C	
5UC/5759	†	PANEL, control, Type 15	1	—	A	
5UC/5760	†	PANEL, control, Type 24	1	—	A	
28D/1011030	A25/2E	Attaching parts for Ref. 5UC/5759 and 5UC/5760:— Bolt, 1/2" BSF (For Ref. 5UC/5760)	4	—	C	
28D/1008151	A25/4E	Bolt, 1/2" BSF (For Ref. 5UC/5759)	4	—	C	
28W/9419405	SP.15/E	Washer	4	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.81.2873	PANEL, ELECTRICAL CONTROL INSTALLATION (MOD. 4799)						—	—	—	
	E.G.4.81.2875	Spares for:— PANEL, ELECTRICAL CONTROL (MOD. 4799)						—	—	—	
26678	E.A.1.81.410	BAR, TERMINAL, ASSEMBLY						4	—	B	
	E.A.1.81.411	Spares for:— BAR, terminal c/w studs						1	—	—	
	E.A.1.81.410A	BASE, 7/8" thick						1	BS.2572	—	
33C/9109210	†	COMPOUND, insulating, Chaddertons						QR	—	C	
6051363	E.A.1.81.410B	COVER, plate, 1/2" thick						1	BS.2572	C	
5077	BULGIN. T.5.	HEAD, terminal, moulded						2	—	C	
		Attaching parts for E.A.1.81.410:—									
28M/1086618	AGS.2002/B/1	Nut, 4 BA						2	—	C	
28S/1007469	A33/B14	Screw, 4 BA						2	—	C	
5X/1002695	703/1/00249	BLOCK, terminal, 20-way						8	—	C	
		Attaching parts for 703/1/00249:—									
28D/9130082	AS.1246/3B	Bolt, 4 BA						2	—	C	
5X/4491394	Z.23213	Pillar, mounting						2	—	C	
28S/1008327	A32/B14	Screw, 4 BA						2	—	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						4	—	C	
5E/4189	†	CABLE, Uninyvin 8						QR	—	C	
5E/4187	†	CABLE, Uninyvin 12						QR	—	C	
5E/3894	†	CABLE, Unisersil 20						QR	—	C	
16923	E.A.2.81.803	CARRIER, SPARE FUSE, ASSEMBLY						1	—	C	
		Spares for:—									
28E/1006932	AS.2294/1	CLIP						24	—	C	
		Attaching parts for E.A.2.81.803:—									
28M/10273	AGS.2001/A/4	Nut, 6 BA						4	—	C	
28S/9995324	A32/A16	Screw, 6 BA						4	—	C	
5CY/5311	†	CIRCUIT-BREAKER, 12 amp.						1	—	B	
5CY/4376489	†	CIRCUIT-BREAKER, 35 amp.						2	—	B	
		Attaching parts for Ref. 5CY/5311 or 5CY/4376489:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
28W/9419465	SP.13/B	Washer						2	—	C	
32A/0119481	†	CORD, nylon. P.V.C.						QR	—	C	
5L/9951271	†	FILAMENT, 28 volts, 3.5 watt						2	—	C	
10H/23865	†	FUSE, 2.5 amp						6	—	C	
10H/23864	†	FUSE, 5 amp						70	—	C	
10H/23862	†	FUSE, 10 amp						32	—	C	
10H/23860	†	FUSE, 20 amp						15	—	C	
10H/23863	†	FUSE, 7.5 amp (Mod. 4222)						2	—	C	
10H/24272	†	FUSE, 40 amp						2	—	C	
10H/21719	†	FUSE, dummy						36	—	C	
5K/1201019	SP.40/A8	GROMMET						1	—	C	
5K/2921	SP.40/A18	GROMMET						2	—	C	
32331	E.B.81.1017	GUARD, SWITCH, ASSEMBLY						1	—	C	
		Spares for:—									
	E.A.3.81.1209	SPRING, tension						1	—	—	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CX/5133	†										
28M/1086618	AGS.2002/B/1										
28S/1008327	A32/B14										
	E.B6.81.4747										
28M/12787189	AGS.2001/B/1										
28W/9419465	SP.13/B										
5X/1004082	703/2/00251										
5X/1004083	703/2/00252										
5X/4491423	703/2/00253										
5X/6897	Z.63021										
5X/1004085	703/2/00254										
	E.B6.81.3365										
	33989										
	E.B6.81.3403										
	E.E. CO. LTD.										
	BRADFORD										
	V.1234										
	E.B6.81.3405										
28M/9455059	A14/EB										
28M/12344	AGS 2002/E/4										
	E.B6.81.3367										
	E.B6.81.3369										
	EEAS.28/22EW										
28W/9418920	SP.10/E										
28D/1011021	A25/16C										
28W/9419402	SP.13/C										
	E.G4.81.2915										
	5X/3271										
	CZ.52815										
28S/1200080	A32/B8										
28S/1012450	A32/B10										
29C/1206041	AGS.2035/B										
5X/9131181	Z.1841										
	E.B6.81.3323										
	E.B6.81.789										
28D/9436920	A25/1C										
28M/1278190	AGS 2001/C/1										
28FP/1004892	ODDIE.213										
28FP/1004893	ODDIE.214										
28W/9419402	SP.13/C										

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.81.2913	PANEL, RELAY EQUIPMENT, TOP, ASSEMBLY (MOD. 4799)						1	—	—	
		Consisting of:—									
	33632 E.B6.81.3411	BOLT , special						6	S.92	C	
	33633 E.B6.81.3329	COVER , relay assembly						1	—	C	
28M/9433473	AGS.2002/C/1	NUT , 2 BA						6	—	C	
	33634 E.B6.81.3327	PANEL , relay, mounting, assembly						1	—	C	
28S/1007469	A33/B14	SCREW , 4 BA						8	—	C	
5CW/6704	7CZ.107794	SOCKET , relay, Type S3						2	—	C	
5CW/6705	7CZ.107805	SOCKET , relay, Type S1						3	—	C	
5CW/6698	7CZ.107791	SWITCH , magnetic, relay						2	—	A	
5CW/6699	7CZ.107792	SWITCH , magnetic, relay						3	—	A	
28W/9419454	SP.10/C	WASHER						2	—	C	
28W/9419402	SP.13/C	WASHER						6	—	C	
		Attaching parts for E.G4.81.2913:—									
28D/1010658	A25/1B	Bolt , 4 BA						4	—	C	
28W/9419465	SP.13/B	Washer						4	—	C	
	E.B6.81.5505	PANEL						2	—	—	
	E.G4.81.2651	PLATE, TERMINAL BLOCK, ASSEMBLY (MOD. 4864)						1	—	—	
		Spares for:—									
5X/1002694	CZ.50207	BLOCK , terminal, 5-way						1	—	C	
		Attaching parts for CZ.50207:—									
28M/1278189	AGS.2001/B/1	Nut , 4 BA						2	—	C	
28S/1200033	A31/B24	Screw , 4 BA						2	—	C	
	E.G4.81.2649	PLATE , mounting, engraved, 18 SWG						1	L72	LM	
	E.B6.81.3837	PLATE , insulating, fuse mounting						1	—	—	
	E.G4.81.3095	PLATE , cover, inspection						1	—	—	
		Attaching parts for E.G4.81.3095:—									
28FP/1004892	ODDIE.213	Stud						11	—	C	
28FP/1004893	ODDIE.214	Washer						11	—	C	
	E.G4.81.3219	PLATE , switch, inverter No. 1 ground test, 18 SWG (Alt. R60/61—Mod. 5100)						1	L73	LM	
5X/5805562	2CZ.111224	PLUG , fixed, 9-way						5	—	C	
5X/7151	2CZ.111226	PLUG , fixed, 12-way						1	—	C	
5X/7152	2CZ.111227	PLUG , fixed, 14-way						2	—	C	
5X/7159	2CZ.111229	PLUG , fixed, 26-way						13	—	C	
5X/7142	2CZ.111401	PLUG , fixed, 5-way						2	—	C	
5X/7156	2CZ.111408	PLUG , fixed, 13-way						2	—	C	
5X/5805563	2CZ.111412	PLUG , fixed, 27-way						1	—	C	
5X/7140	2CZ.111399	PLUG , fixed, 4-way						1	—	C	
6A/1200	†	RESISTANCE-UNIT						2	—	B	
		Attaching parts for Ref. 6A/1200:—									
28M/1086618	AGS.2002/B/1	Nut , 4 BA						2	—	C	
28S/1016732	A32/B18	Screw , 4 BA						2	—	C	
28W/9419465	SP.13/B	Washer						2	—	C	
	PLESSEY										
5CW/4706404	508/2/12373/002	RING , antichafe						1	—	—	
	AS.10512M-1	SHROUD , terminal (Alt. R60/61—Mod. 5100)						2	—	C	
5X/1005131	Z.49428	SLEEVE , adaptor, 6-12 amp						305	—	C	
5X/9525146	Z.49397	SLEEVE , adaptor, 12-24 amp						1	—	C	
5K/4346876	EEAS.146/6	SLEEVE , 3/4" long						QR	—	C	
5F/	CXH.	SLEEVE , 3 m/m i/d x 3/8" long						QR	—	C	
5K/4346887	EEAS.146/20	SLEEVE , 3/4" long						QR	—	C	
5K/4346882	EEAS.146/16	SLEEVE , 3/4" long						QR	—	C	
5K/4346878	EEAS.146/12	SLEEVE , 3/4" long						QR	—	C	
5K/4346878	EEAS.146/10	SLEEVE , 3/4" long						QR	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5K/1107826	EEAS.146/000							QR	—	C	
10H/21301	2CZ.66961							2	—	C	
	MS3102E-20-14S							1	—	—	
5X/0011634	460-14-19S							1	—	C	
10H/0560120	†							1	—	C	
5935-99-013	508/1/07042/200							1	—	C	
-0841											
	.PLESSEY										
	508/1/07049/220							1	—	—	
	MS3102E-24-11S							1	—	—	
5CY/597	†							1	—	C	
5F/9454141	NY.18007A							QR	—	C	
5F/9138823	NY.3255							180	—	C	
5CW/5856	NSF.8396/B102							1	—	C	
	or										
5CW/4408107	AS.10512B-2							1	—	B	
5CW/4400123	NSF.8810/K6							1	—	C	
	or										
5CW/4408107	AS.10512B-2							1	—	B	
5CW/4620	†							1	—	B	
28D/9133012	A25/3C							2	—	C	
28E/1009753	AS.3180/3C							1	—	C	
28W/9419402	SP.13/C							2	—	C	
5CW/1102662	†							8	—	C	
28M/10273	AGS 2001/A/4							4	—	C	
28S/9995324	A32/A16							4	—	C	
5X/9709524	HC.310							26	—	C	
5X/9400083	703/2/00371							14	—	C	
5X/9450396	HC.490							208	—	C	
5X/9482491	HC.500							94	—	C	
5X/9450224	HC.510							107	—	C	
5X/9462745	HC.304							6	—	C	
5X/1036505	HC.314C							11	—	C	
5X/6793	ERMA.12310							2	—	C	
5X/6869	ERMA.12311							1	—	C	
5X/4491624	ERMA.12318							1	—	C	
5X/1010324	HC.296							17	—	C	
33635	E.B6.81.3407							1	—	C	
	E.B6.81.3409							1	BSS 265	—	
28M/4342710	AGS.2001/B/4							6	—	C	
28S/1012364	A45/B32							6	—	C	
28W/9437455	SP.25/B							12	—	C	
28D/9140203	AS.1246/3C							2	—	C	
28M/1278190	AGS.2001/C/1							3	—	C	
28S/9473755	A44/C16							1	—	C	
28W/9419402	SP.13/C							3	—	C	
17524	EEAS.43/3							2	L.72	C	
5E/9424113	†							QR	—	C	
5E/9424124	†							QR	—	C	
5E/9424164	†							QR	—	C	
28D/9436920	A25/1C							3	—	C	
28D/9133011	A25/2C							6	—	C	
28W/9419402	SP.13/C							9	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.81.2889	PANEL, MAIN ELECTRICAL, ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
24291	E.A9.81.1003	BRACKET , assembly, for field CB's						1	—	C	
28D/9128739	AS.1248/4B	Attaching parts for E.A9.81.1003:— Bolt , 4 BA						4	—	C	
	E.B6.81.1579	BUS-BAR , P.10 interconnector, assembly ...						1	—	—	
	E.B7.81.1221	CABLE ASSEMBLY , E21, from M.E.P. to earth ...						1	—	—	
	E.B6.81.1015	CABLE ASSEMBLY , E201, from inverter type 201 to earth ...						1	—	—	
28M/10278	AGS.2001/J4	Attaching parts for E.B7.81.1221 and E.B6.81.1015:— Nut , 3/8" BSF						1	—	C	
17175	E.B7.81.1007	Stud , earth						1	BS.249	C	
8439	EEAS.28/33EP	Washer						2	—	C	
	E.B6.81.2851	CABLE ASSEMBLY , M5, from M.E.P. to inverter, type 201 ...						1	—	—	
		Attaching parts for E.B6.81.2851:—									
33511	E.B6.81.4281	Bolt , special						1	—	C	
33509	E.B6.81.4713	Washer , bearing						1	—	C	
24517	E.A9.81.2403	Washer , contact						1	—	C	
28W/9128920	SP.56/G	Washer						1	—	C	
	E.B6.81.1099	CABLE ASSEMBLY , F33, from bus-bar panel fuse to plug break at frame 11 ...						1	—	—	
5E/4193	†	CABLE , Uninyvin 1						QR	—	C	
5E/4188	†	CABLE , Uninyvin 10						QR	—	C	
5E/4187	†	CABLE , Uninyvin 12						QR	—	C	
5E/4185	†	CABLE , Uninyvin 16						QR	—	C	
5E/4183	†	CABLE , Uninyvin 20						QR	—	C	
5CY/4520	†	CAP , protective						2	—	C	
5CY/4376383	†	CIRCUIT-BREAKER , type A3						2	—	C	
40633	E.B6.81.3729	CLAMP , half, for cable attachment						2	—	C	
40634	E.B6.81.4939	CLAMP , half, for cable attachment						2	—	C	
28D/1017157	A25/25C	Attaching parts for E.B6.81.3729 and E.B6.81.4939:— Bolt , 2 BA						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
32A/0119481	†	CORD , nylon, P.V.C.						QR	—	C	
5X/9400053	AS.2673	FERRULE , cable						4	—	C	
5X/9400055	AS.2674	FERRULE , cable						6	—	C	
10H/23864	†	FUSE , 5 amp, type A.S. H.R.C.						2	—	C	
10H/23862	†	FUSE , 10 amp, type A.S. H.R.C.						4	—	C	
10H/21791	†	FUSE , dummy						5	—	C	
33512	E.B6.81.4943	LINK , bus-bar, P.3						1	—	C	
33513	E.B6.81.4945	LINK , bus-bar, P.4						1	—	C	
		Attaching parts for E.B6.81.4943 and E.B6.81.4945:—									
33510	E.B6.81.4779	Bolt , special						1	—	C	
5CZ/4335526	†	Cover , terminal lug						1	—	C	
33509	E.B6.81.4713	Washer , bearing						1	—	C	
24517	E.A9.81.2403	Washer , contact						1	—	C	
28W/9128920	SP.56/G	Washer						1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.F. L.M.	Plate No.
		1	2	3	4	5	6				
5X/4491436	EEAS.71/2	LINK, 3-way	2	—	C		
5X/1004082	Z.50210	LINK, commoning, 2-way	12	—	C		
5X/6903	Z.54032	LINK, commoning, 2-way	3	—	C		
5X/4491423	Z.63021	LINK, commoning, 4-way	5	—	C		
5X/1012212	Z.50218	LINK, commoning, 10-way	1	—	C		
5X/4499943	HC.326G	LUG, ring, tongue	4	—	C		
5X/4491651	HC.1189	LUG, cranked, 6 amp, 4 BA	9	—	C		
5X/9462954	HC.306A	LUG, 12 amp, 6 BA	3	—	C		
5X/9709513	HC.294D	LUG, crimping, 6 amp, 4 BA	16	—	C		
5X/9400995	12341	LUG, crimping, 150 amp, 1/4" BSF	1	—	C		
5X/9400096	Z.70030	LUG, crimping, 150 amp, 5/8" BSF	1	—	C		
5X/9015490	AS.2696	LUG, cable, adaptor	2	—	C		
5X/9484486	AS.2697	LUG, cable, adaptor	2	—	C		
5X/4491841	HC.314/G	LUG, ring, tongue, 24 amp, 4 BA	6	—	C		
5X/7632	HC.4212	LUG, ring, tongue, 24 amp, 1/2" BSF	2	—	C		
SCZ/4350503	†	LUG, terminal, 24 amp, 4 BA	4	—	C		
	E.G4.81.2891	PANEL, BUS-BAR, ASSEMBLY (MOD. 4799)	1	—	—		
		Spares for:—									
5X/9482906	AS.2654	BLOCK, connector	1	—	B		
		Attaching parts for AS.2654:—									
28S/9140642	A31/B36	Screw, 2 BA	2	—	C		
28W/19544	AS.2721	Washer	2	—	C		
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way	3	—	C		
		Attaching parts for CZ.23212/1:—									
5X/9450403	Z.28426	Pillar-fixing	2	—	C		
5X/4491394	Z.23213	Pillar mounting	2	—	C		
28S/1201448	A31/B10	Screw, 4 BA	4	—	C		
29C/1206041	AGS.2035/B	Washer	4	—	C		
5X/3271	CZ.52815	BLOCK, fuse	5	—	C		
		Attaching parts for CZ.52815:—									
28S/1201448	A31/B10	Screw, 4 BA	2	—	C		
29C/1206041	AGS.2035/B	Washer, shakeproof	2	—	C		
	E.B6.81.1625	BUS-BAR, connector	1	—	—		
	E.B6.81.1627	BUS-BAR, connector	1	—	—		
		Attaching parts for E.B6.81.1625 and E.B6.81.1627:—									
28D/1011240	A25/7E	Bolt, 1/2" BSF	2	—	C		
28M/4342850	AGS.2001/E/4	Nut, 1/2" BSF	2	—	C		
28M/10312	AGS.2002/G/4	Nut, 5/8" BSF	2	—	C		
33516	E.B6.81.4787	Stud, 5/8" BSF	2	BS.249	C		
28W/9418921	SP.13/E	Washer	2	—	C		
	EEAS.28/32DW	Washer	2	—	—		
33514	E.B6.81.2943	BUS-BAR, P.10	1	—	C		
	E.A1.81.542	CARRIER, spare fuse	1	—	—		
		Attaching parts for E.A1.81.542:—									
28M/9418829	AGS.2002/A/1	Nut, 6 BA	2	—	C		
28S/1017747	A32/A14	Screw, 6 BA	2	—	C		
34319	E.B6.81.3001	COVER, assembly, for bus-bar, P.9	1	—	C		
		Attaching parts for E.B6.81.3001:—									
28D/1213047	AS.4566/5B	Bolt, 2 BA	1	—	C		
28D/1213049	AS.4566/9B	Bolt, 2 BA	1	—	C		

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
34537	E.B6.81.3083										
5X/9704508	AS.2655										
5X/9149643	CZ.25111										
10H/21791	†										
10H/28364	†										
10H/28362	†										
10H/28360	†										
10H/0590126	AP.19264										
10H/0590127	AP.19265										
10H/0590128	AP.19266										
10H/0590129	AP.19275										
10H/0119128	115111T										
10H/23853	TFP.160										
	E.G4.81.851										
40251	E.B7.81.1039								BSS.1432		
26333	E.B7.81.1041								BSS.1432		
	E.B6.81.3347								BSS.1432		
5K/4346020	E.B7.81.1011										
5K/4346021	E.B7.81.1009										
17176	E.B7.81.1035										
28D/1200119	A25/4C										
28W/9419402	SP.13/C										
	—										
5X/3271	CZ.52815										
28S/1201448	A31/B10										
29C/1206041	AGS.2035/B										
	E.B6.81.3109										
	E.B6.81.2997										
28D/1214876	AS.1246/14B										
	E.G4.81.727										
	E.B6.81.2999										
28D/1214876	AS.1246/14B										
28D/1215088	AS.1246/15C										
	E.G4.81.549										
28M/1990760	AGS.2002/C/4										
	E.G4.81.1171										
	E.G4.81.725										

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.G4.81.3153	COVER , assembly (SRIM.3533) (Mod. 4799) (Made from E.G4.81.731, Ref. No. 34642)	1	—	—	
		Attaching parts for E.G4.81.3153:—				
28D/1213047	AS.4566/5B	Bolt, 4 BA	1	—	C	
28D/1213049	AS.4566/9B	Bolt, 4 BA	1	—	C	
10H/21791	†	FUSE , dummy	4	—	C	
10H/0590126	AP.19264	FUSE , 40 amp, type H.R.C.	2	—	C	
5X/4491431	EEAS.71/3	LINK , 4-way	1	—	C	
26333	E.B7.81.1041	LINK , copper	2	BSS.1432	C	
		Attaching parts for E.B7.81.1041:—				
28M/12344	AGS.2002/E/4	Nut, 3/4" BSF	1	—	C	
28M/1990760	AGS.2002/C/4	Nut, 2 BA	1	—	C	
5K/4346020	E.B7.81.1011	Screw	1	—	C	
17176	E.B7.81.1035	Washer	1	—	C	
	E.G4.81.725	Washer	1	—	C	
28W/19544	AS.2721	Washer	1	—	C	
	E.G4.81.479	PANEL , assembly	1	—	—	
		Attaching parts for E.G4.81.479:—				
28D/1013301	AS.1248/4C	Bolt, 2 BA	2	—	C	
	E.B6.81.3165	PANEL, M.E.P. FORWARD, ASSEMBLY	1	—	—	
		Spares for:—				
24518	E.A9.81.2405	BUS-BAR , connector, from R.C., C/B to top joint	1	L.16	C	
24520	E.A9.81.2409	BUS-BAR , connector, from C/B to top joint	1	L.16	C	
24521	E.A9.81.2411	BUS-BAR , connector assembly from GS to C/B	1	L.16	C	
24522	E.A9.81.2415	BUS-BAR , connector, from P.10 to C/B	2	L.16	C	
		Attaching parts for E.A9.81.2405, E.A9.81.2409, E.A9.81.2411 and E.A9.81.2415:—				
28D/1008145	A25/6E	Bolt, 3/4" BSF	7	—	C	
28M/1011475	A27/EP	Nut, 1/2" BSF	7	—	C	
24517	E.A9.81.2403	Washer	4	—	C	
28W/9418921	SP.13/E	Washer	14	—	C	
28W/9416644	SP.47/E	Washer	7	—	C	
5CY/4376492	†	CIRCUIT-BREAKER , type D2B	1	—	A	
		Attaching parts for Ref. 5CY/4376492:—				
28D/1011025	A25/24C	Bolt, 2 BA	4	—	C	
	E.A9.81.2433	Piece, distance	8	BS.2572	—	
28W/9419402	SP.13/C	Washer	4	—	C	
5CY/4376067	L.E.A.300/B4	CIRCUIT-BREAKER , type 1B, No. 6	2	—	A	
		Attaching parts for L.E.A. 300/B4:—				
28D/9436920	A25/1C	Bolt, 2 BA	4	—	C	
24508	E.A9.81.2357	COVER , assembly	1	—	C	
		Attaching parts for E.A9.81.2357:—				
28S/1011490	A32/C16	Screw, 2 BA	3	—	C	
24511	E.A9.81.2371	COVER , end, assembly	1	BS.2572	C	
24510	E.A9.81.2369	COVER , top	1	BS.2572	C	
		Attaching parts for E.A9.81.2371 and E.A9.81.2369:—				
28S/1008327	A32/B14	Screw, 4 BA	4	—	C	
28S/9995376	A32/B20	Screw, 4 BA	1	—	C	
29C/1206041	AGS.2035/B	Washer	4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.							Description	No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
24519	E.A9.81.2407							1	—	C		
24509	E.A9.81.2365							1	—	B		
	E.A9.81.869							1	BS.2572	—		
	E.A9.81.2367							1	BS.2572	—		
42475	E.A9.81.2417							1	—	C		
5CY/1054157	S.I.S.6202							1	—	C		
33181	E.A9.81.891							1	—	C		
27316	E.A9.81.2419							1	—	C		
28S/1200034	A31/B16							4	—	C		
5CW/9010256	†							2	—	C		
28S/1200040	A31/B20							4	—	C		
5CW/6183	†							1	—	A		
or												
5CW/6185	†							1	—	A		
28D/1200119	A25/4C							4	—	C		
24525	E.A9.81.2433							8	BS.2572	C		
28W/9419402	SP.13/C							4	—	C		
24284	E.A9.81.951							2	—	C		
28S/1200066	A33/B20							2	—	C		
28D/1011240	A25/5E							70	—	C		
	E.B6.81.3171							1	—	—		
5UC/1054116	†							2	—	C		
28S/1011488	A32/B28							2	—	C		
5CW/6165	F.6701							2	—	A		
28S/1200040	A31/B20							4	—	C		
28W/9419465	SP.13/B							4	—	C		
5CW/6166	F6801							2	—	A		
28D/9133013	A25/5C							4	—	C		
28W/9419402	SP.13/C							4	—	C		
28D/9133013	A25/5C							6	—	C		
28D/1011240	A25/5E							3	—	C		
	E.B6.81.4881							1	—	—		
5CW/4408139	AS.10512L-2							2	—	C		
5CW/4408142	AS.10512M-2							2	—	C		
5CY/4376392	†							2	—	C		
28M/1086618	AGS.2002/B/1							3	—	C		
28S/1007469	A33/B14							3	—	C		
28W/9419465	SP.13/B							3	—	C		

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/6441	†							2	—	C	
	or										
5CW/4408122	AS.10512C-7							2	—	B	
28S/9992525	A32/B12							4	—	C	
29C/1206041	AGS.2035/B							4	—	C	
28S/1200034	A31/B16							4	—	C	
28W/9419465	SP.13/B							4	—	C	
5K/4346882	EEAS.146/16							223	—	C	
5K/4346878	EEAS.146/12							32	—	C	
5K/4346876	EEAS.146/6							8	—	C	
5K/1107826	EEAS.146/00							4	—	C	
5F/9454141	NY.18007/A							QR	—	C	
5F/9138822	NY.3342							300	—	C	
5X/9462745	HC.304							4	—	C	
5X/1010324	HC.296							48	—	C	
5X/9450380	HC.312							1	—	C	
5X/1930220	HC.324C							2	—	C	
5X/1036505	HC.314C							4	—	C	
5X/9450396	HC.490							69	—	C	
5X/9482491	HC.500							6	—	C	
5X/9450224	HC.510							19	—	C	
5X/9450393	HC.292							7	—	C	
5X/7299	HC.4010							2	—	C	
5X/1930222	HC.4012							4	—	C	
5F/	†							QR	—	C	
	E.G.4.81.139/2							1	—	C	
5X/1002694	703/1/00238							1	—	C	
28M/1278189	AGS.2001/B/1							2	—	C	
28S/15036	A32/B44							2	—	C	
	AS.2810/4/050							2	L.62	LM	
28W/9419465	SP.13/B							2	—	C	
5E/4183	†							QR	—	C	
5E/4185	†							QR	—	C	
5CW/5253	HV.3710							2	—	C	
5CW/5252	HV.3711							3	—	C	
	PAGE ENG.										
5L/9959118	A259							2	—	C	
34305	E.G.4.81.193							1	—	C	
27352	E.A.4.81.1661							1	—	C	
5X/1877	Z.1719							1	—	C	
5X/1004083	703/2/00252							1	—	C	
5X/9400384	703/2/00358							2	—	C	
5CW/8815	AS.10512L-1							3	—	C	
5CW/4408139	AS.10512L-2							2	—	C	
5X/6182	CZ.50357							2	—	C	
5X/9171	508/1/06399							2	—	C	
5X/6185	CZ.50361							1	—	C	
5X/9173	508/1/06401							1	—	C	
5CZ/4335544	†							2	—	A	
28M/1278190	AGS.2001/C/1							3	—	C	
28S/9997545	A31/C16							3	—	C	
28W/9419402	SP.13/C							3	—	C	

ELECTRICAL ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/4706404	AS.10512M-1	SHROUD, terminal (Alt. R60/61—Mod. 5100) ...						3	—	C	
5CW/4408142	AS.10512M-2	SHROUD, terminal (Alt. R60/61—Mod. 5100) ...						2	—	C	
5K/4346882	EEAS.146/16	SLEEVE						2	—	C	
5K/4346878	EEAS.146/12	SLEEVE						74	—	C	
5K/4346876	EEAS.146/6	SLEEVE						5	—	C	
5K/4346887	EEAS.146/20	SLEEVE						6	—	C	
26DK/8896	E.B2.81.8211	SLEEVE, special						1	—	C	
	PAGE ENG.										
5CW/1085840	A257	SLEEVE						2	—	C	
5X/1005131	Z.49428	SLEEVE, adaptor						18	—	C	
5X/9525146	Z.49397	SLEEVE, adaptor						2	—	C	
5F/9434858	HV.3254	STRAP, Helvin						QR	—	C	
5F/9138823	NY.3255	STUD, Helvin						12	—	C	
5CW/4494	FJB/A/5	SWITCH, cartridge selector						2	—	A	
		Attaching parts for FJB/A/5:—									
28S/9992525	A32/B12	Screw, 4 BA						4	—	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						4	—	C	
5CW/1047697	†	SWITCH, D.P. CH.OVER, NO "CENTRE OFF" ... (PRE-MOD. 5100)						2	—	C	
		Spares for:—									
5CW/5253	HV.3710	CAP, dolly, Helvin						2	—	C	
		Attaching parts for Ref. 5CW/1047697:—									
28S/9992525	A32/B12	Screw, 4 BA						4	—	C	
1465	EEAS.28/2EP	Washer						8	L.16	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						4	—	C	
5CW/9255	AS.10512C-1	SWITCH, master starting (Alt. R60/61 — Mod. 5100)						2	—	B	
5CW/1047693	†	SWITCH, S.P., CH.OVER (PRE-MOD. 5100) ...						3	—	C	
		Spares for:—									
5CW/5252	HV.3711	CAP, dolly, Helvin						3	—	C	
		Attaching parts for Ref. 5CW/1047693:—									
28S/9992525	A32/B12	Screw, 4 BA						2	—	C	
1465	EEAS.28/2EP	Washer						4	L.16	C	
29C/1206041	AGS.2035/B	Washer, shakeproof						2	—	C	
5CW/9235	AS.10512A-2	SWITCH, ignition and G.M. compass (Alt. R60/61 — Mod. 5100)						3	—	B	
5CW/1097575	C.180/C/7	SWITCH, push button, amber						1	—	B	
5CW/1097574	C.180/B/7	SWITCH, push button, green						1	—	C	
	EEAS.20/8DR	TAB, locking						1	—	C	
5X/9450396	HC.490	TAG, crimping, No. 1						4	—	C	
5X/9482491	HC.500	TAG						8	—	C	
5X/9462957	HC.294	TAG, ring tongue						2	—	C	
5X/1010324	HC.296	TAG, ring tongue						2	—	C	
5E/9102377	†	WIRE, copper, tinned, 24 SWG						QR	—	C	
5E/9102380	†	WIRE, copper, tinned, 30 SWG						QR	—	C	
		Attaching parts for E.G4.81.139:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						4	—	C	
28S/9992525	A32/B12	Screw, 4 BA						4	—	C	
	E.G4.81.3121	PANEL, SWITCH, NAVIGATOR'S, EQUIPMENT AND WIRING (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5E/4185	†	CABLE, Uninyvin 16						QR	—	C	
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
32A/0119481	†	CORD, nylon, P.V.C.						QR	—	C	
5X/4491289	508/2/11405/400	FERRULE, size C						1	—	C	
5X/4491290	508/2/11405/500	FERRULE, size D						1	—	C	
5CZ/5074	†	INDICATOR, electro magnetic (SRIM. 3533) (Mod. 4799)						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.81.3247							1	L.73	LM	
5X/4491295	Z.18501/C							1	—	C	
5X/4491296	Z.18501/D							1	—	C	
5CW/4706404	AS.10512M-1							9	—	C	
5X/1005131	Z.49428							12	—	C	
5X/4346882	EEAS.146/16							46	—	C	
5X/4346878	EEAS.146/12							4	—	C	
5X/1107826	EEAS.146/00							4	—	C	
5X/3369	EEAS.146/0000							2	—	C	
5X/9400944	EEAS.146/B							2	—	C	
5X/7185	2CZ.111236							1	—	C	
5X/7192	2CZ.111238							1	—	C	
5CW/4400085	NSF.8295/B109							4	—	C	
	or										
5CW/9235	AS.10512A-2							4	—	B	
5CW/4400086	NSF.8295/B110							3	—	C	
	or										
5CW/9239	AS.10512A-6							3	—	B	
5CW/4400087	NSF.8295/B111							2	—	C	
	or										
5CW/9240	AS.10512A-7							2	—	B	
5CW/9235	AS.10512C-1							1	—	B	
5X/1010324	HC.296							26	—	C	
5X/9462953	HC.306							3	—	C	
5X/9450396	HC.490							2	—	C	
5F/2037	†							QR	—	C	
5F/4342000	†							QR	—	C	
	E.G.4.81.2879							—	—	—	
	E.G.4.81.2881							1	—	—	
	5E/4187	†						QR	—	C	
	5E/4185	†						QR	—	C	
	5E/4183	†						QR	—	C	
	E.B7.81.1171							1	—	—	
	28M/1086618	AGS.2002/B/1						4	—	C	
	28S/1012450	A32/B10						4	—	C	
		E.B7.81.1173						1	—	—	
	40993	E.B6.81.4911						2	—	MR	
		E.B6.81.893						2	—	—	
		E.B6.81.4905						1	—	—	
	5X/7142	2CZ.111401						1	—	C	
	5X/6329	CZ.50358						1	—	C	
	5X/7147	2CZ.111299						1	—	C	
	5X/6185	CZ.50361						2	—	C	
	5X/7159	2CZ.111229						2	—	C	
	10H/	CZ.49112						1	—	—	
	1110	EEAS.43/2						1	L.72	C	
	5K/4346882	EEAS.146/16						114	—	C	
	5K/4346878	EEAS.146/12						12	—	C	
	5K/4346876	EEAS.146/6						8	—	C	
	5X/9525146	Z.49397						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
5CW/5839	NSF.8810/B104	SWITCH, inter-com., master (SRIM.3533) (Mod. 4799)						1	—	C		
5CW/4400085	NSF.8295/B109	SWITCH, S.P., heaters P/H & W/S, canopy demist, battery, generators						6	—	C		
5CW/4400088	NSF.8375/B105	SWITCH, D.P., fuel cocks						10	—	C		
5CW/4400084	NSF.7321/B103	SWITCH, S.P., vent valves						1	—	C		
5CW/8577	NSF.7360/K7	SWITCH, D.P., canopy master snatch (Alternative to NSF.7360/B102)						1	—	C		
5CW/8962	NSF.7360/B102	SWITCH, D.P. (Alternative to NSF.7360/K7) ...						1	—	C		
5CW/5252	HV.3711	Attaching parts for switches:—										
17104	E.B7.81.259	Cap, dolly, Helvin						1	—	C		
		Washer, packing						1	—	C		
5X/9462954	HC.306	TAG, R.T.						4	—	C		
5X/1010324	HC.296	TAG, R.T.						65	—	C		
		Attaching parts for E.G4.81.2881:—										
28D/9436920	A25/1C	Bolt, 2 BA						1	—	C		
	E.B7.81.955	Packing						1	—	—		
	E.B7.81.957	Packing						1	—	—		
28S/1011490	A32/C16	Screw, 2 BA						3	—	C		
	E.G4.80.1161	PLATE, MOUNTING, VOLTAGE REGULATOR, INSTALLATION (MOD. 4864)						—	—	—		
		Spares for:—										
	E.G4.80.1163	PLATE, mounting, 18 SWG						1	L.72	LM		
		Attaching parts for E.G4.80.1163:—										
28D/9436920	A25/1C	Bolt, 2 BA						4	—	C		
28M/1278190	AGS.2001/C/1	Nut, 2 BA						4	—	C		
	E.G4.81.2845	PLUGS, SOCKETS AND BUNGS, THROUGH PRESSURE BULKHEAD (MOD. 4799)						—	—	—		
		Spares for:—										
5935-99-932	†	ADAPTER, bulkhead, type N (SRIM.3533) (Mod. 4799)						1	—	C		
-1715												
5X/7336	SR.3897	BUNG, pressure, solid (SRIM.3533) (Mod. 4799)						2	—	C		
5X/10147	SR.5273	BUNG, pressure, solid, size A (SRIM.3533) (Mod. 4799)						1	—	C		
5X/6880	†	BUNG, pressure, size D (SRIM.3533) (Mod. 4799)						2	—	C		
5935-99-951	†	CONNECTOR						1	—	C		
-4738												
	EEAS.150/1	GASKET						4	—	—		
22451	EEAS.150/3	GASKET						2	—	C		
5X/6133	CZ.28057	PLUG, bulkhead, size D (Pre-Mod. 3879) ...						3	—	C		
5X/8556	2CZ.138115	PLUG, bulkhead, size D (Mod. 3879) ...						3	—	C		
5X/6063	CZ.28043	PLUG, bulkhead, size B (Pre-Mod. 3879) ...						1	—	C		
5X/	2CZ.138105	PLUG, bulkhead, size B (Mod. 3879) ...						1	—	—		
5X/6422	CZ.57212	PLUG, bulkhead, size B (Pre-Mod. 3879) ...						1	—	C		
5X/	2CZ.138247	PLUG, bulkhead, size B (Mod. 3879) ...						1	—	—		
5X/6028	CZ.28036	PLUG, bulkhead, size Z (Pre-Mod. 3879) ...						2	—	C		
5X/8551	2CZ.138098	PLUG, bulkhead, size Z (Mod. 3879) ...						2	—	C		
5X/6008	CZ.28032	PLUG, bulkhead, size A (Pre-Mod. 3879) ...						1	—	C		
5X/	2CZ.138099	PLUG, bulkhead, size A (Mod. 3879) ...						1	—	—		
5X/6018	2CZ.28034	PLUG, bulkhead, size Z (Pre-Mod. 3879) ...						3	—	C		
5X/	2CZ.138104	PLUG, bulkhead, size Z (Mod. 3879) ...						3	—	—		

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/6038	2CZ.28038	PLUG, bulkhead, size B (Pre-Mod. 3879) ...						2	—	C	
5X/	2CZ.138246	PLUG, bulkhead, size B (Mod. 3879) ...						2	—	—	
10H/19493	CZ.62277	PLUG/SOCKET, Mk. 4, 25-way ...						4	—	C	
10H/19488	CZ.62276/1	PLUG/SOCKET, Mk. 4, 18-way ...						1	—	C	
10H/19491	CZ.62276/4	PLUG/SOCKET, Mk. 4, 18-way ...						1	—	C	
10H/19481	CZ.62275	PLUG/SOCKET, Mk. 4, 12-way ...						5	—	C	
10H/19475	CZ.62274	PLUG/SOCKET, Mk. 4, 6-way ...						1	—	C	
10H/19457	CZ.62271	PLUG/SOCKET, Mk. 4, 6-way ...						5	—	C	
10H/19458	CZ.62271/1	PLUG/SOCKET, Mk. 4, 6-way ...						2	—	C	
10H/19439	CZ.62268	PLUG/SOCKET, Mk. 4, 2-way ...						1	—	C	
10H/19485	CZ.62275/4	PLUG/SOCKET, Mk. 4, 12-way ...						1	—	C	
10H/19451	CZ.62270	PLUG/SOCKET, Mk. 4, 4-way ...						1	—	C	
10H/19445	CZ.62269	PLUG/SOCKET, Mk. 4, 3-way ...						1	—	C	
10H/19452	CZ.62270/1	PLUG/SOCKET, Mk. 4, 6-way ...						1	—	C	
10H/19487	CZ.62276	PLUG/SOCKET, Mk. 4, 18-way ...						1	—	C	
	508/1/40189/320	PLUG/SOCKET, Mk. 4 (Mod. 4864) ...						1	—	—	
	508/1/07183/221	PLUG/SOCKET, Mk. 7 (Mod. 4864) ...						1	—	—	
10H/19487	†	PLUG/SOCKET, Mk. 4 (SRIM.3533) (Mod. 4799)						1	—	C	
10H/19610	†	SOCKET, coaxial ...						2	—	C	
10H/0560042	†	SOCKET, coaxial ...						5	—	C	
10H/20417	CZ.61887	SOCKET, plug, Mk. 4, 12-way ...						1	—	C	
5935-99-932	†	SOCKET, fixed (SRIM.3533) (Mod. 4799) ...						2	—	C	
-3124											
5935-99-013	†	SOCKET, fixed (SRIM.3533) (Mod. 4799) ...						1	—	C	
-0109											
5X/9831	HAN3100E-145-6S	SOCKET ...						1	—	C	
5X/11971	HAN3100E-24-28S	SOCKET ...						1	—	C	
	508/1/40176/320	SOCKET/PLUG, Mk. 4 (Mod. 4864) ...						1	—	—	
10H/20735	†	SOCKET/PLUG, Mk. 4 (SRIM.3533) (Mod. 4799)						1	—	C	
10H/20415	†	SOCKET/PLUG, Mk. 4 (SRIM.3533) (Mod. 4799)						1	—	C	
10H/19481	†	SOCKET/PLUG, Mk. 4 (SRIM.3533) (Mod. 4799)						1	—	C	
	508/2/15597/002	WASHER, panel, packing ...						1	—	—	
5UC/4379142	†	REGULATOR, type 60, for ILS ...						1	—	A	
5CW/10329	†	RELAY, diamond 'H' (Mod. 4420) ...						1	—	B	
		Attaching parts for Ref. 5CW/10329:—									
28D/1007979	AS.1246/1B	Bolt, 4 BA ...						4	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...						4	—	C	
28W/9419474	SP.15/B	Washer ...						4	—	C	
5X/4504065	418618-20	STOWAGE, dummy (Mod. 4864) ...						1	—	C	
5CY/7001363	†	SUPPRESSOR, type B4, No. 4 ...						1	—	C	
5CY/4376043	†	SUPPRESSOR, type P, No. 1 ...						2	—	C	
	E.G.4.81.3187	SUPPRESSOR, TYPE B4, AT FRAME 4, INSTALLATION (MOD. 4799)						—	—	—	
		Spares for:—									
4202	E.A.3.81.1165	STUD, mounting, assembly ...						2	—	C	
5CY/7001363	†	SUPPRESSOR, type B4, No. 4 ...						1	—	C	
		Attaching parts for Ref. 5CY/7001363:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA ...						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.G.4.81.1355	SWITCH, WING CLEARING EMERGENCY JET-TISON, INSTALLATION (MOD. 4298)	—	—	—	
		Spares for:—				
1438547	E.G.4.81.1349	BRACKET, assembly	1	—	C	
		Attaching parts for E.G.4.81.1349:—				
28D/9133011	A25/2C	Bolt, 2 BA	2	—	C	
28D/1908149	A25/2B	Bolt, 4 BA	2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	2	—	C	
28W/9419475	SP.15/C	Washer	2	—	C	
28W/9419474	SP.15/B	Washer	2	—	C	
1438548	E.G.4.81.2087	SWITCH, modified (5CW/1102662)	1	—	B	
		Attaching parts for E.G.4.81.2087:—				
28S/9419437	A31/A16	Screw, 6 BA	4	—	C	
28W/9419473	SP.15/A	Washer	4	—	C	
27N/93	†	SWITCH, inertia	2	—	A	
		Attaching parts for Ref. 27N/93:—				
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
23023	E.B6.81.2417	Packing, piece	1	—	C	
28S/9997545	A31/C36	Screw, 2 BA	4	—	C	
5CW/6452	†	SWITCH, magnetic, type 9B, No. 1A	1	—	C	
		Attaching parts for Ref. 5CW/6452:—				
28S/1200040	A31/B20	Screw, 4 BA	2	—	C	
28W/9419474	SP.15/B	Washer	2	—	C	
5CW/5907	E.A.P.2340	SWITCH, torque	1	—	A	
		Attaching parts for E.A.P.2340:—				
28S/1200040	A31/B20	Screw, 4 BA	3	—	C	
	E.B7.81.1377	SWITCHES, TIME, INSTALLATION	—	—	—	
		Spares for:—				
5CW/4402866	E.B7.81.1375	BRACKET, assembly	1	—	—	
	F.H.M.A25	SWITCH, time	2	—	A	
		Attaching parts for F.H.M. A25:—				
28S/9435713	A31/C20	Screw, 2 BA	4	—	C	
10KB/1449	†	TRANSFORMER, type 1562	1	—	A	
		Attaching parts for Ref. 10KB/1449:—				
28D/1215327	AS.1246/1E	Bolt, 1/2" BSF	4	—	C	
	E.G.4.81.61	WIRING AND CLIPPING PRESSURE BULKHEAD, TO FRAME 12	—	—	—	
		Spares for:—				
32A/0119481	†	CORD, nylon lacing, P.V.C.	QR	—	C	
4966	E.A1.81.251	GUIDE, strap	4	—	C	
		Attaching parts for E.A1.81.251:—				
29D/1218384	AS.1248/1B	Bolt, 4 BA	2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	2	—	C	
28W/9419474	SP.15/B	Washer	2	—	C	
3418	EEAS.132/12	STRAP, cable	1	—	C	
3419	EEAS.132/15	STRAP, cable	1	—	C	
3614	EEAS.132/18	STRAP, cable	4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
SF/9434858	HV.3254	STRAP, Helvin						40	—	C	
SF/9138823	NY.3255	STUD, Helvin						100	—	C	
32B/1168	†	TAPE, P.V.C., black, 1" wide						QR	—	C	
	E.G4.81.2877	WIRING AND CLIPPING, DETAILS FRAME B TO PRESSURE BULKHEAD (MOD. 4799)						—	—	—	
		Spares for:—									
34391	E.B6.81.5189	BAG, stowage, assembly						1	—	C	
34390	E.B6.81.5455	BAG, stowage, assembly						1	—	C	
	E.B6.81.10149	BAG, STOWAGE, EXTENSION LEAD, INSTALLATION						—	—	—	
		Spares for:—									
5CX/370	†	LEAD, extension, c/w bag, stowage						1	—	C	
		Attaching parts for Ref. 5CX/370:—									
28D/1218384	AS1248/1B	Bolt, 4 BA						3	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						3	—	C	
28W/9419474	SP.15/B	Washer						6	—	C	
5CZ/1053794	S.I.S.1564	BLOCK, terminal, type B						1	—	C	
		Attaching parts for S.I.S. 1564:—									
28M/1987493	AGS.2001/A/1	Nut, 6 BA						2	—	C	
28S/9992531	A33/A24	Screw, 6 BA						2	—	C	
	E.B6.81.4005	BRACKET, for jettison terminal block support						1	—	—	
	E.A1.81.252	BRACKET, cable support						2	—	—	
	E.A1.81.265	BRACKET, cable support						1	—	—	
4966	E.A1.81.251	BRACKET, strap guide						22	—	C	
	E.B6.81.769	BRACKET, strap support						2	—	—	
	E.B7.81.1543	BRACKET, strap, support (Pre-Mod. 3958)						1	—	—	
	E.G4.81.353	BRACKET, strap, support (Mod. 3958-S.O.O.)						1	—	—	
5340-99-416	EEAS.136/A	BRACKET, strap support						14	—	C	
-3724											
	E.G4.81.2859	CANOPY AND HATCH, JETTISON SYSTEM ... (SRIM.3533) (MOD. 4799)						—	—	—	
		Spares for:—									
5J/9101543	†	BATTERY, lead acid, 12v, 14 A.H.						2	—	B	
5CZ/4329938	WB/UN/1146/D/3/W	BLOCK, terminal, 6-way (Mod. 4435)						1	—	C	
		Attaching parts for Ref. 5CZ/4329938:—									
5CZ/6424	WB/1114/28	Pillar, fixing						2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
43109	E.G7.81.3111	BOX, FILTER, ASSEMBLY (SRIM.3533) ... (MOD. 4799)						10	—	B	
		Spares for:—									
1438511	E.G7.81.3125	COVER, ASSEMBLY						1	—	C	
		Spares for:—									
	EEAS.250/6 STEPHENSON MILLS LTD. 31103	BOLT, special						4	—	—	
26DK/5913	E.B2.81.1525	STRIP, Tecknit, 1/2" dia.						QR	—	—	
	E.G7.81.3113	WASHER, retaining						4	—	C	
		MODULE, ASSEMBLY						1	—	—	
		Spares for:—									
	E.G7.81.1571	BLOCK, terminal						1	BS.2572	—	
		Attaching parts for E.G7.81.1571:—									
28M/15819	AGS.2021/B/1	Nut, cap, translucent, 4 BA						4	—	C	
28S/5694	A32/B40	Screw, 4 BA						4	—	C	
43111	AS.2810/4/070	Tube, distance						4	—	C	
29C/1200328	AGS.2037/B	Washer, shakeproof						4	—	C	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
SCZ/4329840	WARD BROOKE WB/UN/1146/S /2/W E.G7.81.1523							1	—	C	
								1	L.72	—	
28M/4095821	AGS.2002/B/4							2	—	C	
28S/9435716	A33/B12							2	—	C	
28W/9419474	SP.15/B							2	—	C	
5E/4183	† E.G7.81.1531							QR	—	C	
								1	—	—	
10W/0113276	†							8	—	C	
10H/0120202	†							8	—	C	
SCZ/1034491	WARD BROOKE WB/NY/1110/B/2 ERIE ELECTR. 1215-000 or 1215-025 SP.40/B8							1	—	C	
								2	—	—	
5E/4183	† E.G7.81.1531							1	—	—	
SCZ/6424	WARD BROOKE WB/1114/28 E.G7.81.3029							2	—	C	
								2	—	—	
SCZ/4337585	WARD BROOKE WB/1114/23 E.G7.81.1585							2	—	C	
								1	BS.265	—	
								—	—	—	
28M/1990760	AGS.2002/C/4							12	—	C	
28S/9993003	A43/B8							12	—	C	
1438513	E.G7.81.3197							12	—	C	
28W/1009752	SP.25/C							8	—	C	
	HADDON & STOKES										
10AC/9436077	DP.1003							12	—	C	
5X/9462951	HC.294							2	—	C	
5E/4515	†							QR	—	C	
								2	—	C	
28S/1200056	A33/A10							4	—	C	
28S/1006948	A32/A12							1	—	C	
28S/9992525	A32/B12							4	—	C	
28W/9419464	SP.13/A							1	—	C	
28W/9419465	SP.13/B							1	—	C	
								2	—	C	
28D/1007975	AS.1242/1C							4	—	C	
28D/9140202	AS.1246/1C							4	—	C	
28M/1278190	AGS.2001/C/1 SCB.79264							4	—	C	
								1	L.72	—	
								4	—	C	
28S/1011490	A32/C16							4	—	C	
28W/9419475	SP.15/C							4	—	C	
28W/1200071	SP.23/C							4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
43110	E.G7.81.3139							1	—	B	
1438512	E.G7.81.3143							1	—	C	
	EEAS.250/6							4	—	—	
	STEPHENSON										
	MILLS LTD.										
	31103							QR	—	—	
26DK/5913	E.B2.81.1525							4	—	C	
	E.G7.81.3141							1	—	—	
	E.G7.81.1581							1	BS.2572	—	
28M/1278189	AGS.2001/B/1							2	—	C	
	28S/5694							2	—	C	
	43111							2	—	C	
29C/1200328	AGS.2037/B							2	—	C	
5CZ/4329840	WARD BROOKE WB/UN/1146/S /2/W E.G7.81.1523							1	—	C	
								1	L.72	—	
28M/4095821	AGS.2002/B/4							2	—	C	
	28S/9435716							2	—	C	
28W/9419474	SP.15/B							2	—	C	
5E/4183	† E.G7.81.1547							QR	—	C	
10W/0113276	† OXLEY							1	—	C	
	WARD BROOKE							2	—	—	
5CZ/1034491	WB/NY/1110/B/2							1	—	C	
	ERIE ELECTR.										
	1215-000							2	—	—	
	or										
	1215-025										
	SP.40/B8							1	—	—	
	WARD BROOKE										
5CZ/6424	WB/1114/28							2	—	C	
	E.G7.81.3029							2	—	—	
	WARD BROOKE										
5CZ/4337585	WB/1114/23							2	—	C	
	—							—	—	—	
28M/1990760	AGS.2002/C/4							2	—	C	
	28S/9993003							2	—	C	
	1438513							2	—	C	
28W/1009752	SP.25/C							2	—	C	
	HADDON & STOKES										
10AC/9436077	DP.1003							2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
SX/9462951 SE/4515	HC.294 †							2 QR	— —	C C	
28S/1200056	A33/A10							2	—	C	
28S/1006948	A32/A12							4	—	C	
28S/9992525	A32/B12							1	—	C	
28W/9419464	SP.13/A							4	—	C	
28W/9419465	SP.13/B							1	—	C	
1438861	E.G7.81.3373							1	—	B	
	E.G7.81.3379							1	—	—	
	E.G7.81.3389 STEPHENSON MILLS LTD. 31103							4	—	—	
26DK/5913	E.B2.81.1525							QR 4	— —	— C	
	E.G7.81.3375							1	—	—	
	E.G7.81.1531							1	—	—	
	E.G7.81.3391							1	—	—	
10W/0113276	†							8	—	C	
10H/0120202	†							8	—	C	
1438960	E.G7.81.3251							1	—	B	
5CZ/1053794	†							1	—	C	
28M/1987493	AGS.2001/A/1							2	—	C	
	E.G7.81.3261							1	BSS.2966	—	
28S/9133018	A33/A2B							2	—	C	
	E.G7.81.3255							1	—	—	
1438890	E.G7.81.3253							1	—	C	
	E.F3.81.13973							1	—	—	
26DK/8443	EEAS.250/1							4	—	C	
	E.F3.81.14855							1	—	—	
26DK/5913	E.B2.81.1525							4	—	C	
28D/9436920	A25/1C							2	—	C	
	8421							1	—	C	
28M/1278190	AGS.2001/C/1							2	—	C	
28W/9419475	SP.15/C							2	—	C	
	SCC.79445							1	L72	—	

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
28D/9436920 28W/9419475	E.B6.81.705	BRACKET, jettison relay, mounting						1	—	—	
	A25/1C SP.15/C	Attaching parts for E.B6.81.705:— Bolt, 2 BA						6	—	C	
		Washer						6	—	C	
	E.B6.81.1205	CABLE, ASSEMBLY, N48-A1, from resistance unit to resistance unit						1	—	—	
	E.B6.81.1207	CABLE, ASSEMBLY, N48-A2, from resistance unit to resistance unit						1	—	—	
	E.B6.81.5549	CABLE, ASSEMBLY, N48-B5, from pressure bulkhead to resistance unit						1	—	—	
	E.B7.81.1251/2	CABLE, ASSEMBLY, E48-B3, from starboard pressure bulkhead connection to resistance unit						1	—	—	
	E.B7.81.1253	CABLE, ASSEMBLY, F48-B4, between rear port and starboard resistance units						1	—	—	
	E.B7.81.1255/2	CABLE, ASSEMBLY, E48-B5, between port, pressure bulkhead connection and resistance unit						1	—	—	
1439022	E.G7.81.3267	CABLE, ASSEMBLY, flexible, from junction box to filter box (SRIM.3533) (Mod. 4799)						1	—	C	
8428	E.B7.81.1321	CABLE, ASSEMBLY, emergency accumulator ...						1	—	C	
(See Cable Chart for Breakdown Spares)											
1802	E.A1.81.425	CAP, detonator spring retaining						64	L.64	C	
5CZ/1034995	WARD BROOKE WB/NY/1110/B /B	COVER, terminal block						1	—	C	
12G/1461	†	DETONATOR, No. 108, Mk. 3						64	—	C	
12G/1463	†	DETONATOR, No. 109, Mk. 2						1	—	C	
1439030	E.G7.81.3199	NUT, blanking, for unused gland entries on filter box (SRIM.3533) (Mod. 4799)						22	—	C	
5071	E.A6.10.2181	PACKING, tapered for studs						24	—	C	
1803	E.A1.81.942	PLATE, detonator cable, securing						2	L.72	C	
28S/1200055	A33/A6	Attachments for E.A1.81.942:— Screw, 6 BA						2	—	C	
1882	E.A1.81.940	PLUG, detonator wiring						2	DTD.683	C	
	SCD.79402/1	SHEATH, ASSEMBLY (SRIM.3533) (Mod. 4799)						1	—	—	
	SCD.79402/2	SHEATH, ASSEMBLY (SRIM.3533) (Mod. 4799)						1	—	—	
Spares for:—											
1439029	E.G7.81.1527	FERRULE						1	—	—	
	E.G7.81.2675	NUT, clamping						1	—	C	
1803	E.A1.81.942	PLATE, securing						1	—	C	
	E.G7.81.2317	PLUG, detonator						1	—	—	
	E.G7.81.2933	WASHER, special						1	—	—	
	SCD.79402/3	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/4	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/5	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/6	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/7	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/8	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCD.79402/9	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/10	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/11	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/12	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/13	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/14	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/15	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/16	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/17	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/18	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/19	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/20	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/21	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/22	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/23	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/24	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/25	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/26	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/27	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/28	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/29	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/30	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/31	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/32	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/33	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/34	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/35	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/36	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/37	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/38	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/39	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/40	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/41	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/42	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/43	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/44	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/45	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/46	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/47	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/48	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/49	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/50	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/51	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/52	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/53	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/54	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/55	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/56	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/57	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/58	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/59	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/60	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/61	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/62	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/63	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	
	SCD.79402/64	SHEATH, ASSEMBLY (SRIM.3533) (MOD. 4799)						1	—	—	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.G4.81.2811	ELECTRICAL EQUIPMENT, REAR FUSELAGE, ASSEMBLY (MOD. 4799) Spares for:—	—	—	—	
5W/4695	E. E. CO. LTD., BRADFORD	ACTUATOR , rudder bias, type 258, Mk. B6 ...	1	—	A	
5W/4697	E. E. CO. LTD., BRADFORD	ACTUATOR , tail plane, type AE.4022, Mk. 2 ...	1	—	A	
5CZ/1053794	†	BLOCK , terminal ...	1	—	C	
28S/1200062	A33/A20	Attaching parts for Ref. 5CZ/1053794:— Screw, 6 BA ...	2	—	C	
	E.G4.81.2997	BOX, JUNCTION NO. 6, ASSEMBLY (MOD. 4799) Spares for:—	1	—	—	
5X/1002695	703/1/00269	BLOCK , terminal, 20-way ...	2	—	C	
28D/1214867	AS.1246/5B	Attaching parts for 703/1/00269:— Bolt, 4 BA ...	2	—	C	
28W/9416642	SP.47/B	Washer ...	2	—	C	
5E/4189	E.B6.81.3703	BOX , junction, 40-way ...	1	—	—	
18783	†	CABLE , Uninyvin 8 ...	QR	—	C	
20457	E.B7.81.963	COVER , assembly ...	1	—	B	
1066	EEAS.117/1	Attaching parts for E.B7.81.963:— Screw ...	6	S.92	C	
1108	EEAS.28/2CU	Washer ...	12	DTD.124A	C	
	EEAS.42	Washer ...	6	Leather	C	
5X/1074460	508/4/11290/004	GASKET , plug, shell ...	1	—	C	
5X/8662	508/4/11290/006	GASKET , plug, shell ...	1	—	C	
5X/2790	Z.22634	GROMMET , dummy ...	5	—	C	
5X/6314	703/2/00255	LINK , 6-way commoning ...	1	—	C	
5X/1004082	703/2/00251	LINK , 2-way terminal, connecting ...	1	—	C	
5X/5805561	2CZ.111406	PLUG , standard ...	1	—	C	
5X/5805563	2CZ.111412	PLUG , 27-way ...	1	—	C	
5X/1005131	Z.49428	SLEEVE , adaptor ...	15	—	C	
5K/4346875	EEAS.146/6	SLEEVE , 1/2" long ...	44	—	C	
5K/4346876	EEAS.146/6	SLEEVE , 1/2" long ...	4	—	C	
5K/4346882	EEAS.146/16	SLEEVE , 1/2" long ...	28	—	C	
5K/4346885	EEAS.146/22	SLEEVE , 1/2" long ...	1	—	C	
5K/4346887	EEAS.146/22	SLEEVE , 1/2" long ...	1	—	C	
5X/9482491	HC.500	TAG , QR ...	1	—	C	
5X/9450396	HC.490	TAG , QR ...	14	—	C	
5E/9424113	†	WIRE , equipment, black, type 3, 23/0076 ...	QR	—	C	
5E/9424124	†	WIRE , equipment, black, type 3, 40/0076 ...	QR	—	C	
28D/9436920	A25/1C	Attaching parts for E.G4.81.2997:— Bolt, 2 BA ...	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA ...	4	—	C	
28W/9419402	SP.13/C	Washer ...	4	—	C	
	E.A1.81.252	BRACKET , cable strap ...	2	—	—	
	E.B7.81.435	BRACKET, MOUNTING RELAY, PANEL, INSTALLATION Spares for:—	—	—	—	
18757	E.B7.81.437	BRACKET ...	4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.367	BRACKET , relay, mounting						1	—	—	
28S/9435712	A31/B8	Attaching parts for E.A1.81.367:—									
28S/1201448	A31/B10	Screw, 4 BA						3	—	C	
		Screw, 4 BA						1	—	C	
18753	E.B7.81.331	BRACKET , mounting, cable clamp						1	—	C	
6734	EEAS.136	BRACKET , cable clip						2	—	C	
	or										
5340-99-4163724	EEAS.136A										
	HELL. DEUTSCH										
	416125-10	GAP , protective (Mod. 4864)						2	—	—	
18782	E.B7.81.805	CLAMP , cable						1	BS.2572	C	
		Attaching parts for E.B7.81.805:—									
28D/1011013	A25/13B	Bolt, 4 BA						2	—	C	
28M/1956039	AGS.2001/B/3	Nut, 4 BA						2	—	C	
28W/9419465	SP.13/B	Washer						2	—	C	
32A/1058027	†	CORD , braided waxed						QR	—	C	
	E.A3.81.6481	DIODE, TAIL TRIM, CIRCUIT, INSTALLATION (MOD. 4335)						—	—	—	
		Spares for:—									
1438549	E.A3.81.6473	PLATE, MOUNTING DIODE, ASSEMBLY ...						1	—	—	
		Spares for:—									
	E.A3.81.6477	CABLE, ASSEMBLY, T.451, FROM T.100B RELAY TO DIODE						1	—	—	
		Consisting of:—									
5E/3894	†	CABLE , Uniersil 20						QR	—	C	
5K/9107065	EEAS.146/16	SLEEVE , 1½" long						3	—	C	
5K/4346887	EEAS.146/20	SLEEVE , ¾" long						4	—	C	
5K/3643	WE.487	TAG						2	—	C	
5K/	H.T.X.1380-4C	CLIP , "P"						1	—	—	
		Attaching parts for H.T.X.1380-4C:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
28S/9435716	A33/B12	Screw, 4 BA						1	—	C	
26DK/9852	EEAS.238/1A	Washer, "D"						1	—	C	
28E/9436947	AS.3180/4B	CLIP						1	—	C	
28E/1008744	AS.2295/1	CLIP , spring						1	—	C	
10CV/7019	FERRANTI ZR.12	DIODE						1	—	C	
	E.A3.81.6475	PLATE , mounting diode						1	L.72	—	
10H/22535	156/5D/LP	POST , barb, binding						2	—	C	
		Attaching parts for E.A3.81.6473:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						2	—	C	
	E.A3.81.6479	Packing, ⅜" thick, vinton rubber						1	DTD.5543	—	
28S/1200034	A31/B16	Screw, 4 BA						2	—	C	
	—	EARTH, CONNECTION AT FRAME 39						—	—	—	
		Consisting of:—									
28M/1006504	A27/BT	NUT , 4 BA						1	—	C	
28M/1086618	AGS.2002/B/1	NUT , 4 BA						1	—	C	
28S/1200033	A31/B24	SCREW , 4 BA						1	—	C	
12928	EEAS.28/3DPH	WASHER (non anodised)						3	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	SCD.79402/65							1	—	—	
	SCD.79402/66							1	—	—	
	E.G7.81.1527							2	—	—	
1439029	E.G7.81.2675							2	—	C	
1439022	E.G7.81.3265							1	—	B	
	E.G7.81.1527							2	—	—	
1439029	E.G7.81.2675							1	—	C	
	E.G7.81.2335							1	—	—	
1579	E.A1.81.938							66	S.201	C	
SF/9434858	HV.3254							QR	—	C	
SF/9138823	NY.3255							QR	—	C	
3900	E.A1.81.943							36	—	C	
	E.G4.80.263							—	—	—	
	E.B6.80.6089							1	—	—	
	E.A3.81.6517							1	—	—	
1439163	E.A3.81.6519							1	—	C	
	E.A3.81.6513							1	—	LM	
27353	E.A4.81.1659							1	—	C	
27352	E.A4.81.1661							1	—	C	
40619	E.A4.81.1663							1	—	C	
28W/9419473	SP.15/A							1	—	C	
3223	E.A6.81.369							1	—	C	
3224	E.A1.81.929							1	—	C	
	E.A3.81.6497							1	—	—	
5CW/9255	AS.10512C-1							2	—	B	
28S/1006948	A32/A12							4	—	C	
28W/9419473	SP.15/A							4	—	C	
	E.G5.80.447							—	—	—	
	E.B7.81.1069							1	—	—	
5CW/5252	HV.3711							1	—	C	
5CW/4401008	E.B7.81.369							1	—	C	
3223	E.A6.81.369							1	—	C	
5CW/8815	AS.10512L-1							1	—	C	
5CW/4706404	AS.10512M-1							1	—	C	
3224	E.A1.81.929							1	—	C	
5CW/1047693	†							1	—	C	
	or							1	—	C	
5CW/9235	AS.10512A-2							1	—	C	
28S/9419435	A31/B12							2	—	C	
1465	EEAS.28/2EP							4	L.16	C	
28W/9416642	SP.47/B							2	—	C	
28S/1200045	A31/A10							4	—	C	
28W/9419473	SP.15/A							4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5F/2022	†										
5K/3401	BULGIN T.102							QR	—	C	
5K/3400	BULGIN T.102							1	—	C	
5X/6240	E.A1.81.429							1	—	C	
17201	E.B7.81.1177							2	—	C	
								1	—	B	
13114	E.B7.81.1181										
								2	—	C	
28D/9436920	A25/1C										
28W/9410475	SP.15/C							4	—	C	
								4	—	C	
1807	E.A1.81.426							34	L.62	C	
1806	E.A1.81.427							30	L.62	C	
1808	E.A1.81.941							2	L.65	C	
5F/2124	†										
	E.G4.81.3151							QR	—	C	
								1	—	—	
5X/1002694	CZ.50207										
								1	—	C	
28S/9446305	A43/B28										
								2	—	C	
5E/4183	†										
5E/4186	†							QR	—	C	
5E/4187	†							QR	—	C	
17224	E.B7.81.1273							1	—	B/MR	
32C/614	†										
	E.EAS.117/1							QR	DTD.552	C	
20457	EEAS.117/1							3	S.92	C	
1108	EEAS.42							3	—	C	
1066	EEAS.28/2CU							3	S.514	C	
17226	E.B7.81.1323							1	—	B/MR	
32C/614	†										
	E.EAS.117/1							QR	DTD.552	C	
20457	EEAS.117/1							4	S.92	C	
1108	EEAS.42							4	—	C	
1066	EEAS.28/2CU							4	S.514	C	
5X/5805562	2CZ.111224							1	—	C	
5X/7148	2CZ.111405							3	—	C	
5K/4346878	EEAS.146/12							20	—	C	
5K/4346887	EEAS.146/20							6	—	C	
5X/1005131	Z.49428							1	—	C	
5X/1005132	Z.28081							8	—	C	
5X/9729122	†							2	—	C	
5X/9482491	HC.500							1	—	C	
5X/9450224	HC.510							3	—	C	
28D/9436920	A25/1C							4	—	C	
28W/9419475	SP.15/C							4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.4355										
28D/1010658	A25/1B										
28M/1278189	AGS.2001/B/1										
28W/9419474	SP.15/B										
	E.B6.81.4361										
	E.B6.81.4363										
28D/9436920	A25/1C										
28M/1278190	AGS.2001//C/1										
28W/9419475	SP.15/C										
	33721										
	E.B6.81.10219										
28M/1278190	AGS.2001/C/1										
28W/9419402	SP.13/C										
	E.B6.81.729										
28E/9428427	TERRY 81/2										
28S/1006948	A32/A12										
	28E/10051										
	TERRY 257/1/2										
28S/1213935	4006/6/1/2										
32A/1058027	†										
32A/0119481	†										
	E.B6.81.4313										
	33629										
	E.B6.81.4315										
28D/1007982	AS.1248/1C										
28W/9419475	SP.15/C										
	E.B6.81.4317										
28D/1007982	AS.1248/1C										
28W/9419475	SP.15/C										
	E.A3.81.791										
28S/1018882	4101/6/1/2"										
	33720										
	E.B6.81.10207										
28S/1213933	4000/4/1/2"										
	5CZ/1961										
	S.I.S.2407										
28D/9706306	A25/17E										
28M/9480017	AGS.2001/E/1										
28W/9419405	SP.15/E										
	5K/7000231										
	AS.3360/B3C										

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No	Description						No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.81.2857	LIGHTING, FRONT FUSELAGE, ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
5CZ/4329841	WB/UN/1146/S/3/W	BLOCK, terminal						1	—	C	
		Attaching parts for WB/UN/1146/S/3/W:—									
33440	E.B6.81.5349	Pillar, fixing						2	—	C	
28S/1200066	A33/B20	Screw, 4 BA						1	—	C	
28S/1212705	A40/B10	Screw, 4 BA						1	—	C	
28W/9419474	SP.15/B	Washer						2	—	C	
29C/1200328	AGS.2037/B	Washer, shakeproof						1	—	C	
5X/1004088	703-2-00244	BLOCK, terminal, 10-way						1	—	C	
		Attaching parts for 703-2-00244:—									
28M/1278189	AGS.2001/B/1	Nut						1	—	C	
5X/9450403	Z.28426	Pillar						2	—	C	
5X/1002695	703-1-00249	BLOCK, terminal, 20-way						3	—	C	
		Attaching parts for 703-1-00249:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA (As required)						2	—	C	
5X/9450403	Z.28426	Pillar (As required)						2	—	C	
28S/1011488	A32/B28	Screw (As required)						2	—	C	
33439	E.B6.81.5315	BRACKET, dimmer switch, assembly						1	—	C	
		Attaching parts for E.B6.81.5315:—									
28D/1010658	A25/1B	Bolt, 4 BA						4	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						4	—	C	
	E.B6.81.10159	Packer						1	—	C	
	E.B6.81.2461	Strip, packing						1	—	C	
28W/9419474	SP.15/B	Washer						1	—	C	
	E.B6.81.5053	CABLE, ASSEMBLY, LIA.1, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5057	CABLE, ASSEMBLY, LIA.2, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5059	CABLE, ASSEMBLY, LIA.3, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5061	CABLE, ASSEMBLY, LIB, pilot's terminal block to dimmer switch						1	—	—	
	E.B6.81.5065	CABLE, ASSEMBLY, LIB.2, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5067	CABLE, ASSEMBLY, LIB.3, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5069	CABLE, ASSEMBLY, LIB.4, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5071	CABLE, ASSEMBLY, LIC, pilot's terminal block to dimmer lamp						1	—	—	
	E.B6.81.5073	CABLE, ASSEMBLY, LIC.1, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5075	CABLE, ASSEMBLY, LIC.2, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5077	CABLE, ASSEMBLY, LIC.3, pilot's terminal block to lamp						1	—	—	
		(See Cable Chart for Breakdown Spares)									

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.5079	CABLE, ASSEMBLY, LIC.4, bomb aimer's terminal block prone position to pilot's terminal block						1	—	—	
	E.G5.81.583	CABLE, ASSEMBLY, LID, inner u.v. lamp and pilot's dimmer switch (Mod. 4075 and 4227)						1	—	—	
	E.B6.81.5083	CABLE, ASSEMBLY, LID.i, inner u.v. lamp and pilot's terminal block to outer u.v. lamp						1	—	—	
	E.B6.81.5085	CABLE, ASSEMBLY, LIE, outer u.v. lamp and pilot's terminal block to dimmer switch						1	—	—	
	E.B6.81.5087	CABLE, ASSEMBLY, LIE1, outer u.v. lamp and pilot's terminal board to inner u.v. lamp						1	—	—	
	E.B6.81.5089	CABLE, ASSEMBLY, LIF, pilot's terminal block to dimmer switch						1	—	—	
	E.B6.81.5091	CABLE, ASSEMBLY, LIFi, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5093	CABLE, ASSEMBLY, LIF2, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5097	CABLE, ASSEMBLY, LIG, pilot's terminal block to dimmer switch						1	—	—	
	E.B6.81.5099	CABLE, ASSEMBLY, N79A-9 prone terminal block to prone emergency light switch						1	—	—	
	or E.G4.81.3229	CABLE, ASSEMBLY, N79A-9 (Alt. R60/61 — Mod. 5100)						1	—	LM	
	E.B6.81.5101	CABLE, ASSEMBLY, LIH, pilot's terminal block to console panel and console terminal						1	—	—	
	E.B6.81.5103	CABLE, ASSEMBLY, L2A, prone terminal block to dimmer switch						1	—	—	
	E.B6.81.5105	CABLE, ASSEMBLY, L2A1, prone terminal block to wander lamp						1	—	—	
	E.B6.81.5107	CABLE, ASSEMBLY, LID2, dimmer switch and pilot's terminal block to u.v. lamp						1	—	—	
	E.B6.81.5109	CABLE, ASSEMBLY, L2A2, prone terminal block to cabin lamp (Pre-Mod. 3833)						1	—	—	
	E.G4.81.1233	CABLE, ASSEMBLY, L2A2, prone terminal block to cabin lamp (Mod. 3833)						1	—	—	
	E.B6.81.5111	CABLE, ASSEMBLY, L2B, navigator's terminal block to dimmer switch						1	—	—	
	E.B6.81.5113	CABLE, ASSEMBLY, L2B2, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5115	CABLE, ASSEMBLY, L2B3, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5117	CABLE, ASSEMBLY, L2B4, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5119	CABLE, ASSEMBLY, L4B3, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5121	CABLE, ASSEMBLY, L4B1, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5123	CABLE, ASSEMBLY, L4B2, navigator's terminal block to lamp						1	—	—	
	E.B6.81.5125	CABLE, ASSEMBLY, N79A, pilot's terminal block to pilot's emergency light switch						1	—	—	
	or E.G4.81.3235	CABLE, ASSEMBLY, N79A (Alt. R60/61—Mod. 5100)						1	—	LM	
	E.B6.81.5127	CABLE, ASSEMBLY, N79A1, pilot's terminal block to lamp						1	—	—	
	E.B6.81.5129	CABLE, ASSEMBLY, N79A2, pilot's terminal block to lamp						1	—	—	

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.							Description	No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
	E.B6.81.5131							CABLE, ASSEMBLY, N79A3, bomb aimer's terminal block prone position to pilot's terminal block	1	—	—	
	E.B6.81.5133							CABLE, ASSEMBLY, N79A4, prone terminal block to lamp	1	—	—	
	E.B6.81.5135							CABLE, ASSEMBLY, N79A5, navigator's terminal block to navigator's emergency light switch (Pre-Mod. 4415)	1	—	—	
	or E.G4.81.3225							CABLE, ASSEMBLY, N79A5 (Alt. R60/61—Mod. 5100)	1	—	LM	
	E.B6.81.5137							CABLE, ASSEMBLY, N79A6, navigator's terminal block to lamp	1	—	—	
	E.B6.81.5141							CABLE, ASSEMBLY, N123, E.C.P. to pilot's anti-dazzle switch and pilot's terminal block	1	—	—	
	or E.G4.81.3245							CABLE, ASSEMBLY, N123 (Alt. R60/61—Mod. 5100)	1	—	LM	
	E.B6.81.5143							CABLE, ASSEMBLY, N125, pilot's switch and No. 2 resistance, to navigator's switch	1	—	—	
	or E.G4.81.3227							CABLE, ASSEMBLY, N125 (Alt. R60/61—Mod. 5100)	1	—	LM	
	E.B6.81.5145							CABLE, ASSEMBLY, N126, No. 1 resistance to pilot's switch	1	—	—	
	or E.G4.81.3237							CABLE, ASSEMBLY, N126 (Alt. R60/61—Mod. 5100)	1	—	LM	
	E.B6.81.5147							CABLE, ASSEMBLY, N127, No. 1 resistance to No. 2 resistance	1	—	—	
	E.B6.81.5149							CABLE, ASSEMBLY, N128, No. 2 resistance to starboard anti-dazzle lamp	1	—	—	
	E.B6.81.5151							CABLE, ASSEMBLY, N129, No. 1 resistance to port anti-dazzle lamp	1	—	—	
	E.B6.81.5169							CABLE, ASSEMBLY, LID3, prone terminal block to u.v. lamp	1	—	—	
	E.B6.81.5171							CABLE, ASSEMBLY, LID4, pilot's terminal block to prone terminal block	1	—	—	
	E.B6.81.5175							CABLE, ASSEMBLY, N79A10, pilot's terminal block to navigator's terminal block	1	—	—	
	E.B6.81.5177							CABLE, ASSEMBLY, L3B, navigator's terminal block to dimmer switch	1	—	—	
	E.B6.81.5179							CABLE, ASSEMBLY, L3B1, navigator's terminal block to lamp	1	—	—	
	E.B6.81.5193							CABLE, ASSEMBLY, 14F1, dimmer switch to anglepoise lamp	1	—	—	
	E.B6.81.5295							CABLE, ASSEMBLY, 13F, 13G, 13N, JB13 to navigator's terminal block, cabin lamp and navigator's terminal block	1	—	—	
	E.B6.81.5297							CABLE ASSEMBLY, 14F, from JB14 to dimmer switch	1	—	—	
	E.B6.81.5303							CABLE, ASSEMBLY, L3A, dimmer switch to pilot's terminal block	1	—	—	
	E.B6.81.5307							CABLE, ASSEMBLY, L4B, dimmer switch, to navigator's terminal block	1	—	—	
	E.B6.81.5309							CABLE, ASSEMBLY, L1F4, pilot's terminal block to lamp	1	—	—	
	E.B6.81.5311							CABLE, ASSEMBLY, LIB5, pilot's terminal block to prone position terminal block	1	—	—	
	E.B6.81.5319							CABLE, ASSEMBLY, L1A, pilot's terminal block to dimmer switch	1	—	—	
(See Cable Chart for Breakdown Spares)												

ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
10H/21797	†							3	—	C	
10H/21798	†							8	—	C	
10H/21799	†							3	—	C	
10H/21800	†							2	—	C	
10H/23998	†							3	—	C	
5CZ/5073	†							1	—	C	
5CW/4509	E.A3.81.787							1	DTD.683	C	
	E.A3.81.1089							1	5.96	—	
	or										
28S/1008070	A55/A4							1	—	C	
5CW/4832	E.A3.81.2077							1	—	C	
28S/1005622	A31/B28							1	—	C	
29C/1206041	AGS.2035/B							1	—	C	
	E.G4.80.481							1	—	—	
	E.G4.81.3215							1	L.73	LM	
5X/7140	2CZ.111399							1	—	C	
5X/7159	2CZ.111229							3	—	C	
5X/7032	2CZ.85945							1	—	C	
5CW/4706404	AS.10512M-1							8	—	C	
5CW/4408142	AS.10512M-2							2	—	C	
5K/4346876	EEAS.146/6							8	—	C	
5CW/6453	†							1	—	B	
28M/1086618	AGS.2002/B/1							2	—	C	
28S/1007817	A32/B24							2	—	C	
	AS.2810/4/020							2	L.62	LM	
28W/9419465	SP.13/B							2	—	C	
	E.A9.81.3379							1	—	—	
5CW/4612	ROTAX-D-10001							1	—	B	
5CW/4835	E.A3.81.2073							1	—	C	
42076	E.A3.81.6375							1	—	B	
	E.A4.81.6801							1	—	—	
5CW/8053	XD800							1	—	C	
0AC/9436077	DP.1003							6	—	C	
28S/1012450	A32/B10							4	—	C	
29C/1206041	AGS.2035/B							4	—	C	
	E.KS.81.923							2	—	LM	
5CW/14141	DN1260.Z74							1	—	C	
5CW/14139	1260.Z165							1	—	C	
28S/9451799	A35/Z24							1	—	C	
5CW/9234	AS.10512A-1							1	—	B	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/4612	ROTAX-D-10001							1	—	B	
	or										
5CW/4408132	AS.10512E-1							1	—	B	
5CW/7539	†							1	—	C	
	or										
	E.K5.81.927							1	—	LM	
5CW/14141	DN1260.Z74							1	—	C	
5CW/14138	1260.Z163							1	—	C	
28S/9150230	A35/Z28							1	—	C	
5CW/9234	AS.10512A-1							1	—	B	
5CW/6429	†							5	—	C	
	or										
5CW/9235	AS.10512A-2							3	—	B	
5CW/9255	AS.10512C-1							1	—	B	
5CW/1047692	†							1	—	C	
	or										
5CW/9239	AS.10512A-6							1	—	B	
28S/9992522	A32/B16							2	—	C	
3526	EEAS.28/2HP							2	—	C	
29C/1206041	AGS.2035/B							2	—	C	
5CW/1047693	†							1	—	C	
	or										
5CW/9235	AS.10512A-2							1	—	B	
5F/	†							QR	—	—	
28D/9133011	A25/2C							12	—	C	
28W/9419402	SP.13/C							12	—	C	
	E.B6.80.263							1	—	—	
28S/1212707	A40/B14							4	—	C	
5CW/4408139	AS.10512L-2							2	—	C	
5CW/4408142	AS.10512M-2							2	—	C	
3417	EEAS.132/9							4	—	C	
28D/1218384	AS.1248/1B							1	—	C	
28M/1278189	AGS.2001/B/1							1	—	C	
3420	EEAS.73							1	—	C	
5F/943485B	HV.3254							QR	—	C	
5F/9138823	NY.3255							QR	—	C	
5CW/1047697	†							2	—	C	
	or										
5CW/9255	AS.10512C-1							2	—	B	
28S/9440345	A40/B8							4	—	C	
28W/9416642	SP.47/B							4	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN FRONT FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
28E/9000883	AS.3180/9B							3	—	C	
28E/9436947	AS.3180/4B							1	—	C	
28E/9436819	AS.3180/3B							9	—	C	
28E/1009753	AS.3180/3C							1	—	C	
28E/1201828	AS.3180/11B							3	—	C	
32A/1058027	↑							QR	—	C	
28M/9403519	A27/BP							13	—	C	
28M/1278190	AGS.2001/C/1							1	—	C	
28S/1011490	A32/C16							1	—	C	
28S/9992525	A32/B12							3	—	C	
	BURGESS										
5CW/9504373	MS.5752							1	—	C	
	HONEYWELL										
5CW/1085884	1H.Y1							1	—	B	
	DOWTY										
5CW/12444	1322Z Mk.2							1	—	B	
5CW/13598	1322Z Mk.3							1	—	B	
28W/9416642	SP.47/B							1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.41	EQUIPMENT, ELECTRICAL, REAR FUSELAGE FAIRING, ASSEMBLY						—	—	—	
		Spares for:—									
5L/9953294	†	FILAMENT, 28v., 12w.						2	—	C	
	E.A1.81.91/1	LIGHT, TAIL, UPPER, ASSEMBLY						1	—	—	
		Spares for:—									
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
5X/9491422	Z.22430	GROMMET, Helsyn. No. 2						1	—	C	
5CX/4330113	E.A1.81.978	LAMP, ASSEMBLY (less cable)						1	—	C	
		Spares for:—									
5CX/4242	E.A1.81.332	DOME, lamp, protecting						1	Perspex	C	
5CX/887	†	LAMP, navigation, type B						1	—	C	
5CX/4243	E.A1.81.331	SCREEN, cap dome, mounting						1	DTD.683	C	
5K/4346888	†	SLEEVE						4	—	C	
5K/9140109	†	SLEEVE						2	—	C	
		Attaching parts for E.A1.81.91/1:—									
28M/9403518	A27/AP	Nut, 6 BA						4	—	C	
28W/9416641	SP.47/A	Washer, spring						4	—	C	
	E.A1.81.92/1	LIGHT, TAIL LOWER, ASSEMBLY						1	—	—	
		Spares for this assembly are identical with those for assembly Part No. E.A1.81.91/1, except for the following deletion:—									
		Delete:—									
5X/9491422	Z.22430	GROMMET, Helsyn. No. 2						1	—	C	
5X/9009937	Z.23672	GROMMET						2	—	C	
	E.G4.81.2057	LAMP, ANTI-COLLISION AND FLASHER UNIT, AT FRAMES 32-34, INSTALLATION (MOD. 4313)						—	—	—	
		Spares for:—									
28E/9436819	AS.3180/3B	CLIP, "P", rubber covered						6	—	C	
		Attaching parts for AS.3180/3B:—									
28M/1228189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
28S/9992522	A32/B16	Screw, 4 BA						1	—	C	
28W/9419465	SP.13/B	Washer						1	—	C	
5CZ/1044107	†	FLASHER, UNIT, type A, 24 volt						1	—	A	
		Attaching parts for Rcf. 5CZ/1044107:—									
28S/1200047	A31/C24	Screw, 2 BA						4	—	C	
	AS.2299/025	Tube, distance						4	—	—	
28W/9419402	SP.13/C	Washer						4	—	C	
5L/9952445	†	LAMP, filament, 28v., 40w., S.C.C.						1	—	C	
	THORN										
5CX/4330324	F.N.L.50	LAMP, navigation						1	—	C	
34314	E.B6.81.10341	MEMBER, support, flasher unit						1	—	C	
40688	E.B6.81.10347	PLATE, packing, lamp						1	—	C	
40687	E.B6.81.10345	RING, packing, lamp						1	—	C	
	E.B6.81.10355	LAMP, ANTI-COLLISION AT FRAMES 33-34, INSTALLATION (MOD. 3599)						—	—	—	
		Spares for:—									
28E/9436819	AS 3180/3B	CLIP, "P", rubber covered						1	—	C	
		Attaching parts for AS.3180/3B:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
28S/9992522	A32/B16	Screw, 4 BA						1	—	C	
28W/9419465	SP.13/B	Washer						1	—	C	
40691	E.B6.81.10363	COVER						1	—	C	
		Attaching parts for E.B6.81.10363:—									
28FP/9488815	DZUS A4/30	Fastener						6	—	C	
28FP/9430916	DZUS S4/200	Spring						6	—	C	
28W/9419464	SP.13/A	Washer						6	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.	
		1	2	3	4	5	6					
5L/9952445	† THORN							LAMP, filament, 28v., 40w., S.C.C.	1	—	C	
5CX/4330324	F.N.L.50							LAMP, navigation	1	—	C	
40688	E.B6.81.10347							PLATE, packing, lamp	1	—	C	
40687	E.B6.81.10345							RING, packing, lamp	1	—	C	
	E.G4.81.2837							LOOMS; CABLE, ASSEMBLY (MOD. 4799) ...	—	—	—	
								Consisting of:—				
	E.G4.81.2631							CABLE, ASSEMBLY, 1F2D, FROM PRESSURE BULKHEAD TO AERIAL SWITCHING UNIT, TRANSMITTER/RECEIVER AND PLUG BREAK (MOD. 4864)	1	—	—	
								Spares for:—				
5X/1956336	416750/14							CLAMP, cable	1	—	C	
5X/1986976	466-14-195							SOCKET	1	—	C	
								Remainder of spares to connector SCA.78015/87 (SRIM.3533) (Mod. 4799)				
	or											
	E.G4.82.1127							CABLE, ASSEMBLY, 1F2D (Alt. R60/61 — Mod. 5100)	1	—	LM	
	E.B6.81.3663							CABLE, ASSEMBLY, T6, rear bulkhead to junction box 6	1	—	—	
10971	E.B7.81.531							CABLE, ASSEMBLY, 6E, junction box to earth ...	1	—	C	
	E.B7.81.573/2							CABLE, ASSEMBLY, T33, bomb bay bulkhead to tailplane relay panel	1	—	—	
41509	E.B7.81.575/2							CABLE, ASSEMBLY, T33H, tailplane relay panel to tailplane actuator high speed motor	1	—	C	
41649	E.B7.81.577/2							CABLE, ASSEMBLY, T33L, tailplane relay panel to tailplane actuator low speed motor	1	—	C	
26356	E.B6.81.2367							CABLE, ASSEMBLY, T99, from relay T100B to reversing relay	1	—	C	
41650	E.B7.81.583/2							CABLE, ASSEMBLY, 6A, junction box 6 to tailplane position transmitter (Pre-Mod. 5091)	1	—	C	
	E.B7.81.6905							CABLE, ASSEMBLY, 6A, junction box 6 to tailplane position transmitter (Mod. 5091)	1	—	LM	
23024	E.A9.81.3213							CABLE, ASSEMBLY, 6C1, from tailplane limit switches, upper, to relay panel	1	—	C	
	E.A1.81.802/2							CABLE, ASSEMBLY, T94, rear bomb bay bulkhead connection to plug panel rear scanner	1	—	—	
	E.A9.81.5415/2							CABLE, ASSEMBLY, T96, bomb bay bulkhead to plug panel rear scanner (Mod. 3841)	1	—	—	
10966	E.A1.81.806/1							CABLE, ASSEMBLY, 6G, junction box 6 to tail navigation lights, terminal board	1	—	B	
	E.B7.81.2471							CABLE, ASSEMBLY, N104A, crimping connector between frames 38 and 39 to rudder trim actuator (Pre-Mod. 5091)	1	—	—	
	E.B7.81.6577							CABLE, ASSEMBLY, N104A, crimping connector between frames 38 and 39 to rudder trim actuator (Mod. 5091)	1	—	LM	
10969	E.A2.81.1065							CABLE, ASSEMBLY, 6F, junction box 6 to rudder trim position transmitter (Pre-Mod. 5091)	1	—	B	
	E.A2.81.5955							CABLE, ASSEMBLY, 6F, junction box 6 to rudder trim position transmitter (Mod. 5091)	1	—	LM	
26355	E.B7.81.2027							CABLE, ASSEMBLY, T33A, from T100B relay to reversing relay	1	—	C	
23025	E.A9.81.3215							CABLE, ASSEMBLY, 6B1, tailplane limit switches, lower, to relay panel	1	—	C	
								(See Cable Chart for Breakdown Spares)				

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G4.81.293	CABLE ASSEMBLY , 6N, from JB6 to upper and lower flasher lights and flasher unit (Mod. 3599)						1	—	—	
		(See Cable Chart for Breakdown Spares)									
5X/2790	Z.22634	GROMMET , dummy						4	—	C	
	E.A1.81.42	MOUNTING, JUNCTION BOX, NO. 6, INSTALLATION						1	—	—	
		Consisting of:—									
10972	E.A1.81.489	CHANNEL						1	—	C	
10973	E.A1.81.490	CHANNEL						1	—	C	
		Attaching parts for E.A1.81.489 and E.A1.81.490:—									
28D/9436920	A25/1C	Bolt , 2 BA						2	—	C	
28M/1278190	AGS.2001/C/1	Nut , 2 BA						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
	E.B7.81.425	PANEL, RELAY REVERSING, ASSEMBLY						1	—	—	
		Spares for:—									
5X/1957037	703/1/00232	BLOCK , terminal, 3-way						1	—	C	
	SE/4183	CABLE , Uninyvin 20						QR	—	C	
	18755	CLAMP , cable						1	—	C	
	18756	CLAMP , cable						1	—	C	
		Attaching parts for E.B7.81.429 and E.B7.81.431:—									
28D/1213262	AS.4565/10B	Bolt , 4 BA						2	—	C	
5X/1957036	703/1/00263	COVER , perspex						1	—	C	
	E.B7.81.5153	LABEL (Mod. 3557)						1	—	—	
5X/1004083	703/2/00252	LINK , 3-way						1	—	C	
	18754	PANEL , base						1	—	B/MR	
5X/9450403	703/2/00267	PILLAR , fixing						2	—	—	
5K/4346878	EEAS.146/12	SLEEVE , 3/4" long						8	—	C	
5K/4346876	EEAS.146/6	SLEEVE , 1/2" long						3	—	C	
5X/1005131	Z.49428	SLEEVE						4	—	C	
5CW/11257	ROTAX D.5107/3	SWITCH , time (Mod. 4107)						1	—	A	
		Attaching parts for Rotax D.5107/3:—									
28S/9464989	A43/C23	Screw , 2 BA						3	—	C	
5X/9462952	HC.302	TAG						4	—	C	
5X/9450396	HC.490	TAG						4	—	C	
5X/9400064	703/2/00340/020	THIMBLE						4	—	C	
		Attaching parts for E.B7.81.425:—									
28M/1278190	AGS.2001/C/1	Nut , 2 BA						4	—	C	
28S/1011490	A32/C16	Screw , 2 BA						4	—	C	
3420	EEAS.73	PLATE , clamp, securing cable webbing to airframe						3	—	C	
		Attaching parts for EEAS.73:—									
28D/9128739	AS.1248/1B	Bolt , 4 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut , 4 BA						1	—	C	
	E.A3.81.2825	RELAY, T.100B, INSTALLATION						—	—	—	
		Spares for:—									
22448	E.A3.81.2827	BRACKET , assembly						1	—	MR	
22449	E.A3.81.2829	BRACKET						1	—	MR	
22450	E.A3.81.2831	BRACKET						1	—	MR	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/5986	†	RELAY, T.100B						1	—	A	
28S/1200039	A31/832	Attaching parts for Ref. 5CW/5986:—									
1108	EEAS.42	Screw, † BA						4	—	C	
		Washer, leather						4	—	C	
3416	EEAS.132/7	STRAP, cable, c/w buckle						3	—	C	
5F/9434857	HV.3341	STRAP						QR	—	C	
5F/9138822	NY.3342	STUD						QR	—	C	
18752	E.B7.81.329	STUD, earth						1	—	C	
	E.B7.81.1101	SWITCH AND MOUNTING, TAILPLANE UNIT, INSTALLATION						—	—	—	
		Spares for:—									
	E.B7.81.6555	BLOCK, packing (Mod. 4287)						1	—	—	
6946	E.B7.81.1105	CRADLE, switch, mounting						1	—	C	
	BURGESS										
5CW/6672	MS.5750	SWITCH, micro, top limit (Pre-Mod. 4287) ...						2	—	C	
5CW/6672	MS.5750	SWITCH, micro, top limit (Mod. 4287) (Pre-Mod. 4288)						1	—	C	
5CW/1085884	HONEYWELL 1H.Y1	SWITCH, limit, top (Mod. 4288)						1	—	B	
5CW/12444	DOWTY 1322Z Mk.2	SWITCH, limit, top (Mod. 4449-S.O.O.) (Pre-Mod. 4959)						1	—	B	
5CW/13598	1322Z Mk.3	SWITCH, limit, top (Mod. 4959)						1	—	B	
		Attaching parts for micro or limit switches and E.B7.81.6555:—									
6943	E.B7.81.1093	Bolt, eccentric						2	—	C	
6944	E.B7.81.1099	Bolt, locking						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, † BA						3	—	C	
18787	E.B7.81.1097	Plate, locking						1	—	C	
6947	E.B7.81.1095	Washer, eccentric						2	—	C	
	BURGESS										
5CW/6672	MS.5750	SWITCH, micro, lower limit (Pre-Mod. 4287) ...						2	—	C	
5CW/6672	MS.5750	SWITCH, micro, lower limit (Mod. 4287) (Pre-Mod. 4288)						1	—	C	
5CW/1085884	HONEYWELL 1H.Y1	SWITCH, limit, lower (Mod. 4288)						1	—	B	
5CW/12444	DOWTY 1322Z Mk.2	SWITCH, limit, lower (Mod. 4449-S.O.O.) (Pre-Mod. 4959)						1	—	B	
5CW/13598	1322Z Mk.3	SWITCH, limit, lower (Mod. 4959)						1	—	B	
		Attaching parts for switches:—									
6945	E.B7.81.1399	Bolt, eccentric						2	—	C	
6944	E.B7.81.1099	Bolt, locking						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, † BA						3	—	C	
18787	E.B7.81.1097	Plate, locking						1	—	C	
6947	E.B7.81.1095	Washer, eccentric						2	—	C	
32B/1168	†	TAPE, P.V.C., 1"						QR	—	C	
5F/	†	TUBING, P.V.C., 5 m/m						QR	—	C	
17521	EEAS.28/10DPH	WASHER, at earth stud connection						2	—	C	
28W/9416644	SP.47/E	WASHER, spring, at earth stud						1	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN REAR FUSELAGE**

Ref. No.	Part No.	Description						No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.G.4.81.283	WIRING AND CLIPPING, FRAMES 31 TO 38, ASSEMBLY						—	—	—	
		Spares for:—									
	E.A1.81.252	BRACKET , cable, strap guide						6	—	—	
32A/9429657	†	CORD , nylon, P.V.C.						QR	—	—	C
30B/2008	†	GAUZE , fine mesh						QR	—	—	C
3420	EEAS.73	PLATE , clamp, securing, cable strap						2	—	—	C
		Attaching parts for EEAS.73:—									
28D/9128739	AS.1248/1B	Bolt , 4 BA						1	—	—	C
28M/1278189	AGS.2001/B/1	Nut , 4 BA						1	—	—	C
	3416	STRAP , cable, c/w buckle						8	—	—	C
5F/9434858	HV.3254	STRAP						QR	—	—	C
5F/9138823	NY.3255	STUD						QR	—	—	C
	32B/1168	TAPE , P.V.C., 1"						QR	—	—	C
	5F/2034	TUBE , P.V.C., 1/2" dia.						QR	—	—	C

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
	E.G4.81.2809	ELECTRICAL EQUIPMENT, IN PORT WING, ASSEMBLY (MOD. 4799)	—	—	—	
	E.G4.81.247	CONDUITS ACROSS ENGINE NACELLE, ASSEMBLY	—	—	—	
		Spares for:—				
17036	E.A3.81.2135	CLIP, conduit securing	1	—	C	
33290	E.B6.20.1147	CLIP, conduit securing	2	L.72	C	
33291	E.B6.20.1149	CLIP, conduit securing	2	L.72	C	
33292	E.B6.20.1189	CLIP, conduit securing	2	L.72	C	
33293	E.B6.20.1191	CLIP, conduit securing	2	L.72	C	
		Attaching parts for E.A3.81.2135, E.B6.20.1147, E.B6.20.1149, E.B6.20.1189 and E.B6.20.1191:—				
28D/1008149	A25/2B	Bolt; 4 BA (As required)	1	—	C	
28D/9419452	A25/3B	Bolt; 4 BA (As required)	1	—	C	
28D/9436920	A25/1C	Bolt; 2 BA (As required)	2	—	C	
28M/1278189	AGS.2001/B/1	Nut; 4 BA (As required)	1	—	C	
28M/1278190	AGS.2001/C/1	Nut; 2 BA (As required)	2	—	C	
28W/9419402	SP.13/C	Washer (As required)	2	—	C	
28W/9419475	SP.15/C	Washer (As required)	2	—	C	
33296	E.A9.81.1075	Washer square (As required)	1	—	C	
17046	E.A3.81.2171	CONDUIT	1	L.54	C	
17047	E.A3.81.2173	CONDUIT	1	L.54	C	
33288	E.B6.20.1049	CONDUIT	1	L.54	C	
33294	E.B6.20.1217	CONDUIT-END	1	L.54	C	
17016	E.A3.81.1595	SLEEVE , conduit coupling	1	—	C	
33295	E.B6.20.1231	SLEEVE , conduit coupling	1	L.54	C	
	E.G4.81.249	CONDUITS, IN INNER WING, ASSEMBLY	—	—	—	
		Spares for:—				
9747	E.A1.81.108	CLIP, conduit securing	1	—	C	
9746	E.A1.81.111	CLIP, conduit securing	2	—	C	
17091	E.A3.81.2479	CLIP, conduit securing	2	—	C	
17092	E.A3.81.2485	CLIP, conduit securing	2	—	C	
33289	E.B6.20.1135	CLIP, conduit securing	2	L.72	C	
		Attaching parts for E.A1.81.108, E.A1.81.111, E.A3.81.2479, E.A3.81.2485 and E.B6.20.1135:—				
28D/1010658	A25/1B	Bolt; 4 BA (As required)	2	—	C	
28D/1008149	A25/2B	Bolt; 4 BA (As required)	1	—	C	
28D/9436920	A25/1C	Bolt; 2 BA (As required)	2	—	C	
28M/9403519	A27/BP	Nut; 4 BA (As required)	2	—	C	
28M/9433473	AGS.2002/C/1	Nut; 2 BA (As required)	2	—	C	
28W/9416642	SP.47/B	Washer (As required)	2	—	C	
28W/9419402	SP.13/C	Washer (As required)	2	—	C	
17035	E.A3.81.2133	Washer "D" (As required)	1	—	C	
17093	E.A3.81.2487	CONDUIT	1	L.54	C	
17094	E.A3.81.2489	CONDUIT	1	L.54	C	
17095	E.A3.81.2491	CONDUIT	1	L.54	C	
33287	E.B6.20.1045	CONDUIT	1	L.54	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.17	CONDUITS ON RIB 7, INNER WING, ASSEMBLY						—	—	—	
		Spares for:—									
9739	E.A1.81.102	CLIP, conduit securing						1	—	C	
9751	E.A1.81.110	CLIP, conduit securing						5	—	C	
		Attaching parts for E.A1.81.102 and E.A1.81.110:—									
28D/9436920	A25/1C	Bolt, 2 BA (As required)						2	—	C	
28D/9133011	A25/2C	Bolt, 2 BA (As required)						1	—	C	
28M/9403520	A27/CP	Nut, 2 BA (As required)						2	—	C	
28W/9416643	SP.47/C	Washer (As required)						2	—	C	
9750	E.A1.81.17A	CONDUIT, 1½" o/d x 82" long, 20 SWG						1	T.9	C	
	E.G4.81.241	CONDUITS, IN OUTER WING, ASSEMBLY						—	—	—	
		Spares for:—									
17037	E.A3.81.2137	CLIP, conduit securing						7	—	C	
17038	E.A3.81.2139	CLIP, conduit securing						2	—	C	
		Attaching parts for E.A3.81.2137 and E.A3.81.2139:—									
28D/1010658	A25/1B	Bolt, 4 BA (As required)						2	—	C	
28M/9403519	A27/BP	Nut, 4 BA (As required)						2	—	C	
28W/9419474	SP.15/B	Washer (As required)						2	—	C	
17031	E.A3.81.2125	CONDUIT						1	—	C	
17032	E.A3.81.2127	CONDUIT						1	—	C	
17043	E.A3.81.2149	CONDUIT						1	—	C	
	E.G4.81.243	CONDUIT (Make from Ref. 17030)						1	—	LM	
	E.G4.81.245	CONDUIT (Make from Ref. 17030)						1	—	LM	
	E.A3.81.1665	SLEEVE						2	—	—	
	E.A3.81.2129	SUPPORT , conduit at rib 7A						2	—	—	
		Attaching parts for E.A3.81.2129:—									
28D/1011023	A25/20C	Bolt, 2 BA						2	—	C	
	E.B7.81.603	ELECTRICAL EQUIPMENT IN ENGINE BAY, ASSEMBLY						—	—	—	
		Spares for:—									
21902	E.B6.81.897	CONDUIT , ½" o/d x 22 SWG						1	L.62	C	
5K/4329335	AGS.1658/1	NUT , gland						2	—	C	
5X/6002	CZ.28180	PLUG , 2-way, size A (Pre-Mod. 3879)						2	—	C	
5X/7021	2CZ.84864	PLUG , 2-way, size A (Mod. 3879)						2	—	C	
5X/6007	CZ.28181	PLUG , 4-way, size A (Pre-Mod. 3879)						1	—	C	
5X/7022	2CZ.84865	PLUG , 4-way, size A (Mod. 3879)						1	—	C	
5X/6440	CZ.23144/Z	PLUG , clamp						6	—	C	
17242	E.B7.81.1523	RING , locking adapter						2	L.64	C	
5K/1008392	AGS.1654/1	SLEEVE , outer						2	—	C	
	E.B7.81.2921	TUBE , Helsen plus (Make from Ref. 5F/2343)						1	—	LM	
	E.B7.81.2925	TUBE , Helsen plus (Make from Ref. 5F/2343)						1	—	LM	
	E.B7.81.2927	TUBE , Helsen plus (Make from Ref. 5F/2343)						1	—	LM	
7782	EEAS.21/1ER	WASHER , "D"						6	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.G4.81.237	ELECTRICAL EQUIPMENT IN INNER WING, REAR, ASSEMBLY	—	—	—	
	E.B7.81.377	Spares for:— BOX, JUNCTION, NO. 9, ASSEMBLY	1	—	—	
5X/1002695	CZ.23212/1	Spares for:— BLOCK , terminal, 20-way	2	—	C	
28S/1200033	A31/B24	Attaching parts for CZ.23212/1:— Screw, 4 BA	2	—	C	
	E.A1.81.583	BOX , bare	1	—	—	
	E.B7.81.381	COVER , assembly	1	—	—	
5X/6180	CZ.24650	FERRULE , plate	1	—	C	
5X/6168	Z.23197	GASKET , size C	2	—	C	
5X/6169	Z.23198	GASKET , size D	2	—	C	
5X/6315	Z.50215	LINK , commoning, 7-way	1	—	C	
5X/3143	CZ.23144/D	RING , clamp, size D	1	—	C	
5K/4346876	EEAS.146/6	SLEEVE	33	—	C	
28D/9133013	A25/5C	Attaching parts for E.B7.81.377:— Bolt, 2 BA	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
	A5.2811/5/045	Tube, distance, 17 SWG	3	L.62	LM	
	A5.2811/5/049	Tube, distance, 17 SWG	1	L.62	LM	
6A/4332834	†	COMPENSATOR , cold junction, type B	1	—	C	
28D/9706373	A25/2A	Attaching parts for 6A/4332834:— Bolt, 6 BA	4	—	C	
7186	E.A3.81.1473	FAIRLEAD , 3/4" thick	2	LFS	C	
28D/1010142	A25/9B	Attaching parts for E.A3.81.1473:— Bolt, 4 BA	3	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	3	—	C	
28M/1006504	A27/BT	Nut, 4 BA	3	—	C	
28W/9419474	SP.15/B	Washer	3	—	C	
3416	EEAS.132/7	STRAP , c/w buckle	1	—	C	
28D/9128739	AS.1248/3B	Attaching parts for EEAS.132/7:— Bolt, 4 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	L.72	C	
3417	EEAS.132/9	STRAP , c/w buckle	2	—	C	
28D/1218386	AS.1248/3B	Attaching parts for EEAS.132/9:— Bolt, 4 BA	1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
3420	EEAS.73	Plate, clamp	1	L.72	C	
5F/9434888	HV.3254	STRAP	QR	—	C	
5F/9138823	NY.3255	STUD	14	—	C	
	E.G4.81.251	ELECTRICAL EQUIPMENT IN LEADING EDGE, ASSEMBLY	—	—	—	
9734	E.A3.81.559	Spares for:— BRACKET , mounting, air thermocouple	1	—	C/MR	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No							Description	No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
6A/2783	SANGAMO WESTON †							BULB, thermocouple, 2 1/4" long, c/w 96" connecting cable	1	—	A	
17361	E.B6.81.381							FAIRLEAD, half, in engine rib, for high energy ignition cables	2	BS.2572	C/MR	
28M/1278189	AGS.2001/B/1							Attaching parts for E.B6.81.381 (Per pair):—				
28S/9419453	A31/B14							Nut, 4 BA	4	—	C	
28W/9419465	SP.13/B							Screw, 4 BA	4	—	C	
								Washer	4	—	C	
5X/9491421	Z.22431							GROMMET	1	—	C	
	E.B6.81.4883							PANEL, VOLTAGE REGULATOR, ASSEMBLY	1	—	—	
								Spares for:—				
	E.B7.81.2501 †							PANEL	1	—	—	
5UC/6360								REGULATOR, type 114	1	—	A	
								Attaching parts for Ref. 5UC/6360:—				
28D/1011238	A25/3E							Bolt, 3/8" BSF	4	—	C	
								Attaching parts for E.B6.81.4883:—				
28D/9133011	A25/2C							Bolt, 2 BA	4	—	C	
28M/1278190	AGS.2001/C/1							Nut, 2 BA	4	—	C	
28W/9419475	SP.15/C							Washer	4	—	C	
5K/4346878	EEAS.146/12							SLEEVE	2	—	C	
5K/4346873	EEAS.146/2							SLEEVE	2	—	C	
5X/9482491	HC.500							TAG	2	—	C	
	E.G4.81.2869							ELECTRICAL EQUIPMENT AND WIRING IN OUTER WING, ASSEMBLY (MOD. 4799)	—	—	—	
								Spares for:—				
5CZ/1053794	†							BLOCK, terminal, 2-way	1	—	B	
								Attaching parts for Ref. 5CZ/1053794:—				
28M/1987493	AGS.2001/A/1							Nut, 6 BA	2	—	C	
28S/1011484	A32/A20							Screw, 6 BA	2	—	C	
	E.G4.81.1745							BOX, CABLE, CONNECTOR, AMPLIFIER, FUEL CONTENTS, INSTALLATION (MOD. 3479) OR (MOD. 4154)	—	—	—	
								Spares for:—				
	SMITH-WAY-MOUTH											
6A/9490	1ST/JY/101							BOX, cable connector, type JY 88	1	—	C	
								Attaching parts for 1ST/JY/101				
28D/9453970	A25/15C							Bolt, 2 BA	2	—	C	
28M/1278190	AGS.2001/C/1							Nut, 2 BA	2	—	C	
	AS.2811/5/090							Tube, distance, 1 1/8" o/d.	2	L.62	LM	
28W/9419402	SP.13/C							Washer	2	—	C	
	SMITH-WAY-MOUTH											
6A/4333118	XA							BRACKET, amplifier, fuel contents, attachment	1	—	C	
								Attaching parts for XA:—				
28D/1007975	AS.1242/1C							Bolt, 2 BA	4	—	C	
	SMITH-WAY-MOUTH											
6A/4333096	FAA							TRANSMITTER, amplifier, fuel contents	1	—	A	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
6734	EEAS.136	BRACKET , cable clip						6	—	C	
	or										
5340-99- 4163724 17361	EEAS.136A										
	E.B6.81.381	FAIRLEAD , half						2	—	C	
		Attaching parts for E.B6.81.381 (per pair):—									
28D/1008149	A25/2B	Bolt, 4 BA						4	—	C	
28W/9419474	SP.15/B	Washer						4	—	C	
5F/9434858	HV.3254	STRAP						QR	—	C	
5F/9138823	NY.3255	STUD						16	—	C	
5CY/4376390	S.I.S. 3671	SUPPRESSOR , type O, No. 2						1	—	B	
		Attaching parts for S.I.S.3671:—									
28D/1008149	A25/2B	Bolt, 4 BA						4	—	C	
37A/1401	NB.25/2	UNIT , ignition, high energy (Alternative) ...						1	—	B	
37A/1790	C.10T.S./3	UNIT , ignition, high energy (Alternative) ...						1	—	B	
		Attaching parts for NB.25/2 or C.10T.S./3:—									
28D/1011247	A25/13E	Bolt, 3/8" BSF						3	—	C	
5L/9954717	†	FILAMENT , 24v., 240w.						1	—	C	
5CX/5009	†	LAMP , landing, type J, Mk. 2						1	—	A	
	E.G4.81.2839	LDOMS: CABLE ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
9687	E.A1.81.819/1	CABLE ASSEMBLY , 7A1, from terminal block to undercarriage "up" micro switch (Pre-Mod. 5091)						1	—	C	
	E.A1.81.1211	CABLE ASSEMBLY , 7A1, from terminal block to undercarriage "up" micro switch (Mod. 5091)						1	—	LM	
	E.A1.81.876/1	CABLE ASSEMBLY , 7A, from JB7 to undercarriage wiring terminal block						1	—	—	
	E.A1.81.881/1	CABLE ASSEMBLY , 7A4, from undercarriage terminal block to port wheel door micro switch						1	—	—	
9679	E.A3.81.877/1	CABLE ASSEMBLY , 9D, from JB9 to landing lamp						1	—	B	
5380	E.A3.81.895/1	CABLE ASSEMBLY , 9B3, from navigation light contact band to navigation light terminal block						1	—	C/MR	
	E.A3.81.1469	CABLE ASSEMBLY , 9F, from JB9 to cold junction compensator						1	—	—	
9691	E.A3.81.1583	CABLE ASSEMBLY , 9B, from JB9 to wing tip terminal block (Pre-Mod. 4936)						1	—	C	
	E.A3.81.6717	CABLE ASSEMBLY , 9B, from JB9 to wing tip terminal block (Mod. 4936)						1	—	—	
5429	E.A3.81.1591	CABLE ASSEMBLY , 9B1, from wing tip terminal block to jettison tank and navigation light terminal block						1	—	C/MR	
5430	E.A3.81.1593	CABLE ASSEMBLY , 9B2, from terminal block to wing tip taxiing lamp connection						1	—	C/MR	
	E.A3.81.1597	CABLE ASSEMBLY , 9B4, from wing tip terminal block to jettison tank detonator terminal block (Pre-Mod. 4063)						1	—	—	
	E.A3.81.6321	CABLE ASSEMBLY , 9B4, from terminal block to jettison tank detonator (Mod. 4063) (Pre-Mod. 4936)						1	—	—	
	E.A3.81.6721	CABLE ASSEMBLY , 9B4, from terminal block to jettison tank detonator (Mod. 4936)						1	—	—	
(See Cable Chart for Breakdown Spares)											

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
5431	E.A3.81.1599	CABLE	ASSEMBLY	9B5	from wing tip terminal block to jettison tank forward detonator terminal block (Pre-Mod. 4063)			1	—	C/MR		
	E.A3.81.6319	CABLE	ASSEMBLY	9B5	from wing tip terminal block to jettison tank forward detonator terminal block (Mod. 4063) (Pre-Mod. 4936)			1	—	—		
	E.A3.81.6723	CABLE	ASSEMBLY	9B5	from wing tip terminal block to jettison tank forward detonator terminal block (Mod. 4936)			1	—	—		
	E.A6.81.514/2	CABLE	ASSEMBLY	9A and 9J	from JB9 to nitrogen valve and vent valve heater terminal			1	—	—		
	E.G4.81.1761	CABLE	ASSEMBLY	9C	from JB9 to tank transmitter (Mod. 4154 or 3748)			1	—	—		
	E.A6.81.524	CABLE	ASSEMBLY	9G	from JB9 to fuel pump suppressor			1	—	—		
	E.A6.81.525/2	CABLE	ASSEMBLY	9G1	from suppressor to fuel pump			1	—	—		
	E.A6.81.526/2	CABLE	ASSEMBLY	9H	from JB9 to engine fuel cock			1	—	—		
	E.A6.81.527/2	CABLE	ASSEMBLY	9K	from JB9 to main tank fuel cock			1	—	—		
	E.A9.81.5437/2	CABLE	ASSEMBLY	7F, 7D, 7P	from JB7 to fire extinguisher bottles (Mod. 3773)			1	—	—		
	E.B6.81.503/2	CABLE	ASSEMBLY	7H	from JB7 to general services J.B. plug on inboard engine rib			1	—	—		
	E.B6.81.505/2	CABLE	ASSEMBLY	7J	from JB7, to anti-icing services J.B. plug on inboard engine rib			1	—	—		
	E.B6.81.513/2	CABLE	ASSEMBLY	9L	from JB9 to outboard high energy ignition unit			1	—	—		
17386	E.B6.81.521/2	CABLE	ASSEMBLY	7N, 7M, 7R	from JB7 to flame detectors and cowl unit anti-icing actuator plugs on inboard engine rib			1	—	B		
41508	E.B6.81.523/2	CABLE	ASSEMBLY	7N1	from inboard engine rib plug to cowl anti-icing actuator (Pre-Mod. 5091)			1	—	C		
	E.B6.81.6379	CABLE	ASSEMBLY	7N1	from inboard engine rib plug to cowl anti-icing actuator (Mod. 5091)			1	—	LM		
	E.B6.81.527	CABLE	ASSEMBLY	E7	from JB7 to earth connection			1	—	—		
	E.B6.81.531	CABLE	ASSEMBLY	E9	from JB9 to earth connection			1	—	—		
	E.B6.81.537/2	CABLE	ASSEMBLY	P9	from JB9 to fuselage connection			1	—	—		
	E.B6.81.601	CABLE	ASSEMBLY	7R2	connection between first and second flame detectors (Pre-Mod. 4303)			1	—	—		
	E.B6.81.6153	CABLE	ASSEMBLY	7R2	connection between first and second flame detectors (Mod. 4303)			1	—	—		
	E.B6.81.603	CABLE	ASSEMBLY	7R3	connection between second and third flame detectors (Pre-Mod. 4303)			1	—	—		
	E.B6.81.6155	CABLE	ASSEMBLY	7R3	connection between second and third flame detectors (Mod. 4303)			1	—	—		

(See Cable Chart for Breakdown Spares)

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.								
		1	2	3	4	5	6												
	E.B6.81.605	CABLE	ASSEMBLY	7R4,	connection	between	third	and	fourth	flame	detectors	(Pre-Mod. 4303)	1	—	—				
	E.B6.81.6157	CABLE	ASSEMBLY	7R4,	connection	between	third	and	fourth	flame	detectors	(Mod. 4303)	1	—	—				
	E.B6.81.615	CABLE	ASSEMBLY	7M3,	connection	between	out-	board	engine	rib	flame	detectors	(Pre-Mod. 4303)	1	—	—			
	E.B6.81.6163	CABLE	ASSEMBLY	7M3,	connection	between	out-	board	engine	rib	flame	detectors	(Mod. 4303)	1	—	—			
	E.B6.81.623/2	CABLE	ASSEMBLY	7M1,	from	plug	on	inboard	engine	rib	to	inboard	wing	flame	detector	(Pre-Mod. 4303)	1	—	—
	E.B6.81.6159	CABLE	ASSEMBLY	7M1,	from	plug	on	inboard	engine	rib	to	inboard	wing	flame	detector	(Mod. 4303)	1	—	—
	E.B6.81.627/2	CABLE	ASSEMBLY	7R1,	from	plug	at	inboard	engine	rib	to	flame	detector	(Pre-Mod. 4303)	1	—	—		
	E.B6.81.6151	CABLE	ASSEMBLY	7R1,	from	plug	at	inboard	engine	rib	to	flame	detector	(Mod. 4303)	1	—	—		
	E.B6.81.1707	CABLE	ASSEMBLY	P31,	from	generator	No. 1	to	leading	edge	diaphragm		1	—	—				
	E.B6.81.4705	CABLE	ASSEMBLY	EP,	from	generator	No. 1	(neg.)	to	earth			1	—	—				
	E.B7.81.1295	CABLE	ASSEMBLY	7A2,	from	terminal	block	to	undercarriage	"down"	micro	switch	(Pre-Mod. 5091)	1	—	—			
	E.A1.81.1213	CABLE	ASSEMBLY	7A2,	from	terminal	block	to	undercarriage	"down"	micro	switch	(Mod. 5091)	1	—	LM			
	E.B7.81.1325	CABLE	ASSEMBLY	7A3,	from	terminal	block	to	undercarriage	"down"	micro	switch	(Pre-Mod. 5091)	1	—	—			
	E.A1.81.1215	CABLE	ASSEMBLY	7A3,	from	terminal	block	to	undercarriage	"down"	micro	switch	(Mod. 5091)	1	—	LM			
	E.B7.81.1441/2	CABLE	ASSEMBLY	7C,	from	JB7	to	mixing	valve	actuator			1	—	—				
17239	E.B7.81.1443	CABLE	ASSEMBLY	7G,	from	JB7	to	mixing	valve	position	transmitter		1	—	C				
	E.B7.81.1445/2	CABLE	ASSEMBLY	7Q,	from	JB7	to	fire	extin-	guisher			1	—	—				
	E.B7.81.1447/2	CABLE	ASSEMBLY	7L,	from	JB7	to	gate	valve				1	—	—				
	E.B7.81.2949	CABLE	ASSEMBLY	7M2,	between	inboard	and	outboard	engine	rib	flame	detectors	(Pre-Mod. 4303)	1	—	—			
	E.B6.81.6161	CABLE	ASSEMBLY	7M2,	between	inboard	and	outboard	engine	rib	flame	detectors	(Mod. 4303)	1	—	—			
					(See Cable Chart for Breakdown Spares)														
5K/3689	WE.490	CABLE	END,	crown	type	2	—	C				
	E.B6.81.6149	CABLE	END	(Use	alternative	5X/9709513)	(Mod. 4303)						2	—	—				

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
6A/4333083	SMITH WAYMOUTH CA.12	CONNECTOR, fuel contents unit JB to transmitter						1	—	C	
6A/4333341	SMITH WAYMOUTH CA.62	CONNECTOR, fuel contents unit JB to tank unit terminal block at rib 2 (Mod. 4154 or 3749)						1	—	C	
6A/9491	SMITH WAYMOUTH CA.112	CONNECTOR, fuel contents unit JB to tank unit terminal block at rib 4 (Mod. 4154 or 3749)						1	—	C	
5K/4329498	AGS.1725/1	DISC, blanking						2	—	C	
5X/2790	Z.22634	GROMMET, dummy						2	—	C	
6A/1942	†	LEAD, extension for thermocouples						4	—	C	
6827	E.B6.81.519	LEAD, H.T. ignition						1	—	C	
6828	E.B7.81.1449	LEAD, H.T. ignition						1	—	C	
5K/4329335	AGS.1658/1	NUT, cable, gland						2	—	C	
5K/3457	EEAS.146/TC E.G4.81.261	SLEEVE						2	—	C	
		WIRING, BEHIND LEADING EDGE DIAPHRAGM, ASSEMBLY						—	—	—	
		Spares for:—									
5K/4894	HV.3974	SHROUD, Helvin						1	—	C	
5F/9434858	HV.3254	STRAP, Helvin						QR	—	C	
5F/9138823	NY.3255	STUD						5	—	C	
5F/2023	†	TENATUBE, 5 m/m x 1 m/m wall						QR	—	C	
7156	E.A3.81.1957 E.G4.81.263	WASHER, for earth connection						3	—	C	
		WIRING, ON LEADING EDGE, DIAPHRAGM, ASSEMBLY						—	—	—	
		Spares for:—									
13192	E.A9.81.1095	BLOCK, connector						2	LFB.82	C	
		Attaching parts for E.A9.81.1095:—									
28M/1278189	AGS.2001/B/1	Nut, 4 BA						4	—	C	
28S/1005622	A31/B28	Screw, 4 BA						4	—	C	
28W/9419474	SP.15/B	Washer						4	—	C	
	E.B6.81.10441/2	BOX, JUNCTION, NO. 7, ASSEMBLY (MOD. 3773)						1	—	—	
		Spares for:—									
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way						2	—	C	
		Attaching parts for CZ.23212/1:—									
28S/9130752	A43/B24	Screw, 4 BA						2	—	C	
	E.A1.81.583	BOX, bare						1	—	—	
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
5E/4185	†	CABLE, Uninyvin 16						QR	—	C	
5E/4187	†	CABLE, Uninyvin 12						QR	—	C	
	E.B7.81.365	COVER, ASSEMBLY						1	—	—	
		Spares for:—									
20457	EEAS.117/1	SCREW, cover						6	S.92	C	
1066	EEAS.28/2CU	WASHER						12	S.514	C	
1108	EEAS.42	WASHER, leather						6	—	C	
5X/6168	Z.23197	GASKET, size C						2	—	C	
5X/6169	Z.23198	GASKET, size D						2	—	C	
5X/6174	Z.50216	LINK, commoning, 8-way						1	—	C	
5X/6184	CZ.50360	PLUG, 12-way, size C (Pre-Mod. 3879)						1	—	C	
5X/7151	2CZ.111226	PLUG, 12-way, size C (Mod. 3879)						1	—	C	
5X/6091	CZ.28108	PLUG, 14-way, size C (Pre-Mod. 3879)						1	—	C	
5X/7152	2CZ.111227	PLUG, 14-way, size C (Mod. 3879)						1	—	C	
5X/6185	CZ.50361	PLUG, 26-way, size D						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5K/4346882	EEAS.146/16	SLEEVE	13	—	C	
5K/4346878	EEAS.146/12	SLEEVE	28	—	C	
5K/4346876	EEAS.146/6	SLEEVE	30	—	C	
5X/9525146	Z.49397	SLEEVE	1	—	C	
5X/1005131	Z.49428	SLEEVE	45	—	C	
5X/9450396	HC.490	TAG, QR	27	—	C	
		Attaching parts for E.B6.81.10441/2:—									
28D/9133011	A25/2C	Bolt, 2 BA	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28W/9419475	SP.15/C	Washer	4	—	C	
13193	E.A9.81.1099	FARLEAD, half	2	—	C	
		Attaching parts for E.A9.81.1099 per pair:—									
28D/9133011	A25/2C	Bolt, 2 BA	6	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	6	—	C	
28W/9419475	SP.15/C	Washer	6	—	C	
5K/4894	HY.3974	SHROUD, Helvin	2	—	C	
3417	EEAS.132/9	STRAP, c/w buckle	5	—	C	
		Attaching parts for EEAS.132/9:—									
28D/1007982	AS.1248/1C	Bolt, 2 BA	1	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	1	—	C	
	E.A3.81.1955	Piece, packing	1	—	—	
13194	E.A9.81.1097	STUD, connector	1	BS.369	C	
5F/9130207	†	TENATUBE, 5 m/m x 1 m/m wall	QR	—	C	
37A/1401	NB.25/2	UNIT, high energy ignition (Alternative)	1	—	B	
37A/1790	C.10TS/3	UNIT, high energy ignition (Alternative)	1	—	B	
		Attaching parts for NB.25/2 or C.10TS/3:—									
28D/1011247	A25/13E	Bolt, 1" BSF	3	—	C	
7156	E.A3.81.1957	WASHER	3	—	C	
13195	EEAS.28/23EP	WASHER	4	—	C	
	E.A1.81.27	WIRING, JET PIPE THERMOCOUPLES, ASSEMBLY						—	—	—	
		Spares for:—									
5CZ/1053794	†	BLOCK, terminal, type B, No. 1	4	—	C	
		Attaching parts for Ref. 5CZ/1053794:—									
28S/1011495	A33/A32	Screw, 6 BA	2	—	C	
29H/9437201	BROWN BROS. AV/W50 E.B7.81.1307	CLIP, thermocouple leads	3	—	C	
		WIRING, MAIN UNDERCARRIAGE, ASSEMBLY						—	—	—	
		Spares for:—									
5CZ/4350489	S.I.S.2057	BLOCK, terminal, type B, No. 1	1	—	C	
		Attaching parts for S.I.S.2057:—									
28M/1987493	AGS.2001/A/1	Nut, 6 BA	2	—	C	
28S/1200062	A33/A20	Screw, 6 BA	2	—	C	
5CW/9504373	BURGESS MS.5752	SWITCH, micro "up" lock (Mod. 3759) (Pre-Mod. 4080)	1	—	C	
5CW/6672	MS.5750	SWITCH, micro "down" lock (Mod. 3759) (Pre-Mod. 4080)	1	—	C	
5CW/1085884	HONEYWELL 1H.Y1	SWITCH, limit "up" and "down" locks (Mod. 4080)	2	—	B	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING**

Ref. No.	Part No.	Description	No. off	Mati Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
5CW/12244	DOWTY DN.1322Z Mk.2	SWITCH, limit "up" and "down" locks (Mod. 4449-S.O.O.) (Pre-Mods. 4958 and 4959)	2	—	B	
5CW/13598	DN.1322Z Mk.3	SWITCH, limit "up" lock (Mod. 4958) ...	1	—	B	
5CW/13598	DN.1322Z Mk.3	SWITCH, limit "down" lock (Mod. 4959) ...	1	—	B	
28D/1010029	A25/6B	Attaching parts for switches:— Bolt, 4 BA ...	1	—	C	
2029	E.A1.20.1245	Bolt, special, 2 BA ...	1	—	C	
28M/9403520	A27/CP	Nut, 2 BA ...	1	—	C	
29C/1206041	AGS.2035/B	Washer ...	1	—	C	
29C/1006946	AGS.2035/C	Washer ...	1	—	C	
	E.G4.81.2893	WIRING, AND ELECTRICAL EQUIPMENT, OUTBOARD OF RIB 8, ASSEMBLY (MOD. 4799)	—	—	—	
		Spares for:—				
5CZ/4335533	E.A1.81.1047	BLOCK, contact, assembly ...	1	—	C	
5X/9409328	CZ.50178	BLOCK, terminal, type J, 2-way ...	1	—	C	
5X/9010436	CZ.50179	BLOCK, terminal, type J, 3-way ...	1	—	C	
		Attaching parts for CZ.50178 and CZ.50179:—				
28S/9130752	A43/B24	Screw, 4 BA ...	2	—	C	
5CZ/4350489	†	BLOCK, terminal, type B, No. 1 ...	1	—	C	
		Attaching parts for Ref. 5CZ/4350489:—				
28S/1200062	A33/A20	Screw, 6 BA ...	2	—	C	
	SCD.79641	DETONATORS, WING TIP TANK, INSTALLATION (SRIM.3533) (MOD. 4799)	—	—	—	
		Spares for:—				
43096	E.G7.81.2945	BOX, filter, potted, assembly ...	1	—	C	
43097	E.G7.81.2983	BOX, filter, potted, assembly ...	1	—	C	
		Attaching parts for E.G7.81.2945 or E.G7.81.2983:—				
28D/1007971	A25/1/8	Bolt, 4 BA ...	2	—	C	
28W/9419465	SP.13/B	Washer ...	2	—	C	
43093	E.G7.81.2081	CONDUIT, DETONATOR, ASSEMBLY, FORWARD EXPLOSIVE BOLT	1	—	C	
43094	E.G7.81.2082	CONDUIT, DETONATOR, ASSEMBLY, REAR OUTBOARD EXPLOSIVE BOLT	1	—	C	
43095	E.G7.81.2819	CONDUIT, DETONATOR, ASSEMBLY, REAR INBOARD EXPLOSIVE BOLT	1	—	C	
		Spares for:—				
1578	E.A1.81.939	PLUG, detonator ...	1	—	C	
5F/	A.E.I.TWT/11	TUBING, P.T.F.E. ...	QR	—	—	
5K/1200724	SP.40/B8	GROMMET ...	4	—	C	
9757	E.A3.81.493	PLATE, base, resistance block, assembly (Pre-Mod. 4063)	1	—	C	
41770	E.A3.81.6307	PLATE, base, resistor, assembly (Mod. 4063) ...	1	—	C	
	or	(Preferred spare) (Mod. 4063)				
5385	E.H7.81.745	PLATE, base, resistance block, assembly (Pre-Mod. 4063)	1	—	C	
	E.A3.81.495	PLATE, base, resistor, assembly (Mod. 4063) ...	1	—	C	
41769	E.A3.81.6305	PLATE, base, resistor, assembly (Mod. 4063) ...	1	—	C	
	or	(Preferred spare) (Mod. 4063)				
10W/0241026	E.H7.81.743	RESISTOR, 15 ohms, 25 watt (Mod. 4063) ...	3	—	C	
5F/9454141	†	STRAP ...	QR	—	C	
5F/9138822	NY.18007A	STUD ...	QR	—	C	
5X/9450396	NY.3342	TAG ...	2	—	C	
5K/9436636	HC.490	TAG, terminal ...	5	—	C	
	†					

Pages ED.11 to ED.14 Not Issued

ELECTRICAL
ELECTRICAL EQUIPMENT IN PORT WING TIP

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.	
		1	2	3	4	5	6			M.R. L.M.		
	E.A1.81.19	ELECTRICAL EQUIPMENT, ASSEMBLY						—	—	—		
	5CZ/430	†	Spares for:—									
			BLOCK , terminal						1	—	B	
			Attaching parts for Ref. 5CZ/430:—									
28M/9403518	A27/AP		Nut, 6 BA						2	—	C	
28S/1200062	A33/A20		Screws, 6 BA						2	—	C	
28W/9416641	SP.47/A		Washer						2	—	C	
5L/9952511	†	FILAMENT , 24v., 60w.						1	—	B		
	E.A1.81.125		LAMP, NAVIGATION, ASSEMBLY						1	—	—	
			Consisting of:—									
	E.A1.81.127		BRACKET , assembly						1	L.72	—	
5E/4183	†	CABLE , Uninyvin 20						QR	—	C		
5L/9952431	†	FILAMENT , 28v., 24w.						1	—	B		
5K/9107065	†	SLEEVE						2	—	C		
5K/9107066	†	SLEEVE						2	—	C		
5CX/887	†	LAMP , type B						1	—	B		
28M/10326	AGS.2002/A/1		NUT , 6 BA						4	—	C	
5CX/3863	†	LAMP , taxiing, type A						1	—	B		
			Attaching parts for Ref. 5CX/3863:—									
28M/7002430	AGS.2002/E/1		Nut, 3/8" BSF						2	—	C	
	E.A3.20.3193		Washer						2	—	—	
28W/9419487	SP.16/E		Washer						2	—	C	
3510	EEAS.28/20ER		WASHER						2	L.72	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.G.4.81.2810	ELECTRICAL EQUIPMENT IN STARBOARD WING, ASSEMBLY (MOD. 4799)	—	—	—	
	E.G.4.81.248	CONDUITS, ACROSS ENGINE NACELLE, ASSEMBLY	—	—	—	
		Spares for:—				
	17036 E.A.3.81.2135	CLIP, conduit, securing	1	—	C	
	33290 E.B.6.20.1147	CLIP, conduit, securing	2	L.72	C	
	33291 E.B.6.20.1149	CLIP, conduit, securing	2	L.72	C	
	33292 E.B.6.20.1189	CLIP, conduit, securing	2	L.72	C	
	33293 E.B.6.20.1191	CLIP, conduit, securing	2	L.72	C	
		Attaching parts for E.A.3.81.2135, E.B.6.20.1147, E.B.6.20.1149, E.B.6.20.1189 and E.B.6.20.1191:—				
28D/1008149	A25/2B	Bolt, 4 BA (As required)	1	—	C	
28D/9419452	A25/3B	Bolt, 4 BA (As required)	1	—	C	
28D/9436920	A25/1C	Bolt, 2 BA (As required)	2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA (As required)	1	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA (As required)	2	—	C	
28W/9419402	SP.13/C	Washer (As required)	2	—	C	
28W/9419475	SP.15/C	Washer (As required)	2	—	C	
	33296 E.A.9.81.1075	Washer, square (As required)	1	—	C	
	17046 E.A.3.81.2171	CONDUIT	1	L.54	C	
	17047 E.A.3.81.2173	CONDUIT	1	L.54	C	
	33288 E.B.6.20.1049	CONDUIT	1	L.54	C	
	33294 E.B.6.20.1217	CONDUIT-END	1	L.54	C	
	17016 E.A.3.81.1595	SLEEVE, conduit, coupling	1	—	C	
	33295 E.B.6.20.1231	SLEEVE, conduit, coupling	1	L.54	C	
	E.G.4.81.250	CONDUITS, IN INNER WING, ASSEMBLY	—	—	—	
		Spares for:—				
	9747 E.A.1.81.108	CLIP, conduit, securing	1	—	C	
	9746 E.A.1.81.111	CLIP, conduit, securing	2	—	C	
	17091 E.A.3.81.2479	CLIP, conduit, securing	2	—	C	
	17092 E.A.3.81.2485	CLIP, conduit, securing	2	—	C	
	33289 E.B.6.20.1135	CLIP, conduit, securing	2	L.72	C	
		Attaching parts for E.A.1.81.108, E.A.1.81.111, E.A.3.81.2479, E.A.3.81.2485 and E.B.6.20.1135:—				
28D/1010658	A25/1B	Bolt, 4 BA (As required)	2	—	C	
28D/1008149	A25/2B	Bolt, 4 BA (As required)	1	—	C	
28D/9436920	A25/1C	Bolt, 2 BA (As required)	2	—	C	
28M/9403519	A27/BP	Nut, 4 BA (As required)	2	—	C	
28M/9433473	AGS.2002/C/1	Nut, 2 BA (As required)	2	—	C	
28W/9416642	SP.47/B	Washer (As required)	2	—	C	
28W/9419402	SP.13/C	Washer (As required)	2	—	C	
	17035 E.A.3.81.2133	Washer (As required)	1	—	C	
	17093 E.A.3.81.2487	CONDUIT	1	L.54	C	
	17094 E.A.3.81.2489	CONDUIT	1	L.54	C	
	17095 E.A.3.81.2491	CONDUIT	1	L.54	C	
	33287 E.B.6.20.1045	CONDUIT	1	L.54	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.18	CONDUIT ON RIB 7, INNER WING, ASSEMBLY						—	—	—	
		Spares for:—									
9739	E.A1.81.102	CLIP, conduit, securing						1	—	C	
9751	E.A1.81.110	CLIP, conduit, securing						5	—	C	
		Attaching parts for E.A1.81.102 and E.A1.81.110:—									
28D/9436920	A25/1C	Bolt, 2 BA (As required)						2	—	C	
28D/9133011	A25/2C	Bolt, 2 BA (As required)						1	—	C	
28M/9403520	A27/CP	Nut, 2 BA (As required)						2	—	C	
28W/9416643	SP.47/C	Washer (As required)						2	—	C	
9750	E.A1.81.17A	CONDUIT, 1½" o/d x 82" long, 20 SWG ...						1	L.54	C	
	E.G4.81.242	CONDUITS IN OUTER WING, ASSEMBLY ...						—	—	—	
		Spares for:—									
17037	E.A3.81.2137	CLIP, conduit, securing						7	—	C	
17038	E.A3.81.2139	CLIP, conduit, securing						2	—	C	
		Attaching parts for E.A3.81.2137 and E.A3.81.2139:—									
28D/1010658	A25/1B	Bolt, 4 BA (As required)						2	—	C	
28M/9403510	A27/BP	Nut, 4 BA (As required)						2	—	C	
28W/9419474	SP.15/B	Washer (As required)						2	—	C	
17031	E.A3.81.2125	CONDUIT						1	—	C	
17032	E.A3.81.2127	CONDUIT						1	—	C	
17043	E.A3.81.2149	CONDUIT						1	—	C	
	E.G4.81.243	CONDUIT (Make from Ref. 17030) ...						1	—	LM	
	E.G4.81.245	CONDUIT (Make from Ref. 17030) ...						1	—	LM	
	E.A3.81.1665	SLEEVE						2	—	—	
	E.A3.81.2129	SUPPORT , conduit at rib 7A						2	—	—	
		Attaching parts for E.A3.81.2129:—									
28D/1011023	A25/20C	Bolt, 2 BA						2	—	C	
	E.B7.81.604	ELECTRICAL EQUIPMENT IN ENGINE BAY, ASSEMBLY						—	—	—	
		Spares for:—									
	E.B7.81.1553	CLIP, pipe						1	—	—	
21902	E.B6.81.897	CONDUIT , ½" o/d x 22 SWG						1	L.62	C	
5K/4329335	AGS.1658/1	NUT, gland						2	—	C	
5X/6002	CZ.28180	PLUG, 2-way, size A (Pre-Mod. 3879) ...						2	—	C	
5X/7021	2CZ.84864	PLUG, 2-way, size A (Mod. 3879) ...						2	—	C	
5K/6007	CZ.28181	PLUG, 4-way, size A (Pre-Mod. 3879) ...						1	—	C	
5X/7022	2CZ.84865	PLUG, 4-way, size A (Mod. 3879) ...						1	—	C	
5X/4491456	CZ.23144Z	RING, clamp						6	—	C	
17242	E.B7.81.1523	RING, locking adaptor						2	L.64	C	
5K/1008392	AGS.1654/1	SLEEVE, outer						2	—	C	
	E.B7.81.2921	TUBE, Helsen plus (Make from Ref. 5F/2343) ...						1	—	LM	
	E.B7.81.2923	TUBE, Helsen plus (Make from Ref. 5F/2343) ...						1	—	LM	
	E.B7.81.2927	TUBE, Helsen plus (Make from Ref. 5F/2343) ...						1	—	LM	
7782	EEAS.21/1ER	WASHER, "D"						5	—	C	
	E.G4.81.238	ELECTRICAL EQUIPMENT IN INNER WING, REAR, ASSEMBLY						—	—	—	
		Spares for:—									
	E.B7.81.379	BOX, JUNCTION, NO. 10, ASSEMBLY ...						1	—	—	
		Spares for:—									
5X/1002695	CZ.23212/1	BLOCK, terminal, 20-way						2	—	C	
		Attaching parts for CZ.23212/1:—									
28S/1200033	A31/B24	Screw, 4 BA						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A1.81.583										
	E.87.81.383										
5X/6180	CZ.24650										
5X/6168	Z.23197										
5X/6169	Z.23198										
5X/6315	703/2/00256										
5X/3143	CZ.23144/D										
5K/4346877	EEAS.146/6										
28D/9133013	A25/5C										
28M/1278190	AGS.2001/C/1										
	AS.2811/5/045										
	AS.2811/5/049										
6A/4332834	†										
28D/9706373	A25/2A										
7186	E.A3.81.1473										
28D/1010142	A25/9B										
28M/1278189	AGS.2001/B/1										
28M/1006504	A27/BT										
28W/9419474	SP.15/B										
3416	EEAS.132/7										
28D/9128739	AS.1248/4B										
3420	EEAS.73										
3417	EEAS.132/9										
28D/1218386	AS.1248/3B										
28M/1278189	AGS.2001/B/1										
3420	EEAS.73										
5F/9434858	HV.3254										
5F/9138823	NY.3255										
	E.G4.81.2871										
	E.G5.81.665										
	E.G5.81.615										
5X/1002694	703/1/00238										
5X/9450403	†										
SE/9100020	†										
10H/0970055	CZ.51538										

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
6A/4333118	SMITH WAYMOUTH XA							1	—	C	
28D/1007975	AS.1242/1C							4	—	C	
6A/4333096	SMITH WAYMOUTH FAA E.A3.81.1537							1	—	A	
5X/1957037	703/1/00232							1	—	C	
28M/1278189	AGS.2001/B/1							2	—	C	
28S/1005622	A31/B28							2	—	C	
	E.A3.81.1539							1	—	—	
	E.A3.81.1543							1	—	—	
28S/9997545	A31/C16							4	—	C	
6734	EEAS.136							6	—	C	
	or										
5340-99- 4163724 17361	EEAS.136A										
	E.B6.81.381							2	—	C	
28D/1008149	A25/2B							4	—	C	
28W/9419474	SP.15/B							4	—	C	
5X/6488	CZ.23144/B							2	—	C	
5CY/4376390	S.I.S.3671							1	—	B	
28D/1008149	A25/2B							4	—	C	
37A/1401	NB.25/2							1	—	B	
37A/1790	C.10TS/3							1	—	B	
28D/1011247	A25/13E							3	—	C	
	E.G4.81.2841							—	—	—	
6078	E.A1.81.820/1							1	—	B	
	E.A1.81.1217							1	—	LM	
	E.A1.81.829/1							1	—	—	
	E.A1.81.880/1							1	—	—	
	E.A3.81.896/1							1	—	—	
9706	E.A3.81.1470							1	—	B	

(See Cable Chart for Breakdown Spares)

ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING

Ref. No.	Part No.							Description	No. off	Mati Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6					
9707	E.A3.81.1584							CABLE ASSEMBLY, 10B, from JB10 to wing tip terminal block (Pre-Mod. 4936)	1	—	B	
	E.A3.81.6719							CABLE ASSEMBLY, 10B, from JB10 to wing tip terminal block (Mod. 4936)	1	—	—	
9708	E.A3.81.1592							CABLE ASSEMBLY, 10B1, from wing tip terminal block to navigation light contact block	1	—	B	
	E.A3.81.1594							CABLE ASSEMBLY, 10B2, from terminal block to wing tip taxiing lamp connection	1	—	—	
	E.A3.81.1598							CABLE ASSEMBLY, 10B4, from terminal block to jettison tank detonator (Pre-Mod. 4063)	1	—	—	
	E.A3.81.6317							CABLE ASSEMBLY, 10B4, from terminal block to jettison tank detonator (Mod. 4063) (Pre-Mod. 4936)	1	—	—	
	E.A3.81.6725							CABLE ASSEMBLY, 10B4, from terminal block to jettison tank detonator (Mod. 4936)	1	—	—	
	E.A3.81.1600							CABLE ASSEMBLY, 10B5, from wing tip terminal block to jettison tank forward detonator terminal block (Pre-Mod. 4063)	1	—	—	
	E.A3.81.6315							CABLE ASSEMBLY, 10B5, from wing tip terminal block to jettison tank forward detonator terminal block (Mod. 4063) (Pre-Mod. 4936)	1	—	—	
	E.A3.81.6727							CABLE ASSEMBLY, 10B5, from wing tip terminal block to jettison tank forward detonator terminal block (Mod. 4936)	1	—	—	
	E.A6.81.565/2							CABLE ASSEMBLY, 10A, 10J, from JB10 to nitrogen and vent valve heater	1	—	—	
	E.G4.81.1763							CABLE ASSEMBLY, 10C, from JB10 to tank unit transmitter (Mod. 4154 or 3479)	1	—	—	
	E.A6.81.574							CABLE ASSEMBLY, 10G, from JB10 to fuel pump suppressor	1	—	—	
	E.A6.81.575/2							CABLE ASSEMBLY, 10G1, from suppressor to fuel pump	1	—	—	
	E.A6.81.576/2							CABLE ASSEMBLY, 10H, from JB10 to engine fuel cock	1	—	—	
	E.A6.81.577/2							CABLE ASSEMBLY, 10K, from JB10 to main tank fuel cock	1	—	—	
	E.A9.81.5439/2							CABLE ASSEMBLY, 8F, 8D, 8P, connection from JB7 to fire extinguisher bottles (Mod. 3773)	1	—	—	
	E.B6.81.515/2							CABLE ASSEMBLY, 10L, from JB10 to outboard high energy ignition unit	1	—	—	
41643	E.B6.81.525/2							CABLE ASSEMBLY, 8N1, from inboard engine rib plug to cowl anti-icing actuator (Pre-Mod. 5091)	1	—	C	
	E.B6.81.6381							CABLE ASSEMBLY, 8N1, from inboard engine rib plug to cowl anti-icing actuator (Mod. 5091)	1	—	LM	
	E.B6.81.529							CABLE ASSEMBLY, E8, earth connection for JB8	1	—	—	
9724	E.B6.81.533							CABLE ASSEMBLY, E10, earth connection for JB10	1	—	C	
	E.B6.81.535							CABLE ASSEMBLY, 10D from JB10 to air brake jack	1	—	—	
	E.B6.81.539/2							CABLE ASSEMBLY, S10, from JB10 to fuselage connection	1	—	—	
	E.B6.81.607							CABLE ASSEMBLY, 8R2, connection between first and second flame detector (Pre-Mod. 4303)	1	—	—	
(See Cable Chart for Breakdown Spares)												

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.81.6167	CABLE	ASSEMBLY	8R2	connection	between first and second flame detector (Mod. 4303)	1	—	—		
	E.B6.81.609	CABLE	ASSEMBLY	8R3	connection	between second and third flame detectors (Pre-Mod. 4303)	1	—	—		
	E.B6.81.6169	CABLE	ASSEMBLY	8R3	connection	between second and third flame detectors (Mod. 4303)	1	—	—		
	E.B6.81.611	CABLE	ASSEMBLY	8R4	connection	between third and fourth flame detectors (Pre-Mod. 4303)	1	—	—		
	E.B6.81.6171	CABLE	ASSEMBLY	8R4	connection	between third and fourth flame detectors (Mod. 4303)	1	—	—		
21895	E.B6.81.617	CABLE	ASSEMBLY	8M2	between inboard engine rib	flame detectors (Pre-Mod. 4303)	1	—	C		
	E.B6.81.6175	CABLE	ASSEMBLY	8M2	between inboard engine rib	flame detectors (Mod. 4303)	1	—	—		
	E.B6.81.621	CABLE	ASSEMBLY	8M4	between outboard engine rib	flame detectors (Pre-Mod. 4303)	1	—	—		
	E.B6.81.6179	CABLE	ASSEMBLY	8M4	between outboard engine rib	flame detectors (Mod. 4303)	1	—	—		
	E.B6.81.625/2	CABLE	ASSEMBLY	8M1	from plug on inboard engine rib	to inboard wing flame detector (Pre-Mod. 4303)	1	—	—		
	E.B6.81.6173	CABLE	ASSEMBLY	8M1	from plug on inboard engine rib	to inboard wing flame detector (Mod. 4303)	1	—	—		
	E.B6.81.629/2	CABLE	ASSEMBLY	8R1	from plug at inboard engine rib	to flame detector (Pre-Mod. 4303)	1	—	—		
	E.B6.81.6165	CABLE	ASSEMBLY	8R1	from plug at inboard engine rib	to flame detector (Mod. 4303)	1	—	—		
	E.B6.81.1705	CABLE	ASSEMBLY	S32	from generator No. 2	to leading edge diaphragm	1	—	—		
	E.B6.81.4129	CABLE	ASSEMBLY	8B	from JB8	to G45B camera	1	—	—		
	E.B6.81.4707	CABLE	ASSEMBLY	ES	from generator No. 2	(Neg.) to earth	1	—	—		
	E.B7.81.1327	CABLE	ASSEMBLY	8A2	from terminal block	to undercarriage "down" micro switch (Pre-Mod. 5091)	1	—	—		
	E.A1.81.1219	CABLE	ASSEMBLY	8A2	from terminal block	to undercarriage "down" micro switch (Mod. 5091)	1	—	LM		
	E.B7.81.1329	CABLE	ASSEMBLY	8A3	from terminal block	to undercarriage "down" micro switch (Pre-Mod. 5091)	1	—	—		
	E.A1.81.1221	CABLE	ASSEMBLY	8A3	from terminal block	to undercarriage "down" micro switch (Mod. 5091)	1	—	LM		
	E.B7.81.1331	CABLE	ASSEMBLY	8A5	from terminal block	to oleo switch (Pre-Mod. 5091)	1	—	—		
	E.A1.81.1223	CABLE	ASSEMBLY	8A5	from terminal block	to oleo switch (Mod. 5091)	1	—	LM		
	E.B7.81.1453	CABLE	ASSEMBLY	8A	from JB8	to undercarriage wing terminal block	1	—	—		
	E.B7.81.1455/2	CABLE	ASSEMBLY	8Q	from JB8	to fire extinguisher	1	—	—		

(See Cable Chart for Breakdown Spares)

ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING

Ref. No.	Part No.	Description						No. off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
7156	E.A3.81.1957	WASHER, earth						3	Alumin.	C	
13195	EEAS.28/23EP	WASHER, stud connector						4	—	C	
	E.A1.81.28	WIRING, JET PIPE THERMOCOUPLE, ASSEMBLY						—	—	—	
		Spares for:—									
5CZ/1053794	†	BLOCK, terminal, type B, No. 1						4	—	C	
		Attaching parts for Ref. 5CZ/1053794:—									
28S/1011495	A33/A32	Screw, 6 BA						2	—	C	
	BROWN BROS.										
29H/9437201	AV/W50	CLIP, thermocouple leads						3	—	C	
	E.B7.81.1308	WIRING, MAIN UNDERCARRIAGE, ASSEMBLY ...						—	—	—	
		Spares for:—									
5CZ/1053794	†	BLOCK, terminal, type B, No. 1, 2-way						2	—	C	
5CZ/4350489	†	BLOCK, terminal, type B, No. 1, 5-way						1	—	C	
		Attaching parts for 5CZ/1053794 and 5CZ/4350489:—									
28M/1987493	AGS.2001/A/1	Nut, 6 BA						2	—	C	
28S/1200062	A33/A20	Screw, 6 BA						2	—	C	
	BURGESS										
5CW/9504373	MS.5752	SWITCH, micro "up" lock and oleo (Mod. 3759) (Pre-Mod. 4080)						2	—	C	
5CW/6672	MS.5750	SWITCH, micro "down" lock (Mod. 3759) (Pre-Mod. 4080)						1	—	C	
	HONEYWELL										
5CW/1085884	1H.Y1	SWITCH, limit "up" and "down" lock and oleo (Mod. 4080)						3	—	B	
	DOWTY										
5CW/12444	DN.1322Z Mk.2	SWITCH, limit "up" and "down" lock and oleo (Mod. 4449-S.O.O.) (Pre-Mods. 4958 and 4959)						3	—	B	
5CW/13598	DN.1322Z Mk.3	SWITCH, limit "up" lock (Mod. 4958)						1	—	B	
5CW/13598	DN.1322Z Mk.3	SWITCH, limit "down" lock and oleo (Mod. 4959)						2	—	B	
		Attaching parts for switches:—									
28D/1010029	A25/6B	Bolt, 4 BA						1	—	C	
2029	E.A1.20.1245	Bolt, special, 2 BA						1	—	C	
28M/9403520	A27/CP	Nut, 2 BA						1	—	C	
29C/1206041	AGS.2035/B	Washer						1	—	C	
29C/1006946	AGS.2035/C	Washer						1	—	C	
	E.G4.81.2894	WIRING, AND ELECTRICAL EQUIPMENT OUT-BOARD OF RIB 8, ASSEMBLY (MOD. 4799)						—	—	—	
		Spares for:—									
5CZ/4335533	E.A1.81.1047	BLOCK, contact, assembly						1	—	C	
5X/9409328	CZ.50178	BLOCK, terminal, type J, 2-way						1	—	C	
5X/9010436	CZ.50179	BLOCK, terminal, type J, 3-way						1	—	C	
		Attaching parts for CZ.50178 and CZ.50179:—									
28S/9130752	A43/B24	Screw, 4 BA						2	—	C	
5CZ/4350489	†	BLOCK, terminal, type B, No. 1						1	—	C	
		Attaching parts for Ref. 5CZ/4350489:—									
28S/1200062	A33/A20	Screw, 6 BA						2	—	C	
	9530	CLIP, socket, support						1	—	C	
		Attaching parts for E.A3.81.2653:—									
28D/1272940	A61/2C	Bolt, 2 BA						2	—	C	

**ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING**

Ref. No.	Part No.	Description	No. off	Matl Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	SCD.79641	DETONATORS, WING TIP TANK, INSTALLATION (SRIM.3533) (MOD. 4799)	—	—	—	
		Spares for:—				
43096	E.G7.81.2945	BOX, filter, potted, assembly	1	—	C	
43097	E.G7.81.2983	BOX, filter, potted, assembly	1	—	C	
		Attaching parts for E.G7.81.2945 or E.G7.81.2983:—				
28D/1007971	A25/1/2B	Bolt, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
43093	E.G7.81.2081	CONDUIT, DETONATOR, ASSEMBLY, FORWARD EXPLOSIVE BOLT	1	—	C	
43094	E.G7.81.2082	CONDUIT, DETONATOR, ASSEMBLY, REAR OUTBOARD EXPLOSIVE BOLT	1	—	C	
43095	E.G7.81.2819	CONDUIT, DETONATOR, ASSEMBLY, REAR INBOARD EXPLOSIVE BOLT	1	—	C	
		Spares for:—				
1578	E.A1.81.939	PLUG, detonator	1	—	C	
5F/	A.E.I. TWT/11	TUBING, P.T.F.E.	QR	—	—	
5K/1200724	SP.40/B8	GROMMET	4	—	C	
9757	E.A3.81.493	PLATE, base, resistance block, assembly (Pre-Mod. 4063)	1	—	C	
41770	E.A3.81.6307	PLATE, base, resistor, assembly (Mod. 4063) ...	1	—	C	
	or	(Preferred spare) (Mod. 4063)				
5385	E.H7.81.745	PLATE, base, resistor block, assembly (Pre-Mod. 4063)	1	—	C	
41769	E.A3.81.6305	PLATE, base, resistor, assembly (Mod. 4063) ...	1	—	C	
	or	(Preferred spare) (Mod. 4063)				
10W/0241026	P.2001/F/15	RESISTOR, 15 ohms, 25 watt (Mod. 4063) ...	3	—	C	
5F/9454141	NY.18007A	STRAP	QR	—	C	
5F/9138822	NY.3342	STUD	QR	—	C	
5X/9450396	HC.490	TAG	2	—	C	

Pages EE.13 to EE.16 Not Issued

ELECTRICAL
ELECTRICAL EQUIPMENT IN STARBOARD WING TIP

Ref. No.	Part No.	Description 1 2 3 4 5 6	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.A1.81.20	ELECTRICAL EQUIPMENT, ASSEMBLY	—	—	—	
		Spares for:—				
5CZ/430	†	BLOCK , terminal	1	—	B	
		Attaching parts for Ref. 5CZ/430:—				
28M/9403518	A27/AP	Nut, 6 BA	2	—	C	
28S/1200062	A33/A20	Screw, 6 BA	2	—	C	
28W/9416641	SP.47/A	Washer	2	—	C	
5L/9952511	†	FILAMENT , 24V., 60W.	1	—	B	
	E.A1.81.126	LAMP, NAVIGATION, ASSEMBLY	1	—	—	
		Consisting of:—				
	E.A1.81.127	BRACKET , assembly	1	L.72	—	
5E/4183	†	CABLE , Uninyvin 20	QR	—	C	
5L/9952431	†	FILAMENT , 28V., 24W.	1	—	B	
5K/9107065	†	SLEEVE	2	—	C	
5K/9107066	†	SLEEVE	2	—	C	
5CX/889	†	LAMP , type B	1	—	B	
28M/10326	AGS.2002/A/1	NUT , 6 BA	4	—	C	
5CX/3863	†	LAMP , taxying, type A	1	—	B	
		Attaching parts for Ref. 5CX/3863:—				
28M/7002430	AGS.2002/E/1	Nut, 1/2" BSF	2	—	C	
	E.A3.20.3193	Washer	2	—	—	
28W/9419487	SP.16/E	Washer	2	—	C	
3510	EEAS.28/20ER	WASHER	2	L.72	C	

ELECTRICAL

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
SUMMARY OF STOCK ITEMS USED ON ELECTRICAL EQUIPMENT											
28D/1008147	A25/1A	Bolt,	6	BA		C	
28D/9706373	A25/2A	Bolt,	6	BA		C	
28D/1007971	A25/1B	Bolt,	4	BA		C	
28D/1010658	A25/1B	Bolt,	4	BA		C	
28D/1008149	A25/2B	Bolt,	4	BA		C	
28D/9419452	A25/3B	Bolt,	4	BA		C	
28D/1011006	A25/5B	Bolt,	4	BA		C	
28D/1010029	A25/6B	Bolt,	4	BA		C	
28D/1010142	A25/9B	Bolt,	4	BA		C	
28D/9435711	A25/10B	Bolt,	4	BA		C	
28D/1011013	A25/13B	Bolt,	4	BA		C	
28D/1212276	A25/15B	Bolt,	4	BA		C	
28D/9138768	A25/1C	Bolt,	2	BA		C	
28D/9436920	A25/1C	Bolt,	2	BA		C	
28D/9133011	A25/2C	Bolt,	2	BA		C	
28D/9133012	A25/3C	Bolt,	2	BA		C	
28D/1200119	A25/4C	Bolt,	2	BA		C	
28D/9133013	A25/5C	Bolt,	2	BA		C	
28D/7002428	A25/6C	Bolt,	2	BA		C	
28D/1010030	A25/7C	Bolt,	2	BA		C	
28D/1011021	A25/16C	Bolt,	2	BA		C	
28D/1011023	A25/20C	Bolt,	2	BA		C	
28D/1011025	A25/24C	Bolt,	2	BA		C	
28D/1017157	A25/25C	Bolt,	2	BA		C	
28D/1212399	A25/28C	Bolt,	2	BA		C	
28D/1212401	A25/30C	Bolt,	2	BA		C	
28D/1212405	A25/36C	Bolt,	2	BA		C	
28D/1011029	A25/1E	Bolt,	1/2"	BSF		C	
28D/1011030	A25/2E	Bolt,	1/2"	BSF		C	
28D/1011238	A25/3E	Bolt,	1/2"	BSF		C	
28D/1008151	A25/4E	Bolt,	1/2"	BSF		C	
28D/1011240	A25/5E	Bolt,	1/2"	BSF		C	
28D/1008145	A25/6E	Bolt,	1/2"	BSF		C	
28D/1011242	A25/7E	Bolt,	1/2"	BSF		C	
28D/1010031	A25/8E	Bolt,	1/2"	BSF		C	
28D/1011247	A25/13E	Bolt,	1/2"	BSF		C	
28D/9706306	A25/17E	Bolt,	1/2"	BSF		C	
28D/1011255	A25/3G	Bolt,	1/8"	BSF		C	
28D/1202771	A25/4G	Bolt,	1/8"	BSF		C	
28D/1215686	A59/7E	Bolt,	1/2"	BSF		C	
28D/1212940	A61/2C	Bolt,	2	BA		C	
28D/9709461	AS.1242/3C	Bolt,	2	BA		C	
28D/1013173	AS.1242/10C	Bolt,	2	BA		C	
28D/1202334	AS.1242/3E	Bolt,	1/2"	BSF		C	
28D/1212825	AS.1242/4E	Bolt,	1/2"	BSF		C	
28D/1212747	AS.1242/6G	Bolt,	1/8"	BSF		C	
28D/1212749	AS.1242/9G	Bolt,	1/8"	BSF		C	
28D/1007979	AS.1246/1B	Bolt,	4	BA		C	
28D/1214867	AS.1246/5B	Bolt,	4	BA		C	
28D/1214876	AS.1246/14B	Bolt,	4	BA		C	
28D/1214884	AS.1246/22B	Bolt,	4	BA		C	
28D/9140202	AS.1246/1C	Bolt,	2	BA		C	
28D/9140203	AS.1246/3C	Bolt,	2	BA		C	

ELECTRICAL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
28D/9137410	AS.1246/10C	Bolt, 2 BA					
28D/1215327	AS.1246/1E	Bolt, 1" BSF					
28D/9128739	AS.1248/1B	Bolt, 4 BA					
28D/8337	AS.1248/1B	Bolt, 4 BA					
28D/1218385	AS.1248/2B	Bolt, 4 BA					
28D/1218386	AS.1248/3B	Bolt, 4 BA					
28D/1007981	AS.1248/1C	Bolt, 2 BA					
28D/1007982	AS.1248/1C	Bolt, 2 BA					
28D/1213262	AS.4565/10B	Bolt, 4 BA					
28D/1215164	AS.4565/7C	Bolt, 2 BA					
28D/1213047	AS.4566/5B	Bolt, 4 BA					
28D/1213049	AS.4566/9B	Bolt, 4 BA					
28M/9455059	A14/EB	Nut, 1" BSF					
28M/5238	A14/GB	Nut, 1/2" BSF					
28M/9403518	A27/AP	Nut, 6 BA					
28M/9403519	A27/BP	Nut, 4 BA					
28M/1006504	A27/BT	Nut, 4 BA					
28M/9403520	A27/CP	Nut, 2 BA					
28M/1011475	A27/EP	Nut, 1" BSF					
28M/1011467	A27/ES	Nut, 1" BSF					
28M/1007403	A27/ET	Nut, 1/2" BSF					
28M/10286	AGS.2001/A/1	Nut, 6 BA					
28M/1278189	AGS.2001/B/1	Nut, 4 BA					
28M/1956039	AGS.2001/B/3	Nut, 4 BA					
28M/10274	AGS.2001/B/4	Nut, 4 BA					
28M/1278190	AGS.2001/C/1	Nut, 2 BA					
28M/1201610	AGS.2001/E/1/77	Nut, 1/2" BSF					
28M/10276	AGS.2001/E/4	Nut, 1" BSF					
28M/10291	AGS.2001/G/1	Nut, 1/2" BSF					
28M/10278	AGS.2001/J/4	Nut, 1" BSF					
28M/10326	AGS.2002/A/1	Nut, 6 BA					
28M/1086618	AGS.2002/B/1	Nut, 4 BA					
28M/9433473	AGS.2002/C/1	Nut, 2 BA					
28M/7002430	AGS.2002/E/1	Nut, 1/2" BSF					
28M/12344	AGS.2002/E/4	Nut, 1" BSF					
28M/10312	AGS.2002/G/4	Nut, 1/2" BSF					
28S/9436892	A31/A8	Screw, 6 BA					
28S/1200045	A31/A40	Screw, 6 BA					
28S/1200044	A31/A14	Screw, 6 BA					
28S/9419437	A31/A16	Screw, 6 BA					
28S/9435712	A31/B8	Screw, 4 BA					
28S/1201448	A31/B10	Screw, 4 BA					
28S/9419435	A31/B12	Screw, 4 BA					
28S/9419453	A31/B14	Screw, 4 BA					
28S/1200034	A31/B16	Screw, 4 BA					
28S/1200040	A31/B20	Screw, 4 BA					
28S/1200033	A31/B24	Screw, 4 BA					
28S/1005622	A31/B28	Screw, 4 BA					
28S/1200039	A31/B32	Screw, 4 BA					
28S/9140642	A31/B36	Screw, 4 BA					
28S/9131095	A31/C14	Screw, 2 BA					
28S/9997545	A31/C16	Screw, 2 BA					
28S/9435713	A31/C20	Screw, 2 BA					
28S/1200047	A31/C24	Screw, 2 BA					
28S/1004979	A32/A10	Screw, 6 BA					

ELECTRICAL

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
28S/1006948	A32/A12	Screw	6	BA		C	
28S/9995324	A32/A16	Screw	6	BA		C	
28S/1011484	A32/A20	Screw	6	BA		C	
28S/1009986	A32/B6	Screw	4	BA		C	
28S/1212450	A32/B10	Screw	4	BA		C	
28S/9992525	A32/B12	Screw	4	BA		C	
28S/1008327	A32/B14	Screw	4	BA		C	
28S/9992522	A32/B16	Screw	4	BA		C	
28S/1016732	A32/B18	Screw	4	BA		C	
28S/9995376	A32/B20	Screw	4	BA		C	
28S/1007817	A32/B24	Screw	4	BA		C	
28S/1011488	A32/B28	Screw	4	BA		C	
28S/5694	A32/B40	Screw	4	BA		C	
28S/15036	A32/B44	Screw	4	BA		C	
28S/1214216	A32/C6	Screw	2	BA		C	
28S/1011489	A32/C8	Screw	2	BA		C	
28S/1011490	A32/C16	Screw	2	BA		C	
28S/9992533	A32/C20	Screw	2	BA		C	
28S/1011492	A32/C28	Screw	2	BA		C	
28S/1200055	A33/A6	Screw	6	BA		C	
28S/1200061	A33/A18	Screw	6	BA		C	
28S/1200062	A33/A20	Screw	6	BA		C	
28S/9992531	A33/A24	Screw	6	BA		C	
28S/9133018	A33/A28	Screw	6	BA		C	
28S/1011495	A33/A32	Screw	6	BA		C	
28S/1007469	A33/B14	Screw	4	BA		C	
28S/9435715	A33/B16	Screw	4	BA		C	
28S/1200066	A33/B20	Screw	4	BA		C	
28S/1200065	A33/B28	Screw	4	BA		C	
28S/9435717	A33/C20	Screw	2	BA		C	
28S/9440345	A40/B8	Screw	4	BA		C	
28S/1212705	A40/B10	Screw	4	BA		C	
28S/1212707	A40/B14	Screw	4	BA		C	
28S/1008075	A41/B16	Screw	4	BA		C	
28S/1213960	A41/B20	Screw	4	BA		C	
28S/9130752	A43/B24	Screw	4	BA		C	
28S/9446305	A43/B28	Screw	4	BA		C	
28S/9464989	A43/C28	Screw	2	BA		C	
28S/1012364	A45/B32	Screw	4	BA		C	
28S/1008070	A55/A4	Screw	6	BA		C	
28S/1213933	4000/4/1/2"	Screw	self tapping		C	
28S/1213935	4000/6/1/2"	Screw	self tapping		C	
28S/1018882	4101/6/1/2"	Screw	self tapping		C	
28S/1012290	4101/6/1/2"	Screw	self tapping		C	
28S/9436890	4101/8/1/2"	Screw	self tapping		C	
28S/	4103/8/1"	Screw	self tapping		C	
28W/9419401	SP.10/B	Washer		C	
28W/9419454	SP.10/C	Washer		C	
28W/9418920	SP.10/E	Washer		C	
28W/9419464	SP.13/A	Washer		C	
28W/9419465	SP.13/B	Washer		C	
28W/9419402	SP.13/C	Washer		C	
28W/9418921	SP.13/E	Washer		C	
28W/9419403	SP.13/G	Washer		C	
28W/9419473	SP.15/A	Washer		C	

ELECTRICAL

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
28W/9419474	SP.15/B	Washer				C	
28W/9419475	SP.15/C	Washer				C	
28W/9419405	SP.15/E	Washer				C	
28W/9419476	SP.15/G	Washer				C	
28W/9419485	SP.16/A	Washer				C	
28W/9419486	SP.16/B	Washer				C	
28W/9419404	SP.16/C	Washer				C	
28W/9140967	SP.18/B	Washer				C	
28W/9437455	SP.25/B	Washer				C	
28W/9480389	SP.26/B	Washer				C	
28W/9419447	SP.41/C	Washer				C	
28W/9416641	SP.47/A	Washer				C	
28W/9416642	SP.47/B	Washer				C	
28W/9416643	SP.47/C	Washer				C	
28W/9416644	SP.47/E	Washer				C	
28W/9128920	SP.56/G	Washer				C	
28W/9475535	AGS.162/A	Washer				C	
28W/1010155	AGS.162/B	Washer				C	
28W/1007983	AGS.162/C	Washer				C	
28W/6315	AGS.585/B	Washer				C	
28W/9467259	AGS.586/B	Washer				C	
28W/1007776	AGS.2034/B	Washer				C	
28W/1006940	AGS.2034/C	Washer				C	
28W/9419185	AGS.2035/A	Washer				C	
28W/1206041	AGS.2035/B	Washer				C	
28W/1206065	AGS.2036/B	Washer				C	
28W/1200328	AGS.2037/B	Washer				C	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

