

## FUSELAGE

## FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R —	NOSE FUSELAGE ASSEMBLY (EG9.00.5) (Pre-Mod 5349)	—	—	1/1
R EG9.00.285	NOSE FUSELAGE ASSEMBLY (Spares condition based on EG9.00.5 to LTF standard) (Mod 5349) Spares for:-	1	—	
EG9.75.5	. AIR VENTILATED SUIT SYSTEM (See page NA1)	—	—	
—	. BLAST COOLING FOR INVERTER TYPE 103A AND 108A ASSEMBLY (EG9.74.1) Spares for:-	—	—	1/2
AGS605/3 or SP91L	. . CLIP, hose	2	—	1/3
EG9.74.3	. . CLIP, hose	2	—	1/3
	. . INTAKE, air assembly	1	—	1/4
	Attaching parts for EG9.74.3:-			
AS1248/1C	. . Bolt, 2 BA mushroom head	9	—	1/5
AGS2001C1	. . Nut, stiff, 2 BA	9	—	1/6
SP13C	. . Washer, 2 BA plain	9	—	1/7
EG9.74.13 BELLS ASBESTOS	. . PIPE, inverter cooling	1	L.54 or L.59	1/8
BAS161/1/2/36/12 BELLS ASBESTOS	. . SLEEVE, connecting	1	—	1/9
BAS184-2 EG9.75.3	. . TAPE, bedding	QR	—	1/10
	. CABIN PRESSURE SYSTEM (See page NB1)	—	—	
EG9.74.19	. COLD AIR TO PILOT, ASSEMBLY (See page NF1)	—	—	
—	. COMPASS G4B INSTALLATION (EG9.80.727) Spares for:-	—	—	1/11
—	. . PANEL CONTROL G4B INSTALLATION (EA3.80.1327) Spares for:-	—	—	1/12
R 15402-0	. . . PANEL, control type A Attaching parts for 15402-0:-	1	—	1/13
A32C16	. . . Screw, 2 BA round head	4	—	1/14
EA1.47.5	. CONTROLS ENGINE ASSEMBLY (See page DC1)	—	—	
EA3.45.3	. CONTROLS FLYING ASSEMBLY (See page DH1)	—	—	
EG9.76.1	. DEMISTING SYSTEM ASSEMBLY (See page NG1)	—	—	
EG9.81.5	. ELECTRICAL EQUIPMENT IN FRONT FUSELAGE (See page EA1)	—	—	
EG9.80.1	. EQUIPMENT IN PRESSURE CABIN (See page F1)	—	—	

FUSELAGE  
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.	
					1
—	GEAR EMERGENCY RELEASE MECHANISM BOMB DOORS AND UNDERCARRIAGE ASSEMBLY (EA1.45.749) Spares for:-	—	—	2/1	
—	BRACKETS AND HANDLE AT FRAMES 1 AND 2 ASSEMBLY (EA1.45.815) Spares for:-	—	—	2/2	
EA1.45.1041	BRACKET, bottom frame 1	1	L.72	2/3	
EA2.45.201	BRACKET, top frame 1	1	L.72	2/4	
EA1.45.831	BRACKET, bottom frame 2	1	L.72	2/5	
EA1.45.829	BRACKET, top frame 2	1	L.72	2/6	
	Attaching parts for EA1.45.1041, EA2.45.201, EA1.45.831 and EA1.45.829:-				
A25/1C	Bolt, 2 BA hex head	3	—	2/7	
AGS2001C1	Nut, stiff, 2 BA	3	—	2/8	
SP15C	Washer, 2 BA plain	3	—	2/9	
EA3.45.633	HANDLE, operating assembly (Mod 5220) Attaching parts for EA3.45.633:-	1	L.72	2/10	
A25/1C	Bolt, 2 BA hex head	4	—	2/11	
SP15C	Washer, 2 BA plain	4	—	2/12	
AS107 or AS1151	PULLEY, shrouded	2	—	2/13	
	PULLEY shrouded (Alternative to AS.107) Attaching parts for AS107:-	2	—		
A25/8E	Bolt, 1/4" BSF hex head	1	—	2/14	
AGS2001E1	Nut stiff, 1/4" BSF	1	—	2/15	
SP16E	Washer, 1/4" BSF plain	1	—	2/16	
R 5E/5253563	WIRE, copper enamelled	QR	—		
—	BRACKETS AND LEVER AT FRAME 4 ASSEMBLY (EA1.45.813) Spares for:-	—	—	2/17	
EA1.45.875	BRACKET, bottom inboard	1	L.72	2/18	
EA1.45.877	BRACKET, bottom outboard	1	L.72	2/19	
EA1.45.871	BRACKET, top inboard	1	L.72	2/20	
EA1.45.873	BRACKET, top outboard	1	L.72	2/21	
	Attaching parts for EA1.45.875, EA1.45.877, EA1.45.871 and EA1.45.873:-				
AS1242/1C	Bolt, 2 BA c'sk head (as required)	1	—	2/22	
A25/1C	Bolt, 2 BA hex head (as required)	11	—	2/23	
AGS2001C1	Nut, stiff 2 BA (as required)	12	—	2/24	
SP15C	Washer, 2 BA plain (as required)	12	—	2/25	
EA1.45.883	FAIRLEAD Attaching parts for EA1.45.883:-	1	LFS.21	2/26	
A25/6C	Bolt, 2 BA hex head	2	—	2/27	
AGS2001C1	Nut, stiff, 2 BA	2	—	2/28	
EA3.45.295	LEVER, assembly Attaching parts for EA3.45.295:-	1	—	2/29	
A25/3E	Bolt, 1/4" BSF hex head	1	—	2/30	
AGS2001E1	Nut, stiff 1/4" BSF	1	—	2/31	
SP16E	Washer, 1/4" BSF plain	1	—	2/32	

AP101B-0418-3A

FUSELAGE  
FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EEAS15/75/150/ ER	. . .	PLATE, link, lower	2	L72	2/33
EA1.45/909	. . .	PLATE, link, upper Attaching parts for EA1.45.909:—	2	—	2/34
AGS899/2	. . .	Collar	1	—	2/35
SP4Y/B14	. . .	Pin, shackle	1	—	2/36
EA1.45.1317	. . .	Tube, distance	2	—	2/37
AS1151	. . .	PULLEY, shrouded (Alternative to AS107) Attaching parts for AS1151:—	2	—	2/38
A25/8E	. . .	Bolt, 1/4" BSF hex. head	1	—	2/39
A25/9E	. . .	Bolt, 1/4" BSF hex. head	1	—	2/40
AGS2001/E/1	. . .	Nut, stiff, 1/4" BSF	1	—	2/41
SP16/E	. . .	Washer, 1/4" BSF plain	1	—	2/42
5E/5253563	. . .	WIRE, copper, enamelled (SAS4746)	QR	—	—
EA3.45.275	. . .	CABLES, BOMB AND UNDERCARRIAGE, ASSEMBLY Spares for:—	1	—	2/43
EA2.45.413	. . .	BARREL, pressure seal	1	—	2/44
AGS2030/147	. . .	CIRCLIP, internal, 3/4" bore	1	—	2/45
EA1.45.1129	. . .	ROLLER, aft end bomb door	1	—	2/46
SP8Y/13	. . .	ROLLER	3	—	2/47
EA1.45.889	. . .	WASHER, felt, pressure seal	7	DTD590 R64 Felt	2/48
EA1.45.891	. . .	WASHER, retaining, pressure seal	1	LFS21	2/49
EA1.45.275A	. . .	WIRE, flexible steel, bomb door	1	6WT/4	2/50
EA1.45.275B	. . .	WIRE, flexible steel, undercarriage	1	6WT/4	2/51
EA1.45.883	. . .	FAIRLEAD, frame 3 Attaching parts for EA1.45.883:—	1	LFS21	2/52
A25/6C	. . .	Bolt, 2 BA hex. head	2	—	2/53
AGS2002/C/1	. . .	Nut, stiff, 2 BA	2	—	2/54
EA1.45.881	. . .	FAIRLEAD, frames 5 to 11 Attaching parts for EA1.45.881:—	7	LFS21	2/55
A25/6C	. . .	Bolt, 2 BA hex. head	2	—	2/56
AGS2002/C/1	. . .	Nut, stiff, 2 BA	2	—	2/57
EA1.45.1121	. . .	FAIRLEAD, frame 12A Attaching parts for EA1.45.1121:—	1	LFS21	2/58
AS1242/5B	. . .	Bolt, 4 BA c'sk head	2	—	2/59
AGS2001/B/1	. . .	Nut, stiff, 4 BA	2	—	2/60
A33/B24	. . .	Screw, 4 BA c'sk head	2	—	2/61
SP15/B	. . .	Washer, 4 BA plain	2	—	2/62
EA2.45.415	. . .	WASHER, wedge, pressure bulkhead Attaching parts for EA2.45.415:—	2	—	2/63
A25/10C	. . .	Bolt, 2 BA hex. head	2	—	2/64
AGS2001/C/1	. . .	Nut, stiff, 2 BA	2	—	2/65
—	. . .	HYDRAULIC EQUIPMENT IN FRONT FUSELAGE (EG9.73.5) (See page NV1)	—	—	—

FUSELAGE  
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R	—	—	—	
	INSULATION, CABIN (EG9.17.1)			
	Spares for:—			
R	Bostic CS2558	QR	—	
R	EG9.17.23	1	—	36/1
R	EG9.17.25	1	—	36/2
R	EG9.17.27	1	—	36/3
R	EG9.17.29	1	—	36/4
R	EG9.17.31	1	—	36/5
R	EG9.17.33	1	—	36/6
R	EG9.17.35	1	—	36/7
R	EG9.17.37	1	—	36/8
R	EG9.17.39	1	—	36/9
R	EG9.17.41	1	—	36/10
R	EG9.17.43	1	—	36/11
R	EG9.17.45	1	—	36/12
R	EG9.17.47	1	—	36/13
R	EG9.17.49	1	—	36/14
R	EG9.17.3	1	—	36/15
R	EG9.17.51	1	—	36/16
R	EG9.17.89	1	—	36/17
R	EG9.17.5	1	—	36/18
R	EG9.17.7	1	—	36/19
R	EG9.17.53	1	—	36/20
R	EG9.17.55	1	—	36/21
R	EG9.17.57	1	—	36/22
R	EG9.17.59	1	—	36/23
R	EG9.17.61	1	—	36/24
R	EG9.17.63	1	—	36/25
R	EG9.17.65	1	—	36/26
R	EG9.17.67	1	—	36/27
R	EG9.17.69	1	—	36/28
R	EG9.17.71	1	—	36/29
R	EG9.17.73	1	—	36/30
R	EG9.17.75	1	—	36/31
R	EG9.17.77	1	—	36/32
R	EG9.17.79	1	—	36/33
R	EG9.17.81	1	—	36/34
R	EG9.17.83	1	—	36/35
R	EG9.17.9	1	—	36/36
R	EG9.17.11	1	—	36/37
R	EG9.17.13	1	—	36/38
R	EG9.17.15	1	—	36/39
R	EG9.17.17	1	—	36/40
R	EG9.17.191	1	—	36/41
R	EG9.17.85	1	—	36/42
R	EG9.17.87	1	—	36/43

## FUSELAGE

## FRONT FUSELAGE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
EG9.80.563	.	INSULATION, passengers floor	1	-	36/44
EB6.17.137	.	MAT, rubber	1	-	36/45
EB6.17.135	.	MAT, rubber	1	-	36/46
EG9.17.21	.	MAT, floor	1	-	36/47
EB7.17.35	.	PAD, insulation (Pre—Mod 5513)	1	-	36/48
EB7.17.37	.	PAD, insulation	1	-	36/49
EA3.17.5339	.	PAD, insulation	1	-	36/50
EA3.17.5341	.	PAD, insulation	1	-	36/51
EA3.17.5349	.	PAD, insulation	1	-	36/52
EA3.17.5385	.	PAD, insulation	1	-	36/53
EA3.17.5387	.	PAD, insulation	1	-	36/54
-		NOSE, UNDERCARRIAGE ASSEMBLY (EA9.40.1) (See page RB1)	-	-	
-		OXYGEN DEMAND SYSTEM, ASSEMBLY (EG9.71.1) (See page NAA1)	-	-	

FUSELAGE  
FRONT FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EG9.80.197	. PITOT AND STATIC PIPES (See page NAC1)	-	-	
EG9.10.1	. STRUCTURE, FRONT FUSELAGE (See page HA1)	-	-	
-	. TUNNEL, BOMB AIMER'S, ASSEMBLY (EG9.10.115) Spares for:—	-	-	3/1
EA3.10.2311	. . COVER, hand pump	1	L59	3/2
EG9.10.113	. . FAIRING, channel Attaching parts for EG9.10.113:—	1	-	3/3
AS1248/2B	. . Bolt, 4BA mushroom head	6	-	3/4
EB6.10.333	. . PLATFORM, BOMB AIMER'S CHEST, AND CUSHION, ASSEMBLY Spares for:—	1	-	3/5
EA3.10.2853	. . . CUSHION Spares for:—	1	-	3/6
708A	. . . . PLATE, clinch	11	-	3/7
N608	. . . . SOCKET	11	-	3/8
EB6.10.329	. . . PLATFORM, BOMB AIMER'S, ASSEMBLY Spares for:—	1	-	3/9
EB6.10.319	. . . . SPIGOT	1	S92	3/10
EB6.10.320	. . . . SPIGOT	1	S92	3/11
-	. . . TUNNEL, ACCESSORIES, ASSEMBLY (EG9.10.117) Spares for:—	-	-	3/12
EA3.10.2297	. . . . COVER, inner	1	-	3/13
EA3.10.2303	. . . . GUARD, pedal	1	-	3/14

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
-	FRONT FUSELAGE STRUCTURE, ASSEMBLY (EG9.10.1) (EA3.10.1) Spares for:-	-	-	4/1
-	ALTERATIONS TO NAVIGATOR'S HATCH LONGERONS AND FORWARD AND AFT MEMBERS (EA3.10.6387) (Alt. R60/88) Spares for:-	-	-	
EA3.10.6417	. . . ANGLE, LH	1	-	37/1
EA3.10.6418	. . . ANGLE, RH	1	-	37/2
EA3.10.6419	. . . ANGLE, LH	1	-	37/3
EA3.10.6420	. . . ANGLE, RH	1	-	37/4
EA3.10.6421	. . . ANGLE, LH	1	-	37/5
EA3.10.6422	. . . ANGLE, RH	1	-	37/6
EA3.10.6427	. . . ANGLE, LH	3	-	37/7
EA3.10.6428	. . . ANGLE, RH	3	-	37/8
EA3.10.6429	. . . ANGLE, LH	1	-	37/9
EA3.10.6430	. . . ANGLE, RH	1	-	37/10
EA3.10.65	. . . ANGLE, LH	1	-	37/11
EA3.10.66	. . . ANGLE, RH	1	-	37/12
EA3.10.6395	. . . ARCH, forward member (Pre-Mod 5349)	1	-	37/13
EA3.00.5737	. . . ARCH, forward member (Mod 5349)	1	-	
EA3.10.6399	. . . ARCH, aft member (Pre-Mod 5349)	1	-	37/14
EA3.00.5735	. . . ARCH, aft member (Mod 5349)	1	-	
EA3.10.561	. . . ARM, steady	23	-	37/15
EA3.10.173	. . . CLEAT	2	-	37/16
EA3.10.171	. . . CLEAT	2	-	37/17
EA3.10.6415	. . . DIAPHRAGM, LH	1	-	37/18
EA3.10.6416	. . . DIAPHRAGM, RH	1	-	37/19
EA3.10.6501	. . . DIAPHRAGM, LH	1	-	37/20
EA3.10.6502	. . . DIAPHRAGM, RH	1	-	37/21
EA3.10.6503	. . . DIAPHRAGM, LH	1	-	37/22
EA3.10.6504	. . . DIAPHRAGM, RH	1	-	37/23
EA3.10.6505	. . . DOUBLING, LH	1	-	37/24
EA3.10.6506	. . . DOUBLING, RH	1	-	37/25
EA3.10.6389	. . . FRAME, bolt assembly (Pre-Mod 5349)	1	-	37/26
EA3.00.5783	. . . FRAME, bolt assembly (Mod 5349) Spares for:-	1	-	
EA3.10.6391	. . . BLOCK, corner	2	-	37/27
EA3.10.6393	. . . BLOCK, corner	2	-	37/28
EA3.10.1981	. . . BLOCK	30	-	37/29
EA3.10.161	. . . FRAME, bolt, forward	1	-	37/30
EA3.10.163	. . . FRAME, bolt, aft	1	-	37/31
EA3.10.165	. . . FRAME, bolt, LH	1	-	37/32
EA3.10.166	. . . FRAME, bolt, RH	1	-	37/33
AGS2008/E/1	. . . NUT, anchor, 1/4" BSF thin Attachments for:-	68	-	37/34
EA1.10.1029	. . . Bolt, explosive	34	-	37/35
EA3.10.6407	. . . Bush	21	-	37/36
EA3.10.6511	. . . Bush	2	-	37/37
A27LT	. . . Nut, thin, 7/16" BSF	34	-	37/38
EA3.10.6411	. . . Tube, distance	2	-	37/39
EA3.10.6413	. . . Tube, distance	21	-	37/40
AGS2035L	. . . Washer, shakeproof 7/16" BSF	34	-	37/38A

R

R

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R EA3.10.6401	. . FITTING, forward, LH	1	-	38/1
R EA3.10.6403	. . FITTING, aft, LH	1	-	38/2
R A59/7E	. . Bolt, 1/4" BSF	3	-	38/3
R A59/5E	. . Bolt, 1/4" BSF	4	-	38/4
R A59/3E	. . Bolt, 1/4" BSF	4	-	38/5
R A25/3C	. . Bolt, 2BA	5	-	38/6
R A27/CP	. . Nut, 2BA, plain	5	-	38/7
R A27/EP	. . Nut, 1/4" BSF, plain	11	-	38/8
R SP124/E	. . Washer, thin	4	-	38/9
R SP125/E	. . Washer, thick	4	-	38/10
R SP125/C	. . Washer, thick	5	-	38/11
R EA3.10.6402	. . FITTING, forward, RH	1	-	38/12
R EA3.10.6404	. . FITTING, aft, RH	1	-	38/13
R A59/7E	. . Bolt, 1/4" BSF	3	-	38/14
R A59/5E	. . Bolt, 1/4" BSF	4	-	38/15
R A59/3E	. . Bolt, 1/4" BSF	4	-	38/16
R A25/3C	. . Bolt, 2BA	5	-	38/17
R A27/CP	. . Nut, 2BA, plain	5	-	38/18
R A27/EP	. . Nut, 1/4" BSF, plain	11	-	38/19
R SP124/E	. . Washer, thin	4	-	38/20
R SP125/E	. . Washer, thick	4	-	38/21
R SP125/C	. . Washer, thick	5	-	38/22
R EA3.10.6513	. . GUSSET, LH	1	-	38/23
R EA3.10.6514	. . GUSSET, RH	1	-	38/24
R EA3.10.6433	. . LONGERON, escape hatch, LH	1	-	38/25
R EA3.10.6435	. . LONGERON, escape hatch RH	1	-	38/26
R EA3.10.45	. . LONGERON, member, LH	1	-	38/27
R EA3.10.46	. . LONGERON, member, RH	1	-	38/28
R EA3.10.6497	. . PACKING	1	-	38/29
R EA3.10.6499	. . PACKING	1	-	38/30
R EA3.10.6481	. . PANEL, skin, LH	1	-	38/31
R EA3.10.6482	. . PANEL, skin, RH	1	-	38/32
R EA3.10.515	. . PANEL, skin	1	-	38/33
R EA3.10.1097	. . PANEL, skin	1	-	38/34
R EA3.10.503	. . PANEL, skin	1	-	38/35
R EA3.10.1099	. . PANEL, skin	1	-	38/36
R EA3.10.519	. . PANEL, skin	1	-	38/37
R EA3.10.6431	. . PLATE, tie	1	-	38/38
R EA3.10.6432	. . PLATE, tie	1	-	38/39
R EA3.10.6515	. . REINFORCING, LH	1	-	38/41
R EA3.10.6516	. . REINFORCING, RH	1	-	38/42
R EA3.10.549	. . SEAL, pressure	1	-	37/41
R EA3.10.6489	. . SHIM	2	-	38/44
R EA3.10.6491	. . SHIM	2	-	38/45
R EA3.10.6493	. . SHIM	2	-	38/46
R EA3.10.6495	. . SHIM	2	-	38/47
R EA3.10.6397	. . STIFFENER	1	-	38/48
R EA3.10.6483	. . STRAP, butt	2	-	38/49
R EA3.10.6485	. . STRAP, butt	2	-	38/50
R EA3.10.6487	. . STRAP, butt	2	-	38/51
R EA3.10.471	. . WEDGE, packing	10	-	38/52

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.						
					1	2	3	4	5	6
EA3.10.391	. ARM, steady, L.H., for escape hatch explosive bolt Attaching parts for EA3.10.391:—	1	EEDX90	4/2						
A61/2C	. Bolt, 2BA, hex. head	2	—	4/3						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/4						
EA3.10.392	. ARM, steady, R.H., for escape hatch explosive bolt Attaching parts for EA3.10.392:—	1	EEDX90	4/5						
A61/2C	. Bolt, 2BA, hex. head	2	—	4/3						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/4						
EA3.10.561	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.561:—	24	L72	4/6						
A25/3C	. Bolt, 2BA, hex. head (at 2 positions)	2	—	4/7						
A61/2C	. Bolt, 2BA, hex. head (at 6 positions)	2	—	4/8						
A61/3C	. Bolt, 2BA, hex. head	2	—	4/9						
A27/CP	. Nut, 2BA, plain (at 2 positions)	2	—	4/10						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/11						
EA3.10.2551	. ARM, steady, L.H., for escape hatch explosive bolt Attaching parts for EA3.10.2551:—	1	L72	4/12						
A61/3C	. Bolt, 2BA, hex. head	2	—	4/13						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/14						
EA3.10.2552	. ARM, steady, R.H., for escape hatch explosive bolt Attaching parts for EA3.10.2552:—	1	L72	4/15						
A61/3C	. Bolt, 2BA, hex. head	2	—	4/13						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/14						
EA3.10.2583	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.2583:—	3	EEDX90	4/16						
A61/3C	. Bolt, 2BA, hex. head	2	—	4/17						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/18						
EA3.10.2584	. ARM, steady, for escape hatch explosive bolt Attaching parts for EA3.10.2584:—	3	EEDX90	4/19						
A61/3C	. Bolt, 2BA, hex. head	2	—	4/17						
AGS2001/C/3	. Nut, stiff, 2BA	2	—	4/18						
EA1.10.1029	. BOLT, special, navigator's escape hatch	34	L40	4/20						
R EA3.10.2581	. BRACKET, hinge Attaching parts for EA3.10.2581:—	1	L40	4/21						
R AS1242/4C	. Bolt, 2BA, csk head	2	—	4/22						
or										
R AS1242/5C	. Bolt, 2BA, csk head	2	—	4/23						
R AS1242/6C	. Bolt, 2BA, csk head	2	—	4/24						
or										
R AS1242/7C	. Bolt, 2BA, csk head	2	—	4/25						
R AGS2001/C/1	. Nut, stiff, 2BA	4	—	4/26						
R SP13/C	. Washer, 2BA plain	4	—	4/27						
R EA1.20.1033	. Washer, special	8	Lam. Alum.	4/28						



## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.	1 2 3 4 5 6					
EA1.10.2513	. . STRIP, securing	1	—	5/16						
EA1.10.2515	. . STRIP, securing	1	—	5/17						
EEAS6C	. . WASHER, cap	2	DTD.124A	5/18						
EA1.10.940	. DOOR NOSE UNDERCARRIAGE STARBOARD GROUP (Supplied to Part No. EA3.00.150 for spares purposes) Spares for:-	1	—	5/19						
EA3.10.3129	. . BLOCK, nose wheel door latch Attaching parts for EA3.10.3129:-	1	—	5/20						
EA1.10.983	. . Bolt, special	2	—	5/21						
SP47C	. . Washer, 2 BA spring	2	—	5/22						
EA1.10.1367	. . BRACKET, door pick-up Attaching parts for EA1.10.1367:-	1	—	5/6						
EA1.10.2707	. . Bolt, special (make from A25/3C)	8	—	5/7						
EA1.10.1369	. . Shim	1	—	5/8						
EA1.10.2071	. . BRACKET, roller Attaching parts for EA1.10.2071:-	1	—	5/23						
A25/3C	. . Bolt, 2 BA hex head	2	—	5/24						
A27CP	. . Nut, 2 BA plain	2	—	5/25						
EA1.10.2077	. . Washer, special	2	—	5/26						
EA3.10.3085	. . BRACKET, spring seating Attaching parts for EA3.10.3085:-	1	L.40	5/27						
A25/3C	. . Bolt, 2 BA hex head	2	—	5/28						
AGS2002C1	. . Nut, stiff, 2 BA	2	—	5/29						
SP16C	. . Washer, 2 BA plain	2	—	5/30						
EA1.10.1272	. . HINGE, assembly (Make from AS1880 Ref 28N/9486785)	1	—	5/31						
EA1.10.1414	. . HINGE	1	—	5/32						
EA3.10.3193	. . HOOK, door latch forward Attaching parts for EA3.10.3193:-	1	S.11	5/33						
EA1.10.971	. . Pin pivot	1	—	5/34						
EA1.45.989	. . Shim	1	—	5/35						
EA3.10.3239	. . HOOK, door latch aft Attaching parts for EA3.10.3239:-	1	S.11	5/36						
EA3.10.3375	. . Packing	5	L.72	5/37						
EA1.10.971	. . Pin, pivot	1	—	5/38						
SP15G	. . Washer, 5/16" BSF plain	1	—	5/39						
EA1.10.955	. . PAD, rubber	1	—	5/9						
EA1.10.1725	. . PLATE, cover Attaching parts for EA1.10.1725:-	1	—	5/40						
A33B12	. . Screw 4 BA c'sk head	2	—	5/41						
EA3.10.3211	. . ROD CONNECTING NOSE UNDERCARRIAGE DOOR HOOKS ASSEMBLY Consisting of:-	1	—	5/42						
R EA3.10.3083	. . . COLLAR, spring adjusting	1	L.40	5/43						
EA3.10.3207	. . . FORK-END	1	S.96	5/44						
EA3.10.3213	. . . FORK-END	1	S.96	5/45						
R A27CP	. . . NUT, 2 BA plain	2	—	5/46						
R A27CPL	. . . NUT, 2 BA plain L.H.	1	—	5/47						
R EA3.10.3209	. . . ROD,connecting	1	S.96	5/48						
R EA3.20.2271	. . . SPRING Attaching parts for EA3.10.3211:-	1	DTD239A	5/49						
R AGS899/1	. . Collar, shackle pin	2	—	5/50						
R SP4Y/A7	. . Pin, shackle	2	—	5/51						
R SP90A2	. . Pin, split	2	—	5/52						

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.10.2075	. . ROLLER Attaching parts for EA1.10.2075:-	1	—	5/53
EA1.10.2073	. . Pin	1	—	5/54
EA3.10.2811	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS122) (26FZ/4756)	1	—	5/13
EA3.10.6583	. . SEAL, 'P' (Mod 5282) (Make from EEAS844) (26FZ/6147755) Attaching parts for EA3.10.2811 and EA3.10.6583:-	1	—	5/13
AGS2001A1	. . Nut, stiff, 6 BA	16	—	5/14
A33A12	. . Screw, 6 BA c'sk head	16	—	5/15
EA1.10.949	. . SHIM	1	Light Atlov	5/11
EA1.10.2145	. . STRIP, securing seal	1	—	5/55
EA1.10.2515	. . STRIP, securing seal	1	—	5/17
EEAS6C	. . WASHER, cap	2	DTD124A	5/18
EA1.10.1189	. DOOR, access, hydraulic reservoir	1	L.72	5/56
—	. DOOR EQUIPMENT WITH A.D.F. LOOP AERIAL INSTALLATION (EG9.10.109) Spares for:-	—	—	6/1
A25/7J	. . BOLT, 3/8" BSF hex head door hinge attachment	2	—	6/2
EEAS136	. . BRACKET, bonding lead attachment	2	L.72	6/3
EG9.82.99	. . DOOR EQUIPMENT HATCH AND STRUCTURE FOR A.D.F. LOOP AERIAL GROUP Spares for:-	1	—	6/4
EG7.10.227	. . . BLOCK, insulation	1	Tufnol	6/5
EA9.11.1681	. . . BRACKET, jury strut pivot	1	L.72	6/6
EA1.10.511	. . . LINK, connecting Attaching parts for EA1.10.511:-	2	—	6/7
SP4Y/B2	. . . Pin, shackle	1	—	6/8
SP90C4	. . . Pin, split	1	—	6/9
AS2866P	. . . LOCK Spares for:-	1	—	6/10
FGS50	. . . . KEY	1	—	
or FFE4	. . . . KEY Attaching parts for AS2866P:-			
EA1.10.2421	. . . Ring, packing	1	L.72	6/11
A33B12	. . . Screw, 4 BA c'sk head	11	—	6/12
EA3.82.363	. . . PANEL, dielectric	1	—	6/13
EA3.82.379	. . . PANEL, equipment access	1	L.72	6/14
EA1.10.2423	. . . PANEL, removable Attaching parts for EA1.10.2423:-	1	L.72	6/15
AS1248/1/2B	. . . Bolt, 4 BA mushroom head	26	—	6/16
EA1.10.549	. . . ROD, door lock	2	L.64	6/17
EA3.82.381	. . . SEAL, dielectric panel 1/16" thick	1	Neo-K-Tex	6/18
EA1.10.2425	. . . STRIP, sealing 1/2" wide (Make from EEAS141/1, Ref 12713)	1	—	6/19
EEAS237/11A	. . . WASHER, 'D'	1	L.72	6/20

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
—	. . . FRAME HATCH MODIFICATION (EA3.82.391) Spares for:-	—	—	6/21
EA3.82.395	. . . BRACKET, for plate L.H.	1	L.27	6/22
EA3.82.397	. . . BRACKET, for plate R.H.	1	L.72	6/23
EA3.82.393	. . . PLATE, strut roller slot	1	L.72	6/24
—	. . . HINGES ATTACHMENT TO FUSELAGE ASSEMBLY (EA3.82.399) Spares for:-	—	—	6/25
EA3.82.401	. . . BRACKET, hinge assembly	1	—	6/26
EA3.82.402	. . . BRACKET, hinge assembly	1	—	6/27
EA3.82.409	. . . PLATE, lipped	1	—	6/28
EA3.82.415	. . . ROLLER Attaching parts for EA3.82.415:-	2	L.40	6/29
EA3.82.411	. . . Bolt, special 2 BA	1	L.40	6/30
A27CS	. . . Nut, 2 BA slotted	1	—	6/31
SP90C7	. . . Pin split	1	—	6/32
EA3.82.413	. . . Tube, distance 3/8" o/d x 17 SWG	1	L.62	6/33
SP15E	. . . Washer, 1/4" BSF plain	8	—	6/34
EA3.82.543	. . . SHIM, laminated	4	Alum Alloy	6/35
AGS2001J3	. . . NUT, stiff, 3/8" BSF door hinge bolt attachment	2	—	6/36
EA3.82.421	. . . STRUT, door assembly Attaching parts for EA3.82.421:-	1	—	6/37
A25/9E	. . . Bolt, 1/4" BSF hex head	1	—	6/38
A27CS	. . . Nut, 2 BA slotted	1	—	6/39
A27ES	. . . Nut, 1/4" BSF slotted	1	—	6/40
SP90C7	. . . Pin split	2	—	6/41
EA9.11.1677	. . . Roller	1	T.45	6/42
EA9.11.1679	. . . Tube distance	1	T.35	6/43
EEAS27/46EU	. . . Washer, special	2	S.515	6/44
EA3.10.1401	. . . DOOR MAIN ENTRANCE ASSEMBLY (File door skin line until door fits freely in the frame clearance around door skin line 0".100±0".020) Spares for:-	1	—	7/1
EA1.10.1143	. . . BOLT, assembly door forward	1	—	7/2
EA1.10.1145	. . . BOLT, assembly door aft	1	—	7/3
EA3.10.2313	. . . FAIRING, handle internal Attaching parts for EA3.10.2313:-	1	—	7/4
AS1248/2C	. . . Bolt, 2 BA mushroom head	13	—	7/5
EA1.10.1785	. . . HANDLE, door internal Attaching parts for EA1.10.1785:-	1	—	7/6
AS1248/2C	. . . Bolt, 2 BA mushroom head	1	—	7/7
AGS585C	. . . Washer, 2 BA spring	1	—	7/8
SP13C	. . . Washer, 2 BA plain	1	—	7/9
AS2549	. . . HANDLE, door outer	1	—	7/10
EA1.10.813	. . . LEVER, cranked forward Attaching parts for EA1.10.813:-	1	DTD124A	7/11
A25/6C	. . . Bolt, 2 BA hex head	1	—	7/12
EA1.10.1149	. . . Tube, distance	1	—	7/13

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.10.1337	. . . LEVER, cranked aft Attaching parts for EA1.10.1337:-	1	DTD124A	7/14
A25/6C	. . . Bolt, 2 BA hex head	1	-	7/12
EA1.10.1149	. . . Tube distance	1	-	7/13
EA1.10.821	. . . LINK, coupling crank lever to door handle Attaching parts for EA1.10.821:-	1	-	7/15
SP4Y/B4	. . . Pin shackle	2	-	7/16
SP90A3	. . . Pin split	2	-	7/17
SP13C	. . . Washer, 2 BA plain	2	-	7/18
AS2864P	. . . LOCK, flush fitting door Spares for:-	1	-	7/19
R FGS50 or R FFE4	. . . . KEY Attaching parts for AS2864P:-	1	-	
AS1248/1B	. . . Bolt, 4 BA mushroom head	4	-	7/20
A33/B20	. . . Screw, 4 BA c'sk head	11	-	7/21
EA1.10.1319	. . . PLATE, swivel door strap	1	L.72	7/22
EA1.10.1651	. . . SEAL, cabin weather (Make from 32C/652)	A/R	-	
R -	. . . STOWAGE FOR UNDERCARRIAGE FLAP AND BOMB DOOR LOCK PINS (CM.015) Consisting of:-	-	-	
R CM015FIG2	. . . . PANEL, stowage mounting	1	-	
R CM015FIG3	. . . . PLATE, backing	1	-	
R CM015FIG4	. . . . POCKET, and flap Attaching parts for CM015FIG2, CM015FIG3 and CM015FIG4:-	1	-	
R AS2923/1/2C	. . . . Bolt, mushroom head 2 BA	6	-	
R 4101-10-1/2	. . . . Screw, PK	4	-	
R AGS2001C1	. . . . Nut, stiff 2 BA	6	-	
R SP10C	. . . . Washer	12	-	
R EA3.83.299	. . . . LOCK, undercarriage safety (Ref only)	-	-	
R EA3.83.175	. . . . LOCK, flap switch (Ref only)	-	-	
R EA3.83.151	. . . . LOCK, bomb door (Ref only)	-	-	
EA3.10.2813	. . . STRAP, support strut stowage	1	-	7/23
EA3.10.1459	. . . TUBE, stay door prop	1	-	7/24
EA3.10.157	. FRAME, bolt navigator's escape hatch	1	-	8/1
R EA3.10.6389 R EA3.00.5783	. FRAME, bolt navigator's escape hatch (Pre Mod 5349) . FRAME, bolt assembly (Spares for EA3.10.6389) (Mod 5349)	1	-	
EA1.10.1153	. HANDLE, main door jettison Attaching parts for EA1.10.1153:-	1	L.40	7/25
AS1248/5B	. Bolt, 4 BA mushroom head	1	-	7/26
AGS2035B	. Washer, 4 BA shakeproof	1	-	7/27

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R EA3.00.5325	. HATCH NAVIGATOR'S ESCAPE ASSEMBLY (EA3.10.6301) (Pre-Mod 5349) Spares for:-	1	-	8/2
R 1240	. . BLOCK, terminal	1	-	8/3
R A33A20	. . Attaching parts for 1240:- . . Screw, 6 BA c'sk head	2	-	8/4
EA3.81.5849	. . CABLE ASSEMBLY N417, FROM T/B ON BLANKING PLATE, TO BUTT CONNECTOR GROUP Consisting of:-	1	-	
R UNTERSIL20	. . . CABLE, untersil 20	QR	-	
R CD2313	. . . CONNECTOR, butting 2-way	1	-	
EEAS146/12	. . . SLEEVE, binding, 1/2" long	QR	-	
EEAS146/20	. . . SLEEVE, ident, 3/4" long	QR	-	
EEAS146/12	. . . SLEEVE, ident 1" long	QR	-	
R 5X/6958	. . . TAG, ring tongue	-	-	
EA3.10.6109	. . CHANNEL, butt connector Attaching parts for EA3.10.6109:-	1	L.72	8/5
A25/2C	. . Bolt, 2 BA hex head	4	-	8/6
AGS2001C1	. . Nut, stiff 2 BA	4	-	8/7
SP16C	. . Washer, 2 BA plain	4	-	8/8
MARTIN BAKER MB/EU320EE	. . CLIP, safety harness stowage Attaching parts for MB/EU320EE .	4	-	8/9
A25/5B	. . Bolt, 4 BA hex head	4	-	8/10
AGS2001B1	. . Nut, stiff 4 BA	4	-	8/11
R EA3.10.2277	. . Piece packing	1	LFS21	8/12
EA3.10.2281	. . Piece packing	2	LFS21	8/13
SP15B	. . Washer, 2 BA plain	4	-	8/14

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
MARTIN BAKER MB/EU/321/EE	. . CLIP, parachute harness stowage	4	—	8/15
A25/5B	Attaching parts for MB/EU/321/EE:— . . Bolt, 4BA, hex. head	4	—	8/16
AGS2001/B/1	. . Nut, stiff, 4BA	4	—	8/17
EA3.10.2275	. . Piece, packing	1	LFS21	8/18
EA3.10.2279	. . Piece, packing (at 2 positions)	2	LFS21	8/19
EA3.10.6135	. . Piece, packing (at 2 positions)	1	LFS21	8/20
SP15/B	. . Washer, 4BA, plain	4	—	8/21
EA6.10.2683	. . CURTAIN, window blackout	2	—	8/22
EA6.10.2589	. . FAIRING, canopy	1	L72	8/23
EB7.10.5093	. . FORK-END (Mod 5093) Attaching parts for EB7.10.5093:—	1	S94	8/24
AGS2001/C/1	. . Nut, stiff, 2BA	1	—	8/25
SP15/C	. . Washer, 2BA, plain	1	—	8/26
EA3.80.6659	. . EYEBOLT (Mod 5093)	1	—	
EA3.10.6111	. . HOLDER, spigot Attaching parts for EA3.10.6111:—	1	L65	8/27
A25/4E	. . Bolt, 1/4" BSF hex. head	2	—	8/28
SP16/E	. . Washer, 1/4" BSF plain	2	—	8/29
EA3.10.111	. . PLATE, window securing Attaching parts for EA3.10.111:—	1	L72	8/30
AGS2001/C/1	. . Nut, stiff, 2BA	48	—	8/31
EEAS1/1C	. . Screw, 2BA, 120 deg csk. head	42	S96	8/32
EEAS1/2C	. . Screw, 2BA, 120 deg csk. head	6	S96	8/33
SP15/C	. . Washer, 2BA, plain	48	—	8/34
EA3.10.6275	. . PLATE, window securing Attaching parts for EA3.10.6275:—	1	L72	8/35
AGS2001/C/1	. . Nut, stiff, 2BA	48	—	8/36
EEAS1/1C	. . Screw, 2BA, 120 deg csk. head	46	S96	8/37
EEAS1/2C	. . Screw, 2BA, 120 deg csk. head	2	S96	8/38
SP15/C	. . Washer, 2BA, plain	48	—	8/39
EA3.10.3765	. . PLATE, blanking, periscope	1	L40	8/40
EA3.10.6121	. . RING, packing	1	L72	8/41
EA3.10.6137	. . RING, packing, 3/32" thick	1	Langite	8/42
EA3.10.6247	. . RING, packing, 1/32" thick	1	Langite	8/43
EEAS1/1C	. . SCREW, 2BA, 120 deg. csk. head, canopy fairing	10	S96	8/44
EEAS1/2E	. . SCREW, 1/4" BSF, 120 deg. csk. head, canopy fairing	2	S96	8/45
EA3.10.309	. . SEAL, rubber strip, 38" long (Make from Ref. 208)	2	—	8/46
EA3.10.311	. . SEAL, rubber strip, 64" long (Make from Ref. 208)	1	—	8/47
EA3.10.313	. . SEAL, rubber strip, 61" long (Make from Ref. 208)	1	—	8/48
EA3.80.1787	. . STRIP, securing, window curtain Attaching parts for EA3.80.1787:—	2	L72	8/49
AS1246/1B	. . Bolt, 4BA, round head	3	—	8/50
AGS2001/B/1	. . Nut, stiff, 4BA	3	—	8/51
EA3.10.6099	. . SPIGOT, screwed, 3/8" BSF	2	S96	8/52
EA3.10.305	. . WINDOW, perspex, 0" .5 thick Attaching parts for EA3.10.305:—	2	DTD846	8/53
EA3.10.985	. . Bush, rubber	20	Natural Rubber SH35/45	8/54
AGS2001/C/1	. . Nut, stiff	20	—	8/55
EEAS1/6C	. . Screw, 2BA, 120 deg. csk. head	20	S96	8/56
EA3.10.307	. . Seat, rubber	2	Natural Rubber SH35/45	8/57
SP15/C	. . Washer, 2BA, plain	20	—	8/58

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R -	. HATCH, NAVIGATOR'S ASSEMBLY Comprising:-	-	-	
R EA3.00.5713	. . HATCH, NAVIGATOR'S (Spares for EA3.10.6301 modified to EA3.10.6461) (Alt R60/44) (Mod 5349)	1	-	39/1
R EA3.00.5793	. . KIT, LOOSE EQUIPMENT FOR NAVIGATOR'S HATCH (LOOSE EQUIPMENT KIT IS ESSENTIAL REQUIREMENT WITH HATCH) (Mod 5349) Comprising:-	1	-	
R TYPE B No. 1	. . . BLOCK, terminal	1	-	39/2
R EEAS1/1C	. . . BOLT	10	-	39/3
R AS1246/1B	. . . BOLT	6	-	39/4
R A25/1B	. . . BOLT	3	-	39/5
R EA3.10.6477	. . . BOLT, special	68	-	39/6
R EA3.81.5849	. . . CABLE, assembly	1	-	39/7
R AS3180/4B	. . . CLIP 'P'	3	-	39/8
R EA6.10.2683	. . . CURTAIN	2	-	39/9
R EA6.10.2589	. . . FAIRING, canopy	1	-	39/10
R EB7.10.5093	. . . FORK-END	1	-	39/11
R AGS2007C1	. . . NUT, anchor	10	-	39/12
R AGS2001C1	. . . NUT, stiff	2	-	39/13
R AGS2001B1	. . . NUT, stiff	6	-	39/14
R EA3.80.1787	. . . PLATE	2	L72 x 20 SWG	39/15
R AS2230-303	. . . RIVET	20	-	39/16
R ND	. . . SCREW, hook	8	-	39/17
R A33A20	. . . SCREW	2	-	39/18
R EEAS1/2E	. . . SCREW	2	-	39/19
R A33B6	. . . SCREW	4	-	39/20
R EA3.10.309	. . . SEAL, rubber (Make from 26FZ/208-EEAS74)	2	-	39/21
R EA3.10.311	. . . SEAL, rubber (Make from 26FZ/208-EEAS74)	1	-	39/22
R EA3.10.313	. . . SEAL, rubber (Make from 26FZ/208-EEAS74)	1	-	39/23
R SP15C	. . . WASHER	2	-	39/24
R SP15B	. . . WASHER	3	-	39/25
R ND	. . . WIRE, 8" long  (For installation details of the above refer to drawings EA3.10.6301 and EA3.10.6461)	4	-	39/26

FUSELAGE

FRONT FUSELAGE STRUCTURE

<b>Part Number</b>	<b>Description</b> 1 2 3 4 5 6	<b>No. Off</b>	<b>Matl. Spec.</b>	<b>Plate No.</b>

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.
—	. HOOD, COUPE, ASSEMBLY TO FUSELAGE (EA3.10.3481) Spares for:—	—	—	9/1
EA3.10.2085	. . . BOLT, special, explosive hood fixing	2	L40	9/2
EA3.10.2221	. . . BOLT, special, explosive hood fixing	27	L40	9/3
EA1.10.1035	. . . BUSH, coaming tube explosive bolt	31	L40	9/4
EA1.10.1167	. . . BUSH, coaming tube explosive bolt entry	2	L40	9/5
EA1.10.1169	. . . BUSH, coaming tube explosive bolt entry	30	L40	9/6
EA1.10.1435	. . . BUSH, coaming tube explosive bolt	1	L40	9/7
EA3.00.509	. . . HOOD, COUPE, C/W EDGE, MEMBER, GROUP (EA3.15.125) Spares for:—	1	—	9/8
EA3.10.3479	. . . BRACKET, hinge Attaching parts for EA3.10.3479:—	1	L40	9/9
AS1242/18C	. . . Bolt, 2BA, csk. head	2	—	9/10
AS1242/3E	. . . Bolt, 1/4" BSF, csk. head	2	—	9/11
A27/CT	. . . Nut, 2BA, thin	2	—	9/12
EA3.10.3061	. . . Shim	2	Lam. Alum.	9/13
EA3.10.3063	. . . Shim	2	Lam. Alum.	9/14
SP13/C	. . . Washer, 2BA, plain	2	—	9/15
EA3.10.3480	. . . BRACKET, hinge Attaching parts for EA3.10.3480:—	1	L40	9/16
AS1242/18C	. . . Bolt, 2BA, csk. head	2	—	9/17
AS1242/3E	. . . Bolt, 1/4" BSF, csk. head	2	—	9/18
A27/CT	. . . Nut, 2BA, thin	2	—	9/19
EA3.10.3061	. . . Shim	2	Lam. Alum.	9/20
EA3.10.3063	. . . Shim	2	Lam. Alum.	9/21
SP13/C	. . . Washer, 2BA, plain	2	—	9/22
EA6.10.2587	. . . FAIRING, canopy, forward section Attaching parts for EA6.10.2587:—	1	L72	9/23
AS1242/13C	. . . Bolt, 2BA, csk. head	6	—	9/24
EA6.10.2679 or EA2.10.661	. . . STRIP, rubber (Make from 32C/537) Strip, rubber	QR QR	Linatex Natural Rubber	9/25 9/26
EA3.15.115	. . . HOOD, ASSEMBLY Spares for:—	1	—	9/27
EA1.15.9	. . . BRACKET, fastener	1	L40	9/28
EA1.15.13	. . . BRACKET, hinge	1	L40	9/29
EA3.15.95	. . . BUSH, rubber, for attachment screws	148	Natural Rubber	9/30
R EA1.81.689/1	. . . CABLE, ASSEMBLY, N47A, HEATED WINDSCREEN TO COUPE BREAK, GROUP Consisting of:—	1	—	9/31
DUPREN 6 1252	. . . CABLE, dupren 6	QR	—	
—	. . . PLUG, 2 way, type R	1	—	
—	. . . SLEEVE, No. 1 x 3/4"	4	—	
—	. . . SLEEVE, No. 2 x 3/4"	2	—	

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R TYPE R No.3 EA1.15.19	. . . . . SLEEVE, No.3 x 1"	1	-	
	. . . . . SOCKET, 2-way, type 2	1	-	
	. . . . . EYE-BOLT, 2 BA Attaching parts for EA1.15.19:-	1	DTD126A	9/32
A25/6C	. . . . . Bolt, 2 BA hex. head	1	-	9/33
A27/CP	. . . . . Nut, 2 BA plain	1	-	9/34
EA3.15.129	. . . . . LANDING, door (D.V. window) Attaching parts for EA3.15.129:-	1	L72	9/35
AS1242/13B	. . . . . Bolt, 4 BA c'sk head	20	-	9/36
AS1242/14B	. . . . . Bolt, 4 BA c'sk head	4	-	9/37
A27/ET	. . . . . Nut, 4 BA thin	4	-	9/38
AGS2002/B/1	. . . . . Nut, stiff, 4 BA	20	-	9/39
EA1.15.17	. . . . . NUT, knurled, 2 BA	1	L40	9/40
EA3.15.107	. . . . . RING, packing, perspex door landing	1	L40	9/41
EA3.15.133	. . . . . RING, sealing, door landing	1	L72	9/42
EA3.15.87	. . . . . SEALING, rubber, between edge member and hood, 1/16" x 1-1/4" x 216" long (Make from 32C/271)	1	Natural Rubber	9/43
EA3.15.135	. . . . . SEAL, rubber, 1/32" thick, door landing, inboard	1	SH30	9/44
EA1.15.23	. . . . . SPRING, 20 SWG	1	Spring Steel	9/45
EA3.15.131	. . . . . WASHER, sealing, door landing, outboard	1	Rubber SH30/40	9/46
EA3.15.105	. . . . . WINDOW, DIRECT VISION, GROUP (PRE MOD.4333) Consisting of:-	1	-	10/1
AS1242/13B	. . . . . BOLT, 4 BA c'sk head	10	-	10/2
AS1242/14B	. . . . . BOLT, 4 BA c'sk head	6	-	10/3
EA1.15.161	. . . . . BRACKET, fastener	1	L40	10/4
EA1.15.163	. . . . . BRACKET, hinge, c/w bushes	1	L65	10/5
A27/ET	. . . . . NUT, 4 BA thin	16	-	10/6
EA1.15.173	. . . . . PACKING, fastener bracket	1	Lam. Alum.	10/7
EA1.15.175	. . . . . PACKING, hinge bracket	1	Lam. Alum.	10/8
EA3.15.69	. . . . . PANEL, c/w elements	1	Glass	10/9
EA1.15.151	. . . . . PLATE, 16 SWG	1	L73	10/10
EA3.15.127	. . . . . RING, panel frame	1	LFS26	10/11
EA1.15.145	. . . . . RING, rubber insulator	1	SH40	10/12
EA1.15.147	. . . . . RING, rubber sealing	1	SH40	10/13
EA1.15.155	. . . . . RING, rubber sealing	1	Rubber	10/14
EA1.15.157	. . . . . RING, clamping	1	L72	10/15
EA3.15.111	. . . . . TERMINAL	4	BSS249	10/16

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA3.15.139	WINDOW, DIRECT VISION, GROUP (MOD.4333) Spares for this group are identical to those for Part No.EA3.15.105 on page HA9, except for the following deletions and additions:— Delete:—	1	—	10/17
R EA3.15.69	PANEL, c/w elements Add:—	1	Glass	10/9
R BOSTIC No.3	ADHESIVE (SAS4746)	QR	DTD900-4418	10/35
R EA3.15.137	PANEL, c/w elements	1	Glass	10/18
R EA3.10.18822/15	RING, sealing (SAS4746)	1	—	10/36
EA3.10.2223	MEMBER, edge, coupe hood Spares for:—	1	—	10/19
EEAS603/J	NUT, anchor, floating, double lug	32	—	10/34
EA3.10.3451	PLATE, attachment, port	1	L72	10/20
EA3.10.3453	PLATE, attachment, starboard	1	L72	10/21
EA3.10.3455	PLATE, attachment, rear	1	L72	10/22
EA3.10.3457	PLATE, attachment, front	1	L72	10/23
EA3.10.2249	SEAL, rubber, coaming tube to canopy, 1/8" x 1-1/4" (Make from 32C/519)	QR	Linatex	10/24
EA3.10.2251	SEAL, rubber, coaming tube to canopy, 1/16" x 1-1/4" (Make from 32C/271)	QR	Linatex	10/25
EA3.10.2245	TUBE, COAMING, COUPE, GROUP Spares for:—	1	—	10/26
EA3.16.5025	BRACKET, eye-bolt, pilot's guide rail attachment	2	S96	10/27
EA1.10.1657	CLIP, top half, air drier mounting	4	DTD124	10/28
EA1.10.1659	CLIP, bottom half, air drier mounting	4	DTD124	10/29
EA1.10.1663	NUT, knurled	8	L40	10/30
EA3.10.2773	PLATE, blast	1	L72	10/31
EA1.10.847	WASHER, saddle, pilot's seat, rear fixing	2	L40	10/32
EA1.10.849	WASHER, saddle, pilot's seat, rear fixing	2	L40	10/33
EA3.10.17	KEEL-UNIT, COMPLETE, ASSEMBLY	1	—	11/1
EA3.00.285	KEEL-UNIT, ASSEMBLY (REPAIR) Spares for:—	1	—	11/2
EA3.11.655	BOLT, special	4	—	11/3
EA3.10.885	DOOR, probe access Attaching parts for EA3.10.885:—	1	—	11/4
AS1248/1C	Bolt, 2 BA mushroom head	12	—	11/5

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index	
		1	2	3	4	5	6	7					
	—	SKINNING, PRESSURE CABIN KEEL UNIT ASSEMBLY (E.A3.10.11)							—	—	—	11/6	
R	—	Spares for:— DELETION OF K AERIAL (E.A3.10.6615) (Mod. 5223)							—	—	—		
R	E.A3.10.6535	CLEAT							1	L.73 x 18 SWG	LM		
R	E.A3.10.6519	PANEL, skin, starboard							1	L.72 x 20 SWG	LM		
R	E.A3.10.6521	PANEL, skin, port							1	L.72 x 20 SWG	LM		
R	E.A3.10.6533	STRAP, butt, 10.5" approx.							1	L.73 x 18 SWG	LM		
R	E.A3.10.6527	STRINGER, port, outboard (Make from EEDX.68, Ref. 26/FZ/475, 19" long approx.)							1	EEDX.68	LM		
R	E.A3.10.6525	STRINGER, port, inboard (Make from EEDX.68, Ref. 26FZ/4475, 28" long approx.)							1	EEDX.68	LM		
R	E.A3.10.6523	STRINGER, centre (Make from EEDX.68, Ref. 26FZ/4475, 28" long approx.)							1	EEDX.68	LM		
R	E.A3.10.6531	STRINGER, starboard, outboard (Make from EEDX.68, Ref. 26FZ/4475 19" long, approx.)							1	EEDX.68	LM		
R	E.A3.10.6529	STRINGER, starboard, inboard (Make from EEDX.68, Ref. 26FZ/4475 28" long approx.)							1	EEDX.68	LM		
R	4378	E.A3.10.2373	PANEL, skin, starboard (Pre-Mod. 5223)							1	—	C	
R	4377	E.A3.10.2371	PANEL, skin, port (Pre-Mod. 5223)							1	—	C	
	4690	E.A1.10.829	PLUG, drain, assembly Consisting of:—							1	—	B	11/7
	4232	E.A1.10.827	HOUSING							1	L.40	C	11/8
	5084	ANGUS OR.12	RING, sealing							1	SH.60	C	11/10
	4231	E.A1.10.825	SCREW, special							1	L.4	C	11/11



AP.101B-0418-3A

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
-	STRUCTURE MAIN FLOOR PRESSURE CABIN KEEL-UNIT ASSEMBLY (EA3.10.9)	-	-	11/12
	Spares for:-			
EA3.10.2383	BOLT, special bracket mounting	4	S.96	11/13
EA1.10.217	BRACKET MOUNTING L.H. NOSEWHEEL PIVOT SHAFT ASSEMBLY	1	-	11/14
or EA1.10.219				
	Spares for:-			
EA1.10.2685	CAP,	1	-	11/15
SP21	NIPPLE	1	-	11/16
EA1.10.217A	SPIGOT	1	S.94, S.95 or S.96	11/17
EA1.10.218	BRACKET, MOUNTING R.H. NOSEWHEEL PIVOT SHAFT ASSEMBLY	1	-	11/18
or EA1.10.220				
	Spares for:-			
EA1.10.2685	CAP	1	-	11/19
SP21	NIPPLE	1	-	11/20
EA1.10.217A	SPIGOT	1	S.94, S.95 or S.96	11/21
EA1.10.231	BUSH	2	DTD217	11/22
-	BULKHEAD PRESSURE ASSEMBLY (EA3.10.37)	-	-	11/23
	Spares for:-			
EA9.10.5091	BRACKET FORWARD LATCH ASSEMBLY	1	-	11/24
	Spares for:-			
EA3.10.1739	BLOCK	1	-	11/25
	Attaching parts for EA3.10.1739:-			
A25/25E	Bolt, 1/4" BSF hex head	2	-	11/26
A27ET	Nut, 1/4" BSF thin	2	-	11/27
AS2811/6/135	Tube, distance	2	L.62	11/28
EA1.10.1429	PLATE	1	-	11/29
	Attaching parts for EA1.10.1429:-			
A45C16	Screw 2 BA c'sk head	2	-	11/30
EA9.10.5093	PLATE, side	1	-	11/31
EA9.10.5095	PLATE, side	1	-	11/32
EA1.10.1431	SHIM	1	-	11/33
NORMALAIR 506713	CAP, blanking ground pressure test valve	1	-	11/34
NORMALAIR 504600	CONNECTOR, ground pressurising	1	-	11/35
EA1.10.621	STRINGER, port (Pre-Mod 5223)	1	-	
EA1.10.619	STRINGER, port inboard (Pre-Mod 5223)	1	-	
EA1.10.617	STRINGER, centre (Pre-Mod 5223)	1	-	
EA1.10.622	STRINGER, starboard outboard (Pre-Mod 5223)	1	-	
EA1.10.620	STRINGER, starboard inboard (Pre-Mod 5223)	1	-	
EA3.10.2793	WASHER, special	4	L.40	11/36
EA3.10.2381	WINDOW, aerial (Pre-Mod 5223)	1	-	
-	MOUNTING FOR CONTROL PANEL TYPE15 ASSEMBLY (EG9.81.517)	-	-	12/1
	Spares for:-			
EG9.81.999	CHANNEL, assembly	1	EEDX320	12/2
	Attaching parts for EG9.81.999:-			
A25/1E	Bolt, 1/4" BSF hex head	2	-	12/3
SP15E	Washer, 1/4" BSF plain	2	-	12/4
EG9.81.1000	CHANNEL, assembly	1	EEDX320	12/5
	Attaching parts :-			
A25/1E	Bolt, 1/4" BSF hex head	2	-	12/6
SP15E	Washer, 1/4" BSF plain	2	-	12/7

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EG9.10.121	. NOSE PERSPEX ASSEMBLY Spares for:—	1	—	12/8
EA2.10.659	. . BUSH, rubber nose fixing bolts (Make from 26FZ/4166)	64	Natural Rubber	12/9
EA2.10.1501	. . BUSH, rubber nose fixing bolts	34	Natural Rubber	12/10
EA2.10.653	. . RING, half retaining window inner seal	1	L.72	12/11
EA2.10.655	. . RING, half retaining window inner seal	1	L.72	12/12
EA2.10.1601	. . RING, half retaining window seal	1	L.72	12/13
EA2.10.1603	. . RING, half retaining window seal	1	L.72	12/14
EA2.10.685	. . RING, rubber inner seal	1	H.R.C.	12/15
EA2.10.1503	. . RING, rubber window seal	1	H.R.C.	12/16
EA2.10.665	. . STRAP joint assembly	4	—	12/17
EA2.10.657	. . STRIP sealing, 1/32" x 0.9" x 95"	1	Natural Rubber	12/18
EA2.10.661	. . STRIP, inner retaining ring seal 1/32" x 3/4" x 95"	1	Natural Rubber	12/19
EA2.10.687	. . WINDOW, observation	1	Triplex Glass	12/20
EA1.10.1131	. PIECE, distance	21	T.4	12/21
EA1.10.1133	. PIECE, distance	13	T.4	12/22
EA3.10.6411	. PIECE, distance	2	—	
EA3.10.6413	. PIECE, distance	21	—	
EA3.10.3007	. PLATE, nut for navigator's lamp mounting bracket (Pre-Mod.3423)	1	—	12/23
EA3.10.3821	. PLATE, nut for navigator's lamp mounting bracket (Mod.3423)	1	S.3 or S.82	12/24
EA3.10.3247	. PLATE, access door hinge and jettison mechanism inspection pressure sealing	1	—	7/28
EA2.10.707	. RAMP BOMB AIMER'S ASSEMBLY Spares for:—	1	—	12/25
EA2.10.709	. . SPIGOT, assembly Attaching parts for EA2.10.709:—	2	—	12/26
AS1246/1C	. . Bolt, 2 BA round head	4	—	12/27
EA3.10.6477	. SCREW, special (Alt R60/44 (Mod.5102))	68	—	13/1
EA3.10.549	. SEAL, pressure navigator's escape hatch	1	BTR8853	13/2
EA1.10.1171	. SEAL, door pressure cabin entrance	1	BTR8853	
EA3.10.651	. SHIM, escape hatch steady arm	76	L.72	13/3
EA3.10.2549	. SHIM, escape hatch steady arm	8	—	13/4
—	. SKINNING STRUCTURE PRESSURE BULKHEAD TO FRAME 12 ASSEMBLY (EA3.10.13) Spares for:—	—	—	
EA1.10.187	. . DOOR ACCESS V.H.F. MAIN ELECTRICAL PANEL AND GROUND FLIGHT SWITCH GROUP (Supplied to Part No. EA3.00.151 for spares purposes) Spares for:—	2	—	13/5
AS2850P	. . . LOCK, L.H. FLUSH TYPE ASSEMBLY Spares for:—	1	—	13/6
AS2552	. . . . HANDLE	1	—	13/7
FGS50 or FFE4	. . . . KEY	1	—	
	. . . . KEY Attaching parts for AS2850P:—			
AS1248/1/2B	. . . Bolt, 4 BA mushroom head	4	—	13/8
A33B20	. . . Screw, 4 BA c'sk head	11	—	13/9

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.10.1919	. . . . SEAL, section (Make from EEAS141/1, Ref. 12713)	1	—	13/10
EA1.10.1815	. . . . STAY, door	1	—	13/11
EA3.10.2805	. . . . STOWAGE, DOOR SUPPORT STRUT, ASSEMBLY Spares for:—	1	—	13/12
EA3.10.2809	. . . . PLATE, stiffening	1	L.73	13/13
EA3.10.2807	. . . . STRAP	1	—	13/14
EEAS27/27/DU	. . . . WASHER, for door stay attachment	1	S.515	13/15
EA1.10.1033	. . . . PLUG, forward jacking point housing	1	L.40	13/16
EEAS1/3C	. . . . SCREW, 2 BA 120 deg. c'sk head	24	S.96	13/17
—	. . . . STRUCTURE, PRESSURE BULKHEAD TO FRAME 12, ASSEMBLY (EA3.10.15) Spares for:—	—	—	—
EA3.10.6375	. . . . CLEAT, nose undercarriage hook return spring (Mod.4449)	1	L.72	—
—	. . . . FRAME 12A, JOINT, FORWARD PORTION, ASSEMBLY (EA1.10.55) Spares for:—	—	—	14/1
EA3.71.389	. . . . BEAM, oxygen bottle mounting	2	—	14/2
EA1.10.909	. . . . BRACKET, door lock, starboard (Supplied to Part No.EA3.00.596 for spares purposes)	1	—	14/3
EA1.10.1621	. . . . BRACKET, door lock, port	1	L.72	14/4
EA6.10.775	. . . . BRACKET, oxygen cylinder cradle	2	L.72	14/5
EA3.71.403	. . . . BRACKET, oxygen mounting beam	7	L.72	14/6
EA1.10.557	. . . . BRACKET, strut pick-up	1	L.72	14/7
EA3.10.6571	. . . . BRACKET (Note: Still used on A/C with front fuselage married up)	1	—	—
EA1.10.1179	. . . . BRACKET (Note: Used on A/C with front fuselage de-married)	1	—	—
EA3.10.2447	. . . . GUARD, assembly Attaching parts for EA3.10.2447:—	1	L.72	14/8
A32/C16	. . . . Screw, 2 BA round head	4	—	14/9
EA3.10.3353	. . . . GUARD, lock lever, assembly Attaching parts for EA3.10.3353:—	1	L.72	14/10
A32/C16	. . . . Screw, 2 BA round head	4	—	14/11
—	. . . . INSTALLATION OF ATTACHMENT LUG BOLTS (EA3.10.6573) (Alt. R60/301—Mod.5102) Spares for:—	—	—	—
EA1.10.1177	. . . . PLATE, tie (Pre-Alt. R60/301—Mod.5102)	1	—	—
EA3.10.6575	. . . . PLATE, tie (Alt. R60/301—Mod.5102)	1	—	—
EA3.10.2455	. . . . PLATE, reinforcing (Pre-Alt. R60/301—Mod.5102)	1	—	—
EA3.10.6577	. . . . PLATE, reinforcing (Alt. R60/301—Mod.5102)	1	—	—
EA6.10.1815	. . . . PLATE, reinforcing (Pre-Alt. R60/301—Mod.5102)	1	—	—
EA3.10.6579	. . . . PLATE, nut (Alt. R60/301—Mod.5102) Attaching parts:—	1	—	—
AS1242/2C	. . . . Bolt, c'sk, 2 BA	3	—	—
AGS2019/C1	. . . . Nut, anchor	3	—	—

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
R EK5.10.803	. . . . .	LEVER, LOCK, ASSEMBLY (Alt. R60/15-- Mod.5102) Consisting of:--	1	--	14/12
R EK5.10.807	. . . . .	BRACKET (Alt. R60/15--Mod.5102)	1	--	14/13
EA3.10.3159	. . . . .	LEVER, ASSEMBLY Attaching parts for EA3.10.3159:--	1	--	14/14
EA3.10.3219	. . . . .	Bolt, shoulder, 5/16" BSF	1	S.96	14/15
A27/GS	. . . . .	Nut, 5/16" BSF slotted	1	--	14/16
SP90/C7	. . . . .	Pin, split	1	--	14/17
SP15/G	. . . . .	Washer, 5/16" BSF plain	1	--	14/18
EA1.10.1407	. . . . .	Washer, spacing	1	--	14/19
R EK5.10.805	. . . . .	LEVER, LOCK ASSEMBLY (Alt. R60/15--Mod.5102) Consisting of:--	1	--	14/20
R EK5.10.808	. . . . .	BRACKET (Alt. R60/15--Mod.5102)	1	--	14/21
EA3.10.3335	. . . . .	LEVER, assembly Attaching parts for EA3.10.3335:--	1	--	14/22
EA3.10.3219	. . . . .	Bolt, shoulder, 5/16" BSF	1	S.96	14/23
A27/GS	. . . . .	Nut, 5/16" BSF slotted	1	--	14/24
SP90/C7	. . . . .	Pin, split	1	--	14/25
SP15/G	. . . . .	Washer, 5/16" BSF plain	1	--	14/26
EA1.10.1407	. . . . .	Washer, spacing	1	--	14/27

FUSELAGE

FRONT FUSELAGE STRUCTURE

Part Number	Description 1 2 3 4 5 6	No. Off	Matl. Spec.	Plate No.

FUSELAGE  
FRONT FUSELAGE STRUCTURE

Part Number	1 2 3 4 5 6	Description	No. Off	Matl. Spec.	Plate No.
—	. . . . .	STIFFENER, VERTICAL, CENTRE, PORT, ASSEMBLY (EA9.10.4545) (Mod 1740) Spares for:—	—	—	15/11
EA3.10.3197	. . . . .	CHANNEL	1	—	15/12
EA9.10.4439	. . . . .	PLATE, reinforcing (Mod 1740)	1	—	15/13
—	. . . . .	STIFFENER, VERTICAL, CENTRE, STARBOARD, ASSEMBLY (EA3.10.3206) Spares for:—	—	—	15/14
ASD292.RS/1	. . . . .	ANGLE, inner joint (Repair) (Make from EEJ270, Ref. 7109)	1	L72	15/15
EA3.10.3199	. . . . .	CHANNEL	1	—	15/16
ASD292.RS/5S	. . . . .	INSERTION, channel, starboard (Repair) (Make from EA3.10.3199, Ref. 22326)	1	—	15/17
ASD292.RS/6S	. . . . .	INSERTION, plate, reinforcing (Repair) (Make from EA3.10.3203, Ref. 22328 or 30B/9611240)	1	L73	15/18
EA3.10.3203	. . . . .	PLATE, reinforcing	1	L73	15/19
ASD292.RS/4S	. . . . .	STRAP, joint, forward, outer, starboard (Repair) (Pre Mod 856)	1	—	15/20

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
ASD292RS/4S	. . . . . STRAP, joint, forward, outer, starboard (Repair) (Mod.856 A/C)	1	—	15/21
ASD292RS/3	. . . . . STRAP, joint, forward, leveller, 14 SWG (Repair) (Make from 30B/9611242)	1	L.73	15/22
ASD292RS/2	. . . . . STRAP, joint, aft, 14 SWG (Repair)	1	S.514	15/23
EA3.10.3223	. . . . . STRUT, bracing, assembly Attaching parts for EA3.10.3223:—	2	—	14/28
A25/6E	. . . . . Bolt, 1/4" BSF hex. head	2	—	14/29
A27/EP	. . . . . Nut, 1/4" BSF plain	2	—	14/30
SP15/E	. . . . . Washer, 1/4" BSF plain	1	—	14/31
SP16/E	. . . . . Washer, 1/4" BSF plain	1	—	14/32
EA1.10.1345	. . . . . SOCKET, front frame entrance door bolt Attaching parts for EA1.10.1345:—	1	L.40	17/1
AS1242/4C	. . . . . Bolt, 2 BA c'sk head	2	—	17/2
AS1242/5C	. . . . . Bolt, 2 BA c'sk head	2	—	17/3
AGS2001/C/1	. . . . . Nut, stiff, 2 BA	4	—	17/4
EA1.10.1347	. . . . . SOCKET, rear frame entrance door bolt Attaching parts for EA1.10.1347:—	1	L.40	17/5
AS1242/4C	. . . . . Bolt, 2 BA c'sk head	2	—	17/2
AS1242/5C	. . . . . Bolt, 2 BA c'sk head	2	—	17/3
AGS2001/C/1	. . . . . Nut, stiff, 2 BA	4	—	17/4
S4/250	. . . . . SPRING, "dzus", hydraulic reservoir access door	6	—	5/57
EA3.10.3255	. . . . . STRAP, main door jettison handle stowage	1	—	7/30
—	. . . . . STRUCTURE, NOSE, FORWARD OF FRAME 1, ASSEMBLY (EG9.10.103) (EA3.10.6507) Spares for:—	—	—	16/1
EB6.10.295	. . . . . BRACKET, spigot  Attaching parts for EB6.10.295:—	2	S.1 or S.91	16/2
AS1242/12B	. . . . . Bolt, 4 BA c'sk head	4	—	16/3
AGS2001/B/1	. . . . . Nut, stiff, 4 BA	4	—	16/4
SP13/B	. . . . . Washer, 4 BA plain	4	—	16/5
EA3.10.1583	. . . . . PANEL, access to air drier tube Attaching parts for EA3.10.1583:—	1	L.72	16/6
A25/1C	. . . . . Bolt, 2 BA hex. head	2	—	16/7
AS1248/ 1/2C	. . . . . Bolt, 2 BA mushroom head	4	—	16/8
SP15/C	. . . . . Washer, 2 BA plain	2	—	16/9
EG9.10.119	. . . . . PANEL, access Attaching parts for EG9.10.119:—	1	L.72	16/10
AS1248/1B	. . . . . Bolt, 4 BA mushroom head	10	—	16/11
EA1.10.829	. . . . . PLUG, drain assembly Spares for:—	1	—	
EA1.10.827	. . . . . HOUSING	1	L.40	
ANGUS				
O.R.12	. . . . . RING, "O" sealing	1	—	
EA1.10.825	. . . . . SCREW, special	1	L.40	

## FUSELAGE

## FRONT FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
R EA2.10.471	. . WINDOW, bomb aimer's Attaching parts for EA2.10.471:—	1	—	16/12
AS1242/12C	. . Bolt, 2 BA c'sk head	20	—	16/13
EA3.10.983	. . Bush, rubber (May be made from 32C/4656883)	20	—	16/14
EA2.10.477	. . Frame, seal retaining	1	—	16/15
AGS2001/C/3	. . Nut, stiff, 2 BA	20	—	16/16
EA2.10.473	. . Seal, rubber, outer	1	Natural Rubber	16/17
EA2.10.475	. . Seal, rubber, inner	1	Natural Rubber	16/18
—	. STRUCTURE, IN PRESSURE CABIN (EA3.10.7)	—	—	
EA3.10.279	. . FRAME, 7A, port assembly (Alt. R60/88)	1	—	
EA3.10.281	. . FRAME, 8A, port assembly (Alt. R60/88)	1	—	
EA3.10.282	. . FRAME, 8A, stbd. assembly (Alt. R60/88)	1	—	
EA3.10.283	. . FRAME, 9A, port assembly (Alt. R60/88)	1	—	
EA3.10.284	. . FRAME, 9A, stbd. assembly (Alt. R60/88)	1	—	
EA3.10.1813	. . HINGE, casting assembly (Mod.5028)	1	—	
EA3.10.1815	. . HINGE, casting assembly (Mod.5028)	1	—	
EEAS20/3/DR	. TAB, locking	2	L.72	4/34
EA1.20.1033	. WASHER, special	16	Lam. Alum.	4/35
EA3.10.3023	. WASHER, sealing, escape hatch pivot	2	Natural Rubber	4/36
—	. WINDOW, PASSENGER'S, INSTALLATION (EG9.10.55) Spares for:—	—	—	17/6
† EA3.10.361	. . CEMENT, boscoprene 2100	QR	—	
EA3.10.361	. . WINDOW, passenger's, c/w valve Attaching parts for EA3.10.361:—	1	—	17/7
AS1242/14C	. . Bolt, 2 BA c'sk head	16	—	17/8
EA3.10.983	. . Bush, rubber (May be made from 32C/4656883)	16	Natural Rubber	17/9
AGS2001/C/1	. . Nut, stiff, 2 BA	16	—	17/10
EA3.10.153	. . Seal, rubber	1	Natural Rubber	17/11
EA3.10.155	. . Seal, rubber	1	Natural Rubber	17/12
EA3.10.151	. . Strip, seal retaining	1	L.72	17/13
EA3.10.361	. WINDOW, navigator's, c/w valve (Mod.5032) Spares for:—	1	—	17/7
EA3.76.5055	. . ELBOW	1	—	
A27/GT	. . NUT, thin, hex.	1	—	
SP124/G	. . WASHER	1	—	
AS8596	. . WASHER	2	—	
AS1242/12C	. . Bolt, 2 BA c'sk head	16	—	17/14
EA3.10.983	. Bush, rubber (May be made from 32C/4656883)	16	Natural Rubber	17/9
AGS2001/C/1	. Nut, stiff, 2 BA	16	—	17/10
EA3.10/153	. Seal, rubber	1	Natural Rubber	17/11
EA3.10.155	. Seal, rubber	1	Natural Rubber	17/12
EA3.10.151	. Strip, seal retaining	1	L.72	17/13

FUSELAGE  
CENTRE FUSELAGE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index	
							1
	—	CENTRE FUSELAGE, ASSEMBLY (E.G9.00.7)	—	—	—		
	E.G9.75.57	Spares for:— AIR VENTILATED SUIT SYSTEM (See page N1)	—	—	—		
	E.G7.75.5	CABIN PRESSURE SYSTEM (See page NC1)	—	—	—		
	—	CABIN PRESSURE SYSTEM, ALTERATIONS (E.G9.75.123)	—	—	—	18/1	
	—	Spares for:—					
28E/9130219	AGS.605/4 or	CLIP, hose (Pre-Alt. R60/91—Mod. 5102)	14	—	C	18/2	
R 28E/4710971	SP.91/N	CLIP, hose (Alt. R60/91—Mod. 5102)	14	—	C	18/2	
6812	EEAS.66/14	RING, clamping	14	L.72	C	18/3	
	—	CAMERA STRUCTURE INSTALLATION (E.G9.83.1)	—	—	—	18/4	
	—	Spares for:—					
	E.A1.83.77	MOUNTING, camera, assembly	1	—	—	18/5	
	—	Attaching parts for E.A1.83.77:—					
28D/1011029	A25/1E	Bolt, 1/4" BSF hex. head	2	—	C	18/6	
28D/1008151	A25/4E	Bolt, 1/4" BSF hex. head	2	—	C	18/7	
28M/9480017	AGS.2001/E/1	Nut, stiff, 1/4" BSF	4	—	C	18/8	
	3616	E.A1.83.97	RAIL, camera	2	T.4	C	18/9
	—	Attaching parts for E.A1.83.97:—					
28FP/9432062	A.413	Pin, "pip"	2	—	C	18/10	
28W/9419405	SP.15/E	Washer, 1/4" BSF plain	2	—	C	18/11	
	E.A1.47.125	CONTROLS, ENGINE (See page DB1)	—	—	—		
	E.A3.45.379	CONTROLS, FLYING (See page DJ1)	—	—	—		
	E.G9.81.7	ELECTRICAL EQUIPMENT (See page E1)	—	—	—		
	E.A1.60.1	FIRE PROTECTION SYSTEM (See page NK1)	—	—	—		
	E.A1.57.729	FUEL SYSTEM (PRE-MOD. 648) (See page NL1)	—	—	—		
	E.A3.57.67	FUEL SYSTEM (MOD. 648) (See page NL15)	—	—	—		
	—	GEAR, EMERGENCY RELEASE, BOMB DOOR AND UNDERCARRIAGE, ASSEMBLY (E.A1.45.923)	—	—	—	19/1	
	—	Spares for:—					
	7809	E.A3.45.281	CABLE, AFT CONTROL, EMERGENCY RELEASE GEAR, UNDERCARRIAGE, GROUP	1	—	B	19/2
	—	Consisting of:—					
	28U/4063	SP.8/Y/13	ROLLER	2	—	C	19/3
	E.A1.45.905	TUBE, 5/16" o/d x 20 SWG (Make from 30B/1786)	1	T.4	LM	19/4	
	28X/3495	W9/4P	WIRE, rope, 5 cwt.	QR	—	C	19/5

FUSELAGE  
CENTRE FUSELAGE

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
7810	E.A3.45.283	CABLE, AFT CONTROL, EMERGENCY RELEASE GEAR, BOMB DOOR, GROUP Consisting of:—							1	—	B	19/6
R 28U/4063 28X/3495 7808	E.A1.45.1129	ROLLER, special							1	S.1	—	19/7
	SP.8/Y/13	ROLLER							1	—	C	19/8
	W9/4P	WIRE, rope, 5 cwt.							QR	—	C	19/9
	E.A1.45.1211	CLEAT, angle, fairlead support, frame 13							2	L.72	C	19/10
28D/1200149	A25/4C	Attaching parts for E.A1.45.1211:—										
28M/9433473	AGS.2002/C/1	Bolt, 2 BA hex. head							1	—	C	19/11
28W/9419475	SP.15/C	Nut, stiff, 2 BA							1	—	C	19/12
		Washer, 2 BA plain							1	—	C	19/13
28N/1045681	AGS.899/1	COLLAR, shackle pin							2	—	C	19/14
7811	E.A3.45.245	FAIRLEAD, bomb door release cable, floor girder 15, starboard							1	LFS.21	C	19/15
		Attaching parts for E.A3.45.245:—										
28D/1214299	AS.1242/5B	Bolt, 4 BA c'sk head							2	—	C	19/16
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA							2	—	C	19/17
28W/9419474	SP.15/B	Washer, 4 BA plain							2	—	C	19/18
7804	E.A1.45.879	FAIRLEAD, undercarriage release cable, floor girder 15, port							1	LFS.21	C	19/19
		Attaching parts for E.A1.45.879:—										
28D/9133013	A25/5C	Bolt, 2 BA hex. head							2	—	C	19/20
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							2	—	C	19/21
7805	E.A1.45.1123	FAIRLEAD, bomb door and undercarriage release cable, frame 13							1	LFS.21	C	19/22
		Attaching parts for E.A1.45.1123:—										
28D/1011006	A25/5B	Bolt, 4 BA hex. head							2	—	C	19/23
28M/1278189	AGS.2001/B/1	Nut, stiff, 4 BA							2	—	C	19/24
28W/9419474	SP.15/B	Washer, 4 BA plain							2	—	C	19/25
28K/4070321	SP.3/412	JOINT, fork, 4 BA, R.H., undercarriage cable							1	—	C	19/26
28K/4070322	SP.3/412L	JOINT, fork, 4 BA, L.H., undercarriage cable							1	—	C	19/27
28K/4070323	SP.3/413	JOINT, fork, 2 BA, R.H., bomb door cable							1	—	C	19/28
28K/4070324	SP.3/413L	JOINT, fork, 2 BA, L.H., bomb door cable							1	—	C	19/29
28M/1006504	A27/BT	NUT, 4 BA, thin, undercarriage cable tension rod locking							1	—	C	19/30
28M/13141	A27/BTL	NUT, 4 BA, thin, L.H., undercarriage cable tension rod locking							1	—	C	19/31
28M/1006473	A27/CT	NUT, 2 BA, thin, bomb door cable tension rod locking							1	—	C	19/32
28M/13253	A27/CTL	NUT, 2 BA, thin, L.H., bomb door cable tension rod locking							1	—	—	19/33
28P/7002435	SP.4Y/A3	PIN, shackle, undercarriage release cable							2	—	C	19/34
28P/814	SP.4Y/A4	PIN, shackle, undercarriage and bomb door cables to rotary valve lever							2	—	C	19/35
28P/1207864	SP.4Y/B4	PIN, shackle, bomb door release cable							2	—	C	19/36
28P/1202557	SP.90/A5	PIN, split							6	—	C	19/37

AP101B-0418-3A

## FUSELAGE

Page HB3

## CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
				1 2 3 4 5 6
-	PULLEYS, ON FLOOR GIRDER 14, FOR BOMB DOOR AND UNDERCARRIAGE CABLES, ASSEMBLY (EA1.45.859) Spares for:-	-	-	20/1
EA1.45.839	BRACKET, pulley	1	-	20/2
EA1.45.841	BRACKET, pulley, upper Attaching parts for EA1.45.841:-	1	L.72	20/3
A25/1C	Bolt, 2 BA hex. head	3	-	20/4
AGS2001/C/1	Nut, stiff, 2 BA	3	-	20/5
SP15/C	Washer, 2 BA plain	3	-	20/6
EA1.45.843	BRACKET, pulley, lower Attaching parts for EA1.45.843:-	1	L.72	20/7
A25/1C	Bolt, 2 BA hex. head	3	-	20/8
AGS2001/C/1	Nut, stiff, 2 BA	3	-	20/9
SP15/C	Washer, 2 BA plain	3	-	20/10
EA1.45.1005	BRACKET, pulley	1	-	20/11
EA1.45.863	FAIRLEAD Attaching parts for EA1.45.863:-	1	LFS.21	20/12
A25/9C	Bolt, 2 BA hex. head	2	-	20/13
AGS2001/C/1	Nut, stiff, 2 BA	2	-	20/14
AS1151	PULLEY, shrouded Attaching parts for AS1151:-	4	-	20/15
A25/12E	Bolt, 1/4" BSF hex. head (1 position)	1	-	20/16
A25/13E	Bolt, 1/4" BSF hex. head (2 positions)	1	-	20/17
A25/17E	Bolt, 1/4" BSF hex. head (1 position)	1	-	20/18
AGS2001/E/1	Nut, stiff, 1/4" BSF	1	-	20/19
EA1.45.835	Packing (2 positions)	1	Tufnol	20/20
EA1.45.845	Washer, wedge (1 position)	1	L.40	20/21
EA1.45.1015	Washer, wedge (1 position)	1	L.40	20/22
EA1.45.1311	Washer, special (1 position)	1	Lam. Alum.	20/23
EEAS28/53/HR	Washer (1 position)	1	-	20/24
SP15/E	Washer, 1/4" BSF plain (2 positions)	1	-	20/25
SP16/E	Washer, 1/4" BSF plain (2 positions)	1	-	20/26
AS108	PULLEY, shrouded	2	-	20/27
or AS1152	PULLEY, shrouded (Alternative to AS108) Attaching parts for AS108 or AS1152:-	-	-	
A25/11E	Bolt, 1/4" BSF hex. head (1 position)	1	-	20/28
A25/20E	Bolt, 1/4" BSF hex. head (1 position)	1	-	20/29
AGS2001/E/1	Nut, stiff, 1/4" BSF	1	-	20/30
EA1.45.837	Packing	1	Tufnol	20/31
SP15/E	Washer, 1/4" BSF plain	1	-	20/32
EA1.45.1127	RETAINER, cable Attaching parts for EA1.45.1127:-	2	-	19/39
AGS2002/B/1	Nut, stiff, 4 BA	1	-	19/40
A31/B12	Screw, 4 BA cheese head	1	-	19/41
SP8/Y/1	ROD, tension, undercarriage cable	1	-	19/42
SP8/Y/2	ROD, tension, bomb door cable	1	-	19/43
AGS4561/2	TAB, locking (Refer to SEM041 for installation) (SAS4746)	2	-	
5E/5253563	WIRE, copper enamelled (Refer to SEM041 for installation) (SAS4746)	QR	-	

R

R

R

FUSELAGE  
CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.	
					1
EG9.73.121	. HYDRAULIC, EQUIPMENT (See page NU1)	-	-		
-	. PANEL, INVERTER CONTROL, AND ARMAMENT SAFETY BREAK, FRAME 12 AND 13, ASSEMBLY (EG9.81.47) Spares for:-	-	-	21/1	
EG7.81.3217	. . . PANEL, ACCESS, ASSEMBLY Spares for:-	1	-	21/2	
A4/35	. . . . FASTENER, "dzus"	8	-	21/3	
GA4/250	. . . . GROMMET, "dzus"	8	-	21/4	
EB6.81.5259	. . . . LANYARD, assembly	1	-	21/5	
EG7.81.365	. . . PLUG, SHORTING, ASSEMBLY Consisting of:-	1	-	21/6	
EF3.81.11881	. . . . CAP, protective	1	L.59	21/7	
-	. . . . CONNECTIONS, SHORTING PLUG, ASSEMBLY (EG7.81.387) Consisting of:-	-	-	21/8	
R UNTERSIL 16	. . . . . CABLE, unifersil 16	QR	-	21/9	
508/2/04368	. . . . . FILLER, plug	1	-	21/10	
508/2/04548/001	. . . . . PIN, plug, 12/16	9	-	21/11	
2Z139627	. . . . . SLEEVE, sealing, red	8	-	21/12	
EG7.81.451	. . . . LANYARD, ASSEMBLY Consisting of:-	1	-	21/13	
A.M.P.34318	. . . . . CONNECTOR, parallel	2	-	21/14	
AGS796/B	. . . . . EYE-BOLT, 4 BA	1	-	21/15	
R 26DK/2381	. . . . . LINE, nylon, 66-3/32" dia. x 14" long	QR	-	21/16	
EB6.81.4027	. . . . . PENNANT, "ARMAMENT SAFETY BREAK", ASSEMBLY Consisting of:-	1	-	21/17	
EB6.81.4029	. . . . . PENNANT	1	Cotton	21/18	
EB6.81.4049	. . . . . POUCH, assembly	1	Cotton	21/19	
EF3.81.11889	. . . . . RING, lanyard attachment	1	DTD.189	21/20	
EEAS146/20	. . . . . SLEEVE, 1-1/2" long	1	-	21/21	
EF3.81.13155	. . . . . NUT, outlet, modified	1	-	21/22	
690(ET)16-9P	. . . . . PLUG, free, 9-way, Mk.6	1	-	21/23	
S4/200	. . . . . SPRING, "dzus"	8	-	21/24	
EEAS15/71/100GR	. . . . . STRIP, packing, mounting tray anchor nut	4	L.72	22/24	
EA9.81.3661	. . . TRAY, MOUNTING, INVERTER CONTROL PANEL, ASSEMBLY Spares for:-	1	-	22/1	
EA9.81.3675	. . . . BRACKET, catch securing	2	L.72	22/2	

AP101B-0418-3A

## FUSELAGE

## CENTRE FUSELAGE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA9.81.3677	. . . CATCH, control panel Attaching parts for EA9.81.3677:—	2	L72	22/3
EA9.81.3671	. . . Circlip	1	DTD215	22/4
EA9.81.3673	. . . Nut, special, 1/4" BSF	1	S1	22/5
EA9.81.3667	. . . Screw, knurled	1	S92	22/6
SP13/E	. . . Washer, 1/4" BSF plain	1	—	22/7
SP13/A	. . . Washer, 6BA plain	1	—	22/8
AGS163/D	. . . Washer, double spring	1	—	22/9
EA9.81.3669	. . . DOWEL, locating Attaching parts for EA9.81.3669:—	2	L64	22/10
AGS2002/C/1	. . . Nut, stiff, 2BA	1	—	22/11
TYPE 967	. . . MOUNT, anti-vibration, 4 lb Attaching parts for Type 967:—	2	—	22/12
AGS2001/C/1	. . . Nut, stiff, 2BA	4	—	22/13
A31/C20	. . . Screw, 2BA cheese head	4	—	22/14
SP13/C	. . . Washer, 2BA plain	4	—	22/15
TYPE 968	. . . MOUNT, anti-vibration, 6 lb Attaching parts for Type 968:—	2	—	22/16
AGS2001/C/1	. . . Nut, stiff, 2BA	4	—	22/17
A31/C20	. . . Screw, 2BA cheese head	4	—	22/18
SP13/C	. . . Washer, 2BA plain	4	—	22/19
EA9.81.3683	. . . PILLAR Attaching parts for EA9.81.3683:—	2	L64	22/20
AGS2001/B/1	. . . Nut, stiff, 4BA Attaching parts for EA9.81.3661:—	1	—	22/21
A25/10E	. . . Bolt, 1/4" BSF hex head	4	—	22/22
WT33047	. . . Washer, check	8	—	22/23
EA3.57.5043	. PIPE, FUEL TRANSFER AND VENT. AUXILIARY FUEL TANK, ASSEMBLY (MOD 3757) (See page NL19)	—	—	
EA3.80.657	. PITOT AND STATIC PIPES (See page NAB1)	—	—	
EG9.11.1	. STRUCTURE, CENTRE FUSELAGE (See page HC1)	—	—	
EG9.56.1	. TANK, 300 GALLON, FORWARD INSTALLATION (MOD 4473) (See page QB1)	—	—	

R



FUSELAGE  
CENTRE FUSELAGE STRUCTURE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		STRUCTURE, CENTRE FUSELAGE, ASSEMBLY (E.G9.11.1)	—	—	—	
		Spares for:—				
	13091 E.A3.11.655	BOLT, special (Make from A25/4E)	10	—	C	26/1
	7275 E.A3.11.677	BOLT, special (Make from A25/4C)	10	—	C	26/2
R	1438951 E.A1.11.1603	BOLT, special attachment, bulkhead to floor girder at frame 17	2	S.11	C	26/3
R	1438952 E.A1.11.1605	BOLT, special attachment, bulkhead to floor girder at frame 17	5	S.11	C	26/4
	41 E.A1.11.163	BULKHEAD, rear fuel tank (Pre-Mod. 55)	1	—	A	26/5
	3503 E.A3.11.15	BULKHEAD, rear fuel tank (Mod. 55)	1	—	A	26/6
	42 E.A1.11.313	BULKHEAD, fuel tank, at frame 17 (Pre-Mod. 55)	1	—	A	26/7
	4773 E.A1.11.3551	BULKHEAD, fuel tank, at frame 17 (Mod. 55)	1	—	A	26/8
	28N/9513425 AGS.899/12	COLLAR, shackle pin, hydraulic jack pick-up bracket connecting pin, forward	1	—	C	28/1
	28N/4043777 AGS.899/18	COLLAR, shackle pin, hydraulic jack pick-up bracket connecting pin, aft	1	—	C	28/2
	1438748 E.G9.11.3	DOOR, BOMB, PORT, ASSEMBLY	1	—	B	23/1
		Spares for:—				
	11491 E.A1.11.823	BRACKET, DOOR, ROLLER GUIDE, FRAME 15, ASSEMBLY	1	L.40	B	23/2
		Spares for:—				
	237 E.A1.11.837	ROLLER	1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—				
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin	1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 20 SWG	1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/7
		Attaching parts for E.A1.11.823:—				
	15825 E.A1.11.1573	Bolt, special, 1/4" BSF	2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, 1/4" BSF hex. head	2	—	C	23/9
	11492 E.A1.11.825	BRACKET, DOOR, ROLLER GUIDE, FRAME 17, ASSEMBLY	1	L.40	B	23/10
		Spares for:—				
	237 E.A1.11.837	ROLLER	1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—				
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin	1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/7
		Attaching parts for E.A1.11.825:—				
	15825 E.A1.11.1573	Bolt, special, 1/4" BSF	2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, 1/4" BSF hex. head	2	—	C	23/9
	11493 E.A1.11.827	BRACKET, DOOR, ROLLER GUIDE, FRAME 19, ASSEMBLY	1	L.40	B	23/11
		Spares for:—				
	237 E.A1.11.837	ROLLER	1	L.40	C	23/3
		Attaching parts for E.A1.11.837:—				
	236 E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/4
	28M/1011470 A27/GT	Nut, 5/16" BSF thin	1	—	C	23/5
	11588 E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/6
	28W/9419476 SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/7
		Attaching parts for E.A1.11.827:—				
	15825 E.A1.11.1573	Bolt, special, 1/4" BSF	2	S.96	C	23/8
	28D/1011240 A25/5E	Bolt, 1/4" BSF hex. head	2	—	C	23/9

FUSELAGE  
CENTRE FUSELAGE STRUCTURE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index	1 2 3 4 5 6 7									
							1	2	3	4	5	6	7			
11494	E.A1.11.829	BRACKET, DOOR ROLLER GUIDE, FRAME 23, ASSEMBLY Spares for:—	1	L.40	B	23/12										
237	E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—	1	L.40	C	23/13										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/14										
28M/1011470	A27/GT	Nut, 5/16" BSF thin	1	—	C	23/15										
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16										
28W/9419476	SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/17										
28D/1011240	A25/5E	Attaching parts for E.A1.11.829:— Bolt, 1/4" BSF hex. head	4	—	C	23/18										
11495	E.A1.11.831	BRACKET, DOOR, ROLLER GUIDE, FRAME 25, ASSEMBLY Spares for:—	1	L.40	B	23/19										
237	E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—	1	L.40	C	23/13										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/14										
28M/1011470	A27/GT	Nut, 5/16" BSF thin	1	—	C	23/15										
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16										
28W/9419476	SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/17										
28D/1011240	A25/5E	Attaching parts for E.A1.11.831:— Bolt, 1/4" BSF hex. head	4	—	C	23/18										
11496	E.A1.11.833	BRACKET, DOOR, ROLLER GUIDE, FRAME 27B, ASSEMBLY Spares for:—	1	L.40	B	23/20										
237	E.A1.11.837	ROLLER Attaching parts for E.A1.11.837:—	1	L.40	C	23/13										
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/14										
28M/1011470	A27/GT	Nut, 5/16" BSF thin	1	—	C	23/15										
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16										
28W/9419476	SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/17										
28D/1011240	A25/5E	Attaching parts for E.A1.11.833:— Bolt, 1/4" BSF hex. head	4	—	C	23/18										
11497	E.A1.11.845	BRACKET, ROLLER, MOUNTING, BOMB DOOR CENTRE TRACK, GROUP Spares for:—	1	—	B	23/21										
241	E.A1.11.847	ROLLER, locating Attaching parts for E.A1.11.847:—	1	BSS.369	C	23/22										
28D/1212730	AS.1242/30E	Bolt, 1/4" BSF c'sk head	1	—	C	23/23										
28M/1011475	A27/EP	Nut, 1/4" BSF plain	1	—	C	23/24										
239	E.A1.11.853	Pin, special	1	S.94, S.95 or S.96	C	23/25										
244	E.A1.11.857	Washer, special	1	DTD.124	C	23/26										
28W/9994217	SP.18/E	Washer, 1/4" BSF plain	1	—	C	23/27										
242	E.A1.11.849	ROLLER, main Attaching parts for E.A1.11.849:—	1	BSS.369	C	23/28										
240	E.A1.11.855	Pin, special	1	S.94, S.95 or S.96	C	23/29										

AP.101B-0418-3A

## FUSELAGE

## CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.11.1365	. . . ROLLER, main Attaching parts for EA1.11.1365:-	1	BSS369	23/30
A27EP	. . . Nut, 1/4" BSF plain	1	-	23/31
EA1.11.851	. . . Pin, special, 1/4" BSF	1	S.94, S.95 or S.96	23/32
EA1.11.1367	. . . Washer, special	1	S.94, S.95 or S.96	23/33
SP13E	. . . Washer, 1/4" BSF plain Attaching parts for EA1.11.845:-	2	-	23/34
A25/6E	. . Bolt, 1/4" BSF hex head	2	-	23/35
A25/10J	. . Bolt, 3/8" BSF hex head	1	-	23/36
AGS2001J1	. . Nut, stiff, 3/8" BSF	1	-	23/37
EA1.11.1327	. . Stud, special 3/8" BSF	1	HTS.SH	23/38
SP47E	. . Washer, 1/4" BSF spring	2	-	23/39
SP47J	. . Washer, 3/8" BSF spring	1	-	23/40
EA1.11.1177	. . CONNECTION, main hinge stay forward Attaching parts for EA1.11.1177:-	1	L.40	24/1
A25/3C	. . Bolt, 2 BA hex head	4	-	24/2
EA1.11.1179	. . CONNECTION, main hinge stay aft Attaching parts for EA1.11.1179:-	1	L.40	24/3
A25/3C	. . Bolt, 2 BA hex head	4	-	24/4
-	. . DUCT CONDUIT ATTACHMENT (EG9.82.573) Spares for:-	-	-	24/5
AS3180/5C	. . . CLIP, 'P' Attaching parts for AS3180/5C:-	1	-	24/6
A25/1C	. . . Bolt, 2 BA hex head	1	-	24/7
SP13C	. . . Washer, 2 BA plain	1	-	24/8
EB6.82.737	. . . DUCT, cable Attaching parts for EB6.82.737:-	1	-	24/9
AS1246/1C	. . . Bolt, 2 BA round head	2	-	24/10
A25/1C	. . . Bolt, 2 BA hex head	1	-	24/11
AS3181/16C	. . . Clip, 'P'	1	-	24/12
SP15C	. . . Washer, 2 BA plain	1	-	24/13
EA1.11.1441	. . FLAP, roller spring hinged clearance	1	-	25/1
EA1.11.2563	. . FLAP, hinged	1	-	25/2
EA1.11.933	. . HINGE BOMB DOOR MAIN BRACKET REAR END ASSEMBLY Spares for:-	1	-	25/3
EA1.11.927	. . . BEARING, journal	1	DTD197	25/4
EA1.11.929	. . . BEARING, journal	1	DTD197	25/5
EA1.11.1467	. . . BRACKET Attaching parts for EA1.11.1467:-	1	L.40	25/6
A25/1C	. . . Bolt, 2 BA hex head	2	-	25/7
SP47C	. . . Washer, 2 BA spring Attaching parts for EA1.11.933:-	2	-	25/8
A25/4E	. . Bolt, 1/4" BSF hex head	6	-	25/9
A25/7J	. . Bolt, 3/8" BSF hex head	2	-	25/10
A25/7L	. . Bolt, 7/16" BSF hex head	2	-	25/11
EA1.11.2621	. . Shim laminated	1	Lam Alum	25/12

FUSELAGE  
CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.
EA1.11.935	. . HINGE BOMB DOOR MAIN BRACKET FORWARD END ASSEMBLY (Supplied to Part No. EA3.00.1001 for spares purposes) Spares for:-	1	L.40	25/13
EA1.11.929	. . . BEARING, journal	1	DTD.197	25/14
EA1.11.931	. . . BEARING, journal	1	DTD.197	25/15
EA1.11.1467	. . . BRACKET Attaching parts for EA1.11.1467:-	1	L.40	25/16
A25/3C	. . . Bolt, 2 BA hex head	2	-	25/17
A27CP	. . . Nut, 2 BA plain Attaching parts for EA1.11.935:-	2	-	25/18
A25/4C	. . Bolt, 2 BA hex head	6	-	25/19
A25/6G	. . Bolt, 5/16" BSF hex head	2	-	25/20
EA1.11.1601	. . Bolt, special 7/16" BSF	2	HTS.S11	25/21
EA1.11.3197	. . Shim, laminated	1	Lam Alum	25/22
EA1.11.1607	. . HINGE, flap roller clearance (Make from AS1878/15, Ref 28N/10786	1	-	25/23
EG5.82.261	. . PANEL, removable aerial aperture Attaching parts for EG5.82.261:-	1	-	24/14
AS1248/1C	. . Bolt, 2 BA mushroom head	4	-	24/15
AS1248/2C	. . Bolt, 2 BA mushroom head	1	-	24/16
AS1248/3C	. . Bolt, 2 BA mushroom head	1	-	24/17
EG5.82.293	. . PANEL, access Attaching parts for EG5.82.293:-	1	-	24/18
AS1248/2C	. . Bolt, 2 BA mushroom head	9	-	24/19
R EA3.11.117	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/20
R EA3.11.5191	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/20
R EA3.11.119	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/21
R EA3.11.5193	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/21
R EA3.11.121	. . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/22
R EA3.11.5195	. . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/22
EA1.11.1309	. . SPRING, leaf outboard clearance flap	1	Spring	25/24
EA1.11.1311	. . SPRING, leaf inboard clearance flap	1	Steel Spring Steel	25/25
EA1.11.1205	. . STAY, main hinge support assembly Attaching parts for EA1.11.1205:-	1	-	24/23
EA1.11.1231	. . Bolt, eye stay connection to door hinge	1	L.40	25/26
A25/3C	. . Bolt, 2 BA hex head	2	-	24/24
A27EP	. . Nut, 1/4" BSF plain	1	-	25/27
A27CP	. . Nut, 2 BA plain	2	-	24/25
EA1.11.1207	. . STAY, main hinge support assembly Attaching parts for EA1.11.1207:-	1	-	24/26 24/27
EA1.11.1231	. . Bolt, eye stay connection to door hinge	1	L.40	25/26
A25/3C	. . Bolt, 2 BA hex head	2	-	24/27
A27EP	. . Nut, 1/4" BSF plain	1	-	25/27
A27CP	. . Nut, 2 BA plain	2	-	24/28

A.P.101B-0418-3A		FUSELAGE CENTRE FUSELAGE STRUCTURE						Page HC5			
Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
3081	E.A1.11.1098	DOOR, BOMB, STARBOARD, ASSEMBLY						1	—	A	23/41
11491	E.A1.11.823	Spares for:— BRACKET, DOOR, ROLLER GUIDE, FRAME 15, ASSEMBLY						1	L.40	B	23/2
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/3
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/4
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/5
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/6
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22SWG						1	T.45	C	23/7
		Washer, 5/16" BSF plain						1	—	C	23/7
15825	E.A1.11.1573	Attaching parts for E.A1.11.823:—						2	S.96	C	23/8
28D/1011240	A25/5E	Bolt, special, 1/4" BSF						2	—	C	23/9
		Bolt, 1/4" BSF hex. head						2	—	C	23/9
11492	E.A1.11.825	BRACKET, DOOR ROLLER GUIDE, FRAME 17, ASSEMBLY						1	L.40	B	23/10
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/3
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/4
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/5
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/6
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/7
		Washer, 5/16" BSF plain						1	—	C	23/7
15825	E.A1.11.1573	Attaching parts for E.A1.11.825:—						2	S.96	C	23/8
28D/1011240	A25/5E	Bolt, special, 1/4" BSF						2	—	C	23/9
		Bolt, 1/4" BSF hex. head						2	—	C	23/9
11493	E.A1.11.827	BRACKET, DOOR ROLLER GUIDE, FRAME 19, ASSEMBLY						1	L.40	B	23/11
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/3
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/4
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/5
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/6
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/7
		Washer, 5/16" BSF plain						1	—	C	23/7
15825	E.A1.11.1573	Attaching parts for E.A1.11.827:—						2	—	C	23/8
28D/1011240	A25/5E	Bolt, special, 1/4" BSF						2	—	C	23/9
		Bolt, 1/4" BSF hex. head						2	—	C	23/9
11494	E.A1.11.829	BRACKET, DOOR ROLLER GUIDE, FRAME 23, ASSEMBLY						1	L.40	B	23/12
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/13
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/14
28M/1011470	A27/GT	Bolt, special, c/w lubricating nipple						1	—	C	23/15
11588	E.A1.11.1617	Nut, 5/16" BSF thin						1	—	C	23/16
28W/9419476	SP.15/G	Tube, 1/2" o/d x 1".04 x 22 SWG						1	T.45	C	23/17
		Washer, 5/16" BSF plain						1	—	C	23/17
28D/1011240	A.25/5E	Attaching parts for E.A1.11.829:—						4	—	C	23/18
		Bolt, 1/4" BSF hex. head						4	—	C	23/18
11495	E.A1.11.831	BRACKET, DOOR ROLLER GUIDE, FRAME 25, ASSEMBLY						1	L.40	B	23/19
237	E.A1.11.837	Spares for:— ROLLER						1	L.40	C	23/13
236	E.A1.11.1615	Attaching parts for E.A1.11.837:—						1	—	C	23/14
		Bolt, special, c/w lubricating nipple						1	—	C	23/14

Restricted

Page HC6

FUSELAGE  
CENTRE FUSELAGE STRUCTURE

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
28M/1011470	A27/GT	Nut, 5/16" BSF thin	1	—	C	23/15
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16
28W/9419476	SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/17
28D/1011240	A25/5E	Attaching parts for E.A1.11.831:—				
11496	E.A1.11.833	Bolt, 1/4" BSF hex. head	4	—	C	23/18
		BRACKET, DOOR ROLLER GUIDE, FRAME 27B, ASSEMBLY	1	L.40	B	23/20
		Spares for:—				
237	E.A1.11.837	ROLLER	1	L.40	C	23/13
		Attaching parts for E.A1.11.837:—				
236	E.A1.11.1615	Bolt, special, c/w lubricating nipple	1	—	C	23/14
28M/1011470	A27/GT	Nut, 5/16" BSF thin	1	—	C	23/15
11588	E.A1.11.1617	Tube, 1/2" o/d x 1".04 x 22 SWG	1	T.45	C	23/16
28W/9419476	SP.15/G	Washer, 5/16" BSF plain	1	—	C	23/17
28D/1011240	A25/5E	Attaching parts for E.A1.11.833:—				
		Bolt, 1/4" BSF hex. head	4	—	C	23/18
11497	E.A1.11.846	BRACKET, ROLLER MOUNTING, BOMB DOOR CENTRE TRACK, GROUP	1	DTD.300 Casting	B	23/42
		Spares for:—				
241	E.A1.11.847	ROLLER, locating	1	BSS.369	C	23/22
		Attaching parts for E.A1.11.847:—				
28D/1212730	AS.1242/30E	Bolt, 1/4" BSF c'sk head	1	—	C	23/23
28M/1011475	A27/EP	Nut, 1/4" BSF plain	1	—	C	23/24
239	E.A1.11.853	Pin, special	1	S.4, S.95 or S.96	C	23/25
244	E.A1.11.857	Washer, special	1	DTD.124	C	23/26
28W/9994217	SP.18/E	Washer, 1/4" BSF plain	1	—	C	23/27
242	E.A1.11.849	ROLLER, main	1	BSS.369	C	23/28
		Attaching parts for E.A1.11.849:—				
240	E.A1.11.855	Pin, special	1	S.94, S.95 or S.96	C	23/29
243	E.A1.11.1365	ROLLER, main	1	BSS.369	C	23/30
		Attaching parts for E.A1.11.1365:—				
28M/1011475	A27/EP	Nut, 1/4" BSF plain	1	—	C	23/31
238	E.A1.11.851	Pin, special, 1/4" BSF	1	S.94, S.95 or S.96	C	23/32
245	E.A1.11.1367	Washer, special	1	S.94, S.95 or S.96	C	23/33
28W/9418921	SP.13/E	Washer, 1/4" BSF plain	2	—	C	23/34
		Attaching parts for E.A1.11.846:—				
28D/1008145	A25/6E	Bolt, 1/4" BSF hex. head	2	—	C	23/35
28D/1011302	A25/10J	Bolt, 3/8" BSF hex. head	1	—	C	23/36
28M/10292	AGS.2001/J/1	Nut, stiff, 3/8" BSF	1	—	C	23/37
15807	E.A1.11.1327	Stud, special, 3/8" BSF	1	HTS.S11	C	23/38
28W/9416644	SP.47/E	Washer, 1/4" BSF spring	2	—	C	23/39
28W/9416646	SP.47/J	Washer, 3/8" BSF spring	1	—	C	23/40
15799	E.A1.11.1178	CONNECTING, main hinge stay, forward	1	L.40	C	24/29
		Attaching parts for E.A1.11.1178:—				
28D/9133012	A25/3C	Bolt, 2 BA hex. head	4	—	C	24/2
15801	E.A1.11.1180	CONNECTION, main hinge stay, aft	1	DTD.683	C	24/30
		Attaching parts for E.A1.11.1180:—				
28D/9133012	A25/3C	Bolt, 2 BA hex. head	4	—	C	24/4
247	E.A1.11.1441	FLAP, roller, spring hinged clearance	1	—	C	25/1
6868	E.A1.11.2563	FLAP, hinged	1	—	C	25/2

Restricted

## FUSELAGE

## CENTRE FUSELAGE STRUCTURE

Part Number	Description	No. Off	Matl. Spec.	Plate No.						
					1	2	3	4	5	6
EA1.11.934	. . . HINGE BOMB DOOR MAIN BRACKET REAR END ASSEMBLY Spares for:-	1	L.40	25/28						
EA1.11.927	. . . BEARING, journal	1	DTD197	25/4						
EA1.11.929	. . . BEARING, journal	1	DTD197	25/5						
EA1.11.1468	. . . BRACKET Attaching parts for EA1.11.1468:-	1	L.40	25/29						
A25/1C	. . . Bolt, 2 BA hex head	2	-	25/7						
SP47C	. . . Washer, 2 BA spring Attaching parts for EA1.11.934:-	2	-	25/8						
A25/4E	. . . Bolt, 1/4" BSF hex head	6	-	25/9						
A25/7J	. . . Bolt, 3/8" BSF hex head	2	-	25/10						
A25/7L	. . . Bolt, 7/16" BSF hex head	2	-	25/11						
EA1.11.2621	. . . Shim laminated	1	Lam Alum	25/12						
EA11.936	. . . HINGE BOMB DOOR MAIN BRACKET FORWARD END ASSEMBLY (Supplied to Part No. EA3.00.1002 for spares purposes) Spares for:-	1	L.40	25/30						
EA1.11.929	. . . BEARING, journal	1	DTD197	25/14						
EA1.11.931	. . . BEARING, journal	1	DTD197	25/15						
EA1.11.1468	. . . BRACKET Attaching parts for EA1.11.1468:-	1	L.40	25/31						
A25/3C	. . . Bolt, 2 BA hex head	2	-	25/17						
A27CP	. . . Nut, 2 BA plain Attaching parts for EA1.11.936:-	2	-	25/18						
A25/4C	. . . Bolt, 2 BA hex head	6	-	25/19						
A25/5G	. . . Bolt, 3/8" BSF hex head	2	-	25/20						
EA1.11.1601	. . . Bolt, special 7/16" BSF	2	HTS.S11	25/27						
EA1.11.3197	. . . Shim laminated	1	-	25/22						
EA1.11.1607	. . . HINGE, flap roller clearance (Make from AS1878/15, Ref. 28N/9511950)	1	-	25/23						
R EA3.11.117	. . . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/20						
R EA3.11.5191	. . . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/20						
R EA3.11.119	. . . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/21						
R EA3.11.5193	. . . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/21						
R EA3.11.121	. . . SEAL, 'P' (Pre-Mod 5282) (Make from EEAS123) (26FZ/4431)	1	-	24/22						
R EA3.11.5195	. . . SEAL, 'P' (Mod 5282) (Make from EEAS845) (26FZ/6147756)	1	-	24/22						
EA1.11.1309	. . . SPRING, leaf outboard clearance flap	1	Spring Steel	25/24						
EA1.11.1311	. . . SPRING, leaf inboard clearance flap	1	Spring Steel	25/25						
EA1.11.1205	. . . STAY, main hinge support assembly Attaching parts for EA1.11.1205:-	1	-	24/23						
EA1.11.1231	. . . Bolt, eye stay connection to door hinge	1	L.40	25/26						
A25/3C	. . . Bolt, 2 BA hex head	2	-	24/24						
A27EP	. . . Nut, 1/4" BSF plain	1	-	25/27						
A27CP	. . . Nut, 2 BA plain	2	-	24/25						
EA1.11.1207	. . . STAY, main hinge support assembly Attaching parts for EA1.11.1207:-	1	-	24/26						
EA1.11.1231	. . . Bolt, eye stay connection to door hinge	1	-	25/26						
A25/3C	. . . Bolt, 2 BA hex head	2	-	24/27						
A27EP	. . . Nut, 1/4" BSF plain	1	-	25/27						
A27CP	. . . Nut, 2 BA plain	2	-	24/28						

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.



LIGHTNING MK. 1  
COVER PITOT HEAD  
EB2-88-511