

GROUND EQUIPMENT

REF. NO.	PART NO.	DESCRIPTION					No. OFF	MATL. SPEC.	Class of Equip. M.R.	Plate and Illust'n. No.
		1	2	3	4	5				
	EA3-88-5029	EQUIPMENT, GROUND, Spares for:- identical to EA1-88-2. AP 4326B Vol.3, page 351 except for the following  Delete:-								
27D/2812	EA3-88-19	COVER, nose (Pre. Mod.1027)					1	-	B	
27D/2948	EA3-88-301	COVER, nose (Mod. 1027)					1	-	B	
27D/2666	EA1-88-597	COVER, pressure head					1	-	B	
95113	ALVIS AS.18086	HANDLE for Bomb trolley					1	-	A	
95080	AT.81489	HANDLE, crutching					1	-	B	
95086	EA3-88-135	SPANNER, special main U/C oleo axle clamp.					1	-	B	
		TROLLEY, BOMB LOADING, CONVERSION SET.					-	-	-	
		Add:-								
95506	EA3-88-5031	ADAPTOR, PLATFORM, ASSEMBLY used on bomb trolley for loading window launcher crate. Spares for:-					1	-	B	
32A/163	-	CORD, size 3					QR	F.59	C	
28FP/13	EA3-88-5007	HOOK, swinging assembly					4	-	-	
	AVIATION DEV.A421	PIN, quick release					4	-	C	
	EA9-97-1018	TAB, locking					4	-	-	
4G/4131	-	ADAPTOR d/w pressure gauge, 4G/3028 oleo charging					1	-	B	
4G/4139	-	SHIELD, main. U/C towing					1	-	B	
95511	EA3-88-5009	BUNG, intake, upper, port					1	-	B	
95510	EA3-88-5011	BUNG, intake lower starboard					1	-	B	
13142	EA1-88-873	CLAMP, elevator locking, (Port side only)					1	-	B	
95508	EA3-88-5041	COVER, window launcher crate					1	-	B	
27D/2962	-	COVER, pressure head					1	-	B	
26ET/95025	-	CHOCKS, used with nose and radome trolley					2	-	C	
26ET/95023	-	FORMER, fitted to trolley for radome transportation.					1	-	C	
4G/4426		FRAME, extension towing arm					1	-	B	
4Q/1245		GANTRY, main plane lifting					1	-	A	
4G/2595		GAUGE, pressure, modulator					1	-	A	
95449	EA9-88-39	HEAD, for 15 ton pillar jack MK.25					2	-	A	
10AK/684		HANDLE, lifting used with scanner trans- port trolley.					1	-	B	

RESTRICTED

GROUND EQUIPMENT

REF. NO.	PART NO.	DESCRIPTION					No. OFF	MATL. SPEC.	Class of Equipmt.	Plate and Illust'n. No.
		1	2	3	4	5			M.R.	
4Q/2657	-					JACK, pillar. 15 ton	1	-	A	
4Q/2625	-					JACK, main wing 10 ton	2	-	A	
10F/16881	-					LEAK INDICATOR, testing waveguide.	1	-	A	
4G/3966	-					MAT, mainplane	1	-	B	
	EA3-88-133					PIN, locking, flap switch (pre-mod.550)	1	-	-	
						Spares for:-				
28FF/2	AVIATION DEV. A.405					PIN, nip	1	-	C	
95471	EA9-88-71					PIN, locking windbreak door	1	-	C	
4G/5435	-					PUMP, pressurising, modulator	1	-	A	
4G/2764	-					PUMP, oleo charging	1	-	A	
	ND					ROPE, nose wheel pickrting	QR	-	-	
4F/2066	-					SLING, scanner	1	-	C	
4G/4232	-					SLING, R.A.3 engines	1	-	B	
95493	EA1-88-877					SPANNER, to release nose wheel up locks.	1	-	B	
	EB6-88-101					TOOL, separating, tab operating gear	1	-	-	
4Q/2266	-					TRESTLE, jacking, fuselage	1	-	A	
4Q/2652	-					TRESTLE MK.1 used with main wing jack.	1	-	A	
4F/2002	-					TROLLEY, air cooling MK.2A	1	-	A	
4G/2668	-					TROLLEY, bomb type F	1	-	A	
26MT/95006	-					TROLLEY, nose and radome	1	-	A	
4F/2058	-					TROLLEY, radome	1	-	A	
4F/1723	-					TROLLEY, radar servicing type B	1	-	A	
4F/1796	-					TROLLEY, servicing hydraulic MK.2A	1	-	A	
4F/1714	-					TROLLEY, testing cabin pressure	1	-	A	
4F/1913	-					TROLLEY, servicing and starting	1	-	A	
4F/1796	-					TROLLEY, servicing hydraulic MK.2A	1	-	A	

RESTRICTED

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

