

FUNCTIONAL CHECKS AND TESTS

List of Contents

SP No	Title
100	ARI 23232 - Radar Altimeter - Test.
101	Not Allocated.
102	UHF Standby - Installation.
103	Intercom - Installation. (External).
104	Telebrief - Installation.
105	UHF and UHF Homing (PTR 177) Installation.
106	ILS - Installation.
107	U/VHF and VHF Homing (PTR 175) - Installation.
108	ARI 23329/1, Sonar Locator Beacon - Self Test.
109- 299	Not Allocated.

P.F.6

Faint, illegible text, possibly bleed-through from the reverse side of the page. The text is centered and appears to be a list or a set of instructions.



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

