

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	-	FUEL SYSTEM IN STARBOARD WING, ASSEMBLY (E.F2.57.5) (MK. 2 A/C)	-	-	-	52/25
	-	FUEL SYSTEM IN STARBOARD WING, ASSEMBLY (E.F4.57.5) (MK. 2A A/C)	-	-	-	52/26
	-	Spares for:- PUMPS, fuel booster, rib 10-11, assembly	-	-	-	52/27
	-	(E.F2.57.521) Spares for:-				
23432	EEAS.552/9	BOBBIN, distance, ".75 long, pipe clip spacing	1	L65	C	52/4
2451	E.B1.57.495	CLIP, pipe (modified AGS.605) at rib 11	1	-	C	52/5
27FR/2325	F.R. LTD. FRS.73/K	COLLAR, split, fuel booster pump pipe connection ...	2	-	C	52/6
27FR/3518	F.R. LTD. FRS.525/K/1	CONNECTOR, lightweight pipe	1	-	B	52/7
27FR/2331	F.R. LTD. FRS.110/M/1	COUPLING, 2" fuel pipe	1	-	B	52/8
2456	E.B1.57.841	GASKET, fuel booster pump	2	Neo-K-Tex	C	52/9
4570	E.B3.57.23	PIPE, branch, assembly, from fuel booster pumps non-return valves connection to pipe connection at rib 9 on spar 1	1	-	C	52/28
	E.F2.57.844	PIPE, assembly, air continuation between ribs 10 and 11 on spar 1, ambient static pressure (Mod. 2053)	1	-	-	52/29
12644	E.F2.57.162	PIPE, vent, assembly, from connection at spar 3, rib 11, to forward of rib 12A	1	-	C	52/30
11903	E.B3.57.215 or	PIPE, assembly, from pipe connection at rib 9 to fuel recuperator connection on spar 1	1	-	C	52/13
4571	E.B3.57.25	PIPE, drain, fuel booster pumps	2	L54	LM	52/14
5UE/6674	E.B2.57.1925 SELF-PRIMING SPE.2437	PUMP, fuel booster	2	-	A	52/15
27FR/2433	F.R. LTD. FRS.151/K/1	SLEEVE, rubber, 3/4" non-return valve and fuel pipe connecting	2	-	C	52/16
27FR/2434	F.R. LTD. FRS.152/K	SLEEVE, outer, non-return valve and fuel pipe	2	-	C	52/17
26FZ/980	EEAS.20/1R	TAB, locking, 20 SWG	2	L72	C	52/18
27FR/3499	F.R. LTD. FR.9811112	VALVE, non-return, 1-1/2", on forward face of spar .. 1 between ribs 10 and 11	2	-	A	52/19
2490	E.B1.57.277	WASHER, sealing, fuel booster pump pipe	2	Neo-K-Tex	C	52/21
		connection joint				
11172	EEAS.239/1A	WASHER, "D"	3	L72	C	52/20
	-	RIB, 1:2, trailing edge, assembly (E.F2.57.43)	-	-	-	53/20
		Spares for:-				
	E.F2.57.465	ADAPTOR, special bulkhead	1	BAC.M37	-	53/21
		Attachments:-				
28D/9133012	A25/3C	Bolt, 2 BA hex. head	4	-	C	53/22
28W/9419402	SP13/C	Washer, 2 BA plain	3	-	C	53/23
27FR/2435	F.R. LTD. FRS.138/F	COLLAR, split, 3/4" fuel booster pump pipe	1	-	C	53/2
		connection				
27FR/3462	F.R. LTD. FRS.175/H/1	CONNECTION, lightweight	1	-	B	53/3
27FR/2331	F.R. LTD. FRS.110/M/1	COUPLING, fuel pipe	1	-	B	53/4
27FR/	F.R. LTD. FRS.380/M/1	COUPLING, fuel pipe	1	-	B	53/5

SERVICES

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	EEAS.164/12/20	HOSE, rubber, pipe connecting							2	DTD625 Type 1	LM	53/6
18074	E.B2.57.1080	PIPE, fuel, from recuperator fuel pipe connection on (Make from 32C/375)							1	—	C	53/24
1504092	E.B2.57.2621	PIPE, fuel, from recuperator fuel pipe connection on spar 5 to 2" connection at rib 1, 2" o/d x 20 SWG (Mk. 2 A/c) (Pre-Mod. 4355)							1	—	C	53/31
13112	E.B2.57.1102	PIPE, air branch, recuperator control and relief valve, assembly							1	—	C	53/25
21122	E.B2.57.2536	PIPE, drain, recuperator control valve							1	—	C	53/26
7846	PIONEER 3-142	RING, "O", sealing							1	—	C	53/12
12592	PIONEER 3-155	RING, "O", sealing							1	—	C	53/13
10791*	GEO. ANGUS R.155/P60											
1503719	GEO. ANGUS R.155/P6	RING, "O", sealing							1	—	C	
27FR/3529	F.R. LTD. FRS.229/F	SLEEVE, outer, 3/4" recuperator control valve pipe							1	—	C	53/15
27FR/2714	F.R. LTD. FRS.231/F/1	SLEEVE, rubber, 3/4" recuperator control valve pipe							1	—	C	53/16
4851	EEAS.20/1ER	TAB, locking							1	—	C	53/27
7971	E.B2.57.2151	VALVE, relief							1	—	C	53/17
18904	E.B2.57.2525	VALVE, recuperator control, group (Mod. 2117) Consisting of:—							1	—	B	54/1
	E.B2.57.2539	BODY, valve							1	—	—	54/2
4939	E.B2.57.589	BOLT, special							1	—	C	54/3
10798	E.B2.57.2307	BOLT, special							1	—	C	54/4
	E.B2.57.367	CAP, spring seating							1	S92 or S3	—	54/5
2546	E.B2.57.353	DIAPHRAGM							1	—	C	54/6
	E.B2.57.345	END-PLATE							1	L65	—	54/7
	E.B2.57.347	END-PLATE							1	L65	—	54/8
	E.B2.57.369	NUT, locking							1	L65	—	54/9
	E.B2.57.397	NUT, locking							1	S1	—	54/10
28M/9403520	A27/CP	NUT, 2 BA plain							12	—	C	54/11
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA							1	—	C	54/12
	E.B2.57.2529	PLUG, sealing							2	—	—	54/13
2547	PIONEER OS.21	RING, "O", sealig (Pioneer Ref. PO/13711213)							1	—	—	54/14
5976	PIONEER PO/08106210	RING, "O", sealing							1	—	C	54/15
28F/9429636	AGS.1186/3	SEAL, 2 BA bonded							1	—	C	54/18
28F/9129099	AGS.1186/4	SEAL, 1/4" BSF, bonded							2	—	C	54/19
28W/9149448	AGS.2035/B	WASHER, 4 BA shakeproof							2	—	C	54/30
	†	SEALANT, P.R.C.							QR	DTD900/4506	—	54/20
	E.B2.57.2315	SCREW, adjusting							1	L65	—	54/16
	or											
	E.B2.57.363											
	E.B2.57.371	SCREW, adjusting							1	S1	—	54/17
	E.B2.57.547	SPRING, coil							1	DTD215	—	54/21
	E.B2.57.549	SPRING, coil							1	DTD239	—	54/22
	E.B2.57.551	SPACER, spring							1	L65	—	54/23
2548	E.B2.57.355	TAB, locking							1	S515	C	54/24
11905	EEAS.20/1CS	TAB, locking							1	L65	C	54/25
2549	E.B2.57.359	UNION							1	L65	C	54/26
	E.B2.57.351	VALVE, shuttle							1	DTD197	—	54/27

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
28F/9130664	E.B2.57.365	WASHER, special recessed							1	L65	-	54/28
	AGS.1149/2	WASHER, plate							1	Alumn.	C	54/29
28W/9419475	SP15/C	WASHER, 2 BA, plain							1	-	C	54/31
28W/9449447	SP41/C	WASHER, tab, 2 BA							12	-	C	54/32
30A/3055	†	WIRE, locking, 22 SWG							QR	DTD189	C	54/33
	E.F2.57.923	VALVE, fuel, gate, assembly (Mod. 4156)							1	-	-	54/34
		(Pre-Mod. 4237)										
		Consisting of:-										
5W/6781	E.E. Co. B'FORD	ACTUATOR							1	-	A	54/35
		AE.4529 Mk. 4										
28D/1008151	A25/4E	BOLT, 1/4" BSF, hex. head							2	-	C	54/36
		E.F.2.57.921										
28M/7002430	AGS.2002/E/1	NAME-PLATE							1	L73	-	54/37
27F/5806	VICKERS	NUT, stiff, 1/4" BSF							2	-	C	54/38
		A.6046M										
		E.F.2.57.927										
		VALVE, fuel, gate, assembly (Mod. 4237)							1	-	-	54/40
		Consisting of:-										
5W/6781	E.E. Co. B'FORD	ACTUATOR							1	-	A	54/35
		AE.4529 Mk. 4										
28D/1008151	A25/4E	BOLT, 1/4" BSF, hex. head							2	-	C	54/36
		E.F.2.57.921										
28M/7002430	AGS.2002/E/1	NAME-PLATE							1	L73	-	54/37
27F/1444919	VICKERS	NUT, stiff, 1/4" BSF							2	-	C	54/38
		A.6217M										
27FR/30697	F.R. LTD.	VALVE, fuel, "R" type							1	-	A	54/39
		9807210/F										
27FR/30696	F.R. LTD.	VALVE, non-return, 3/4"							1	-	A	53/18
		B.9811246										
26FZ/22959	EEAS.152/C	VALVE, non-return							1	-	A	53/19
11906	EEAS.239/4A	WASHER, sealing							4	L65	C	53/20
10303	EEAS.240/1A	WASHER, "D"							4	L72	C	53/22
9842	EEAS.240/2A	WASHER, "D"							1	L72	C	52/23
		WASHER, "D"							3	L72	C	52/24
		RIB, 2-4, trailing edge, assembly (E.F.2.57.57)							-	-	-	55/78
		Spares for:-										
2449	E.B2.57.335	CLIP, pipe, special, for fuel cock pipe at trailing							1	L72	C	55/2
		edge, rib 3										
		Attachments:-										
28D/9133012	A25/3C	Bolt, 2 BA, hex. head							2	-	C	55/3
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA							2	-	C	55/4
28W/9419402	SP13/C	Washer, 2 BA, plain							2	-	C	55/5
26FR/2325	FLIGHT REFUELLING FRS.73/K	COLLAR, split, pipe connecting inboard of trailing							1	-	C	55/6
		edge										
6089	E.B2.57.1579	CONNECTOR, training edge fuel tank air pipe							1	-	C	55/7
27FR/2329	FLIGHT REFUELLING FRS.110/K/1	COUPLING, fuel pipe, 1-1/2", inboard of trailing							1	-	B	55/8
		edge, rib 3										
27FR/2331	FLIGHT REFUELLING FRS.110/M/1	COUPLING, 2", recuperator fuel pipe							2	-	B	55/9

SERVICES

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6				
11907	E.F2.57.447							1	LFS21	C	55/11
28M/9419397	A25/12C							1	—	C	55/12
28M/1278190	AGS.2001/C/1							1	—	C	55/13
28W/9419402	SP13/C							1	—	C	55/14
12596	E.B2.20.2329							1	L65	C	55/15
	EEAS.164/12/20							1	DTD625	LM	55/16
									Type 1		
37069	E.B3.57.255							QR	L72	C	55/17
11913	E.F2.57.436							1	—	C	55/79
11914	E.B2.57.1088							1	—	C	55/80
	E.F2.57.839							1	L56	—	55/81
13397	E.B2.57.1447							1	—	C	55/22
1504093	E.B2.57.2623							1	—	C	55/97
	E.B2.57.1627							1	—	—	55/23
2473*	G. ANGUS E.124/P60							1	—	C	55/24
1504591	GEO. ANGUS R.124/P5							1	—	C	
12592	PIONEER 3.155							1	—	C	55/28
	or										
10791*	GEO. ANGUS R.155/P60							1	—	C	
1503719	GEO. ANGUS R.155/P5							1	—	C	
2478	PIONEER 11P.12507525/B							1	—	C	55/26
27FR/2433	F.R. LTD. F.R.S.151/K/1							1	—	C	55/27
27FR/2434	F.R. LTD. FRS.152/K/1							1	—	C	55/28
27FR/30698	F.R. LTD. 9809060							1	—	A	55/29
	E.F2.57.923							1	—	—	54/34
5W/6781	E.E. Co. B'FORD AE.4529 Mk. 4							1	—	A	54/35
28D/1008151	A25/4E							2	—	C	54/36
	E.F2.57.921							1	L73	—	54/37
28M/7002430	AGS.2002/E/1							2	—	C	54/38
27F/5806	VICKERS A.6046M							1	—	A	54/39
	E.F2.57/927							1	—	—	54/40
5W/6781	E.E. Co. B'FORD AE.4529 Mk. 4							1	—	A	54/35
28D/1008151	A25/4E							2	—	C	54/36

SERVICES

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
27FR/2352	F.R. LTD.	COUPLING, 3/4"	1	—	B	55/58
5K/3389	FRS.132/F/1 AS.3360/C/4C	LEAD, bonding, at pipe connector outboard of trailing edge rib 10	1	—	C	55/59
20829	E.F.3.57.544	PIPE, fuel, from 3/4" pipe connection inboard of trailing edge rib 15 to 3/4" pipe connection outboard of trailing edge rib 10 to spar 5 (Mod. 2053)	1	—	C	55/90
—	—	RIBS, 14-17, trailing edge, assembly (E.B2.57.1844) (Mk. 2 A/c)	1	—	—	55/91
—	—	RIBS, 14-17, trailing edge, assembly (E.F3.57.1464) (Mk. 2A A/c)	—	—	—	55/92
2453	E.B2.57.1039	Spares for:—				
27FR/2327	F.R. LTD.	CONNECTOR, fuel pipe at trailing edge rib 16	1	—	B	55/63
27FR/2352	FRS.110/H/1	COUPLING, flow sensing valve, series 1	2	—	B	55/64
27FR/2352	F.R. LTD.	COUPLING, 3/4"	2	—	B	55/65
12596	E.B2.20.3129	FERRULE	1	L65	C	55/66
37069	E.B3.57.255	PACKING, ferrule, rib 16 (Mod. 4116)	QR	L72	C	55/67
1440071	E.F3.57.1465	PIPE, fuel (Mk. 2A A/c)	1	—	C	55/68
12637	E.B2.57.1502	PIPE, fuel, from connector at trailing edge rib 16 to 3/4" pipe connection inboard of trailing edge rib 17	1	—	C	55/93
12636	E.B2.57.1504	PIPE, fuel, from 3/4" connection inboard of trailing edge rib 15 to flow sensing valve	1	—	C	55/94
12368	E.B2.57.1846	PIPE, fuel, from flow sensing valve to 3/4" connection inboard of trailing edge rib 17	1	—	C	55/95
30553	E.B2.57.2494	PIPE, drain, from flow sensing valve (Mod. 2018) (Mk. 2 A/c)	1	L56	C	55/96
27FR/2324	F.R. LTD.	RING, split, flow sensing valve pipe connection (Mk. 2 A/c)	1	—	C	55/73
27FR/3004	FRS.73/H	SLEEVE, rubber, flow sensing valve pipe (Mk. 2 A/c)	1	—	C	55/74
26FR/3787	F.R. LTD.	SLEEVE, outer, flow sensing valve pipe (Mk. 2 A/c)	1	—	C	55/75
2478	FRS.152/H	SEAL, fuel pipe connector at trailing edge rib 16	1	—	C	55/76
26FZ/980	PIONEER	TAB, locking, 20 SWG	1	L72	C	55/77
7935	EEAS.20/20R	VALVE, flow sensing, group (Mk. 2 A/c)	1	—	A	56/1
	E.B2.57.1505	Consisting of:—				
	E.B2.57.1507	BODY, valve outer	1	DTD304	—	56/2
	E.B2.57.1509	BODY, valve inner	1	L65	—	56/3
28D/9436920	A25/1C	BOLT, 2 BA, hex. head	2	—	C	56/4
	E.B2.57.1519	BUSH	1	DTD265	—	56/5
28N/13630	AUT'VE ENG.	CIRCLIP, internal, 2-7/8", Seeger type	1	—	C	56/6
8023	AUT'VE ENG.	CIRCLIP, external, 3/16", Seeger type	1	—	C	56/7
	E.B2.57.1533	CLIP, spring	1	DTD215	—	56/8
	E.B2.57.1513	GUIDE, spindle	1	L65	—	56/9
	E.B2.57.1517	GUIDE, spindle	1	L65	—	56/10
	E.B2.57.1949	HEAD, valve	1	L65	—	56/11
	E.B2.57.1527	HEAD, valve	1	L65	—	56/12
	E.B2.57.2073	PIECE, distance, valve head	1	L65	—	56/13
	E.B2.57.1745	PLATE, retaining (Mod. 2018)	1	S510	—	56/14
19193	E.B2.57.1743	PLUG, blanking	1	LA4	C	56/15
27QA/482	SP911B/10	RING, 'O', sealing, Dowty	1	—	C	56/16
	E.B2.57.1521	ROD, push	1	—	—	56/17

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	EEAS.28/10/1B	SHIM, laminated	1	-	-	56/18
	E.B2.57.1515	SPINDLE	1	S1	-	56/19
	E.B2.57.1525	SPRING, compression	1	DTD215	-	56/20
	E.B2.57.1529	SPRING, compression	1	DTD215	-	56/21
	E.B2.57.1523	SWITCH, micro, group	1	-	-	56/22
		Consisting of:-				
	E.B2.57.1543	BRACKET, mounting	1	L59	-	56/23
	E.B2.57.1547	LEVER	1	S513	-	56/24
	E.B2.57.1545	SPINDLE	-	-	-	56/25
		Attachments:-				
28P/1007947	SP9/A3	Pin, split	2	-	C	56/26
28W/9419473	SP15/A	Washer, 6 BA, plain	2	-	C	56/27
5CW/4615	BURGESS MS.1577	SWITCH, micro, "V3"	1	-	B	56/28
		Attachments:-				
28D/1008148	A25/5A	Bolt, 6 BA, hex. head	2	-	C	56/29
28M/10286	AGS.2001/A/1	Nut, stiff, 6 BA	2	-	C	56/30
28W/9419473	SP15/A	Washer	2	-	C	56/31
	E.B2.57.1531	WASHER, special	1	L65 or 72	-	56/32
28W/9419447	SP41/C	WASHER, tab, 2 BA	2	-	C	56/33
	-	SPAR 1, ribs 11-13, assembly (E.F2.57.332)	-	-	-	57/20
		Spares for:-				
	SANGAMO L3.335	CABLE, Duprensheath, inward vent valve heater	1	-	-	57/2
2451	E.B1.57.495	CLIP, pipe, inward vent valve hose clamping	2	-	C	57/3
26FZ/20459	EEAS.143/2	CLIP, pipe, 1/4" o/d, single	1	L72	C	57/4
27FR/2325	F.R. LTD. FRS.73/K	COLLAR, split, for bulkhead fitting at rib 13	1	-	C	57/5
27FR/2329	F.R. LTD. FRS.110/K/1	COUPLING, 1-1/2" non-return valve	1	-	B	57/6
2462	E.B1.57.493	JOINT, flexible, inward vent valve	1	Hycar	C	57/7
12633	E.B2.57.58	PIPE, assembly, air continuation, from rib 11 to inward vent valve coupling on spar 1	1	-	C	57/21
12632	E.B2.57.252	PIPE, assembly, air, from coupling on spar 1 to inward vent valve, ambient static pressure	1	-	C	57/22
11909	E.F2.57.317	PIPE, tank inward vent, from non-return valve to tank end connection on rib 12	1	-	C	57/10
2474*	G. ANGUS R.146/P60	RING, sealing, inward vent valve at rib 13	1	-	C	57/11
1504131	GEO. ANGUS R.146/P5	RING, sealing, inward vent valve at rib 13	1	-	C	57/12
27FR/2433	F.R. LTD. FRS.151/K/1	SEAL, rubber, non-return valve to inward vent valve connecting	1	-	C	57/13
27FR/2434	F.R. LTD. FRS.152/K/1	SLEEVE, outer, for bulkhead fitting at frame 13	1	-	C	57/14
2480	E.B1.20.5269	STUD, inward vent valve and flanged sleeve mounting	3	S95	C	57/15
27FR/30700	F.R. LTD. 9807170K	VALVE, non-return, 1-1/2"	1	-	A	57/16
27FR/2971	SELF PRIMING SPE.2341	VALVE, inward vent	1	-	A	57/23
2491	E.B1.20.5307	WASHER, sealing, tank inward vent pipe	1	Neo-K-Tex	C	57/18
2493	EEAS.21/9/DRH	WASHER, 20 SWG	2	L72	C	57/19
	-	SPAR 1, rib 2-10, assembly (E.F2.57.880) (Mod. 2053)	-	-	-	58/45
		Spares for:-				
19926	E.B4.73.773	BOBBIN, distance, ".5 long, pipe clip spacing	1	L64	C	58/2
23432	EEAS.552/9	BOBBIN, distance, ".75 long, pipe clip spacing	2	L65	C	58/3

SERVICES

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
21383	E.F3.57.588	BRACKET, for bonding clip outboard of rib 4	1	L72	C	58/46
		Attachments:—				
28D/9436920	A25/1C	Bolt, 2 BA, hex. head	1	—	C	58/5
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	2	—	C	58/6
28W/9419475	SP15/C	Washer, 2 BA, plain	2	—	C	58/7
7580	E.B2.57.1715	CLIP, bonding	1	L72	C	58/8
27FR/2479	F.R. LTD. FRS.73/J	COLLAR, split, for inward vent valve	1	—	C	58/9
27FR/3001	F.R. LTD. FRS.175/K/1	CONNECTOR, lightweight, 1-1/2"	2	—	B	58/10
27FR/2328	F.R. LTD. FRS.110/J/1	COUPLING, pipe and shuttle valve	4	—	B	58/11
27FR/3002	F.R. LTD. FRS.110/N/1	COUPLING, recuperator pipe joint	1	—	B	58/12
21386	E.F2.57.897	GROMMET, air pipe at leading edge rib 3	2	S/H 95	C	58/13
20844	BRIT. REFRASIL M.S.285	PAD, monel, jubilee clip at leading edge rib 9	1	—	C	58/14
12602	E.B2.57.1089	PIPE, fuel, from tank connection at leading edge rib 4 to connection at spar 1, 1-1/2" o/d x 22 SWG	1	—	C	58/15
12640	E.B2.57.1098	PIPE, fuel branch, from 1-1/4" connection inboard of leading edge rib 5 to shuttle valve and non-return valve connection	1	—	C	58/16
12604	E.B2.57.1445	PIPE, fuel, from shuttle valve connection at spar 1, 1-1/4" o/d x 22 SWG	1	—	C	58/17
10808	E.B2.57.1712	PIPE, assembly, air, from recuperator to joint at spar 1 between leading edge ribs 7 and 8	1	—	C	58/47
21930	E.F2.57.846	PIPE, assembly, air, from connection at leading edge rib 2 to connection at leading edge rib 10, ambient static pressure	1	—	C	58/48
12605	E.B2.57.2271	PIPE, fuel branch, from tank connection at leading edge rib 4A to branch pipe connection at inboard leading edge rib 5, 1-1/4" o/d x 22 SWG	1	—	C	58/20
	E.B2.57.1054	RECUPERATOR, fuel, group	1	—	—	58/49
		Spares for:—				
12639	E.B2.57.1066	ADAPTOR, fuel pipes and air inlet to recuperator	1	DTD721	C	58/50
2464	E.B1.57.109	BLADDER (Pre-Mod. 2442)	1	Hycatrol 257	C	58/23
23812	E.B2.57.2551	BLADDER (Mod. 2442)	1	Hycatrol 257	C	58/24
2465	E.B1.57.89	CONE, clamping	1	L65	C	58/25
2553	E.B1.57.611	INLET, tube, assembly	1	—	C	58/26
11910	E.B2.57.1067	INLET, air	1	S92	C	58/27
2466	E.B1.57.95	JOINT, expansion	1	—	C	58/28
2467	E.B2.57.1059	JOINT, expansion, board	1	—	C	58/29
2468	E.B1.57.99	NUT, clamping	1	L65	C	58/30
2469	E.B1.57.101	NUT, air inlet pipe locking	3	S92	C	58/31
28M/9403520	A27/CP	NUT, 2 BA, plain, expansion joint attachment	24	—	C	58/32
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA	24	—	C	58/33
2470	E.B1.57.107	RING, sealing, expansion joint and seating (Pre-Mod. 4450)	5	Neo-K-Tex	C	58/34
1504375	E.B2.57.2651	RING, sealing (Mod. 4450)	5	Neo-K-Tex	C	58/51
2554	E.B1.57.103	WASHER, sealing, between air inlet and recuperator insert	1	L34	C	58/35
2471	E.B1.57.105	WASHER, air inlet pipe locknut	2	L17 or L34 bar	C	58/36
28W/9419475	SP15/C	WASHER, 2 BA, plain	24	—	C	58/37
28W/9416643	SP47/C	WASHER, 2 BA, spring, expansion joint attach- ment	24	—	C	58/38

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
2473*	G. ANGUS R.124/P60	RING, sealing, recuperator air pipe connection at spar 1	1	-	C	58/39
1504591	G. ANGUS R.124/P5	RING, sealing, recuperator air pipe connection at spar 1	1	-	C	
27FR/3006	F.R. LTD. FRS.151/J/1	SLEEVE, rubber, recuperator	1	-	C	58/40
27FR/3180	F.R. LTD. FRS.152/J	SLEEVE, outer, recuperator	1	-	C	58/41
27FR/30181	F.R. LTD. B.9813110	VALVE, shuttle (Pre-Mod. 2501)	1	-	A	58/42
27FR/32593	F.R. LTD. B.9813160	VALVE, shuttle (Mod. 2501)	1	-	A	58/43
11172	EEAS.239/1A	WASHER, "D"	4	L72	C	58/44
9842	EEAS.240/2A	WASHER, "D"	9	L72	C	
	-	SPAR 4-5, ribs 6-8, assembly (E.B2.57.1820)	-	-	-	58/19
		Spares for:-				
5UE/6492	PULSOMETER PDC.1001 Mk. 1	ELEMENT, fuel transfer pump (Pre-Mod. 266) (Pre-Mod. 2152)	1	-	A	58/2
R 5UE/10703	LUCAS TPE.103	ELEMENT, fuel transfer pump (Mod. 4752)	1	-	A	58/3
5UE/6492	PULSOMETER PDC.1001 Mk. 2	ELEMENT, fuel transfer pump (Mod. 2152) (Pre-Mod. 2134)	1	-	A	58/4
5UE/7507	PULSOMETER PDC.1001 Mk. 3	ELEMENT, fuel transfer pump (Mod. 2134)	1	-	A	58/5
7959	E.B2.57.1688	PIPE, fuel, from recuperator connection to branch pipe at spar 5, group Consisting of:-	1	-	C	58/20
27FR/2331	FLIGHT REFUELLING FRS.110/M/1 E.B2.57.1666	COUPLING, recuperator joint	1	-	C	58/7
7300	PIONEER 5-008-MP802	PIPE, fuel	1	-	-	58/21
		RING, "O"	1	-	C	58/9
27QA/863	DOWTY SP.911B/6	RING, sealing, 2-1/4" i/d x 2-1/2" o/d (Pre-Mod. 266)	1	-	C	58/10
27QA/862	DOWTY GD.1456B/29	RING, sealing, 2-9/16" i/d x 2-3/4" o/d (Pre-Mod. 266)	1	-	C	58/11
27QA/939	DOWTY GD.1456B/33	RING, sealing, 2-13/16" o/d x 3" o/d (Pre-Mod. 266)	1	-	C	58/12
5UE/9650	LUCAS 77381084	RING, sealing (Mod. 4301)	1	-	C	58/13
5UE/9651	LUCAS 77381085	RING, sealing (Mod. 4301)	1	-	C	58/14
5UE/9652	LUCAS 77381086	RING, sealing (Mod. 4301)	1	-	C	58/15
	-	TANK, leading edge, assembly (E.B2.57.1816)	-	-	-	58/22
		Spares for:-				
5UE/6492	PULSOMETER PDC.1001 Mk. 1	ELEMENT, fuel transfer (Pre-Mod. 266) (Pre-Mod. 2152)	1	-	A	58/2
R 5UE/10703	J. LUCAS LTD. TPE.103	ELEMENT, fuel transfer pump (Mod. 4752)	1	-	A	58/3
5UE/6492	PULSOMETER PDC.1001 Mk. 2	ELEMENT, fuel transfer pump (Mod. 2152) (Pre-Mod. 2134)	1	-	A	58/4
5UE/7507	PULSOMETER PDC.1001 Mk. 3	ELEMENT, fuel transfer pump (Mod. 2134)	1	-	A	58/5
27QA/863	DOWTY SP911B/6	RING, sealing (Pre-Mod. 266)	1	-	C	58/10
27QA/862	DOWTY GD.1456B/29	RING, sealing, 2-9/16" i/d x 2-3/4" o/d (Pre-Mod. 266)	1	-	C	58/11

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
27QA/939	DOWTY GD.1456B/33	RING, sealing, 2-13/16" i/d x 3" o/d (Pre-Mod. 266) ..	1	-	C	59/12
5UE/9650	LUCAS 77381084	RING, sealing (Mod. 4301)	1	-	C	59/13
5UE/9651	LUCAS 77381085	RING, sealing (Mod. 4301)	1	-	C	59/14
5UE/9652	LUCAS 77381086	RING, sealing (Mod. 4301)	1	-	C	59/15
33H/126	†	SEALANT	QR	DTD 900/4506	C	59/17
33H/122	†	SEALANT	QR	DTD 900/4501	C	59/18
-	-	WING-ROOT, assembly (E.F.2.57.33) (Mk. 2 A/c)	-	-	-	60/38
-	-	WING-ROOT, assembly (E.F.4.57.37) (Mk. 2A A/c)	-	-	-	60/39
		Spares for:-				
19926	E.B4.73.773	BOBBIN, distance, ".5 long pipe clip spacing	2	L64	C	60/3
		(Mod. 2053)				
4349	EEAS.196/2-1/2C	BOLT, 2 BA, 120° c'sk head	5	S94 or 95	C	60/4
	E.F.2.57.769	BRACKET, mounting, float valve	1	-	-	60/5
6A/6927	SANGAMO L5.338	CABLE, neoprene black, float switch	2	-	C	60/6
6A/6731	SANGAMO L5.390	CABLE, neoprene black, outward vent valve	1	-	C	60/7
4880	E.B2.57.1237	CLIP, non-return valve attachment at wing rib 1	1	-	C	60/8
27FR/3462	F.R. LTD. FRS.175/H/1	CONNECTOR, lightweight, 1"	1	-	B	60/9
8473	E.B2.57.2245	COWLING, outward vent valve	1	S515	C	60/10
9349	E.B2.57.1375	GASKET, 1/32" thick	2	Neo-K-Tex	C	60/11
21047	E.F3.57.609	GROMMET, for air pipe at rib 1 (Mod. 2053)	1	DTD560	C	60/12
	DUNLOP DC.402/A13	HOSE, flexible, outward vent valve	1	-	B	60/13
11911	DUNLOP AHO.34103/16	HOSE, flexible	1	-	C	60/14
33641	E.F.2.57.913	PIPE, assembly, air, from float valve to air pipe	1	-	C	60/40
		connection on spar 1 (Mod. 2383)				
33640	E.F.2.57.915	PIPE, assembly, air, from float valve to pipe coupling ..	1	-	C	60/41
		at diaphragm "A" (Mod. 2383)				
33639	E.F.2.57.917	PIPE, assembly, air, from float valve to air pipe	1	-	C	60/42
		connection on spar 1 (Mod. 2383)				
	E.F.2.57.803	PIPE, assembly, air, from 4-way piece to spar 1 float ..	1	L56	-	60/43
		valve (Mod. 2053)				
	E.F.2.57.799	PIPE, assembly, air, from fuselage tee connection to ..	1	L56	-	60/44
		elbow at leading edge rib 1 (Mod. 2053)				
	E.F.2.57.805	PIPE, assembly, air, from float valve tee to static	1	L56	-	60/45
		head connection, ambient static pressure line (Mod. 2053)				
	E.F.2.57.842	PIPE, assembly, air, from cone union at leading	1	L56	-	60/46
		edge rib 1 to connection at leading edge rib 2 (Mod. 2053)				
1440072	E.F3.57.1533	PIPE, assembly, balance, from port to starboard wing ..	1	L54	C	60/47
		forward of spar 1 (Mk. 2A A/c)				
		Attachments:-				
28D/9133012	A25/3C	Bolt, 2 BA, hex. head	6	-	C	60/48
	E.F3.57.1567	Plate, packing	2	L72	-	60/49
28F/9429636	AGS.1186/3	Seal, bonded, 2 BA	6	-	C	60/50
28W/9419402	SP13/C	Washer, 2 BA, plain	6	-	C	60/51
	E.F3.57.1567	PLATE, packing	2	-	-	60/54

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
2475*	GEO. ANGUS R.187/P60								1	—	C	60/25
	GEO. ANGUS R.187/P5								1	—	—	
5CW/8722	F.R. LTD. 3504100/184								1	—	A	60/26
5CW/13678	F.R. LTD. 3504100/288								1	—	A	60/27
5F/401209	AV/T40								QR	—	C	60/28
	3662 E.B2.62.385								1	—	C	60/29
	7972 E.B2.57.1557								1	—	A	60/30
27F/5558	SELF-PRIMING SPE.2680								1	—	A	60/31
27F/6660	SELF-PRIMING SPE.20261								1	—	A	60/32
	or											
27F/7671	—								1	—	A	60/33
27F/5522	SELF-PRIMING SPE.2562								1	—	A	60/52
	10303 EEAS.240/1A								4	L72	C	60/34
	8475 E.B2.57.2242								1	—	C	60/53
28M/1010658	A25/1B								4	—	C	60/36
28W/9419465	SP13/B								4	—	C	60/37

SERVICES

FUEL SYSTEM IN STARBOARD WING

Ref. No.	Part No.								No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

