

HYDRAULIC EQUIPMENT COMPONENTS, PORT WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	-	HYDRAULIC EQUIPMENT COMPONENTS, PORT WING . (E.F.2.73.19) (Mk. 2 A/c)	-	-	-	
	-	HYDRAULIC EQUIPMENT COMPONENTS, PORT WING . (E.F.4.73.235) (Mk. 2A A/c) (Mod. 4437) Consisting of:-	-	-	-	
6T/601	HOBSON	AUTOSTABILISER, aileron	1	-	A	138/1
27Q/70401	DOWTY ROTOL TYPE 214 Mk. 2	COUPLING, swivel, wheel brakes	1	-	B	138/2
27Q/1982	DOWTY ROTOL 1.00632.003	COUPLING, swivel, undercarriage door jack "up"	1	-	A	138/3
27Q/70297	DOWTY ROTOL C.8779/MKA	COUPLING, swivel, inboard trailing edge flap jack "up" .	1	-	B	138/4
27Q/1984	DOWTY ROTOL 100434.00.1	COUPLING, swivel, outboard trailing edge flap jack "up"	1	-	A	138/5
27Q/1985	DOWTY ROTOL C.8781Y MKA	COUPLING, swivel, outboard trailing edge flap jack	1	-	A	138/6
27Q/1986	DOWTY ROTOL C.8782Y MKA	"down"				
27Q/1986	DOWTY ROTOL C.8783Y MKA	COUPLING, swivel, inboard trailing edge flap jack	1	-	A	138/7
27Q/1987	DOWTY ROTOL C.8783Y MKA	"down"				
27Q/1987	DOWTY ROTOL C.8784Y MKA	COUPLING, swivel, undercarriage door jack "down"	2	-	A	138/8
12150	PALMER D.10630	FILTER, micronic, group	1	-	A	138/9
		Consisting of:-				
28N/9128964	AGS.596/B	CAP, dust	1	-	C	
28N/9143884	AGS.596/C	CAP, dust	1	-	C	
	D.20063	CASING, inlet	1	-	-	
	D.20064	CASING, outlet	1	-	-	
12151	D.2134	ELEMENT, assembly	1	-	A	
	D.29901	NAMEPLATE	1	-	-	
12153	AQ.330/2	PLUG, dust	1	-	C	
12154	AQ.330/4	PLUG, duct	1	-	C	
12152	D.20198	WASHER, rubber	1	-	C	
27QM/30201	DOWTY ROTOL 5373	JACK, undercarriage door	1	-	A	138/10
27QM/1491196	DOWTY ROTOL 104.266.001	JACK, undercarriage door lock (Mod. 4764)	1	-	A	138/11
27QM/30357	DOWTY ROTOL J.1027	JACK, trailing edge, "inboard" and "outboard"	2	-	A	138/12
27QM/71202	DOWTY ROTOL 1.03003.009	JACK, undercarriage (Mod. 4062) (Pre-Mod. 4112)	1	-	A	138/13
27QM/71287	DOWTY ROTOL 1.03003.011	JACK, undercarriage (Mod. 4112) (Pre-Mod. 4220)	1	-	A	138/14
27QM/1446623	DOWTY ROTOL 1.03003.012	JACK, undercarriage (Mod. 4220) (Pre Mod. 4396)	1	-	A	138/15
27QM/1448511	DOWTY ROTOL 1.03003.013	JACK, undercarriage (Mod. 4396)	1	-	A	138/65
27KH/3147	HOBSON CHA.101580/3	JACK, aileron, inboard and outboard (Type 203 Mk. 3) .. (For spares see AP.4515T, Vol. 3, Part 1, Sect. 2, Chap. 5)	2	-	A	138/16
27VA/5538	DUNLOP 4.W3.101.8.10.34 or	PIPE, flexible, wheel brake pressure	1	-	B	138/17
R 27VA/6115892	4.W2.101.8.10.34					
36568	PALMER FP.404/1032	PIPE, flexible, undercarriage "down" lock jack	1	-	B	138/18
6102392	PALMER AERO 813502895	(Mod. 4051) (Pre-Mod. 4643)				
		PIPE, flexible, undercarriage "down" lock (Mod. 4643) ..	1	-	-	
26VA/5540	DUNLOP 4.W3.102.8.9.17.2 or	PIPE, flexible, undercarriage emergency	1	-	B	138/19
R 27VA/6115890	4.W2.102.8.9.17.2					

SERVICES

HYDRAULIC EQUIPMENT COMPONENTS, PORT WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
27VA/5541	DUNLOP	PIPE, flexible, undercarriage jack "up" (Pre Mod. 1881)	1	—	B	138/20
	DC.202B/14.2					
13203	PALMER	PIPE, flexible, undercarriage jack "up" (Mod. 1881)	1	—	B	138/21
	FP.406/369	(Pre-Mod. 4643)				
R 6102391	PALMER AERO	PIPE, flexible, undercarriage "up" (Mod. 4643)	1	—	B	
	813502881					
R 27VA/5542	DUNLOP	PIPE, flexible, undercarriage jack "down"	1	—	B	138/22
	6.W3.102.8.9.16.8					
	or					
R 27VA/6115891	6.W2.102.8.9.16.8					
27VA/5543	DUNLOP	PIPE, flexible, maxaret return	1	—	B	138/23
	DC.400A/40					
27VA/5544	DUNLOP	PIPE, flexible, maxaret return	1	—	B	138/24
	DC.400C/36					
5212	DUNLOP	PIPE, flexible, inboard and outboard aileron jack	2	—	B	138/25
	AHO.30869	pressure				
7566	DUNLOP	PIPE, flexible, inboard and outboard jack return	2	—	B	138/26
	AHO.34589					
6A/4295	SANGAMO	PLATE, mounting (Mod. 4437)	1	—	C	
	169500					
27UA/5284	DUNLOP	RELAY, pressure (Mod. 4437)	1	—	A	
	ACM.18798					
6A/5441	SANGAMO	TRANSMITTER, pressure (Mod. 4437)	1	—	A	
	S.122/4/61					
27QM/70666	DOWTY ROTOL	VALVE, sequence (Mod. 1958)	1	—	A	138/27
	1.00322.002					
27QM/70680	DOWTY ROTOL	VALVE, sequence (Mod. 1958)	1	—	A	138/29
	1.00321.001					
27Q/30221	DOWTY ROTOL	VALVE, shuttle, undercarriage door and door lock jacks .	2	—	B	138/30
	8423					
27Q/30220	DOWTY ROTOL	VALVE, shuttle, undercarriage jack	1	—	A	138/31
	8420					
27QM/70376	DOWTY ROTOL	VALVE, relief	1	—	A	138/32
	H.5055					
27Y/184	ELECTRO HYDS.	VALVE, hydraulic relay, assembly	1	—	A	
	6960/1					
		Consisting of:—				
27Y/	696013	BODY	1	DTD130A	—	
27Y/4866	696015	CAP, end, 1/8" BSP	1	—	C	
27Y/6238	696014	CAP, end, 1/4" BSP	1	S96	C	
27Y/6239	696017	PLUNGER	1	DTD525	C	
27Y/4423	696020	RING, gland, plunger to body	1	—	C	
27Y/4424	84M/12A-15	RING, plunger head	1	—	C	
27Y/4425	85M/12A-16	RING, plunger head	1	—	C	
27Y/6100477	85M12a-227D	RING, sealing	1	—	C	
27Y/4426	88M/14-16	RING, sealing, valve seat	1	—	C	
27Y/6100478	88M14-227D	RING, sealing	1	—	C	
28F/9434374	AGS.1186/E	SEAL, bonded, 1/8" BSP, end cap to valve body	1	—	C	
28F/9429532	AGS.1186/C	SEAL, bonded, 1/4" BSP, end cap to valve seat	1	—	C	
27Y/4427	696016	SEAT, valve	1	—	C	
27Y/4428	696019	SPRING, plunger	1	—	C	
R 27W/1952	LOCKHEED	SPRING, valve	1	—	C	
	UNC.729					
27Y/6240	696018	VALVE	1	—	C	
27Y/	696021	WASHER, at gland ring	1	L1	—	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

