

Internal Checks — continued

T5 ONLY

Lower Left Side

Canopy operating handle	Up
Ram air valve	CLOSED (fully down)
Demist lever	Operate over full range. Leave slightly open
Oxygen shut-off valves ...	Both open
Throttle servo	ENGAGE. Check spring release. Leave DISENGAGED
JPT controllers	AUTO (wired)
Emergency U/C	Fully down
IFF	SBY. Modes 1 and 3/A selected, mode 2 off. MIL selected. Codes as required
Emergency lights	Off (check function at night)
Flap selector	UP

Upper Left Side

Canopy jack release lever	Outboard (wired)
Frequency card lighting	Test at night
Accelerometer ▶◀ ...	Reset
Pressure override ...	OFF
Airmix control	Pulled out, light on; pushed in, light out
Throttles	Check full range, including reheat. Set at HP COCKS OFF

(continued)

This file was downloaded
from the RTFM Library:

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

