

Internal Checks (T5) — continued**Front Centre**

Probe light	Off
AAR switch	OFF
AAR lights	Out. Dimmer as required
Speed display	Orange disc not visible. Leader spot between reference bars
Altimeter	Orange disc not visible. Set zero. Cross-check with standby altimeter
RCDI	Zero
Attitude indicator	Erect within 3 minutes of MRG ON. Orange disc not visible

Navigation display:

Compass mode	COMP/DG to COMP, check window black. Synchronised and annunciating. Check heading pointer control. Standby DI synchronised (blue light out)
ILS mode	Check display and control of localiser index. Switch off ILS, display centres
TAC/DL modes	Check display and off-set function
◀ Accelerometer	Reset post-SEM/036/STC ▶
E2B compass	Compare with nav display
Autopilot:			
Master	OFF (supplies indicator white/OFF)
Stab	OFF
Mode keys	ATTITUDE
Stick switches	Both OFF

Centre Pedestal

SWP	Cover hinge pin engaged. Day/night screen as required. Test
Ventral tank jettison	Fully in
Canopy jettison handle	Vertical
Seat harnesses	Not interconnected

(continued)

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm
Please see site for usage terms,
and more aircraft documents.

