

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

4109

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	-	ASSEMBLY OF UNDERCARRIAGE TO PORT WING (E.B3.00.13)	-	-	-	
		Spares for:-				
2960	E.B1.20.2263	BELL-CRANK, arm, for latch operating mechanism complete	1	-	C	4/1
		Attachments:-				
28M/1011467	A27/ES	Nut, 1/4" BSF, slotted	1	-	C	4/2
28P/1007741	SP9/C8	Pin, split	1	-	C	4/3
28W/9418921	SP13/E	Washer, 1/4" BSF	1	-	C	4/4
2961	E.B1.20.2285	BELL-CRANK, arm, master latch end complete	1	-	C	4A/5
2963	E.B1.20.5609	BOLT, special, c/w grease nipple, for main undercarriage door hinge, outboard	1	-	C	4/6
		Attachments:-				
28M/1011467	A27/ES	Nut, 1/4" BSF, slotted	1	-	C	4/7
13650	E.F2.20.1017	Plate, locking (Mod. 1907)	1	S514 20 SWG	C	4/8
28P/1007741	SP9/C8	Pin, split, 1/16" dia. x 1" long	1	-	C	4/9
28S/9463125	4101/6/ 3/8	Screw, P.K. (Mod. 1907)	1	-	C	4/10
2964	E.B1.20.5611	Tube, bearing	1	DTD525	C	4/11
29722	E.B2.20.7763	Washer, 1/4" BSF, special	1	-	C	4/12
5269	E.B2.20.6695	BOLT, special, main undercarriage door lever to operating jack connecting, complete	1	-	C	4C/13
		Attachments:-				
28M/5808571	A27/GS	Nut, 5/16" BSF, slotted	1	-	C	4C/14
28P/1007741	SP9/C8	Pin, split, 1/16" dia. x 1" long	1	-	C	4C/15
28M/9419403	SP13/G	Washer, 5/16" BSF, plain	1	-	C	4C/16
5270	E.B1.20.7107	BOLT, special, main undercarriage door inboard hinge (Pre-Mod. 1907)	1	DTD625	C	
		Attachments:-				
28M/5808571	A27/GS	Nut, 5/16" BSF, slotted	1	-	C	
28P/1007741	SP9/C8	Pin, split, 1/16" dia. x 1" long	1	-	C	
5273	E.B1.20.7633	Washer, special	1	-	C	
13648	E.F2.20.1011	BOLT, special, main undercarriage door inboard hinge (Mod. 1907)	1	S96	C	4/17
		Attachments:-				
28M/5808571	A27/GS	Nut, 3/16" BSF, slotted	1	-	C	4/18
28P/9419403	SP9/C8	Pin, split	1	-	C	4/19
13649	E.F2.20.1015	Plate, locking	1	S514 20 SWG	C	4/20
28S/9463125	4101/6/ 3/8	Screw, P.K.	1	-	C	4/21
5273	E.B1.20.7633	Washer, special	1	-	C	4/22
2967	E.B1.20.7623	BOLT, special, main undercarriage 'up' latch jack attachment to master latch operating lever	1	S96	C	4A/23
36064	E.F3.40.23	BRACKET, saddle, attaching aft flap actuating link to undercarriage radius rod (Mod. 2391)	1	L65	C	4B/24
		Attachments:-				
28D/9436920	A25/1C	Bolt, 2 BA, hex. head	4	-	C	4B/25
28W/9419475	SP15/C	Washer, 2 BA, thick	4	-	C	4B/26

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

111

Ref. No.	Part No.	Description	No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		BRACKET, stop, main undercarriage attachment, group (E.B2.20.9621) (Mod. 1830) Consisting of:-	-	-	-	
12521	E.B2.20.9619	BRACKET, stop, undercarriage 'up'	1	-	C	4A/27
		Attachments:-				
28D/9706306	A25/17E	Bolt, 1/4" BSF, hex. head	2	-	C	4A/28
28M/1011467	A27/ES	Nut, 1/4" BSF, slotted	2	-	C	4A/29
28P/1006943	SP9/C6	Pin, split	2	-	C	4A/30
12522	E.B2.20.9613	SHIM, laminated	1	LA3	C	4A/31
12523	E.B2.20.9615	SHIM, laminated	1	LA3	C	4A/32
5271	E.B1.20.7109	BUSH, sliding, for main undercarriage door inboard hinge	1	DTD625	C	4/33
31	E.B1.20.1879	FAIRING, fixed, main undercarriage leg, group	1	-	A	4B/34
		Spares for:-				
6207	E.B2.20.7999	BOLT, special, forward hinge fairing flap attachment	1	S96	C	4C/35
6208	E.B2.20.7997	BOLT, special, forward hinge fairing flap attachment, inboard	1	S96	C	4C/36
1484232	E.F2.07.85	BRACKET, hinge, outboard (E.F2.20.713)	1	-	C	4C/37
9958	E.B1.20.2709	BRACKET, fixed fairing to main undercarriage leg attachment, outboard forward position, assembly	1	-	C	4B/38
		Spares for:-				
22504	E.B1.20.2715	WASHER, special, belville	2	DTD187A or 271	C	4B/39
		Attachments:-				
28D/1200119	A25/4C	Bolt, 2" BA, hex. head	4	-	C	4B/40
12503	E.B1.20.2719	BRACKET, fixed fairing to main undercarriage leg attachment inboard forward position, assembly	1	-	C	4B/41
		Spares for:-				
22504	E.B1.20.2715	WASHER, special, belville	2	DTD187A or 271	C	4B/42
		Attachments:-				
28D/1200119	A25/4C	Bolt, 2" BA, hex. head	4	-	C	4B/43
9960	E.B1.20.2725	BRACKET, fixed fairing to main undercarriage leg attachment, inboard forward intermediate position, assembly	1	-	C	4B/44
		Spares for:-				
22504	E.B1.20.2715	WASHER, special, belville	2	DTD187A or 271	C	4B/45
		Attachments:-				
28D/9133012	A25/3C	Bolt, 2" BA, hex. head	4	-	C	4B/46
9961	E.B1.20.2731	BRACKET, fixed fairing to main undercarriage leg attachment, inboard centre position, group	1	-	C	4B/47
		Spares for:-				
28M/1007403	A27/ET	NUT, 1/4" BSF, thin	1	-	C	4B/48
2973	E.B1.20.2743	SCREW, adjusting	1	-	C	4B/49
22504	E.B1.20.2715	WASHER, special, belville	2	DTD187A or 271	C	4B/50
		Attachments:-				
28D/9133012	A25/3C	Bolt, 2" BA, hex. head	6	-	C	4B/51

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
9963	E B1 20 2737	BRACKET, fixed fairing to main undercarriage leg attachment, inboard rear position, assembly Spares for:—	1	—	C	4B/52
22504	E B1 20 2715	WASHER, special, Bellevue	2	DTD187A or 271	C	4B/53
28D/9133012	A25/3C	Attachments:— Bolt, 2 BA, hex head	4	—	C	4B/54
9964	E B1 20 2745	BRACKET, fixed fairing to main undercarriage leg attachment, outboard rear position, assembly Spares for:—	1	—	C	4B/55
22504	E B1 20 2715	WASHER, special, Bellevue	2	DTD187A or 271	C	4B/56
28D/9133012	A25/3C	Attachments:— Bolt, 2 BA, hex head	4	—	C	4B/57
12504	E B1 20 2749	BRACKET, fixed fairing to main undercarriage leg attachment, outboard centre position, assembly Spares for:—	1	—	C	4B/58
22504	E B1 20 2715	WASHER, special, Bellevue	2	DTD187A or 271	C	4B/59
28D/9133012	A25/3C	Attachments:— Bolt, 2 BA, hex head	2	—	C	4B/60
28D/1200119	A25/4C	Bolt, 2 BA, hex head	1	—	C	4B/61
12471	E F2 20 709	BRACKET, hinge, outboard	1	—	C	4C/62
28N/2005098	AVIA'N DEVEL'S PH 190-3	Attachments:— Bolt, 'jd'	1	—	C	4C/63
28D/1214091	AS 1242/2C	Bolt, 2 BA, c'sk head	1	—	C	4C/64
28D/9133011	A25/2C	Bolt, 2 BA, hex head	2	—	C	4C/65
12506	E B2 81 8065	BRACKET, nut	1	—	C	
12507	E B2 81 8071	BRACKET, mounting	1	L72	C	
12505	E B2 20 8425	FAIRING, taxiing lamp	1	—	C	4B/68
	E B2 20 6469	PACKING, main undercarriage aft hinge fairing	1	L72	—	
12525	E B1 20 3107	PLATE, service	4	DTD546	C	4B/70
12527	E B1 20 3111	PLATE, service	1	DTD546	C	4B/71
12526	E B2 20 6987	PLATE, service	1	L73	C	4B/72
12508	E B1 20 8405	WASHER, special, fairing bracket attachment	9	S510 or S92	C	4B/73
12509	E B1 20 8407	WASHER, special, fairing bracket attachment	9	S510 or S92	C	4B/74
12510	E B1 20 8409	WASHER, special, fairing bracket attachment	2	S510 or S92	C	4B/75
29	E B3 20 53	FAIRING, hinged, forward, main undercarriage, group Spares for:—	1	—	A	4B/76
13749	E B2 07 613	BRACKET, catch, 'up-lock' (E B1 20.2895)	1	DTD721	C	4B/77
	E B2 20 8907	HINGE, outboard, group Spares for:—	1	—	—	4C/78
2974	E B1 20 2885	BUSH	2	Oilite	C	4C/79
2975	E B1 20 2887	BUSH	1	Oilite	C	4C/80
2976	E B1 20 2889	BUSH	1	Oilite	C	4C/81
10787	E B2 20 9297	FORK END, assembly	1	—	C	4C/82

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

111

Ref. No.	Part No.	Description	No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
28M/1011467	A27/ES	NUT, 1/4" BSF, slotted	1	-	C	4C/83
28P/1007741	SP9/C8	PIN, split	1	-	C	4C/84
28W/9418921	SP13/E	WASHER, 1/4" BSF, plain	1	-	C	4C/85
		Attachments:-				
28D/1215671	A59/15C	Bolt, 2 BA, hex. head	3	-	C	4C/86
28D/1215673	A59/17C	Bolt, 2 BA, hex. head	1	-	C	4C/87
28M/9433473	AGS.2002/C/1	Nut, stiff; 2 BA	4	-	C	4C/88
5379	E.B2.20.7567	Washer, special	1	L72	C	4C/89
	E.B1.20.2891	HINGE, inboard	1	-	-	4C/90
12511	E.B1.20.2923	PLATE, service	1	DTD546	C	
33*	E.B1.20.1675	FLAP, hinged, aft, main undercarriage, assembly	1	-	A	
		Spares for:-				
12514	EEAS.297/50/20C	BOLT, special, 2 BA, 120 deg. c'sk head	3	30/147	C	
37231	E.B2.07.803	BRACKET, aft, flap actuating link (E.B1.20.2537)	1	L65	C	
12513	E.B2.20.7519	SHIM, laminated	1	Lam. Alum.	C	
154	E.F3.20.2011	FLAP, hinge, aft main undercarriage fairing, assembly	1	-	A	4B/92
		Spares for:-				
12514	EEAS.297/50/20C	BOLT, special, 2 BA, 120 deg. c'sk head	3	30/147	C	
37231	E.B2.07.803	BRACKET, aft flap actuating link (E.B1.20.2537)	1	-	C	4B/94
33011	E.F3.20.2029	HINGE, undercarriage flap, assembly	1	-	C	4B/95
		Spares for:-				
	E.B2.20.9247	HINGE, main undercarriage fairing	1	S514	-	4B/96
	E.F3.20.2031	HINGE, aft, flap	1	S514	-	4B/97
	E.B2.20.9463	PIN, hinge	1	W1	-	4B/98
12513	E.B2.20.7519	SHIM, laminated	1	Lam. Alum.	C	
2982	E.B1.20.1903	LATCH, master, main undercarriage door, group	1	-	A	4A/100
		Spares for:-				
2983	E.B1.20.1921	BARREL, spring trigger mechanism, assembly	1	-	C	4A/101
		Spares for:-				
12519	E.B1.20.1929	SPRING, trigger mechanism	1	DTD215	C	4A/102
2984	E.B1.20.1947	BEARING, end, trigger mechanism	2	DTD412	C	4A/103
2985	E.B1.20.1935	BOLT, pivot for hook	1	S96	C	4A/104
2986	E.B1.20.1943	BOLT, special, for trigger mechanism pivot	1	S96	C	4A/105
2987	E.B1.20.1949	BOLT, special, for trigger mechanism	1	S96	C	4A/106
2988	E.B1.20.7619	BOLT, adjusting, hook limit stop	1	-	C	4A/107
28D/1214034	AS.1242/12C	BOLT, 2 BA, c'sk head, keep plates and stop fixing	1	-	C	4A/108
2989	E.B1.20.1905	HOOK, latch, group	1	-	C	4A/109
		Consisting of:-				
	E.B1.20.1953	BUSH, main	2	DTD265	-	4A/110
	E.B1.20.1955	BUSH, bottom	1	DTD412	-	4A/111
	E.B1.20.1957	BUSH, top	1	DTD265	-	4A/112
	E.B1.20.1951	HOOK	1	S96	-	4A/113
	or					
	E.B2.20.7595					
28N/13511	HOFFMANN CJ.1	JOINT, self-aligning	1	-	C	4A/114
2990	E.B1.20.1909	LINK, connecting, between trigger mechanism and hook c/w bush	1	-	C	4A/115

A.P.101B-1004-3A

Page JD5

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

1113

Ref. No.	Part No.	Description	No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
2991	E.B1.20.1907	MECHANISM, trigger, assembly	1	-	B	4A/116
		Spares for:-				
12517	E.B1.20.1965	BOLT, adjusting, lower	1	-	C	4A/117
12518	E.B1.20.1967	BOLT, adjusting, upper	1	-	C	4A/118
25159	E.B1.20.1969	STOP, segment	1	S96	C	4A/119
28N/9156370	SP21	NIPPLE, grease, for hook pivot bolt	1	-	C	4A/120
28M/1011467	A27/ES	NUT, 1/4" BSF, slotted, for trigger mechanism and connecting link	1	-	C	4A/121
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA, keep plates and stop fixing bolts	4	-	C	4A/122
10764	E.B2.20.8901	NUT, special, 2 BA	1	S113	C	4A/123
10786	E.B2.20.9215	NUT, special	1	-	C	4A/124
2992	E.B1.20.1915	PIECE, distance, shouldered, keep plates retaining	2	L65	C	4A/125
2993	E.B1.20.1917	PIECE, distance, plain, between keep plates	3	L65	C	4A/126
2994	E.B1.20.7621	PIECE, distance, for keep plates at hook limit stop	1	L62	C	4A/127
2995	E.B1.20.1931	PIN, special, lower spring barrel attachment to trigger mechanism	1	S96	C	4A/128
34478	E.B3.20.1945	PIN, toggle, trigger mechanism and hook connecting link	1	S96	-	4A/129
28P/1007741	SP9/C8	PIN, split, 1/16" dia. x 1" long, trigger mechanism pivot bolt and connecting link nuts retaining	2	-	C	4A/130
28P/1007740	SP9/B4	PIN, split, 3/4" dia. x 1/2" long, for lower spring barrel attachment pin	1	-	C	4A/131
2997	E.B1.20.1919	PLATE, locking, trigger mechanism and hook pivot bolts	2	L65	C	4A/132
28S/1011501	A33/C6	SCREW, 2 BA, c'sk head, locking plate securing	2	-	C	4A/133
2998	E.B1.20.7617	STOP, hook limit	1	L65	C	4A/134
2999	AUT'VE ENG.	TWICLIP, 5/16" BSF, toggle pin retaining	1	-	C	4A/135
3000	AUT'VE ENG.	TWICLIP, 7/16" BSF, main pivot bolt retaining	1	-	C	4A/136
28W/9419475	SP15/C	WASHER, 2 BA, plain, for lower spring barrel attachment pin	1	-	C	4A/137
		Attachments:-				
28D/1212387	A25/14G	Bolt, 5/16" BSF, hex. head	3	-	C	4A/138
28M/10291	AGS.2001/G/1	Nut, stiff, 5/16" BSF	3	-	C	4A/139
3001	E.B1.20.2269	LATCH, undercarriage door, c/w bushes	1	-	C	4A/140
35327	E.F3.20.4047	LINK, actuating, aft flap, assembly (Mod. 2391)	1	-	B	4B/141
		Spares for:-				
17693	E.B2.20.8937	PIN	1	S96	C	4B/142
22500	E.B4.20.9429	PIN, aft flap actuating link	1	S96	C	4B/143
2979	E.B2.20.9355	LINK, actuating, forward flap	1	-	C	4C/144
		Spares for:-				
	E.B2.20.3815	TUBE, assembly	1	-	-	4C/145
		Spares for:-				
29723	E.B2.20.7777	BOLT, special	2	S96	C	4C/146
3002	E.B1.20.2169	LINK, connecting, undercarriage door aft end latches, group	1	-	B	4/147
		Spares for:-				
3003	E.B1.20.2173	CONNECTOR, adjustable, c/w bush, group	1	-	C	4/148
		Spares for:-				
3004	E.B1.20.2461	NUT, lock (Make from A27/QT or S96)	1	-	C	4/149

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

111

Ref. No.	Part No.	Description	No. off	Mtl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
3005	E.B1.20.2255	LINK, drag, between latch mechanism and bell-crank lever, group Consisting of:—	1	—	B	
3006	E.B1.20.2253	BOLT, bell-crank lever connecting	1	S96	C	4/150
3007	E.B1.20.2261	BOLT, special, latch connecting	1	S96	C	4/151
28N/13511	HOFFMANN CJ.1	JOINT, self-aligning	1	—	C	4/152
28W/5808573	E.B1.20.2257	LINK, drag	1	0L65 ;	—	4/153
	A27/CS	NUT, 2 BA, slotted	2	—	C	4/154
	E.B1.20.2259	PIECE, distance, at latch end	2	L65	—	4/155
	E.B1.20.2295	PIECE, distance, at fork-end	2	L65	—	4/156
	28P/1007741	SP9/C8	PIN, split; 1/16" dia. x 1" long	2	—	C
28W/9419405	SP15/E	WASHER, 1/4" BSF, plain	3	—	C	4/158
1441421	E.B2.20.9515	LINK, tubular, for bell-crank, group (Mod. 4211) Consisting of:—	1	—	C	4A/159
3009	E.B1.20.2283	BOLT, special, 2 BA	2	S96	C	4A/160
3004	E.B1.20.2461	NUT, lock	1	S94 or S96	C	4A/161
28M/5808573	A27/CS	NUT, 2 BA, slotted	2	—	C	4A/162
28P/1007741	SP9/C8	PIN, split	2	—	C	4A/163
1441423	E.B2.20.9517	TUBE, assembly Spares for:—	1	—	—	4A/164
	E.B1.20.2277	COLLAR, spring retaining	1	L64	C	
	E.F3.20.4279	SLEEVE, screwed	1	L65	—	
	E.B1.20.2275	SLEEVE, protection	1	T55 or S521	C	
	28W/9471273	SP124/E	TUBE, 20 SWG	1	T4	—
12515	E.B1.20.2281	WASHER, 1/4" UNF, packing	2	—	C	4A/165
28FZ/1195	EEAS.37/14A	YUKE-END, screwed	1	L65 ;	C	4A/166
	28Q/9417277	Attachments:— Nipple, 4 BA	4	S96	C	4A/167
	EEAS.38/2A	Rivet, tucker, 3/16" dia., domed head	2	—	C	
1441425	E.F3.20.4271	Spoke, 4 BA (Make from 28R/6124)	2	S94, S95 or S96	LM	4A/169
	3010	Spring, compression	1	DTD215 or 239	C	4A/170
3011	E.B1.20.2289	LINK, forked, bell-crank connection, master latch end, group Consisting of:—	1	—	B	4A/171
28M/5808573	E.B1.20.2293	BOLT, special	2	S96	C	4A/172
	E.B1.20.2291	LINK, forked	1	L65	—	4A/173
	A27/CS	NUT, 2 BA, slotted	2	—	C	4A/174
	E.B1.20.2295	PIECE, distance	4	L65	—	4A/175
	28P/1007741	SP9/C8	PIN, split; 1/16" dia. x 1" long	2	—	C
3013	EEAS.28/1DER	WASHER	2	L72	C	4A/177
	E.B1.20.1899	MECHANISM, main undercarriage door micro-switch, group Spares for:—	1	—	A	4A/178
28D/9130080	AS.1242/9B	BOLT, 4 BA, c'sk head, micro-switch mounting	2	—	C	4/179
3014	E.B1.20.2619	HOUSING, plunger, group Spares for:—	1	—	C	4/180
3015	E.B1.20.2627	BUSH	1	DTD412	—	
	E.B2.20.9029	LATCH, undercarriage door 'up', group Consisting of:—	1	—	B	4/181
3006	E.B1.20.2253	BOLT, special, mechanism control connecting	1	S96	C	4/182
	E.B1.20.2467	BUSH, main pivot	2	DTD412	—	4/183

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

115

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
29794	E.B2.20.8715 or E.B2.20.8717	HOOK	1	S96	C	4/184
28M/5808573	A27/CS	NUT, 2 BA, slotted	1	-	C	4/185
28M/1007403	A27/ET	NUT, 1/4" BSF, thin	1	-	C	4/186
10766	E.B2.20.8995	PIN, locating	1	S96	C	4/187
28P/1006943	SP9/C6	PIN, split	1	-	C	4/188
28W/9418921	SP13/E	WASHER, 1/4" BSF, plain	1	-	C	4/189
3018	E.B1.20.2629	LEVER, door trip, group Spare for: -	1	-	B	4/190
2A/9500409	SKEFCO CBS.0	BEARING	1	-	C	4/191
28D/1200119	A25/4C	BOLT, 2 BA, hex. head	1	-	C	4/192
28M/5808573	A27/CS	NUT, 2 BA, slotted	1	-	C	4/193
28P/1007741	SP9/C8	PIN, split, 1/16" dia. x 1" long	1	-	C	4/194
3019	E.B1.20.3403	LEVER, trip	1	L65	C	4/195
3020	E.B1.20.8295	LINK, plunger	1	L65	C	4/196
3021	E.B1.20.2633	LINK-PLATE, for bell-crank	2	DTD546	C	4/197
3022	E.B1.20.8291	LINK-PLATE, for trigger, L.H.	1	L65	C	4/198
3023	E.B1.20.8292	LINK-PLATE, for trigger, R.H.	1	L65	C	4/199
3024	E.B1.20.8285	LINK-PLATE, mechanism travel	1	L65	C	4/200
28F/9156370	SP21	NIPPLE, grease	1	-	C	4/201
3025	E.B1.20.8289	NUT, special, trunnion, for travel adjustment	1	S96	C	4/202
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA, plunger housing and keep-plate retaining screw	7	-	C	4/203
28M/1278189	AGS.2001/B/1	NUT, stiff, 4 BA, for micro-switch mounting bolt	2	-	C	4/204
28M/1007403	A27/ET	NUT, 1/4" BSF, thin	1	-	C	4/205
3026	E.B1.20.2647	PIECE, distance, shouldered, between keep-plates	2	L65	C	4/206
3027	E.B1.20.2649	PIECE, distance, plain, for keep-plates	3	L65	C	4/207
3028	E.B1.20.2651	PIECE, distance, for trip lever	2	L65	C	4/208
3029	E.B1.20.2653	PIECE, distance, shouldered, for latch pivot	1	S96	C	4/209
3030	E.B1.20.2631	PIN, door trip lever and trigger pivot	2	S96	C	4/210
3031	E.B1.20.2635	PIN, link, long	2	S96	C	4/211
3032	E.B1.20.2637	PIN, link, short	1	S96	C	4/212
3033	E.B1.20.2641	PIN, plunger guide	1	S96	C	4/213
3034	E.B1.20.3407	PIN, trip lever pivot	1	S96	C	4/214
28P/1007741	SP9/C8	PIN, split, 1/16" dia. x 1" long, link washer retaining	6	-	C	4/215
3035	E.B1.20.2625	PLUNGER, micro-switch operating	1	S11	C	4/216
3036	E.B1.20.2621	PLUG, plunger spring retaining	1	L65	C	4/217
3037	E.B1.20.8267	ROD, mechanism travel adjustment	1	-	C	4/218
3038	EEAS.1/9C	SCREW, 2 BA, 120 deg. c'sk head, plunger housing and keep-plate retaining	7	S96	C	4/219
3039	E.B1.20.2623	SPRING, compression, plunger loading, 16 SWG X 3".63 free length	1	Spring Wire	C	4/220
5378	E.B1.20.8365	SPRING, torsion, for trip lever, 26 SWG	1	DTD215 or 239	C	4/221
5CW/10969	†	SWITCH, micro	1	-	B	4/222
3041	E.B1.20.8283	TRIGGER	1	S96	C	4/223
3042	E.B1.20.8287	TUBE, trunnion nut clamping	1	S96	C	4/224
3043	E.B1.20.8293	WASHER, link spacing	2	L65	C	4/225
28W/9419402	SP13/C	WASHER, 2 BA, plain, for link pins	6	-	C	4/226
28N/9156370	SP21	NIPPLE, grease	3	-	C	4/227

MAIN PLANE
ASSEMBLY OF UNDERCARRIAGE TO PORT WING

111

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
5275	E.B1.20.2747	PIECE, distance, for undercarriage door latch	2	L65	C	4/228
3044	E.B1.20.5091	Pin, hinge, main undercarriage door centre	1	S96	C	4/229
4878	E.B2.20.6229	Pin, pivot, main undercarriage latch bell-crank	1	S96	C	4/230
		Attachments:—				
28D/9133011	A25/2C	Bolt, 2 BA, hex. head	3	—	C	4/231
28M/5808573	A27/CS	Nut, 2 BA, slotted	3	—	C	4/232
28M/1011467	A27/ES	Nut, 1/4" BSF, slotted	1	—	C	
28P/1006943	SP9/C6	Pin, split, 1/16" dia.	3	—	C	4/233
28W/9419402	SP13/C	Washer, 2 BA, thin	3	—	C	4/234
28W/9418921	SP13/E	Washer, 1/4" BSF, thin	1	—	C	
5276	E.B1.20.7575	Pin, pivot, main undercarriage door latch bell-crank, c/w grease nipple	1	S96	C	4A/235
		Attachments:—				
28D/1214091	AS.1242/2C	Bolt, 2 BA, c'sk head	1	—	C	4A/236
5274	E.B1.20.7587	Stop, 12 SWG	1	L72	C	4A/237
3048	E.B1.20.7583	Pin, pivot, for main undercarriage door 'up' latch jack	1	S96	C	
35	E.B1.20.1481	SHAFT, main undercarriage pivot	1	S99	C	4C/239
3049	E.B2.20.1587	SHIM, for master latch	3	Laminated Alumn.	C	4A/240
8986	E.B2.20.8903	SHIM, undercarriage door stop (Mod. 56)	QR	Laminated Alumn.	C	
5263	E.B1.20.5565	TAB, locking, for main undercarriage door hinge pin	1	DTD546	C	4/242
		Attachments:—				
26FZ/5118	EEAS.134/3C	Bolt, 2 BA, 90 deg. c'sk head.	1	S97	C	4/243
28M/5808573	A27/CS	Nut, 2 BA, slotted	1	—	C	4/244
28P/1007741	SP9/C8	Pin, split, 1/16" dia. x 1" long	1	—	C	4/245
5272	E.B1.20.7111	TUBE, bearing, for main undercarriage door inboard hinge	1	DTD625	C	4/246
3052	E.B1.20.5567	WASHER, spacing, for main undercarriage 'up' lock linkage bell-crank	2	L65	C	4A/247

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

