

SERVICES  
FIRE EXTINGUISHING SYSTEM

1419

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	—	FIRE EXTINGUISHING SYSTEM (E.B2.60.3)	—	—	—	
		Spares for:—				
7375	E.B2.60.155	BLOCK, cable, retaining	4	L65	C	36/1
28D/9131782	AS.1242/2B	Attachments:— Bolt, 4:BA, c'sk head	4	—	C	36/2
	EEAS.552/3	BOBBIN, pipe clip spacing (Mod. 2039)	1	L65 or L65	—	
24765	EEAS.552/1	BOBBIN, pipe clip spacing	2	L65	C	
27N/264	GRAVINER Type 57A	BOTTLE, fire extinguisher	2	—	A	36/3
	E.B2.60.75	BRACKET, L.H., Graviner nozzle pipe clip attachment on frame 39	1	L59	MR	36/4
		Attachments:—				
28D/9436920	A25/1C	Bolt, 2:BA, hex. head	1	—	C	36/5
28D/9133011	A25/2C	Bolt, 2:BA, hex. head	1	—	C	36/6
28M/1278190	AGS.2001/C/1	Nut, stiff, 2:BA	2	—	C	36/7
	E.B2.60.77	BRACKET, pipe clip mounting at frame 36, starboard side	1	L72	—	36/8
		Attachments:—				
28D/9436920	A25/1C	Bolt, 2:BA, hex. head	2	—	C	36/9
28M/1278190	AGS.2001/C/1	Nut, stiff, 2:BA	2	—	C	36/10
7880	E.B2.11.17189	CABLE, assembly, fire extinguisher bottle steady	2	—	C	36/11
12K/1316	†	CARTRIDGE, fire extinguisher bottle, 2-pin, Mk. 3 (A716/3)	2	—	C	36/12
12K/1317	†	CARTRIDGE, fire extinguisher bottle, 3-pin, Mk. 3 (A717/3)	2	—	C	36/13
2946	KING A/C C.4205/1/A	CLAMP, pipe, at frames 42, 44, 45 and 46	2	—	C	36/14
28F/11852	AGS.1111/A	CONNECTOR, bulkhead, pipe	2	—	C	36/15
		Attachments:—				
28D/1010658	A25/1B	Bolt, 4:BA, hex. head	10	—	C	36/16
28D/	A25/1-1/2B	Bolt, 4:BA, hex. head	2	—	C	36/17
28M/1086618	AGS.2002/B/1	Nut, stiff, 4:BA	12	—	C	36/18
28F/9152415	AGS.1115/1	Plate, washer	2	—	C	36/19
11143	EEAS.20/7/CR	Tab, locking	2	L72	C	36/20
17976	E.F2.60.89	FAIRLEAD, assembly, at frame 45 (Mod. 1878)	2	—	C	36/53
		Attachments:—				
28D/1008149	A25/2B	Bolt, 4:BA, hex. head	8	—	C	36/54
28M/1086618	AGS.2002/B/1	Nut, stiff, 4:BA	8	—	C	36/55
28W/9419465	SP13/B	Washer, 4:BA, plain	8	—	C	36/56
17977	E.B2.60.183	FAIRLEAD, assembly, at frame 44, port (Mod. 1878)	1	—	C	36/57
		Attachments:—				
28D/1008149	A25/2B	Bolt, 4:BA, hex. head	4	—	C	36/58
28M/1086618	AGS.2002/B/1	Nut, stiff, 4:BA	2	—	C	36/59
28W/9419465	SP13/B	Washer, 4:BA, plain	4	—	C	36/60

SERVICES  
FIRE EXTINGUISHING SYSTEM

1420

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
17978	E.B2.60.184	FAIRLEAD, assembly, at frame 45, starboard (Mod. 1878)	1	—	C	36/61
28D/1008149	A25/2B	Attachments:— Bolt, 4:BA, hex. head	4	—	C	36/62
28M/1086618	AGS.2002/B/1	Nut, stiff, 4:BA	2	—	C	36/63
28W/9419465	SP13/B	Washer, 4:BA, plain	4	—	C	36/64
27N/265	GRAVINER Type A.594	INDICATOR, pressure relief discharge, assembly	2	—	C	36/21
27N/803	GRAVINER A.515	Spares for:— DISC, nylon, c/w sealing plug	1	—	C	36/22
2959	E.B2.57.185	NIPPLE, pipe coupling, at frames 34, 36, 46 and 49	5	BAC.M37	C	36/23
3171	E.B2.57.187	NIPPLE, pipe coupling, for connection aft of frame 48	1	BAC.M37	C	36/24
6003	E.B2.60.131	NIPPLE, pipe joint to fire extinguisher bottle	4	BAC.M37	C	36/25
2812	E.B2.75.1083	NIPPLE, pipe coupling, at frames 29, 39 and 47	4	S110	C	36/26
	E.B2.60.133	PAD, fire extinguisher bottle mounting	2	—	—	36/27
28P/5412	AGS.1551/2	PIN, locking, for pipe clamp at frames 42, 44, 45 and 46	2	—	C	36/28
	E.B2.60.11	PIPE, assembly, from connection aft of frame 36 to coupling at frame 34	1	T55	—	36/29
	E.B2.60.13	PIPE, assembly, from clamp connection aft of frame 48 to coupling aft of frame 36	1	T55	—	36/30
	E.B2.60.37	PIPE, assembly, from coupling forward of frame 39 to coupling aft of frame 48	1	T55	—	36/31
30559	E.B2.60.81	PIPE, assembly, upper engine forward fire extinguisher run, from bottle junction box to connection forward of frame 46	1	T55	C	36/32
	E.B2.60.85	PIPE, assembly, lower engine aft fire extinguisher run, from bottle junction box to connection aft of frame 42	1	T55	—	36/33
13414	E.B2.60.87	PIPE, assembly, lower engine forward fire extinguisher run, from bottle junction box to connection aft of frame 42	1	T55	C	36/34
17691	E.B2.60.101	PIPE, assembly, from transverse pipe coupling to branch pipe coupling at frame 29	1	T55	C	36/35
	E.B2.60.111	PIPE, assembly, transverse, at frame 29	1	DTD743 or T55	—	36/36
	E.B2.60.113	PIPE, assembly, transverse nozzle, forward of frame 39	1	DTD743 or T55	—	36/37
13115	E.B2.60.115	PIPE, assembly, branch from connection forward of frame 46 to nozzle connection aft of frame 47	1	DTD743 or T55	C	36/38
11037	E.B2.60.117	PIPE, assembly, transverse, from branch connection aft of frame 47	1	DTD743 or T55	C	36/39
13413	E.B2.60.123	PIPE, assembly, branch, nozzle, forward of frame 50	1	DTD743 or T55	C	36/40
31746	E.B3.60.67	PIPE, assembly, upper engine aft fire extinguisher run, from bottle junction box to connection forward of frame 47 (Mod. 1823)	1	T55	C	36/41

SERVICES  
FIRE EXTINGUISHING SYSTEM

1421

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
18082	E.B2.60.147	PIPE, assembly, from coupling aft of frame 48 to connection forward of frame 47	1	T55	C	36/42
	E.B2.60.157	PIPE, assembly, branch, from coupling at frame 34 to connections at frame 29	1	T55	-	36/43
13116	E.B2.60.163	PIPE, assembly, branch, from clamp coupling aft of frame 42 to nozzle pipe connections forward of frame 39	1	T55	C	36/44
	E.B2.60.165	PIPE, assembly, port nozzle, forward of frame 39	1	T55	-	36/45
	E.B2.60.173	PIPE, assembly, from banjo connection on fire extinguisher bottle head to bulkhead pipe connector on frame 45, port	1	-	-	36/46
13800	E.B2.60.174	PIPE, assembly, from banjo connection on fire extinguisher bottle head to bulkhead pipe connector on frame 45, starboard	1	-	C	36/47
19705	E.B2.60.175	PIPE, assembly, from bulkhead pipe connector on frame 45 to pressure relief discharge indicator, port	1	-	C	36/48
19706	E.B2.60.177	PIPE, assembly, from bulkhead pipe connector on frame 45 to pressure relief discharge indicator, starboard	1	-	C	36/49
28F/17672	AS.5401	SEAL, pipe clamp, at frames 42, 44, 45 and 46	2	-	C	36/50
26FZ/21984	EEAS.20/3CU	TAB, locking	3	S515	C	36/51
9842	EEAS.240/2A	WASHER, 'D'	1	L72	C	
30A/2296	†	WIRE, locking, 20 SWG	QR	DTD189	C	36/52

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

