

SERVICES
FUEL SYSTEM IN PORT WING

441

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	—	FUEL SYSTEM IN PORT WING, ASSEMBLY (E.B2.57.1003)	—	—	—	
	—	Spares for:—				
	—	PUMPS, fuel booster, ribs 10—11, assembly (E.B2.57.1829)	—	—	—	48/1
	—	Spares for:—				
27FR/2325	F.R. LTD. FRS.73/K	COLLAR, split, fuel booster pump pipe connection	2	—	C	48/2
27FR/2331	F.R. LTD. FRS.110/M/1	COUPLING, 2" fuel pipe	1	—	B	48/3
2456	E.B1.57.841	GASKET, fuel booster pump	2	Neo-K-Tex	C	48/4
4569	E.B3.57.21	PIPE, branch, assembly, from fuel booster pumps non-return valves connection to pipe connection at rib 9 on spar 1	1	—	C	48/5
4571	E.B3.57.25	PIPE, assembly, from pipe connection at rib 9 to fuel recuperator connection on spar 1	1	—	C	48/6
	or					
11903	E.B3.57.215 E.B2.57.55	PIPE, assembly, air continuation, between ribs 10 and 11 on spar 1, ambient static pressure	1	L56	—	48/7
	E.B2.57.1925	PIPE, drain, fuel booster pumps	2	L54	LM	48/8
5UE/6674	SELF PRIMING SPE.2437	PUMP, fuel booster	2	—	A	48/9
27FR/2433	F.R. LTD. FRS.151/K/1	SLEEVE, rubber, 3/4" non-return valve and fuel pipe connecting	2	—	C	48/10
27FR/2434	F.R. LTD. FRS.152/K/	SLEEVE, outer, non-return valve and fuel pipe connecting	2	—	C	48/11
26FZ/980	EEAS.20/1DR	TAB, locking, 20 SWG	2	L72	C	48/12
27FR/3499	F.R. LTD. FR.9811112	VALVE, non-return, 1-1/2" on forward face of spar 1 between ribs 10 and 11	2	—	A	48/13
2490	E.B1.57.277	WASHER, sealing, fuel booster pump pipe connection joint	2	Neo-K-Tex	C	48/14
	—	RIBS, 1—2, trailing edge, assembly (E.B2.57.1821)	—	—	—	49/1
	—	Spares for:—				
27FR/3462	F.R. LTD. FRS.175/H/1	CONNECTOR, lightweight, 1"	1	—	B	49/2
27FR/2331	F.R. LTD. FRS.110/M/1	COUPLING, fuel pipe	2	—	B	49/3
2460	EEAS.164/12/20	HOSE, rubber, pipe connecting	2	—	C	49/4
13803	E.B2.57.1079	PIPE, fuel, from recuperator fuel pipe connection on spar 5 to 2" connector at rib 1, 2" o/d x 20 SWG	1	L56	C	49/5
12338	E.B2.57.1101	PIPE, air branch, recuperator control and relief valve, assembly	1	—	C	49/6
	E.B2.57.2329	PIPE, bleed, non-return valve to connection at frame 42 (Mod. 1577)	1	30/166	—	49/18

SERVICES
FUEL SYSTEM IN PORT WING

442

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
	E.B2.57.2535	PIPE, drain, recuperator control valve (Mod. 2117)	1	—	C	49/7
27FR/2435	F.R. LTD. FRS.138/F	RING, split, 3/4", recuperator control valve	1	—	C	49/8
2477	PIONEER PO.22520013	RING, 'O' sealing, Vicker's fuel cock	1	—	C	49/9
12592 7846	3-155 PIONEER 3-142	RING, 'O' sealing	1	—	C	49/10
36485*	ANGUS R.142/P.60	RING, 'O' sealing	1	—	—	—
27FR/3529	F.R. LTD. FRS.229/F	SLEEVE, outer, 3/4" recuperator control valve pipe	1	—	C	49/11
27FR/2714	F.R. LTD. FRS.231/F/1	SLEEVE, rubber, 3/4", recuperator control valve pipe	1	—	C	49/12
27FR/30805	F.R. LTD. 9811245.B	VALVE, non-return (Mod. 1577)	1	—	C	49/19
28D/1200119	A25/4C	Attachments: Bolt, 2 BA, hex. head	1	—	C	—
28D/9133012	A25/3C	Bolt, 2 BA, hex. head	3	—	C	—
	E.B2.57.2317	Nipple	1	L65	—	—
	E.B2.57.2327	Flange	1	BAC.M37	—	—
4851	EEAS.20/ER	Tab, locking	1	L72	C	—
28F/9429636	AGS.1186/3	Seal, bonded	4	—	C	—
18904	E.B2.57.2525	VALVE, recuperator control, group (Mod. 2117) Consisting of:—	1	—	A	50/1
	E.B2.57.2539	BODY, valve (Mod. 2117)	1	—	—	50/2
4939	E.B2.57.589	BOLT, special	1	—	C	50/3
10798	E.B2.57.2307	BOLT, special	2	—	C	50/30
	E.B2.57.367	CAP, spring seating	1	S92 or S3	—	50/4
2546	E.B2.57.353	DIAPHRAGM	1	Neoprene Nylon Rein'd	C	50/5
	E.B2.57.345	END PLATE	1	L65	—	50/6
	E.B2.57.347	END PLATE	1	L65	—	50/7
	E.B2.57.369	NUT, locking	1	L65	—	50/8
	E.B2.57.397.	NUT, locking	1	S1	—	50/9
28M/9403520	A27/CP	NUT, 2 BA, plain	12	—	C	50/10
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA	1	—	C	50/11
	E.B2.57.2529	PLUG, sealing	2	—	C	50/31
2547	PIONEER 3-136	RING, 'O' sealing	1	—	C	50/32
5976	PIONEER PO/08106210	RING, 'O' sealing	1	—	C	50/13
	E.B2.57.363	SCREW, adjusting	1	L65	—	50/14
	or E.B2.57.2315 E.B2.57.371	SCREW, adjusting	1	S1	—	50/15

SERVICES
FUEL SYSTEM IN PORT WING

1443

Ref. No.	Part No.	Description	No. off	Mtrl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		SEALANT, P.R.C.	QR	-	-	
	BRITISH PAINTS DTD.900/4506					
	E.B2.57.547	SPRING, coil	1	DTD215	-	50/16
	E.B2.57.549	SPRING, coil	1	DTD239	-	50/17
	E.B2.57.551	SPACER, spring	1	L65	-	50/18
2548	E.B2.57.355	TAB, locking	1	S515	C	50/19
11905	EEAS.20/1CS	TAB, locking	1	L65	C	50/20
2549	E.B2.57.359	UNION	1	L65	C	50/21
	E.B2.57.351	VALVE, shuttle	1	DTD197	-	50/22
	E.B2.57.365	WASHER, special recessed	1	L65	-	50/23
				L72		
28W/1206041	AGS.2035/B	WASHER, locking, 4 BA	2	-	C	50/32
28F/9130664	AGS.1149/2	WASHER	1	Alumn.	C	50/24
28F/9429636	AGS.1186/3	SEAL, bonded	1	-	C	50/25
28F/9428450	AGS.1186/4	SEAL, bonded	2	-	C	50/26
28W/9419475	SP15/C	WASHER, 2 BA, plain	1	-	C	50/27
28W/9419447	SP41/C	WASHER, tab	12	-	C	50/28
30A/3055	†	WIRE, locking, 22 SWG	QR	DTD189	C	50/29
7971	E.B2.57.2151	VALVE, relief	1	-	B	48/15
	VICKERS A.5816M	VALVE, fuel, gate	1	-	A	48/16
		Consisting of:-				
5W/2408	PLESSEY CZ.54709/5	ACTUATOR	1	-	A	
27F/5551	VICKERS A.5881	VALVE	1	-	A	
27FR/3495	F.R. LTD. A9809050	VALVE, non-return, 3/4"	1	-	A	48/17
9842	EEAS.240/2A	WASHER, 'D'	2	L72	C	48/18
		RIBS, 2-4, trailing edge, assembly (E.B3.57.45)	-	-	-	
		Spares for:-				
2449	E.B2.57.335	CLIP, pipe, special, for fuel cock pipe at trailing edge, rib 3	1	L72	C	51/1
		Attachments:-				
28D/9133012	A25/3C	Bolt, 2 BA, hex. head	2	-	C	51/2
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	2	-	C	51/3
28W/9419402	SP13/C	Washer, 2 BA, plain	2	-	C	51/4
27FR/2325	F.R. LTD. FRS.73/K	COLLAR, split, for pipe connection inboard of trailing edge, rib 3	1	-	C	51/5
6089	E.B2.57.1579	CONNECTOR, trailing edge, fuel tank air pipe	1	-	B	51/6
27FR/2329	F.R. LTD. FRS.110/K/1	COUPLING, fuel pipe inboard of trailing edge, rib 3	1	-	B	51/7
27FR/2331	F.R. LTD. FRS.110/M/1	COUPLING, recuperator fuel pipe	2	-	B	51/8
2454	E.B2.57.1103	FAIRLEAD, for inward vent valve and pipe, inboard of trailing edge, rib 3	1	LFS21	C	51/9
		Attachments:-				
28D/9419397	A25/12C	Bolt, 2 BA, hex. head	1	-	C	51/10
28M/1278190	AGS.2001/C/1	Nut, stiff, 2 BA	1	-	C	51/11
28W/9419402	SP13/C	Washer, 2 BA, plain	1	-	C	51/12

SERVICES
FUEL SYSTEM IN PORT WING

1444

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
12596	E.B2.20.3129	FERRULE, flap hinge	1	L65	C	51/13
2460	EEAS.164/12/20	HOSE, rubber, pipe connecting	1	DTD625 Type 1	C	51/14
37069	E.B3.57.255	PACKING, ferrule, flap hinge (Mod. 4116)	QR	L72	C	
11580	E.B3.57.115	PIPE, assembly, from 1-1/2" connector, inboard of trailing edge rib 3 to Vickers fuel cock type 'D', c/w tee plug	1	L54	C	51/15
18902	E.B3.57.117	PIPE, assembly, air, from recuperator control valve to recuperator pipe connection outboard of trailing edge, rib 4	1	L56	-	51/16
13117	E.B2.57.1093	PIPE, air branch, from tank connector at trailing edge rib 3 to relief valve connections	1	L56	C	51/17
13397	E.B2.57.1447	PIPE, fuel, from recuperator fuel pipe connection on spar 5 to 2" connector at rib 1, 2" o/d x 20 SWG	1	L54	C	51/18
	E.B2.57.1627	PIPE, assembly, fuel, between 1-1/2" connector and connecting sleeve inboard of trailing edge rib 3	1	L56	-	51/19
2473*	GEO. ANGUS R.124/P.60 R.124/P.5	RING, sealing, recuperator air pipe connection at spar 1	1	-	C	51/20
		RING, sealing, recuperator air pipe connection at spar 1	1	-	-	
2477	PIONEER PO.22520013 or 3-155	RING, 'O' sealing, Vickers fuel cock	1	-	C	51/21
12592	3-155					
2478	PIONEER 11P/12507525/B	SEAL, for trailing edge fuel tank air connector	1	-	C	51/22
27FR/2433	F.R. LTD. FRS.151/K/1	SEAL, rubber, pipe connecting	1	-	C	51/23
27FR/2434	F.R. LTD. FRS.152/K/1	SLEEVE, outer, pipe connection at rib 1	1	-	C	51/24
27FR/3495	F.R. LTD. 9809050 or A9809000	VALVE, non-return, 3/4"	1	-	A	51/25
	VICKERS A.5816M	VALVE, fuel, gate, 2"	1	-	A	51/26
5W/2408	PLESSEY CZ.54709/5	Consisting of:- ACTUATOR	1	-	A	
27F/5551	VICKERS A.5881	VALVE	1	-	A	
	-	RIBS, 4-10, trailing edge, assembly (E.B3.57.47) Spares for:-	-	-	-	51/27
	E.B4.57.61	BLOCK, support, for fuel pipe at trailing edge, rib 7 (Mod. 2039)	1	BS2572 Type F3	-	
	E.B2.81.8548	CABLE, assembly, from Mk. 12 refuelling valve to terminal block on trailing edge, rib 6	1	-	-	51/28

SERVICES
FUEL SYSTEM IN PORT WING

1445

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
21049	E.B4.57.63								1	L72	C	
	E.B2.57.1789								1	—	—	51/29
27F/2967	VICKERS D5828								1	—	A	51/30
12617	E.B2.57.1791								1	—	C	
	E.B2.57.1805								1	—	—	51/31
28D/9436920	A25/1C								2	—	C	51/32
28W/9416643	SP47/C								2	—	C	51/33
27FR/2479	F.R. LTD. FRS.73/J								1	—	C	51/34
2459	E.B1.57.1077								1	Neo-K-Tex	C	51/35
	EEAS.164/16/20								1	DTD625 Type 1	—	51/36
12164	E.B3.57.227								1	—	C	51/37
11578	E.B5.57.221 KING A/C								1	L65	C	51/38
	C.6043/18B or C.6043/18H								1	—	C	51/39
12361*	G. ANGUS R.149/P.60								1	—	C	51/40
27KD/2730	NORMALAIR 522980								1	—	B	51/41
11577	E.B3.57.119								1	—	C	51/42
12616	E.B2.57.1443								1	—	C	51/43
27FR/3006	F.R. LTD. FRS.151/J/1								1	—	C	51/44
27FR/3180	F.R. LTD. FRS.152/J								1	—	C	51/45
27FR/3500	F.R. LTD. A9813014								1	—	A	51/46
27FR/2366*	F.R. LTD. C1112000/3								1	—	A	51/47
27FR/30183	C1112655								1	—	A	51/48
27FR/3513	F.R. LTD. C1127035								1	—	A	51/48

SERVICES
FUEL SYSTEM IN PORT WING

1446

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
9842	EEAS.240/2A	WASHER, 'D'	2	L72	C	
	-	RIBS, 10-14, trailing edge, assembly (E.B2.57.1827) Spares for:-	-	-	-	51/49
27FR/2352	F.R. LTD. FRS.132/F/1	COUPLING, 3/4"	1	-	B	51/50
13107	E.B2.57.1049	PIPE, fuel, from 3/4" pipe connection inboard of trailing edge rib 15 to 3/4" pipe connection outboard of trailing edge rib 10 on spar 5	1	-	C	51/51
	-	RIBS, 14-17, trailing edge, assembly (E.B2.57.1843) Spares for:-	-	-	-	51/52
2453	E.B2.57.1039	CONNECTOR, fuel pipe at trailing edge rib 16	1	-	B	51/53
27FR/2327	F.R. LTD. FRS.110/H/1	COUPLING, flow sensing valve, Series 1	1	-	B	51/54
27FR/2352	F.R. LTD. FRS.132/F/1	COUPLING, 3/4"	2	-	B	51/55
12596	E.B2.20.3129	FERRULE, pipe securing at rib 16	1	-	C	51/56
37069	E.B3.57.255	PACKING, ferrule, rib 16 (Mod. 4116)	1	L72	C	
30552	E.B2.57.2493	PIPE, drain, from flow sensing valve (Mod. 2018)	1	L56	C	
12669	E.B2.57.1501	PIPE, fuel, from connector at trailing edge rib 16 to 3/4" pipe connection inboard of trailing edge rib 17	1	L56	C	51/57
12599	E.B2.57.1503	PIPE, fuel, from 3/4" connection inboard of trailing edge rib 15 to flow sensing valve	1	L56	C	51/58
12600	E.B2.57.1845	PIPE, fuel, from flow sensing valve to 3/4" connection inboard of trailing edge rib 17	1	L56	C	51/59
27FR/2324	F.R. LTD. FRS.73/H	RING, split, flow sensing valve pipe connection	1	-	C	51/60
27FR/3787	F.R. LTD. FRS.152/H	SLEEVE, outer, flow sensing valve pipe	1	-	C	51/61
27FR/3004	F.R. LTD. FRS.151/H/1	SLEEVE, rubber, flow sensing valve pipe	1	-	C	51/62
2478	PIONEER 11P/12507525/B	SEAL, fuel pipe connector, at trailing edge rib 16	1	-	C	51/63
26FZ/981	EEAS.20/2/DR	TAB, locking, 20 SWG	1	L72	C	51/64
7935	E.B2.57.1505	VALVE, flow sensing, group Consisting of:-	1	-	A	52/1
	E.B2.57.1507	BODY, valve, outer	1	DTD304	-	52/2
	E.B2.57.1509	BODY, valve, inner	1	L65	-	52/3
28D/9436920	A25/1C	BOLT, 2 BA, hex. head	2	-	C	52/4
	E.B2.57.1519	BUSH	1	DTD265	-	52/5
	AUTOMOTIVE ENG. CO.	CIRCLIP, internal, 2-7/8", Seeger type	1	-	-	52/6
8023	AUTOMOTIVE ENG. CO.	CIRCLIP, external, 3/16", Seeger type	1	-	C	52/7
	E.B2.57.1533	CLIP, spring	1	DTD215	-	52/8
	E.B2.57.1513	GUIDE, spindle	1	L65	-	52/9
	E.B2.57.1517	GUIDE, spindle	1	L65	-	52/10

SERVICES
FUEL SYSTEM IN PORT WING

1447

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
19193 27QA/482	E.B2.57.1527	HEAD, valve	1	L65	-	52/11
	E.B2.57.1949	HEAD, valve	1	L65	-	52/12
	E.B2.57.2073	PIECE, distance, valve head	1	L65	-	52/13
	E.B2.57.1745	PLATE, retaining (Mod. 2018)	1	S510	-	52/14
	E.B2.57.1743	PLUG, blanking (Mod. 2018)	1	L44	C	52/15
	DOWTY SP911B/10	RJNG, 'O'	1	-	C	52/16
	E.B2.57.1521	ROD, push	1	-	-	52/17
	EEAS.28/10/1B	SHIM, laminated	1	-	-	52/18
	E.B2.57.1515	SPINDLE	1	S1	-	52/19
	E.B2.57.1525	SPRING, compression	1	DTD215	-	52/20
	E.B2.57.1529	SPRING, compression	1	DTD215	-	52/21
	E.B2.57.1523	SWITCH, micro, group Consisting of:-	1	-	-	52/23
	E.B2.57.1543	BRACKET, mounting	1	L59	-	52/24
	E.B2.57.1547	LEVER	1	S513	-	52/25
	E.B2.57.1545	SPINDLE	1	S1	-	52/26
	28P/1007947	AP9/A3	Attachments:- Pin, split	2	-	C
28W/9419473	SP15/A	Washer, 6 BA, plain	2	-	C	52/28
5CW/4615	BURGESS MS1577	SWITCH, micro, 'V3' Attachments:-	1	-	B	52/29
28D/1008148	A25/5A	Bolt, 6 BA, hex. head	2	-	C	52/30
28M/10286	AGS.2001/A/1	Nut, stiff, 6 BA	2	-	C	52/31
28W/9419473	SP15/A	Washer, 6 BA, plain	2	-	C	52/32
28W/9419447	E.B2.57.1531	WASHER, special	1	L65 or L72	-	52/33
	SP41/C	WASHER, tab	2	-	C	52/34
12608	-	SPAR, 1, ribs 2-10, assembly (E.B2.57.1817) Spares for:-	-	-	-	-
	E.B2.57.1623	BRACKET, for bonding clip, outboard rib 4, spar 1	1	L72	C	-
7580	E.B2.57.1715	CLIP, bonding	1	L72	C	53/1
27FR/2479	F.R. LTD. FRS.73/J	COLLAR, split, for inward vent valve	1	-	C	53/2
27FR/3001	F.R. LTD. FRS.175/K/1	CONNECTOR, lightweight, 1-1/2"	2	-	B	53/3
27FR/2328	F.R. LTD. FRS.110/J/1	COUPLING, pipe and shuttle valve	4	-	B	53/4
27FR/3002	F.R. LTD. FRS.110/N/1	COUPLING, recuperator pipe joint	1	-	B	53/5
12602	E.B2.57.1089	PIPE, fuel, from tank connection at leading edge rib 4 to connection at spar 1, 1-1/2" o/d x 22 SWG	1	L54	C	53/6
12603	E.B2.57.1097	PIPE, fuel branch, from 1-1/4" connection inboard of leading edge rib 5 to shuttle valve and non-return valve connection	1	L56	C	53/7
12604	E.B2.57.1445	PIPE, fuel, from shuttle valve connection at spar 1, 1-1/4" o/d x 22 SWG	1	L54	C	53/8
10807	E.B2.57.1711	PIPE, assembly, air, from recuperator to joint at spar 1 between leading edge ribs 7 and 8	1	-	C	53/9

SERVICES
FUEL SYSTEM IN PORT WING

1448

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
20265	E.B2.57.2013	PIPE, assembly, air, from connection at leading edge rib 2 to connection at leading edge rib 10, ambient static pressure	1	L56	C	53/10
12605	E.B2.57.2271	PIPE, fuel branch, from tank connection at leading edge rib 4A to branch pipe connection at inboard leading edge rib, 1-1/4" o/d x 22 SWG	1	L54	C	53/11
	E.B2.57.1053	RECUPERATOR, fuel, group Spares for:-	1	-	-	53/12
12601	E.B2.57.1065	ADAPTOR, fuel pipes and air inlet to recuperator	1	DTD721	C	53/13
2464	E.B1.57.109	BLADDER (Pre-Mod. 2442)	1	Hycatrol 257	C	
23812	E.B2.57.2551	BLADDER (Mod. 2442)	1	Hycatrol 257	C	53/14
2465	E.B1.57.89	CONE, clamping	1	-	C	53/15
2553	E.B1.57.611	INLET, tube, assembly	1	L65	C	53/16
11910	E.B2.57.1067	INLET, air	1	S92	C	53/17
2466	E.B1.57.95	JOINT, expansion, outboard	1	-	C	53/18
2467	E.B2.57.1059	JOINT, expansion, inboard	1	-	C	53/19
2468	E.B1.57.99	NUT, clamping	1	L65	C	53/20
2469	E.B1.57.101	NUT, air inlet pipe locking	3	S92	C	53/21
28M/9403520	A27/CP	NUT, 2 BA, plain, expansion joint attachment	24	-	C	53/22
28M/1278190	AGS.2001/C/1	NUT, stiff, 2 BA	24	-	C	53/23
24/U	E.B1.57.107	RING, sealing, expansion joint and seating	5	Neo-K-Tex	C	53/24
2554	E.B1.57.103	WASHER, sealing, between air inlet and recuperator insert	1	L34	C	53/25
2471	E.B1.57.105	WASHER, air inlet pipe lock nut	2	L16 or L34 bar	C	53/26
28W/9419475	SP15/C	WASHER, 2 BA, plain	24	-	C	53/27
28W/9416643	SP47/C	WASHER, 2 BA, spring expansion joint attachment	24	-	C	53/28
2473*	GEO. ANGUS R124/P60	RING, sealing, recuperator air pipe connection at spar 1	1	-	C	53/29
	R124/P5	RING, sealing, recuperator air pipe connection at spar 1	1	-	-	53/30
27FR/3006	F.R. LTD. FRS.151/J/1	SLEEVE, rubber, recuperator	1	-	C	53/31
27FR/3180	F.R. LTD. FRS.152/J	SLEEVE, outer, recuperator	1	-	C	53/32
5F/401209	AV/T40	TAPE, empire	QR	-	C	
27FR/3516	F.R. LTD. B.9813020	VALVE, shuttle (Pre-Mod. 2501)	1	-	A	53/33
	or					
27FR/30181	9813110	VALVE, shuttle (Mod. 2501)	1	-	C	
27FR/32593	F.R. LTD. B.9813160	VALVE, shuttle (Mod. 2501)	1	-	C	
	EEAS.21/9/DR	WASHER	2	L72	C	53/34

SERVICES
FUEL SYSTEM IN PORT WING

1449

Ref. No.	Part No.	Description							No. off	Mati. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
	-	SPAR, 4-5, ribs 6-8, assembly (E.B2.57.1819)							-	-	-	54/1
		Spares for:-										
5UE/6492	PULSOMETER PDC.1001 Mk. 1	ELEMENT, fuel transfer pump (Pre-Mod. 2152)							1	-	A	54/2
5UE/6492	PULSOMETER PDC.1001 Mk. 2	ELEMENT, fuel transfer pump (Mod. 2152) (Pre-Mod. 2134)							1	-	A	
5UE/7507	PULSOMETER PDC.1001 Mk. 3	ELEMENT, fuel transfer pump (Mod. 2134)							1	-	A	
	7958 E.B2.57.1687	PIPE, fuel, from recuperator connection to branch pipe at spar 5							1	-	C	54/3
		Consisting of:-										
27FR/2331	F.R. LTD. FRS.110/M/1 E.B2.57.1665	COUPLING, recuperator joint							1	-	B	54/4
	7300 PIONEER 5.008	PIPE, fuel							1	-	-	54/5
		RING, 'O'							1	MP802	C	54/6
27QA/863	DOWTY SP911B/6	RING, sealing, pulsometer pump, 2-1/4" i/d x 2-1/2" o/d							1	-	C	54/7
27QA/862	DOWTY GD1456B/29	RING, sealing, pulsometer pump, 2-9/16" i/d x 2-3/4" o/d							1	-	C	54/8
27QA/939	DOWTY GD1456B/33	RING, sealing, pulsometer pump, 2-13/16" i/d x 3" o/d							1	-	C	54/9
	-	SPAR, 1, ribs 10-11, assembly (E.B2.57.1831)							-	-	-	54/10
		Spares for:-										
6A/6729	SANGAMO WESTON L5.355	CABLE, Duprensheath, inward vent valve heater							1	-	-	54/11
	2451 E.B1.57.495	CLIP, inward vent valve hose clamping							2	-	C	54/12
26FZ/20459	EEAS.143/2	CLIP, pipe, 1/4" o/d, single							1	L72	C	54/13
27FR/2325	F.R. LTD. FRS.73/K	COLLAR, split, for bulkhead fitting at rib 13							1	-	C	54/14
27FR/2329	F.R. LTD. FRS.110/K/1	COUPLING, non-return valve							1	-	B	54/15
	2462 E.B1.57.493	JOINT, flexible, inward vent valve							1	Hycar	C	54/16
	2463 E.B2.57.41	PIPE, tank, inward vent, from non-return valve to tank end connection on rib 12							1	L54	C	54/17
	E.B4.57.59	PIPE, assembly, air continuation, from rib 11 to inward vent valve coupling on spar 1 (Mod. 2039)							1	L56	-	54/18
	12597 E.B2.57.251	PIPE, assembly, air, from coupling on spar 1 to inward vent valve, ambient static pressure							1	L56 or L72	C	54/19
	2474* GEO. ANGUS R146/P60 R146/P5	RING, sealing, inward vent valve at rib 13							1	-	C	54/20
27FR/2433	F.R. LTD. FRS.151/K/1	RING, sealing, inward vent valve at rib 13							1	-	-	
27FR/2434	F.R. LTD. FRS.152/K/1	SEAL, rubber, non-return valve to inward vent valve connecting							1	-	C	54/21
	2480 E.B1.20.5269	SLEEVE, outer, for bulkhead fitting at frame 13							1	-	C	54/22
27FR/3487	F.R. LTD. B9807100/3	STUD, inward, vent valve and flanged sleeve mounting							3	S95	C	54/23
		VALVE, non-return, 1-1/2"							1	-	A	54/24

SERVICES
FUEL SYSTEM IN PORT WING

1450

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
27F/2970	SELF PRIMING SPE.2340	VALVE, inward vent	1	—	A	54/25
2491	E.B1.20.5307	WASHER, sealing, tank inward vent pipe	1	Neo-K-Tex	C	54/26
2493	EEAS.21/9/DRH	WASHER, 20 SWG	2	L72	C	54/27
11172	EEAS.239/1A	WASHER, 'D'	1	L72	C	
	—	TANK, leading edge, assembly (E.B2.57.1815)	—	—	—	54/28
		Spares for:—				
5UE/6492	PULSOMETER PDC.1001 Mk. 1	ELEMENT, fuel transfer pump (Pre-Mod. 2152)	1	—	A	54/29
5UE/6492	PULSOMETER PDC.1001 Mk. 2	ELEMENT, fuel transfer pump (Mod. 2152) (Pre-Mod. 2134)	1	—	A	
5UE/7507	PULSOMETER PDC.1001 Mk. 3	ELEMENT, fuel transfer pump (Mod. 2134)	1	—	A	
27QA/863	DOWTY SP911B/6	RING, sealing, pulsometer pump	1	—	C	54/30
27QA/862	DOWTY GD1456B/29	RING, sealing, pulsometer pump	1	—	C	54/31
27QA/939	DOWTY GD1456B/33	RING, sealing, pulsometer pump	1	—	C	54/32
	BRITISH PAINTS 900/4501	SEALANT	QR	—	—	
	BRITISH PAINTS 900/4506	SEALANT	QR	—	—	
	—	WING ROOT, assembly (E.B4.57.51) (Mod. 2039)	—	—	—	
		Spares for:—				
19926	E.B4.73.773	BOBBIN, pipe clip spacing	2	L64	C	55/1
4349	EEAS.196/2-1/2C	BOLT, 2 BA, 120 deg. c'sk head	5	S94 or S95	C	55/2
5994	E.B2.57.1427	BRACKET, mounting, float valve	1	—	C	55/3
6A/6731	SANGAMO WESTON L5.390	CABLE, neoprene black, outward vent valve	1	—	C	55/4
6A/6927	SANGAMO WESTON L5.338	CABLE, neoprene black, float switch	2	—	C	55/5
4880	E.B2.57.1237	CLIP, non-return valve attachment at wing rib 1	1	—	C	55/6
27FR/3462	F.R. LTD. FRS.175/H/1	CONNECTOR, lightweight, 1"	1	—	B	55/7
8473	E.B2.57.2245	COWLING, outward vent valve	1	S515	C	55/8
9349	E.B2.57.1375	GASKET, outward vent pipe, 1/32" thick	2	Neo-K-Tex	C	55/9
21047	E.F3.57.609	GROMMET, special, for air pipe at rib 1	1	DTD560	C	55/30
11911	DUNLOP AHO.34103/16	HOSE, flexible	1	—	C	55/10
27VA/6399	DUNLOP DC.402/A13	HOSE, flexible, outward vent valve	1	—	C	55/11
21045	E.F2.57.801	PIPE, assembly, air, from tee piece to spar 1 float valve coupling, ambient static pressure	1	L56	C	55/12
21046	E.F2.57.793	PIPE, assembly, air, from tee piece to spar 1 float valve coupling, ambient static pressure	1	L56	C	55/13

SERVICES
FUEL SYSTEM IN PORT WING

451

Ref. No.	Part No.	Description							No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Fig. and Index
		1	2	3	4	5	6	7				
18903	E.B2.57.1437	PIPE, assembly, air, from float valve to air pipe connection on spar 1 (Pre-Mod. 2384)							1	L56	C	
	E.F2.57.909	PIPE, assembly, air, from float valve to air pipe connection on spar 1 (Mod. 2384)							1	-	-	55/4
11031	E.B2.57.1439	PIPE, assembly, air, from float valve to air pipe connection on spar 1 (Pre-Mod. 2384)							1	L56	C	
	E.F2.57.911	PIPE, assembly, air, from float valve to air pipe connection on spar 1 (Mod. 2384)							1	-	-	55/15
	E.B4.57.29	PIPE, assembly, air, from fuselage tee connection to cone union at leading edge rib 1							1	L56	-	55/16
	E.B4.57.55	PIPE, assembly, air, from float valve tee to static head connection, ambient static pressure							1	L56	-	55/17
	E.B4.57.27	PIPE, assembly, air, from cone union at leading edge rib 1 to connection at leading edge rib 2							1	L56	-	55/18
12156	E.B2.57.2287	PIPE, assembly, air, from float valve to pipe coupling at diaphragm A (Pre-Mod. 2384)							1	-	C	
	E.F2.57.907	PIPE, assembly, air, from float valve to pipe coupling at diaphragm A (Mod. 2384)							1	-	-	55/19
2475*	GEO. ANGUS R187/P60	RING, 'O' sealing, outward vent valve							1	-	C	55/20
	R187/P5	RING, 'O' sealing, outward vent valve							1	-	-	
5CW/8722	F.R. LTD. 3504100/184	SWITCH, float (Mod. 1973) (Pre-Mod. 4132)							1	-	A	
5CW/11469	F.R. LTD. 3504100/255	SWITCH, float (Mod. 4132)							1	-	A	55/21
5F/401209	AV/T40	TAPE, empire							QR	-	C	
	3662 E.B2.62.385	VALVE, non-return							1	-	C	55/22
	7972 E.B2.57.1557	VALVE, outward vent, 7 P.S.I.							1	-	A	55/23
27F/5522	SELF PRIMING SPE.2562	VALVE, outward vent							1	-	A	55/24
27F/	SELF PRIMING SPE.2519	VALVE, float, Mk. 2 (Pre-Mod. 2384)							1	-	A	
	or											
27F/5367	SPE.2530	VALVE, float, Mk. 3 (Pre-Mod. 2384)							1	-	A	
27F/6660	SELF PRIMING 20261	VALVE, float, A/Mk. 1 (Mod. 2384)							1	-	A	55/25
	or											
27F/	SELF PRIMING 21025	VALVE, float, A/Mk. 2							1	-	A	
10303	EEAS.240/1A	WASHER, 'D'							3	L72	C	55/26
8474	E.B2.57.2241	WELL, float switch							1	-	C	55/27
		Attachments:-										
28D/1010029	A25/6B	Bolt, 4 BA, hex. head							4	-	C	55/28
28W/9419465	SP13B	Washer, 4 BA, plain							4	-	C	55/29

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm
Please see site for usage terms,
and more aircraft documents.

