

SECTION 5

ADAPTERS

RESTRICTED

SECTION 5

LIST OF CHAPTERS

Note.—A list of contents appears at the beginning of each chapter

- 1 Adapters, pressurizing and emptying**
- ◀ 2 Adapter, $\frac{1}{2}$ in. B.S.P., Ref. No. 6C/2582**
- 3 Adapter, 0.60 in. $\times$ 19 T.P.I., Ref. No. 6C/2581 ▶**

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm
Please see site for usage terms,
and more aircraft documents.

