

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|--------------|----------|
| AIRCRAFT | | |
| General Arrangement | E.B6.00.1 | 1 |
| ARMAMENT | | |
| Air Deflector in Bomb Bay (Mod. 3154) (S.O.O.) | E.B6.97.301 | 7 |
| Bomb Gear | E.A1.97.9 | 3 |
| Bombsight Computer, Air Supply | E.B6.70.1 | 11 |
| Carrier Gunsight Assembly | E.B6.97.475 | 18A |
| CONTROLS | | |
| Aileron Controls in Wing, Port | E.A1.45.13 | 19 |
| Aileron Controls in Wing, Starboard | E.A1.45.14 | 31 |
| Engine Controls in Nose Fuselage | E.B6.47.3 | 57 |
| Engine Controls in Wing, Port (Pre-Mod. 2393-2155-2197) | E.A6.47.87 | 71 |
| Engine Controls in Wing, Port (Mod. 2393-2155-2197) | E.B6.47.293 | 71 |
| Engine Controls in Wing, Starboard (Pre-Mod. 2393-2155-2197) | E.A6.47.89 | 75 |
| Engine Controls in Wing, Starboard (Mod. 2393-2155-2197) | E.B6.47.295 | 75 |
| Engine Controls in Centre Fuselage (Pre-Mod. 2393-2155-2197) | E.A1.47.125 | 43 |
| Engine Controls in Centre Fuselage (Mod. 2393-2155-2197) | E.B6.47.297 | 45 |
| Flap Operating Mechanism, Port | E.A1.20.701 | 87 |
| Flap Operating Mechanism, Starboard | E.A1.20.700 | 99 |
| Flying Controls in Cockpit | E.B6.45.3 | 113 |
| Flying Controls in Centre Fuselage | E.A3.45.379 | 137 |
| Flying Controls in Rear Fuselage | E.A3.45.385 | 151 |
| ELECTRICAL INSTALLATION | | |
| Electrical Equipment in Front Fuselage | E.B6.81.5 | 165 |
| Electrical Equipment in Centre Fuselage | E.B6.81.7 | 257 |
| Electrical Equipment in Rear Fuselage | E.B6.81.11 | 303 |
| Electrical Equipment in Wing, Port | E.B7.81.9 | 327 |
| Electrical Equipment in Wing, Starboard | E.B7.81.10 | 359 |
| EQUIPMENT, AIRCRAFT | | |
| Equipment in Pressure Cabin | E.B6.80.1 | 415 |
| Equipment, L.L.A.B.S. Removable Fittings (S.O.O.) | E.B6.81.1515 | 435 |
| EQUIPMENT, ANCILLARY | | |
| Ground Equipment | E.A1.88.2 | 441 |
| FUSELAGE | | |
| Centre Portion (Pre-Mod. 1018) | E.B6.00.43 | 459 |
| Centre Portion (Mod. 1018) | E.B6.00.49 | 462 |
| Centre Structure (Pre-Mod. 1018) | E.B6.11.1521 | 469 |
| Centre Structure (Mod. 1018) | E.B6.11.1 | 479 |
| Front Portion | E.B6.10.1 | 503 |
| Nose, Portion | E.B6.00.41 | 527 |
| Rear Portion | E.B6.12.1 | 543 |
| Rear Fuselage and Tail Unit | E.B6.00.45 | 559 |

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|---------------|----------|
| MAIN PLANE | | |
| Aileron, Port (Mod. 875-895) | E.A3.24.1 | 601 |
| Aileron, Starboard (Mod. 875-895) | E.A3.24.2 | 629 |
| Outer Flap, Port | E.A1.25.1 | 645 |
| Inner Flap, Port | E.A1.25.3 | 646 |
| Outer Flap, Starboard | E.A1.25.2 | 649 |
| Inner Flap, Starboard | E.A1.25.4 | 650 |
| Undercarriage Door, c/w Mechanism, Port | E.A1.20.10733 | 653 |
| Undercarriage Door, c/w Mechanism, Starboard | E.A1.20.10734 | 665 |
| Wing, Port | E.A6.00.11 | 679 |
| Wing, Starboard | E.A6.00.12 | 693 |
| Wing Structure, Port | E.A6.20.1 | 709 |
| Wing Structure, Starboard | E.A6.20.2 | 729 |
| Wing Tip, Port | E.A1.00.67 | 753 |
| Wing Tip, Starboard | E.A1.00.68 | 765 |
| MISCELLANEOUS ATTACHMENTS | | |
| Wing to Fuselage, Port (Pre-Mod. 1018) | E.A1.00.21 | 779 |
| Wing to Fuselage, Port (Mod. 1018) | E.B6.00.21 | 780 |
| Wing to Fuselage, Starboard (Pre-Mod. 1018) | E.A1.00.22 | 780 |
| Wing to Fuselage, Starboard (Mod. 1018) | E.B6.00.22 | 780 |
| Front Fuselage to Centre Fuselage | E.A1.00.23 | 781 |
| Centre Fuselage to Rear Fuselage | E.B6.00.25 | 781 |
| Tail Plane to Rear Fuselage | E.B6.00.53 | 781 |
| Fin to Fuselage | E.A1.00.55 | 782 |
| Rudder to Fin and Fuselage | E.A1.00.57 | 782 |
| Rear Fairing to Fuselage | E.A1.00.59 | 782 |
| Controls to Rudder and Elevator | E.A1.00.63 | 782 |
| Drop Tank to Wing, Port | E.A1.00.81 | 782 |
| Drop Tank to Wing, Starboard | E.A1.00.82 | 782 |
| POWER INSTALLATION | | |
| Engine Cowling, Port | E.A6.50.493 | 795 |
| Engine Cowling, Starboard | E.A6.50.495 | 805 |
| Engine Mountings and Attachments, Port | E.A1.51.1 | 817 |
| Engine Mountings and Attachments, Starboard | E.A1.51.2 | 829 |
| R.A.7. Engine Installation, Port | E.A6.00.13 | 843 |
| R.A.7. Engine Installation, Starboard | E.A6.00.14 | 857 |
| RADIO AND RADAR INSTALLATION | | |
| Radar, Front Fuselage | E.B6.90.127 | 873 |
| Radar, Centre Fuselage | E.B6.90.129 | 875 |
| Radar, Rear Fuselage | E.B6.90.131 | 877 |
| Radio and Inter-Comm. in Centre Fuselage | E.B6.82.7 | 891 |
| Radio and Inter-Comm. in Front Fuselage | E.B6.82.5 | 881 |
| Radio and Inter-Comm. in Port Wing | E.B6.82.181 | 893 |
| Radio and Inter-Comm. in Starboard Wing | E.B6.82.182 | 895 |

INDEX OF ASSEMBLIES

| Assembly | Drawing No. | Page No. |
|---|-------------|----------|
| SERVICES | | |
| Cabin Pressure System in Centre Fuselage | E.B6.75.5 | 897 |
| Cabin Pressure System in Front Fuselage | E.B6.75.3 | 907 |
| Cabin Pressure System in Wing, Port (Pre-Mod. 2393-2155-2197) ... | E.B6.75.359 | 925 |
| Cabin Pressure System in Wing, Port (Mod. 2393-2155-2197) | E.B6.75.825 | 929 |
| Cabin Pressure System in Wing, Starboard | E.B6.75.781 | 941 |
| Camera, Pipe Run (Pre-Mod. 3427 without Mod. 2197) | E.A3.75.507 | 949 |
| Camera, Pipe Run (Mod. 3427 with Mod. 2197) | E.B6.75.571 | 951 |
| De-Misting System | E.A3.76.215 | 955 |
| Equipment in Inner Wing Leading Edge, Port (Pre-Mod. 2392-2155-2197) | E.B6.00.65 | 971 |
| Equipment in Inner Wing Leading Edge, Port (Mod. 2393-2155-2197) | E.B6.00.363 | 973 |
| Equipment in Inner Wing Leading Edge, Starboard (Pre-Mod. 2393-2155-2197) | E.B6.00.66 | 985 |
| Equipment in Inner Wing Leading Edge, Starboard (Mod. 2393-2155-2197) | E.B6.00.364 | 987 |
| Fire Protection System in Fuselage (Pre-Mod. 2614) | E.A1.60.1 | 1001 |
| Fire Protection System in Fuselage (Mod. 2614) | E.B6.60.1 | 1002 |
| Fire Protection System in Wing, Port | E.A1.60.3 | 1015 |
| Fire Protection System in Wing, Starboard | E.A1.60.4 | 1027 |
| Fuel System in Wing, Port | E.B6.57.17 | 1041 |
| Fuel System in Wing, Starboard | E.B6.57.18 | 1055 |
| Fuel System in Centre Fuselage | E.A3.57.67 | 1071 |
| Fuel System (Nitrogen) Front Fuselage | E.A1.57.731 | 1099 |
| Hydraulic Equipment in Front Fuselage | E.B6.73.3 | 1113 |
| Hydraulic Equipment in Centre Fuselage | E.B6.73.5 | 1139 |
| Hydraulic Equipment in Wing, Port | E.A6.73.7 | 1181 |
| Hydraulic Equipment in Wing, Starboard | E.A6.73.8 | 1201 |
| Hydraulic Equipment in Inner Wing Leading Edge, Port (Pre-Mod. 2393-2155-2197) | E.B6.73.23 | 1223 |
| Hydraulic Equipment in Inner Wing Leading Edge, Port (Mod. 2393-2155-2197) | E.B6.73.395 | 1223 |
| Hydraulic Equipment in Inner Wing Leading Edge, Starboard (Pre-Mod. 2393-2155-2197) | E.B6.73.24 | 1235 |
| Hydraulic Equipment in Inner Wing Leading Edge, Starboard (Mod. 2393-2155-2197) | E.B6.73.397 | 1237 |
| Oxygen System | E.B6.71.1 | 1251 |
| TAIL UNIT | | |
| Rudder, c/w Tab | E.A3.33.1 | 1271 |
| Tailplane and Elevators (Pre-Mod. 2182) | E.B6.00.19 | 1287 |
| Tailplane and Elevators (Mod. 2182) | E.A9.00.19 | 1287 |
| TANKS | | |
| Jettison Wing Fuel Tank, Port | E.A3.00.505 | 573 |
| Jettison Wing Fuel Tank, Starboard | E.A3.00.506 | 585 |
| UNDERCARRIAGE | | |
| Main Undercarriage, Port | E.A1.40.727 | 1311 |
| Main Undercarriage, Starboard | E.A1.40.728 | 1329 |
| Nosewheel | E.A9.40.1 | 1347 |

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

