

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.1	PRESSURE CABIN EQUIPMENT, ASSEMBLY						—	—	—	
		Spares for:—									
27N/1	†	AXE, fire (Mod. 2197—S.O.O.)						1	—	B	
	E.A3.83.95	BALLAST UNDER BOMB AIMER'S RAMP, ASSEMBLY						—	—	—	
		Consisting of:—									
	E.A3.84.29	BLOCK, ballast (S.O.O. only)						3	—	—	
32203	E.A3.84.23	BLOCK, ballast, 18½ lbs. (S.O.O.)						1	—	B	
12997	E.A3.84.25	BLOCK, ballast, 49½ lbs. (S.O.O.)						3	—	B	
32202	E.A3.84.21	BLOCK, ballast, 106½ lbs. (S.O.O.)						1	—	B	
26763	E.A3.83.105	BLOCK, packing						1	—	C	
26762	E.A3.83.107	BLOCK, packing						2	—	C	
28D/1011239	A25/3E	BOLT, ½" BSF						1	—	C	
28D/1008151	A25/4E	BOLT, ½" BSF						1	—	C	
28D/1011240	A25/5E	BOLT, ½" BSF						1	—	C	
28D/1011254	A25/10E	BOLT, ½" BSF						4	—	C	
28D/1013176	AS.1242/10E	BOLT, ½" BSF						1	—	C	
28D/1212828	AS.1242/11E	BOLT, ½" BSF						1	—	C	
28D/1212831	AS.1242/14E	BOLT, ½" BSF						7	—	C	
13044	E.A3.83.97	BOX, ballast, assembly						1	—	B	
28M/1011475	A27/EP	NUT, ½" BSF						9	—	C	
28M/1201610	AGS.2001/E/1	NUT, ½" BSF						7	—	C	
26651	E.A3.83.169	PACKING						1	—	MR	
	E.A3.84.27	PACKING, ballast wood (S.O.O.)						1	—	—	
	E.A3.83.113	PACKING, ballast wood (Standard fitment until S.O.O. weights are fitted)						1	—	—	
32204	E.A3.83.99	STRAP, ballast box						1	—	B	
26760	E.A3.83.101	STRAP, supporting						2	—	C	
26650	E.A3.83.103	SUPPORT, ballast box						1	—	MR	
28W/9418921	SP.13/E	WASHER						11	—	C	
26761	E.A3.83.109	WASHER						1	—	C	
33887	E.A3.84.111	WASHER						2	—	C	
	E.A3.80.6175	BLOCK, STOWAGE, PILOT'S EJECTION SEAT SAFETY PINS, INSTALLATION (MOD. 4442)						—	—	—	
		Spares for:—									
6101183	E.A3.80.6547	BLOCK, stowage (Mod. 4925)						1	—	MR	
		Attaching parts for E.A3.80.6547:—									
28D/1204937	AS.1242/6C	Bolt, 2 BA						2	—	C	
1438887	E.A3.80.6173	CLIP, spring						1	—	C	
	E.B6.80.7133	BLOCK, STOWAGE, REAR CREW EJECTION SEAT SAFETY PINS, INSTALLATION (MOD. 4442)						—	—	—	
		Spares for:—									
6101183	E.A3.80.6547	BLOCK, stowage (Mod. 4925)						2	—	MR	
		Attaching parts for E.A3.80.6547:—									
28D/1010030	A25/7C	Bolt, 2 BA (Upper)						2	—	C	
28D/1200120	A25/14B	Bolt, 4 BA (Lower)						2	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA (Upper)						2	—	C	
1438886	E.A3.80.6183	Washer (Lower)						2	—	MR	
28W/9419401	SP.10/B	Washer (Lower)						2	—	C	
28W/9419454	SP.10/C	Washer (Upper)						2	—	C	
28W/9419175	SP.15/C	Washer (Upper)						2	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. Off	Matl Spec.	Cl. of Equip.			Plate No.	
					1	2	3		M.R.
32569	E.B6.90.299	BRACKET , assembly, for type 705 control unit (Mod. 2542)	1	—	—	—	—	C	
	E.B6.82.265	BRACKET , assembly, for control panel type 912 (Mod. 2542)	1	—	—	—	—	—	
	E.B6.10.337	BRACKET , assembly, for intercomm. amplifier (Mod. 2542)	1	—	—	—	—	—	
	E.A3.80.2619	COMPASS, E2A, ASSEMBLY Spares for:—	—	—	—	—	—	—	
4626	E.A3.80.2623	BRACKET , mounting, assembly Attaching parts for E.A3.80.2623:—	1	—	—	—	—	C	
28M/4342710	AGS.2001/B/4	Nut, 4 BA	2	—	—	—	—	C	
28S/9148118	A43/B10	Screw, 4 BA	2	—	—	—	—	C	
6B/4343605	†	COMPASS , type E2A Attaching parts for Ref. 6B/4343605:—	1	—	—	—	—	A	
28M/4342710	AGS.2001/B/4	Nut, 4 BA	2	—	—	—	—	C	
28S/1012356	A43/B12	Screw, 4 BA	2	—	—	—	—	C	
8631	E.A3.80.2621	FLAP (Pre-Mod. 4724) Attaching parts for E.A3.80.2621:—	1	—	—	—	—	—	
28M/10273	AGS.2001/A/4	Nut, 6 BA	2	—	—	—	—	C	
8633	E.A3.80.1949	Pin, hinge	1	—	—	—	—	C	
8632	E.A3.80.2627	Spring	1	—	—	—	—	C	
8630	E.A3.80.2633	Tube	2	—	—	—	—	C	
28W/3537	AGS.1583/D	Washer, double spring	2	—	—	—	—	C	
	E.B6.80.39	CONSOLE, PILOT'S, ASSEMBLY Spares for:—	—	—	—	—	—	—	
	E.B6.80.59	FAIRING, CONTROL, GROUP Spares for:—	—	—	—	—	—	—	
5449	E.A3.80.2579	COVER , detachable	1	—	—	—	—	C	
36277	E.B7.80.135	MEMBER , vertical, assembly	1	—	—	—	—	C	
5808	E.B6.80.53	PANEL , side removable control access	1	L.72	—	—	—	C	
5625	E.B7.80.153	PANEL, REMOVABLE SNATCH UNIT ACCESS, ASSEMBLY Spares for:—	1	—	—	—	—	C	
33048	E.B7.80.419	FAIRING , assembly	1	—	—	—	—	C	
5626	E.B7.80.161	PANEL , side, removable control access	1	L.72	—	—	—	C	
5627	E.B7.80.163	PANEL , side, removable control access	1	L.72	—	—	—	C	
5628	E.B7.80.365	PANEL , forward removable battery access	1	L.72	—	—	—	C	
16709	E.B6.80.47	PLATE , cover	1	—	—	—	—	MR	
	E.A3.80.2057	CONTAINER, URINE, ASSEMBLY Spares for:—	1	—	—	—	—	—	
	E.A3.80.2801	BRACKET , support	1	—	—	—	—	—	
27H/3224	†	CONTAINER , Mk. 2	1	—	—	—	—	C	
27H/2316	†	FUNNEL	1	—	—	—	—	C	
27541	E.A3.10.3059	COVER AND MOUNTING, SIGNAL PISTOL, ASSEMBLY (PRE-MOD. 2187) Spares for:—	—	—	—	—	—	MR	
3654	E.A3.10.3003	BOLT , special	1	—	—	—	—	C	AE.1
2736	E.A3.10.2571	COVER , for signal mounting aperture	1	—	—	—	—	C	AE.1
—	E.A3.10.3033	PATCH , fabric	1	—	—	—	—	—	
2738	E.A3.10.2573	PLATE , spreader	1	—	—	—	—	C	AE.1
2737	E.A3.10.2575	SEAL , pressure	1	Rubber	—	—	—	C	AE.1
4433	E.A3.10.2995	SEAL , pressure	1	Linatex	—	—	—	C	
2734	E.A3.10.2659	WASHER	1	Rubber	—	—	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.B7.80.327	CURTAINS, BLACKOUT, ASSEMBLY	—	—	—	
		Spares for:—				
12993	E.B7.80.331	CURTAIN , main	1	—	B	
6332	E.A3.80.1753	CURTAIN , navigator's	1	—	B	
29G/4137	CARR. 759	FASTENER , "Durable Dot"	3	—	C	
28M/1278190	AGS.2001/C/1	NUT , 2 BA	4	—	C	
28M/9433473	AGS.2002/C/1	NUT , 2 BA	2	—	C	
18721	E.B6.80.139	PLATE , blackout, starboard	1	—	C	
22511	E.B6.80.183	PLATE , blackout, port	1	—	C	
3148	EEAS.132/12	STRAP , securing	2	—	C	
29G/2180	CARR. 882	STUD	6	—	C	
18854	EEAS.27/16ER	WASHER	2	L.72	C	
	E.B6.80.3	EQUIPMENT, BOMB AIMER'S, ASSEMBLY	—	—	—	
		Spares for:—				
6B/562	†	AMPLIFIER , type B, for gyro compass, Mk. 4B	1	—	A	
14A/2210	†	CONTROL , camera, remote, type 35, No. 8	1	—	A	
		Attaching parts for Ref. 14A/2210:—				
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28S/1200053	A.33/C16	Screw, 2 BA	4	—	C	
28W/9419475	SP.15/C	Washer	4	—	C	
8511	E.A3.80.929	FLOOR , assembly, bomb aimer's	1	—	C/MR	
	E.B6.80.41	LABEL , camera, master switch	1	—	—	
5K/3390	AS.3360/B/3B	LEAD , bonding	1	—	C	
		Attaching parts for AS.3360/B/3B:—				
28M/1278189	AGS.2001/B/1	Nut, 4 BA	1	—	C	
28S/1200053	A32/B12	Screw, 4 BA	1	—	C	
	EEAS.28/2CP	Washer	1	—	—	
5D/1482	†	PANEL , 24-way, bomb aimer's	1	—	A	
		Attaching parts for Ref. 5D/1482:—				
28D/1013301	AS.1248/4C	Bolt, 2 BA	6	—	C	
28W/9419475	SP.15/C	Washer	6	—	C	
14A/540	†	PLATE , wedge for camera control	1	—	C	
8515	E.A3.10.2799	RAMP , for strobe unit	1	—	C/MR	
5X/759	†	RING , locking, No. 1	1	—	C	
5X/769	†	RING , locking, No. 2	2	—	C	
5X/799	†	RING , locking, No. 4	2	—	C	
	ROTAX					
5CW/4184	D.5404/3	SWITCH , SP, "on/off"	1	—	B	
		Attaching parts for D.5404/3:—				
28S/1214164	A44/B14	Screw, 4 BA	2	—	C	
28W/1206041	AGS.2035/B	Washer	2	—	C	
5D/1566	†	SWITCH , fusing, Mk. 1	1	—	C	
		Attaching parts for Ref. 5D/1566:—				
28D/1008147	A25/1A	Bolt, 6 BA	4	—	C	
28M/10286	AGS.2001/A/1	Nut, 6 BA	4	—	C	
28W/9419473	SP.15/A	Washer	4	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.B6.80.6089	SWITCH, HATCH, DETONATOR, ASSEMBLY (MOD. 3776)	1	—	—	
		Spares for:—				
1439163	E.A3.81.6517	FLAP, assembly (Mod. 4465)	1	—	—	
	E.A3.81.6519	FLAP, SPRING, ASSEMBLY (MOD. 4465) ...	1	—	C	
		Spares for:—				
40619	E.A3.81.6513	FLAP (Mod. 4465)	1	BSS.265	—	
27353	E.A4.81.1663	FLAP, support	1	—	C	
27352	E.A4.81.1659	PIN	1	—	C	
3223	E.A4.81.1661	SPRING	1	—	C	
3224	E.A6.81.369	PIN, hinge	1	DTD.683	C	
	E.A1.81.929	SPRING, torsion	1	—	C	
	E.A3.81.6497	SWITCH-UNIT, sub-assembly (Mod. 4437) ...	1	—	—	
		Attaching parts for E.A3.81.6497:—				
28S/	E.A3.81.6515	Packing (Mod. 4465)	1	LFS	—	
	A32/A17	Screw, 6 BA (Reduce 28S/1200081 to suit) ...	4	—	—	
5CW/9255	†	SWITCH, type AS.10512C-1 (Mod. 4465) ...	2	—	B	
6B/437	†	TRAY, amplifier, mounting	1	—	B	
		Attaching parts for Ref. 6B/437:—				
28D/1215327	AS.1246/1E	Bolt, 1/4" BSF	4	—	C	
8509	E.A3.82.9	TRAY, mounting, strobe unit	1	—	B	
5D/1742	†	UNIT, control bomb distributor, 12/24way- Mk. 2	1	—	A	
		Attaching parts for Ref. 5D/1742:—				
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	C	
10A/19429	†	Washer, check	8	—	C	
8510	EEAS.12/2CP	WASHER	2	L.16	C	
15493	EEAS.28/2FR	WASHER	2	L.72	—	
	EEAS.28/2GP	WASHER	2	L.16	C	
	—	EQUIPMENT, NAVIGATOR'S AND BOMB AIMER'S LEG RESTRAINT (E.A3.80.2869) (MOD. 2580)	—	—	—	
		Spares for:—				
27L/510	A/MBEU/3666	BRACKET, floor	4	—	C	
27L/2729	B/MBEU/17353	LINE, leg (Mod. 3949)	4	—	C	
27L/80	C/MBEU/1434	PIN	4	—	C	
	—	EQUIPMENT, PILOT'S LEG RESTRAINT (E.B6.16.3) (MOD. 3278)	—	—	—	
		Spares for:—				
27L/510	A/MBEU/3666	BRACKET, floor	2	—	C	
27L/2729	A/MBEU/17353	LINE, leg (Mod. 3948)	2	—	C	
27L/80	C/MBEU/1434	PIN	2	—	C	
	E.A3.80.2009	EQUIPMENT, NAVIGATOR'S COMPARTMENT, ASSEMBLY	—	—	—	
		Spares for:—				
32565	E.B6.80.935	BRACKET, assembly, for A.M.U.	1	—	C	
	E.B6.80.915	BRACKET, assembly, for "G" scope	1	—	—	
	E.A3.80.2023	CONTROL, A.M.U., INSTALLATION	—	—	—	
		Spares for:—				
6B/471	†	PANEL, control for Mk. 4B air mileage unit ...	1	—	A	
		Attaching parts for Ref. 6B/471:—				
28D/9128739	AS.1248/1B	Bolt, 4 BA	4	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.A3.80.2025	EQUIPMENT, FORWARD OF NAVIGATOR'S TABLE						—	—	—	
		Spares for:—									
6B/291	†	DRIVE , flexible						1	—	C	
	E.A3.80.2769	PLATE , base						1	L.72	—	
	E.A3.81.2269	PLATE , mounting						1	L.72	—	
		Attaching parts for E.A3.81.2269:—									
28D/8337	AS.1248/1B	Bolt, 4 BA						6	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						6	—	C	
28W/9419474	SP.15/B	Washer						6	—	C	
6B/314	†	REPEATER unit						1	—	A	
		Attaching parts for Ref. 6B/314:—									
28D/9436920	A25/1C	Bolt, 2 BA						3	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA						3	—	C	
	EEAS.132/7	STRAP , cable						2	—	—	
		Attaching parts for EEAS.132/7:—									
28D/1218385	AS.1248/2B	Bolt, 4 BA						1	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						1	—	C	
28W/9419474	SP.15/B	Washer						1	—	C	
3567	E.A3.80.49	FRAME , receiver, G.H.						1	—	C	AE.1

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.A3.20.2017	MOUNTING, ASSEMBLY, FOR G-H AND CONTROLLER	—	—	—	
8744	E.A3.80.2461	Spares for:— BOLT , G.H. indicator, securing	2	—	C	
28D/9140645	A25/10C	Attaching parts for E.A3.80.2461:— Bolt, 2 BA	1	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	1	—	C	
28W/9419475	SP.15/C	Washer	1	—	C	
8746	E.A3.80.2463	CLAMP , toggle, G-H controller, securing ...	2	—	C	
8745	E.A3.80.107	NUT , knurled finger, G-H indicator securing ...	2	—	C	
	WELLS & CO. LTD.	Attaching parts for E.A3.80.2017:—				
10A/J/	H.D.F.M. 35	Mounting, equiflex	4	—	—	
28M/10292	AGS.2001/J/1	Nut, 1/2" BSF	8	—	C	
28W/9419477	SP.15/J	Washer	8	—	C	
	E.A3.80.2685	MOUNTING, R.F. UNIT, ASSEMBLY	—	—	—	
	E.A3.80.2709	Spares for:— BRACKET	4	—	—	
28D/9436920	A25/1C	Attaching parts for E.A3.80.2709:— Bolt, 2 BA	4	—	C	
28W/9419402	SP.13/C	Washer	4	—	C	
	E.A3.80.2687	MOUNTING, ASSEMBLY	1	—	—	
10A/17616	†	Spares for:— MOUNTING , anti-vibration, type 682 ...	4	—	B	
28D/1011011	A25/8B	Attaching parts for E.A3.80.2687:— Bolt, 4 BA	4	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	
	E.A3.80.2699	Washer	4	—	—	
	E.A3.80.2725	SUPPORT	1	—	—	
	E.A3.80.2726	SUPPORT	1	—	—	
28D/1010658	A25/1B	Attaching parts for E.A3.80.2725 and E.A3.80.2726:— Bolt, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
10AB/2506	159/3	MOUNTING , assembly	1	—	A	
28D/1011245	A25/10E	Attaching parts for 159/3:— Bolt, 1/2" BSF	4	—	C	
28M/10290	AGS.2001/E/1	Nut, 1/2" BSF	4	—	C	
8575	E.A3.80.1323	Washer	4	—	C	
	E.B6.80.5937	PANEL, INSTRUMENT, NAVIGATOR'S, ASSEMBLY (MOD. 3747) (PRE-MOD. 2530)	1	—	—	
6A/8267/1	†	Spares for:— ALTIMETER , Mk. 19F	1	—	A	
28S/1214166	A44/B28	Attaching parts for Ref. 6A/8267/1:— Screw, 4 BA	4	—	C	
28W/9419448	AGS.2035/B	Washer	4	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
8731	E.A3.80.551	BRACKET, L.H., instrument panel, attachment						1	—	C	
8735	E.A3.80.2329	BRACKET, R.H., instrument panel, attachment						1	—	C	
8732	E.A3.80.2325	CLIP, L.H., assembly, panel attachment on coaming tube						1	—	C	
8733	E.A3.80.2327	CLIP, R.H., assembly, panel attachment on coaming tube						1	—	C	
		Attaching parts for E.A3.80.2325 and E.A3.80.2327:—									
28D/9140645	A25/10C	Bolt, 2 BA						2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
6B/634	†	COMPASS, G.4B						1	—	A	
		Attaching parts for Ref. 6B/634:—									
28M/10281	AGS.2001/C3	Nut, 2 BA						3	—	C	
28S/1212721	A40/C32	Screw, 2 BA						3	—	C	
6B/556	†	HOLDER, deviation card						1	—	B	
6B/458	†	INDICATOR, air position						1	—	A	
		Attaching parts for Ref. 6B/458:—									
28D/1213484	AS.4565/9E	Bolt, 1/2" BSF						2	—	C	
28D/1213513	AS.4565/31E	Bolt, 1/2" BSF						1	—	C	
28M/10282	AGS.2001/E/3	Nut, 1/2" BSF						3	—	C	
28W/9419405	SP.15/E	Washer						3	—	C	
6A/4722	†	INDICATOR, air speed						1	—	A	
		Attaching parts for Ref. 6A/4722:—									
28D/1215159	AS.4565/1C	Bolt, 2 BA						3	—	C	
28M/10281	AGS.2001/C/3	Nut, 2 BA						3	—	C	
6A/2769	†	INDICATOR, air temperature S63-112, frame 4						1	—	A	
5CZ/5003	†	INDICATOR, electro magnetic						1	—	B	
10QB/6130	†	INDICATOR unit, type 208						1	—	A	
	E.A3.80.2301	PANEL, INSTRUMENT, SUB-ASSEMBLY ...						1	—	—	
		Spares for:—									
	E.A3.80.533	BRACKET, L.H., attachment						1	—	—	
	E.A3.80.2333	BRACKET, mounting altimeter						1	—	—	
	E.A3.80.2309	BRACKET, mounting indicator, type 208 ...						1	—	—	
	A. WELLS & CO.										
10AJ/	M.D.S.M.10	MOUNTING, equiflex						4	—	—	
6A/7041	†	VIBRATOR, unit and clip						1	—	A	
		Attaching parts for E.B6.80.5937:—									
28D/1011242	A25/7E	Bolt, 1/2" BSF						1	—	C	
28D/1011244	A25/9E	Bolt, 1/2" BSF						1	—	C	
28D/1011245	A25/10E	Bolt, 1/2" BSF						1	—	C	
28D/1011246	A25/11E	Bolt, 1/2" BSF						1	—	C	
28M/10282	AGS.2001/E/3	Nut, 1/2" BSF						1	—	C	
28M/10330	AGS.2002/E/1	Nut, 1/2" BSF						3	—	C	
8734	E.A3.80.2331	Piece, distance						4	—	C	
28W/9419487	SP.16/E	Washer						2	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
	E.B6.80.5939							1	—	—		
	E.A3.80.2301							1	—	—		
10Q/16314	†							1	—	A		
28S/9992525	A32/B12							4	—	C		
10Q/16073	†							1	—	A		
28S/6350	A40/B12							4	—	C		
	E.B6.80.905							1	—	—		
	E.B6.80.917							1	—	—		
28D/1007979	AS.1246/1B							6	—	C		
28M/10287	AGS.2001/B/1							6	—	C		
28W/9419465	SP.13/B							6	—	C		
	E.B6.80.915							1	—	—		
28D/1007979	AS.1246/1B							6	—	C		
	E.A3.80.2013							—	—	—		
8722	E.A3.80.2119							1	—	C		
8815	E.A3.80.2171							1	—	C		
28D/9133011	A25/2C							10	—	C		
28M/9403520	A27/CP							10	—	C		
28W/1007983	AGS.162/C							10	—	C		
28W/9419475	SP.15/C							10	—	C		
8814	E.A3.80.2091							1	—	C		
28D/9133011	A25/2C							4	—	C		
28D/1214044	AS.1242/23C							3	—	C		
28M/9403520	A27/CP							7	—	C		
8726	E.A3.80.2097							1	—	C		
	AS.2808/5/142							3	T.35	LM		
8729	EEAS.27/16DR							3	—	C		
28W/1007983	AGS.162/C							7	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
8813	E.A3.80.2169	SLIDE , table, assembly						1	—	C	
		Attaching parts for E.A3.80.2169:—									
28D/9133011	A25/2C	Bolt, 2 BA						4	—	C	
28D/1214031	AS.1242/8C	Bolt, 2 BA						3	—	C	
28M/9403520	A27/CP	Nut, 2 BA						7	—	C	
8726	E.A3.80.2097	Saddle						1	—	C	
28W/1007983	AGS.162/C	Washer						7	—	C	
8811	E.A3.80.2173	TABLE , folding						1	—	B	
		Attaching parts for E.A3.80.2173:—									
8725	E.A3.80.2133	Bolt, pivot						2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA						2	—	C	
	AS.2808/5/012	Piece, distance						2	T.35	LM	
8728	EEAS.28/36CU	Washer						2	—	C	
8812	E.A3.80.2175	TABLE , fixed						1	—	B	
		Attaching parts for E.A3.80.2175:—									
28D/9133011	A25/2C	Bolt, 2 BA						1	—	C	
28D/8337	AS.1248/1B	Bolt, 4 BA						6	—	C	
28M/9403520	A27/CP	Nut, 2 BA						1	—	C	
28W/1007983	AGS.162/C	Washer						1	—	C	
	E.B7.80.685	TRAY , mounting transmitter G-H (Mod. 1282) ...						1	—	—	
		Attaching parts for E.B7.80.685:—									
28D/1011029	A25/1E	Bolt, 1/2" BSF						16	—	C	
28M/10290	AGS.2001/E/1	Nut, 1/2" BSF						16	—	C	
652	E.A3.80.411	Washer, special						4	L.40	C	
	E.A3.80.647	WASHER , special platform support						1	—	C	
	E.A3.80.651	WASHER , special platform support						2	—	—	
8944	E.A3.80.133	WASHER , special G.H. receiver						4	—	C	
	E.A3.80.899	EXTINGUISHER, FIRE ASSEMBLY (PRE-MOD. 2197)						—	—	—	
		spares for:—									
8625	E.A3.80.1211	BRACKET , assembly						1	—	C	
8626	E.A3.80.1213	BRACKET , assembly						1	—	C	
27N/85	†	BRACKET , fire extinguisher						1	—	B	
27N/70	†	EXTINGUISHER , fire						1	—	A	
	AS.2810/8/05	TUBE , distance						4	T.4	LM	
	E.B6.80.837	EXTINGUISHER, FIRE MOUNTING, ASSEMBLY (MOD. 2197-500)						—	—	—	
	E.B6.80.883	BRACKET , assembly						1	—	—	
	E.B6.80.889	BRACKET , assembly						1	—	—	
27N/85	†	BRACKET , fire extinguisher						1	—	B	
27N/70	†	EXTINGUISHER , fire						1	—	A	
	AS.2810/8/075	PIECE , distance						4	T.4	LM	
	E.A3.83.179	FLAP SWITCH AND UNDERCARRIAGE SWITCH LOCK STOWAGE, ASSEMBLY (MOD. 1724)						—	—	—	
		Spares for:—									
8969	E.A3.83.173	BAG , stowage, for flap, switch, locking pin ...						1	—	B	
22167	E.A3.83.295	BAG , stowage, for undercarriage switch locking pin						1	—	B	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	1	2	3	4	5	6	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
											M.R.	L.M.	
	E.B7.80.35							CLIP , cable	1	—	—		
								Attaching parts for E.B7.80.35:—					
28D/1007971	A25/1/2 B							Bolt, 4 BA	4	—	C		
28M/10287	AGS.2001/B/1							Nut, 4 BA	4	—	C		
	5K/2724							COVER , spring	1	—	—		
5L/9951272	†							FILAMENT , lamp, 28 volt 3.5 watt	9	—	C		
5L/9951286	†							FILAMENT , lamp, 24 volt 2.5 watt	9	—	C		
6A/2924	SMITH 218FL							INDICATOR , flap position	1	—	A		
5CX/4204	†							INDICATOR , undercarriage position	1	—	A		
	or												
	5CX/5164							INDICATOR , undercarriage position	1	—	A		
	†							INDICATOR , undercarriage position	1	—	A		
	E.A3.81.2075							KNOB	1	DTD.683	—		
								Attaching parts for E.A3.81.2075:—					
28S/1005622	A31/B28							Screw, 4 BA	1	—	C		
28W/1206041	AGS.2035/B							Washer	1	—	C		
	E.B7.75.57							LOUVRE, PILOT'S, ASSEMBLY	1	—	—		
								Spares for:—					
15200	E.B7.75.515							BOX , assembly	1	—	C		
20635	E.B7.75.55							LOUVRE	1	—	B		
	E.B7.80.21							PANEL	1	—	—		
	E.B7.80.31							PLATE , instruction	1	L.72	—		
	E.A3.81.5851							SWITCH, OPERATING, UNDERCARRIAGE, ASSEMBLY	1	—	—		
								Spares for:—					
5CW/7748	†							SWITCH , D.P. change-over	1	—	C		
								Attaching parts for Ref. 5CW/7748:—					
28S/9419435	A31/B12							Screw, 4 BA	4	—	C		
28W/1206041	AGS.2035/B							Washer	4	—	C		
	E.A3.81.2073							TOGGLE	1	LFS.26	—		
								Attaching parts for E.A3.81.2073:—					
28S/1200055	A33/A6							Screw, 6 BA	2	—	C		
	5CW/898							SWITCH , push, fuel tank jettison type B No. 1	1	—	B		
								Attaching parts for Ref. 5CW/898:—					
28M/10286	AGS.2001/A/1							Nut, 6 BA	4	—	C		
28S/9995324	A32/A16							Screw, 6 BA	4	—	C		
	5CW/4506							SWITCH , undercarriage operating	1	—	A		
								Attaching parts for Ref. 5CW/4506:—					
28M/10287	AGS.2001/B/1							Nut, 4 BA	2	—	C		
28S/6577	A40/B16							Screw, 4 BA	2	—	C		
	E.B6.80.5941							PANEL, FLYING, ASSEMBLY (MOD.3747)	—	—	—		
								Spares for:—					
6A/2944	†							ALTIMETER , Mk. 19A. (Pre-Mod. 3750)	1	—	A		
6A/7018	†							ALTIMETER , Mk. 19C. (Mod. 3750) Pre-Mod. 3971)	1	—	A		
6A/8267/1	†							ALTIMETER , Mk. 19F. (Mod. 3971) (Pre- Mod. 3923)	1	—	A		
6A/7762	†							ALTIMETER , Mk. 22D. (Mod. 3923)	1	—	A		

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.2841	CABLE, ASSEMBLY, 16N, FROM PANEL FLY- ING, TO J.B.16, ASSEMBLY (MOD. 1420)						1	—	—	
		Consisting of:—									
5E/4183	†	CABLE, Uninyvin 20						QR	—	C	
5617	EEAS.111/4	FERRULE						1	—	C	
10H/0970060	†	GASKET, outlet						1	—	C	
10H/0970067	†	OUTLET, straight						1	—	C	
10H/0970090	†	RING, sealing						1	—	C	
5X/6488	CZ.23144/B	SCREW, clamp						1	—	C	
5K/	EEAS.118/3/16N	SLEEVE, identification						1	—	—	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long						31	—	C	
5K/9107066	EEAS.146/A1	SLEEVE, 3/4" long						1	—	C	
10H/0560220	†	SOCKET, Mk. 4						1	—	C	
	HELLERMANN										
5F/9454141	NY.18067	STRAP						QR	—	C	
5F/9138823	NY.3255	STUD						16	—	C	
32B/1250522	†	THREAD, waxed linen, No. 18						QR	—	C	
5F/	†	TUBE, P.V.C., 15.8 m/m i/d. x 1 m/m wall						QR	—	—	
6A/2089	†	CLOCK, type 5ACA						1	—	A	
or											
6A/2958	†	CLOCK, type Mk. 4B						1	—	A	
or											
6A/2197	†	CLOCK, type Mk. 4						1	—	A	
10L/240	†	CONTROL, volume						1	—	A	
6A/5798	†	GYRO, unit, horizon						1	—	A	
6B/561	†	GYRO, unit, type B						1	—	A	
6A/3147	†	INDICATOR, air speed, Mk. 9H						1	—	A	
5CZ/5074	†	INDICATOR, electro magnetic						1	—	C	
6A/3119	†	INDICATOR						1	—	A	
5CZ/5003	†	INDICATOR, magnetic						1	—	C	
10Q/61	†	INDICATOR, type 7						1	—	A	
6A/2966	†	INDICATOR, rate of climb, Mk. 3AD						1	—	A	
or											
6A/2697	†	INDICATOR, rate of climb, Mk. 3P						1	—	A	
6A/2945	†	INDICATOR, turn and slip						1	—	A	
5180	E.A3.90.26/1	INDICATOR, pilot's, special G-H						1	—	A	
6A/3667	SMITH 496FL	INDICATOR, rudder trim						1	—	A	
6A/5622	SMITH 814FL	INDICATOR, tail trim (Mod. 2302)						1	—	A	
6A/3160	SMITH 430FL	INDICATOR, aileron trim						1	—	A	
5CW/4192	†	LAMP, warning, type B, amber						1	—	C	
6A/3384	†	MACHMETER, type Mk. 2						1	—	A	
	E.B6.80.853	PANEL, FLYING, ASSEMBLY						—	—	—	
		Spares for:—									
	E.B7.80.473	BRACKET, shock absorber (Made from EED41)						4	DTD.683	—	
	E.B6.80.861	PANEL, blank						1	—	—	
33440	E.B6.81.5349	PILLAR, fixing						2	—	—	
	E.B6.80.823	PLATE, blanking, engraved						1	—	—	
6A/3120	†	SELECTOR, course (Pre-Mod. 2659)						1	—	A	
6A/4417	†	SELECTOR, combined heading and control panel (Mod. 2659)						1	—	A	
5CW/1047693	†	SWITCH						1	—	B	
	E.B6.80.5935	VIBRATOR, UNIT, INSTALLATION (MOD. 3747) (PRE-MOD. 3923)						—	—	—	
		Spares for:—									
6A/7041	†	VIBRATOR, unit and clip						1	—	A	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.31	PANEL, ENGINE INSTRUMENT, ASSEMBLY ...						—	—	—	
		Spares for:—									
6A/3855	SMITH AG.25	GAUGE, fuel contents (Mod. 1271) ...						1	—	A	
6A/3853	SMITH AG.26	GAUGE, fuel contents (Mod. 1271) ...						1	—	A	
6A/3854	SMITH AG.27	GAUGE, fuel contents (Mod. 1271) ...						1	—	A	
6A/3878	SMITH AG.28	GAUGE, fuel contents (Mod. 1271) ...						2	—	A	
	E.B6.80.33	PANEL ...						1	—	—	
17517	EEAS.28/2ER	WASHER, special ...						32	L.16	C	
	E.B6.80.467	PANEL, FIXED, STARBOARD, ASSEMBLY (PRE-MOD. 1482)						1	—	—	
		Spares for:—									
6A/2709	†	ALTIMETER, Mk. 18 ...						1	—	A	
5L/9951272	†	FLAMENT, 28v, 3.5w ...						2	—	C	
5L/9951273	†	FLAMENT, 28v, 3.5w ...						1	—	C	
6A/2693	†	GAUGE, Mk. 14LL, hydraulic pressure ...						2	—	C	
5CW/9333	DN1320.Z2	GROMMET (Mod. 4938) ...						1	—	C	
5CW/4222	†	GUARD, locking, switch ...						1	—	C	
6A/3942	SMITH 505FL	INDICATOR, cabin air ...						1	—	C	
5CX/1069	†	LAMP, warning, red ...						1	—	C	
	E.B6.80.463	PANEL, fixed ...						1	—	—	
5CW/9288	AS10512.L2	PLATE, adapter (Mod. 4938) ...						1	—	C	
5CW/6311	†	SWITCH, push, fire warning ...						2	—	B	
5CW/1047693	†	SWITCH, tumbler, S.P. (1 off Pre-Mod. 4938)						3	—	C	
5CW/9258	DN1320.Z1C-4	SWITCH, toggle, D.P. (Mod. 4938) ...						1	—	C	
5CW/7539	†	SWITCH, tumbler, centre off ...						1	—	C	
5CW/4400103	8824.B100	SWITCH, tumbler ...						2	—	C	
5CW/9354	AS10512.M2	TERMINAL, shroud (Mod. 4938) ...						1	—	C	
17104	E.B7.81.259	WASHER, packing, overload tank switches ...						4	—	C	
5CW/11817	†	WINDOW, F1, fire warning switch ...						1	—	C	
5CW/11818	†	WINDOW, F2, fire warning switch ...						1	—	C	
	E.B6.80.689	PANEL, INSTRUMENT, STARBOARD, ASSEMBLY (MOD. 1482) (PRE-MOD. 2659)						—	—	—	
		Spares for:—									
6A/2709	†	ALTIMETER, Mk. 18 ...						1	—	A	
	E.B6.80.605	CABLE ASSEMBLY, 16G, FROM STARBOARD FIXED PANEL TO J.B.6						1	—	—	
		Consisting of:—									
5E/4183	†	CABLE, Uninyvin 20 ...						QR	—	C	
10H/0970296	CZ.69738	CLAMP, cable ...						1	—	C	
10H/0970060	Z.60669	GASKET, outlet ...						1	—	C	
10H/0970110	Z.62239	GASKET, union ...						1	—	C	
10H/0970067	CZ.49186	OUTLET, straight ...						1	—	C	
10H/0970090	Z.62233	RING, sealing ...						1	—	C	
10H/0970098	Z.49084	RING, thrust ...						1	—	C	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long ...						34	—	C	
5K/9107067	EEAS.146/C	SLEEVE, 3/4" long ...						4	—	C	
5K/9107068	EEAS.146/D1	SLEEVE, 3/4" long ...						1	—	C	
5K/9107069	EEAS.146/E	SLEEVE, 3/4" long ...						1	—	C	
5K/9107070	EEAS.146/H	SLEEVE, 1" long ...						4	—	C	
10H/0560220	CZ.49070	SOCKET, Mk. 4, 25-way ...						1	—	C	
	HELLERMANN	STRAP ...						QR	—	C	
5F/9454141	NY.18007A	STUD ...						6	—	C	
5F/9138822	NY.3342	TAPE, rubber ...						QR	—	C	
5F/9401215	†	THREAD, waxed linen, No. 18 ...						QR	—	C	
32B/1250522	†										

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.607	CABLE, ASSEMBLY, 16H, FROM STARBOARD, FIXED PANEL TO J.B.16						1	—	—	
		Consisting of:—									
	5E/4183 †	CABLE, Uninyvin 20						QR	—	C	
10H/0970294	CZ.69735	CLAMP, cable						1	—	C	
10H/0970059	Z.60668	GASKET, outlet						1	—	C	
10H/0970111	Z.62237	GASKET, union						1	—	C	
10H/0970065	CZ.49182	OUTLET, straight						1	—	C	
10H/0970091	Z.62231	RING, sealing						1	—	C	
10H/9995082	Z.66473	RING, thrust						1	—	C	
5K/9107065	EEAS.146/A	SLEEVE, 3/4" long						21	—	C	
5K/9107066	EEAS.146/A1	SLEEVE, 3/4" long						3	—	C	
5K/9107067	EEAS.146/B	SLEEVE, 3/4" long						1	—	C	
5K/9107067	EEAS.146/C	SLEEVE, 3/4" long						2	—	C	
5K/9107069	EEAS.146/E	SLEEVE, 1" long						4	—	C	
10H/0560180	CZ.49126	SOCKET, Mk. 4, 12-way						1	—	C	
	HELLERMANN										
5F/9454141	NY.18307A	STRAP						QR	—	C	
	HELLERMANN										
5F/9138822	NY.3342	STUD						6	—	C	
5X/9450396	HC.490	TAG, QR						3	—	C	
	32B/498 †	THREAD, waxed linen, No. 18						QR	—	C	
5L/9951272	†	FILAMENT, lamp, 28 volt, 3.5 watt						2	—	C	
5L/9951273	†	FILAMENT, lamp, 28 volt, 3.5 watt						2	—	C	
	20387	FLAP, spring, assembly						1	—	C	
	6D/2237 †	GAUGE, pressure, oxygen, Mk. 4						2	—	A	
	6A/2693 †	GAUGE, pressure, Mk. 14LL						2	—	C	
	6A/3942	INDICATOR, cabin, air						1	—	C	
	6A/2775 †	LABEL, hydraulic, fluorescent						2	—	C	
5CX/1553	†	LAMP, warning, Rotax, type H.2702, red						2	—	C	
	E.B6.80.691	PANEL, ASSEMBLY						1	—	—	
		Spares for:—									
	E.B6.80.693	PANEL, blank						1	—	—	
	27357	DOOR, assembly						1	—	C	
	6A/3121 †	PANEL, control, Zero reader						1	—	A	
	19968	PLATE, blanking						2	L.72	—	
	E.B6.80.609	PLATE, blanking						2	L.72	—	
	27356	PLATE, blanking						1	L.72	C	
	27364	SPACER, threaded						2	—	C	
5CW/9438526	†	SWITCH, push, type B						1	—	B	
	5CW/6311 †	SWITCH, fire warning						2	—	B	
	5CW/5818	SWITCH						1	—	—	
	NSF.8812-K7	SWITCH						1	—	—	
	NSF.8810-K6	SWITCH						3	—	C	
	NSF.8295-B109	SWITCH						1	—	C	
	5Q/4347793 †	VOLTMETER, 0-40 volt						1	—	C	
	5CW/11817 †	WINDOW, for fire warning switch, type F1						1	—	C	
	5CW/11818 †	WINDOW, for fire warning switch, type F2						1	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. Off	Matl Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.B6.80.1005	PANEL, INSTRUMENT, STARBOARD, ASSEMBLY (MOD. 2659) Spares for this assembly are identical with those for assembly Part No. E.B6.80.689 on page 426, except for the following deletion and addition Delete:—						—	—	—	
6A/3121	†	PANEL, control, Zero reader						1	—	A	
19968	E.A4.80.377	PLATE, blanking						1	L.72	C	
12611	E.B7.80.497	SNUB, pilot's instrument panel, buffer						4	Shore 30	C	
2033	E.A3.80.1789	WASHER, special, for flexible mounting						10	L.72	C	
6918	EEAS.28/51FR	WASHER, special, for flexible mounting						10	L.72	C	
	EEAS.28/51JR	WASHER, for flexible mounting						2	—	—	
18859	EEAS.28/6GR	WASHER, special, for flexible mounting						2	—	C	
	E.B6.80.779	NAVIGATOR'S INSTRUMENT PANEL, ASSEMBLY (MOD. 2542) Spares for:—						—	—	—	
	E.B6.80.773	PLATE, mounting, assembly						1	—	—	
	E.B6.71.575	RELEASE, BOMB AIMER'S EMERGENCY OXYGEN, INSTALLATION (MOD. 4052) Spares for:—						—	—	—	
	E.B6.71.583	RELEASE, OXYGEN, EMERGENCY, ASSEMBLY ... Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE, assembly						1	—	—	
	E.B6.71.581	TUBE, assembly						1	—	—	
	E.B6.71.635	RELEASE, NAVIGATOR'S EMERGENCY OXYGEN, INSTALLATION (MOD. 4052 AND 4065) Spares for:—						—	—	—	
	E.B6.71.627	PLATE, mounting Attaching parts for E.B6.71.627:—						1	—	—	
28D/9436920	A25/1C	Bolt, 2 BA						4	—	C	
28W/9419475	SP.15/C	Washer						4	—	C	
34350	E.B6.71.579	RELEASE, OXYGEN, EMERGENCY Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE, assembly						1	—	C	
	E.B6.71.577	TUBE, assembly Attaching parts for E.B6.71.577:—						1	—	—	
28D/9436920	A25/1C	Bolt, 2 BA						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
	E.B6.71.593	RELEASE, PILOT'S EMERGENCY, OXYGEN, INSTALLATION (MOD. 4051) Spares for:—						—	—	—	
	E.B6.71.611	RELEASE, OXYGEN, EMERGENCY, ASSEMBLY Spares for:—						1	—	—	
34485	E.B6.71.591	CABLE, ASSEMBLY Spares for:—						1	—	—	
	E.B6.71.587	KNOB Attaching parts for E.B6.71.587:—						1	—	—	
28M/9433473	AGS.2002/C/1	Nut, 2 BA						1	—	C	
28W/9419402	SP.13/C	Washer						1	—	C	
	E.B6.71.589	PIECE, distance						1	—	—	
	E.B6.71.585	WIRE, cable						1	—	—	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	LM	
		1 2 3 4 5 6					
34486	E.B6.71.613	TUBE , and bracket, assembly	1	—	—		
		Attaching parts for E.B6.71.613:—					
28D/9138768	A25/1C	Bolt, 2 BA	2	—	C		
28D/9136920	A25/1C	Bolt, 2 BA	2	—	C		
28W/9419402	SP.13/C	Washer	4	—	C		
	E.B6.71.601	TOP HAT	1	—	—		
		Attaching parts for E.B6.71.601:—					
28D/9136920	A25/1C	Bolt, 2 BA	9	—	C		
28D/9130082	AS.1246/3B	Bolt, 4 BA	2	—	C		
28M/1278190	AGS.2001/C/1	Nut, 2 BA	9	—	C		
28M/1006504	A27/BT	Nut, 4 BA	2	—	C		
28W/9419402	SP.13/C	Washer	9	—	C		
	E.A3.80.1231	SEAT, MAP READER'S, ASSEMBLY	1	—	—		
		Spares for:—					
4537	E.A3.80.1289	CABLE, "BOWDEN", ASSEMBLY	1	—	B		AE.1
		Consisting of:—					
5200	E.A3.80.1293	BRACKET	1	L.72	C		AE.1
29H/2153	P.19/52A	CABLE , Bowdenite, non fray, inner	QR	—	C		
29H/2184	B.52	CONDUIT , outer	QR	—	C		
29H/1893	PN.980	FERRULE , plain	2	—	C		
29H/2154	PN.3341A	NIPPLE , spherical	2	—	C		
29H/1901	PN.1161/1159	STOP , plain, adjusting	1	—	C		
5201	E.A3.80.1291	WASHER , tapped, radiused	1	S.11	C		
2165	EEAS.112/6	CLIP , pipe, 1/4" BSF, single	4	L.16	C		
4538	E.A3.80.1237	LOCK, BOTTOM, ASSEMBLY	1	—	B		AE.1
		Spares for:—					
	E.A3.80.1255	BOLT , special	1	S.11	—		
	E.A3.80.1249	BRACKET , bottom, half	1	L.40	—		
	E.A3.80.1250	BRACKET , bottom half	1	L.40	—		
	E.A3.80.1251	CATCH , bottom	1	DTD.124			AE.1
5066	E.A3.80.1253	SPRING	1	Spring Steel	C		AE.1
	E.A3.80.1285	WASHER , saddle	1	DTD.124			AE.1
18859	EEAS.28/6GR	WASHER	1	L.72	C		
	E.A3.80.1231A	PAD , 2" x 1" (Make from Ref. 32C/384)	1	Sorbo Rubber	LM		AE.1
	E.A3.80.1957	STOWAGE MAP READER'S SEAT, ASSEMBLY	1	—	—		
		Spares for:—					
5197	E.A3.80.1959	STRAP	1	—	C		AE.1
8521	E.A3.80.1235	SUPPORT, MAP READER'S SEAT, ASSEMBLY	1	T.45	B		
		Spares for:—					
31533	E.A3.80.1261	ROLLER, GUIDE, ASSEMBLY	1	—	C		
		Consisting of:—					
	E.A3.80.1259	BOLT	1	S.11			AE.1
	E.A3.80.1257	ROLLER	1	L.40			AE.1
	AS.2811/6/020	WASHER , distance	1	T.4	LM		
	AS.2811/6/025	WASHER , distance	1	T.4	LM		

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.B6.80.867	SEAT, MAP READER'S AND FIRE AXE STOWAGE, ASSEMBLY (MOD. 2197 - S.O.O.) Spares for this assembly are identical with those for assembly Part No. E.A3.80.1231 on page 426C, except for the following deletions and additions:— Delete:—	1	—	—		
8521	E.A3.80.1235	SUPPORT, MAP READER'S SEAT, ASSEMBLY ... Add:—	1	T.45	B		
	E.B6.80.869	SUPPORT, SEAT AND FIRE AXE STOWAGE ... Spares for:—	1	—	—		
	E.B6.80.831	BRACKET, MOUNTING, ASSEMBLY ... Spares for:—	1	—	—		
28E/9513854	AS.2294/8	CLIP, spring ...	1	—	C		
	E.B6.80.815	PLATE, MOUNTING, ASSEMBLY ... Spares for:—	1	—	—		
8596	E.A3.80.1831	STRAP, 1/4" thick, leather ...	1	—	C/MR		
31533	E.A3.80.1261	ROLLER, GUIDE, ASSEMBLY ... Consisting of:—	1	—	B		
	E.A3.80.1259	BOLT ...	1	S.11	—		
	E.A3.80.1257	ROLLER ...	1	L.40	—		
	AS.2811/6/020	WASHER, distance ...	1	T.4	LM		
	E.B6.80.5983	SEATING IN PRESSURE CABIN, ASSEMBLY (MOD. 4051-4052)	—	—	—		
	E.B6.80.5957	SEATING IN PRESSURE CABIN, ASSEMBLY (MOD. 3518-2685) Spares for:—	—	—	—		
	E.B6.80.25	BRACKET, top pilot's seat rail, attachment ...	1	S.95	—		
	E.B6.80.26	BRACKET, top pilot's seat rail, attachment ... Attaching parts for E.B6.80.25 and E.B6.80.26:—	1	S.95	—		
5629	E.B6.80.27	Bolt, 2 BA ...	2	S.97	C		
28M/9436836	AGS.2001/C/2	Nut, 2 BA ...	2	—	C		
16706	E.B6.80.29	Packing, filter ...	2	L.72	C		
	E.G5.80.181	BRACKET, pipe clamp ...	1	—	—		
	E.B6.80.5977	BRACKET, LEG RESTRAINT, INSTALLATION ... Spares for:—	—	—	—		
	MARTIN BAKER A/MBEU/3666	BRACKET, floor ... Attaching parts for A/MBEU/3666:—	2	—	—		
28D/9140644	A25/9C	Bolt, 2 BA ...	4	—	C		
	E.G5.80.159	CHANNEL ...	1	—	—		
	E.G5.80.165	CHANNEL ...	1	—	—		
27L/2729	MARTIN BAKER B/MBEU/17353	LINE, leg ...	2	—	C		
27L/80	O/MBEU/1434	PIN ...	2	—	C		
	E.B6.80.5949	BRACKET, TRIP ROD, BOMB AIMER'S, INSTALLATION Spares for:—	—	—	—		
	E.B6.80.5953	ANGLE, support ...	3	—	—		
	E.B6.80.5951	BRACKET ...	1	—	—		
	E.B6.80.5955	BRACKET ...	3	—	—		

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No Off	Matl Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
	E.B6.80.5947	BRACKET, TRIP ROD, NAVIGATOR'S, INSTALLATION						—	—	—	
		Spares for:—									
	E.B6.80.5953	ANGLE, support						2	—	—	
41333	E.B6.80.5951	BRACKET						1	—	MR	
41334	E.B6.80.5955	BRACKET						3	—	MR	
12K/1277	†	CARTRIDGE, No. 3, Mk. 1						1	—	C	
12K/9629465	†	CARTRIDGE, No. 13, Mk. 1 (Mod. 4448)						3 Sets	—	C	
41866	E.G5.80.177	CLAMP, ASSEMBLY						1	—	C	
		Spares for:—									
	E.G5.80.179	CLAMP, half						2	—	—	
	E.B6.80.8027	EQUIPMENT, SINGLE LEVER EJECTION ON PRESSURE BULKHEAD, INSTALLATION (MOD. 3776)						—	—	—	
		Spares for:—									
1439133	E.A3.80.6409	BOX, sealing						1	—	C	
34835	E.A3.80.6423	CABLE, secondary firing, assembly (For aircraft not embodying Martin Baker Mod. ESA47)						2	—	C	
		Attaching parts for E.A3.80.6423:—									
28P/9140979	SP.4Z/B4	Pin, shackle						2	—	C	
28P/1021104	SP.90/C3	Pin, split						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
	E.A3.80.6609	CABLE, assembly, secondary firing (Made from BS 2W11/5PNC) (Mod. 4948, for aircraft embodying Martin Baker Mod. ESA47)						2	—	—	
		Attaching parts for E.A3.80.6609:—									
28P/9140979	AVDEL BLC-6BA-04SF SP.4/Z/B4	Pin, quick release						1	—	—	
28P/1021104	SP.90/C3	Pin, shackle						1	—	C	
28W/9419402	SP.13/C	Pin, split						1	—	C	
		Washer						1	—	C	
	E.B6.80.8025	CONDUIT, convoluted, bomb aimer's, assembly						1	—	—	
	E.B6.80.8023	CONDUIT, convoluted, navigator's, assembly...						1	—	—	
		Attaching parts for E.B6.80.8023:—									
28D/1008149	A25/2B	Bolt, 4 BA						8	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA						8	—	C	
34849	E.A3.80.6429	Seal, 1/8" thick						1	NEOPRENE	C	
28W/9419465	SP.13/B	Washer						8	—	C	
	E.A3.80.6407	COVER, assembly						1	—	—	
34838	E.A3.80.6417	LEVER, cocking, assembly						2	—	C	
42531	E.A3.80.6413	LINK, cocking, assembly						1	—	C	
		Attaching parts for E.A3.80.6413:—									
28M/1278190	E.A3.80.6411	Bolt						3	S.95	—	
28P/1202569	AGS.2001/C/1	Nut, 2 BA						3	—	C	
28W/9419454	SP.90/E3	Pin, split						3	—	C	
28W/9419404	SP.10/C	Washer						1	—	C	
28W/9418921	SP.16/C	Washer						2	—	C	
	SP.13/E	Washer						3	—	C	
1439180	E.A3.81.6523	MECHANISM, SINGLE LEVER EJECTION BOMB AIMER'S, ASSEMBLY (MOD. 4468)						1	—	B	
		Consisting of:—									
42534	E.A3.81.6047	ARM, cam follower, assembly						1	—	C	
	E.A3.81.6061	BLOCK, guide						1	L.64	—	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
27L/5355	MARTIN BAKER MBCJ/972							1	—	C	
27L/	MARTIN BAKER MBCJ/1582							1	—	—	
27L/5353	MARTIN BAKER MBCJ/970							1	—	C	
27L/50131	MARTIN BAKER EMBEU/1964EE							1	—	B	
28D/1008151	A25/4E							9	—	C	
28D/1011240	A25/5E							8	—	C	
28D/1008145	A25/6E							6	—	C	
28D/1018884	A25/9G							2	—	C	
28D/1213582	A25/5L							5	—	C	
28D/1013178	AS.1242/5E							1	—	C	
28M/1201610	AGS.2001/E/1							24	—	C	
28M/10291	AGS.2001/G/1							2	—	C	
28M/10293	AGS.2001/L/1							5	—	C	
3802	E.A3.10.2197							1	—	C	
4885	E.A3.80.477							2	—	C	
3897	E.A3.80.481							20	—	C	
3935	E.A3.10.571							1	—	C	
28W/9419405	SP.15/E							20	—	C	
28W/9419476	SP.15/G							2	—	C	
28W/9419478	SP.15/L							5	—	C	
28W/9419487	SP.16/E							4	—	C	
27L/50130	MARTIN BAKER EMBEU/1963EE							1	—	B	
28D/1008145	A25/6E							12	—	C	
28D/1011242	A25/7E							10	—	C	
28D/1010031	A25/8E							1	—	C	
28D/1011257	A25/7G							4	—	C	
28D/1011258	A25/8G							1	—	C	
28D/1011259	A25/10G							2	—	C	
28D/1213582	A25/5L							5	—	C	
28D/1013179	AS.1242/6E							1	—	C	
28M/1201610	AGS.2001/E/1							24	—	C	
28M/10291	AGS.2001/G/1							7	—	C	
28M/10293	AGS.2001/L/1							5	—	C	
16667	E.A3.80.439							1	—	C	
3802	E.A3.10.2197							1	—	C	
4885	E.A3.80.477							2	—	C	
4886	E.A3.80.479							5	—	C	
3897	E.A3.80.481							20	—	C	
3935	E.A3.10.571							1	—	C	
28W/9419405	SP.15/E							20	—	C	
28W/9419476	SP.15/G							2	—	C	
28W/9419478	SP.15/L							5	—	C	
28W/9419487	SP.16/E							4	—	C	
28W/9419488	SP.16/G							4	—	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
27L/50129	MARTIN BAKER EMBEU/1902EE	RAIL , guide, pilot's	1	—	B	
		Attaching parts for EMBEU/ 1902EE:—				
28D/1011256	A25/5G	Bolt; $\frac{3}{16}$ " BSF	2	—	C	
28D/1006583	A25/5J	Bolt; $\frac{3}{16}$ " BSF	2	—	C	
28M/10291	AGS.2001/G/1	Nut; $\frac{3}{16}$ " BSF	2	—	C	
28M/10292	AGS.2001/J/1	Nut; $\frac{3}{16}$ " BSF	2	—	C	
28W/9419477	SP.15/J	Washer	2	—	C	
27L/1445204	MARTIN BAKER †	SEAT, EJECTION MK. 2.CA1 MK. 2, PILOT'S (MOD. 4448)	1	—	A	
27L/1445205	MARTIN BAKER †	SEAT, EJECTION, MK. 2.CA2, MK. 4 (MOD. 4448)	2	—	A	
27L/5021	MARTIN BAKER MBCJ/159	TIME RELEASE AND BREACH COMBINED UNIT	1	—	A	
27L/1445196	MARTIN BAKER C76-HC-MB	UNION , coupling (Ermeto)	2	—	C	
	—	STOWAGE PERISCOPE, ASSEMBLY (E.B6.90.943) (MOD. 2312)	—	—	—	
		Spares for:—				
	E.B6.80.947	BRACKET , assembly, lower, stowage	1	—	—	
	E.B6.80.949	BRACKET , upper stowage	1	L.72	—	
	E.B6.80.975	BRACKET , assembly, warning horn	1	—	—	
	E.B6.80.1019	BRACKET , strengthening, upper stowage	1	S.510	—	
32547	E.B6.80.945	TUBE, ASSEMBLY	1	—	B	
		Spares for:—				
	E.B6.80.985	HANDLE	1	—	—	
	E.B6.80.979	LOCK	1	L.65	—	
	E.B6.80.983	NUT	1	L.65	—	
28P/1011122	SP.29/E8	PIN , solid taper	1	—	C	
32548	E.B6.80.981	SPRING	1	BS.1408	C	
	E.B6.80.977	TUBE , assembly	1	—	—	
	EEAS.28/42AR	WASHER , packing	QR	—	—	
	E.A1.80.967	STRAP, BACK OCCASIONAL, SEAT, ASSEMBLY ...	—	—	—	
		Spares for:—				
28FP/1048015	AVDEL A.405	PIN , "pip"	1	H.T.S.	C	AE.1
6407	E.A3.80.2665	STRAP, BACK, ASSEMBLY	1	—	B	
		Spares for:—				
	AS.2394	COLLAR	1	—	—	
8809	E.A1.80.971	EYE-BOLT	1	L.72	C	
	E.A1.80.973	PLATE , strap	1	L.72	—	AE.1
6180	E.A1.80.975	PLATE , strap	1	L.72	C	AE.1
28U/13992	AS.2385	TRUNNION	1	—	C	AE.1
32B/498	†	THREAD , waxed linen, No. 18	QR	—	C	
8810	E.A3.80.2681	WEBBING , 40" long x 6½" wide	1	—	C	
5630	E.A3.83.181	SUNBLIND, PILOT'S, ASSEMBLY (PRE-MOD. 3278)	1	—	A	
		Spares for:—				
8798	E.A3.83.195	BEARING , support, bottom	2	LFS.26	C	
8799	E.A3.83.197	BEARING , support, top	2	LFS.26	C	
13152	E.A3.83.279	BRACKET , and strap support	1	—	C	
	†	COR , silk (Make from Ref. 32A/155)	QR	DTD.67A	—	
	E.A3.83.217	FABRIC , nylon, white (Make from Ref. 32B/1019)	1	DTD.793	—	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R. L.M.		
		1 2 3 4 5 6					
	E.A3.83.219	FABRIC , nylon, green (Make from Ref. 32B/1020)	1	DTD.793	—		
8793	E.A3.83.185	FRAME , inner	1	L.65	—		
8794	E.A3.83.187	FRAME , outer, starboard	1	—	B		
8795	E.A3.83.189	FRAME , OUTER, PORT, ASSEMBLY	1	—	B		
		Spares for:—					
21222	E.A3.83.287	FRAME , outer, flexible	1	Nevellon	B		
5631	E.A3.83.205	SPRING , compression	1	DTD.215	C		
8803	E.A3.83.209	STIFFENER	1	Nevellon	C		
8804	E.A3.83.211	STIFFENER	2	Nevellon	C		
8805	E.A3.83.213	STIFFENER	2	Nevellon	C		
8806	E.A3.83.215	STIFFENER	2	Nevellon	C		
8800	E.A3.83.201	TUBE , spring housing	1	—	C		
8801	E.A3.83.203	TUBE , spring housing	1	—	C		
33335	E.B6.83.363	SUNBLIND, PILOT'S, ASSEMBLY (MOD. 3278) ...	1	—	B		
		Spares for this assembly are identical with those for assembly Part No. E.A3.83.181 on page 426H, except for the following deletion and addition:—					
		Delete:—					
8793	E.A3.83.185	FRAME , inner	1	—	B		
		Add:—					
	E.B6.83.365	FRAME , inner	1	—	—		
41357	E.G5.83.21	SUNBLIND, PILOT'S, ASSEMBLY (MOD. 4051) ...	1	—	B		
		Spares for:—					
	E.G5.83.51	BRACKET , stop, port	1	—	C		
	E.G5.83.53	BRACKET , stop, starboard	1	—	C		
32A/155	†	CORD , silk (Alternative)	QR	DTD.67A	C		
32A/141	†	CORD , nylon (Alternative)	QR	DTD.481F	C		
	E.G5.83.61	FABRIC , nylon, green (Make from Ref. 32B/1020)	1	DTD.793	LM		
	E.G5.83.59	FABRIC , nylon, white (Make from Ref. 32B/1019)	1	DTD.793	LM		
	E.G5.83.55	FRAME , flexible	1	Glass cloth	—		
	E.G5.83.27	FRAME, INNER, ASSEMBLY	1	—	C		
		Spares for:—					
	E.G5.83.31	FRAME , wire	1	—	—		
	E.G5.83.29	MEMBER , inner frame	1	—	—		
	E.G5.83.33	SOCKET , inner frame, port	1	—	—		
	E.G5.83.35	SOCKET , inner frame, starboard	1	—	—		
34436	E.G5.83.63	HANDLE , control	1	—	C		
		Attaching parts for E.G5.83.63:—					
28D/1007468	AS.1242/3B	Bolt, 4 BA	4	—	C		
28M/1278189	AGS.2001/B/1	Nut, 4 BA	4	—	C		
28W/9419465	SP.13/B	Washer	4	—	C		
	E.G5.83.45	LEVER , assembly	1	—	—		
	E.G5.83.47	PLATE , stop, assembly	1	—	—		
	E.G5.83.41	SHAFT , inner	1	—	—		
	E.G5.83.37	SOCKET , outer frame, port	1	—	—		
	E.G5.83.39	SOCKET , outer, frame, starboard	1	—	—		
	E.A3.83.205	SPRING :	1	DTD.215	—		
	E.G5.83.23	STAY , outer, port	1	—	—		
	E.G5.83.25	STAY , outer, starboard	1	—	—		
	E.G5.83.57	STIFFENER	1	—	—		
8804	E.A3.83.211	STIFFENER	2	—	C		
8805	E.A3.83.213	STIFFENER	2	—	C		

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
8806	E.A3.83.215	STIFFENER						2	—	C	
	E.G5.83.43	TUBE , bearing						1	—	—	
8800	E.A3.83.201	TUBE , spring housing						1	—	C	
8801	E.A3.83.203	TUBE , spring housing						1	—	C	
		Attaching parts for E.A3.83.201 and E.A3.83.203:—									
28N/1045681	AGS.899/1	Collar						1	—	C	
28P/814	SP.4Y/A4	Pin, shackle						1	—	C	
28P/9710567	SP.90/C4	Pin, split						1	—	C	
		Attaching parts for E.G5.83.21:—									
8798	E.A3.83.195	Bearing, support, bottom						2	—	C	
8799	E.A3.83.197	Bearing, support, bottom						2	—	C	
28D/1214035	AS.1242/13C	Bolt, 2 BA						4	—	C	
28M/9433473	AGS.2002/C/1	Nut, 2 BA						4	—	C	
28W/9419402	SP.13/C	Washer						4	—	C	
	E.B6.80.787	SWITCH, MASTER, U/C, ASSEMBLY (MOD. 2364)						1	—	—	
		Spares for:—									
37435	E.A9.80.1259	BRACKET , switch, mounting						1	—	C	
5CW/5765	†	SWITCH, GUARD						1	—	B	
5CW/6435	†	SWITCH , D.P. change over						1	—	B	
	E.B6.85.1	WINDOW, CARTRIDGE STOWAGE (MOD. 1435)						—	—	—	
		Spares for:—									
37555	E.B6.85.9	BRACKET , end, L.H.						1	L.72	C/MR	
37556	E.B6.85.10	BRACKET , end, R.H.						1	L.72	C/MR	
26478	E.B6.85.3	STOWING , cartridge, assembly						1	—	B/MR	
	E.B6.80.631	ZERO READER, ASSEMBLY (MOD. 1447)						—	—	—	
		Spares for:—									
	E.B6.80.619	COMPUTER, FLIGHT, FITTINGS						1	—	—	
		Spares for:—									
	E.B6.80.647	ANGLE , forward (Made from R.S.130/42)						1	L.72	C/MR	
	E.B6.80.649	DIAPHRAGM , L.H.						1	L.72	C/MR	
26436	E.B6.80.650	DIAPHRAGM , R.H.						1	L.72	C/MR	
	E.B6.80.761	PIECE , packing						2	L.72	—	
	E.B6.80.653	PLATE , mounting, assembly						1	—	C/MR	
32534	E.B6.80.633	MOUNTING, COMPUTER FLIGHT, ASSEMBLY						1	—	A	
		Spares for:—									
	MARCONI R.I.D.1004A	DEVICE , lock						2	—	—	
	E.B6.80.635	MEMBER , horizontal (Made from Marconi Part R.I.D.101-1, Ref. 9)						1	—	—	
	MARCONI R.I.D.1012-1-Ref. 5	MEMBER , side, R.H.						1	—	—	
	MARCONI R.I.D.1012-2-Ref. 15	MEMBER , side, L.H.						1	—	—	
	SPERRY SK.9054-8	MOUNTING , shock absorber						4	—	—	
	AS.2810/4/02	TUBE , distance						4	—	—	
	MARCONI R.I.D.1012-3	WASHER , domed						8	—	—	
	E.B6.80.637	MOUNTING, BOX, JUNCTION FLIGHT, INSTRUMENTS						1	—	—	
		Spares for:—									
26413	E.B6.80.639	ANGLE , mounting, assembly						1	—	C	
26412	E.B6.80.643	PLATE , mounting, assembly						1	—	C	

EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
SUMMARY OF STOCK ITEMS USED ON PRESSURE CABIN EQUIPMENT						
28D/1008147	A25/1A	Bolt, 6 BA, hex. head, 0"45 long ...				C
28D/1007971	A25/1B	Bolt, 4 BA, hex. head, 0"25 long ...				C
28D/1010658	A25/1B	Bolt, 4 BA, hex. head, 0"5 long ...				C
28D/9140638	A25/4B	Bolt, 4 BA, hex. head, 0"8 long ...				C
28D/1011011	A25/8B	Bolt, 4 BA, hex. head, 1"2 long ...				C
28D/9140639	A25/11B	Bolt, 4 BA, hex. head, 1"5 long ...				C
28D/9436920	A25/1C	Bolt, 2 BA, hex. head, 0"55 long ...				C
28D/9133011	A25/2C	Bolt, 2 BA, hex. head, 0"65 long ...				C
28D/9133012	A25/3C	Bolt, 2 BA, hex. head, 0"75 long ...				C
28D/1200119	A25/4C	Bolt, 2 BA, hex. head, 0"85 long ...				C
28D/1011019	A25/8C	Bolt, 2 BA, hex. head, 1"25 long ...				C
28D/9140645	A25/10C	Bolt, 2 BA, hex. head, 1"5 long ...				C
28D/1011029	A25/1E	Bolt, 1/4" BSF, hex. head, 0"6 long ...				C
28D/1008151	A25/4E	Bolt, 1/4" BSF, hex. head, 0"9 long ...				C
28D/1011240	A25/5E	Bolt, 1/4" BSF, hex. head, 1"0 long ...				C
28D/1008145	A25/6E	Bolt, 1/4" BSF, hex. head, 1"1 long ...				C
28D/1011242	A25/7E	Bolt, 1/4" BSF, hex. head, 1"2 long ...				C
28D/1010031	A25/8E	Bolt, 1/4" BSF, hex. head, 1"3 long ...				C
28D/1011244	A25/9E	Bolt, 1/4" BSF, hex. head, 1"4 long ...				C
28D/1011245	A25/10E	Bolt, 1/4" BSF, hex. head, 1"5 long ...				C
28D/1011246	A25/11E	Bolt, 1/4" BSF, hex. head, 1"6 long ...				C
28D/7002418	A25/14E	Bolt, 1/4" BSF, hex. head, 1"9 long ...				C
28D/9706306	A25/17E	Bolt, 1/4" BSF, hex. head, 2"2 long ...				C
28D/1011256	A25/5G	Bolt, 5/16" BSF, hex. head, 1"05 long ...				C
28D/1011257	A25/7G	Bolt, 5/16" BSF, hex. head, 1"25 long ...				C
28D/1011258	A25/8G	Bolt, 5/16" BSF, hex. head, 1"35 long ...				C
28D/1018884	A25/9G	Bolt, 5/16" BSF, hex. head, 1"45 long ...				C
28D/1011259	A25/10G	Bolt, 5/16" BSF, hex. head, 1"55 long ...				C
28D/1006583	A25/5J	Bolt, 3/8" BSF, hex. head, 1"15 long ...				C
28D/1213582	A25/5L	Bolt, 3/8" BSF, hex. head, 1"2 long ...				C
28D/1212964	A61/1B	Bolt, 4 BA, hex. head, 0"5 long ...				C
28D/1212965	A61/2B	Bolt, 4 BA, hex. head, 0"6 long ...				C
28D/1213235	A61/14E	Bolt, 1" BSF, hex. head, 1"9 long ...				C
28D/1007975	AS.1242/1C	Bolt, 2 BA, c'sk. head, 0"5 long ...				C
28D/9709461	AS.1242/3C	Bolt, 2 BA, c'sk. head, 0"7 long ...				C
28D/1214036	AS.1242/14C	Bolt, 2 BA, c'sk. head, 1"8 long ...				C
28D/1007979	AS.1246/1B	Bolt, 4 BA, round head, 0"5 long ...				C
28D/9140202	AS.1246/1C	Bolt, 2 BA, round head, 0"35 long ...				C
28D/9137409	AS.1246/2C	Bolt, 2 BA, round head, 0"6 long ...				C
28D/9140203	AS.1246/3C	Bolt, 2 BA, round head, 0"7 long ...				C
28D/1215327	AS.1246/1E	Bolt, 1/4" BSF, round head, 0"55 long ...				C
28D/1213450	AS.1247/1B	Bolt, 4 BA, round head, 0"4 long ...				C
28D/1007982	AS.1248/1C	Bolt, 2 BA, mushroom head, 0"5 long ...				C
28D/1013301	AS.1248/4C	Bolt, 2 BA, mushroom head, 0"8 long ...				C
28D/1215159	AS.4565/1C	Bolt, 2 BA, ...				C
28D/1213484	AS.4565/9E	Bolt, 1/4" BSF, ...				C
28D/1213513	AS.4565/31E	Bolt, ...				C
28N/1045681	AGS.899/1	Collar, ...				C
28M/1200096	A27/AT	Nut, 6 BA, thin ...				C
28M/9403519	A27/BP	Nut, 4 BA, plain ...				C
28M/1006504	A27/BT	Nut, 4 BA, thin ...				C
28M/5808573	A27/CS	Nut, 2 BA, slotted ...				C

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
28M/1011475	A27/EP	Nut, 1/2" BSF, plain	C	
28M/10286	AGS.2001/A/1	Nut, stiff, 6:BA	C	
28M/10279	AGS.2001/A/3	Nut, stiff, 6:BA	C	
28M/1278189	AGS.2001/B/1	Nut, stiff, 4:BA	C	
28M/10274	AGS.2001/B/4	Nut, stiff, 4:BA	C	
28M/1278190	AGS.2001/C/1	Nut, stiff, 2:BA	C	
28M/9436836	AGS.2001/C/2	Nut, stiff, 2:BA	C	
28M/10281	AGS.2001/C/3	Nut, stiff, 2:BA	C	
28M/10275	AGS.2001/C/4	Nut, stiff, 2:BA	C	
28M/1201610	AGS.2001/E/1	Nut, stiff, 1/4" BSF	C	
28M/10282	AGS.2001/E/3	Nut, stiff, 1/4" BSF	C	
28M/10291	AGS.2001/G/1	Nut, stiff	C	
28M/10292	AGS.2001/J/1	Nut, stiff, 3/8" BSF	C	
28M/10293	AGS.2001/L/1	Nut, stiff, 7/16" BSF	C	
28M/10318	AGS.2002/B/3	Nut, stiff, 4:BA	C	
28M/11957	AGS.2007/C/1	Nut, stiff, 2:BA	C	
28P/1207920	SP.90/B5	Pin, split, 3/64" dia. x 1/4" long	C	
28P/9710567	SP.90/C4	Pin, split, 1/16" dia. x 5/8" long	C	
28P/9527619	SP.90/C7	Pin, split, 1/16" dia. x 1" long	C	
28P/814	SP.4Y/A4	Pin, shackle	C	
28P/9446312	SP.4Y/B3	Pin, shackle	C	
28S/9419435	A31/B12	Screw, 4:BA, cheese head, 3/8" long	C	
28S/1005622	A31/B28	Screw, 4:BA, cheese head, 7/8" long	C	
28S/1006948	A32/A12	Screw, 6:BA, round head, 3/8" long	C	
28S/9995324	A32/A16	Screw, 6:BA, round head, 1/2" long	C	
28S/9992525	A32/B12	Screw, 4:BA, round head, 3/8" long	C	
28S/1007817	A32/B24	Screw, 4:BA, round head, 3/4" long	C	
28S/1202768	A33/C16	Screw, 2:BA, c'sk. head, 1/2" long	C	
28S/9440345	A40/B8	Screw, 4:BA, round head, 1/4" long	C	
28S/1212706	A40/B12	Screw, 4:BA	C	
28S/121708	A40/B16	Screw, 4:BA, round head, 1/2" long	C	
28S/1212709	A40/B20	Screw, 4:BA, round head, 5/8" long	C	
28S/1212721	A40/C32	Screw	C	
28S/9148119	A43/A10	Screw, 6:BA, cheese head, 1/8" long	C	
28S/9148118	A43/B10	Screw, 4:BA, cheese head, 1/8" long	C	
28S/1012356	A43/B12	Screw, 4:BA, cheese head, 3/8" long	C	
28S/9134016	A43/B14	Screw, 4:BA, cheese head, 1/8" long	C	
28S/9144116	A43/B20	Screw, 4:BA, cheese head, 5/8" long	C	
28S/9130752	A43/B24	Screw, 4:BA, cheese head, 3/4" long	C	
28S/9992520	A43/C20	Screw, 4:BA, cheese head, 1" long	C	
28S/9134791	A44/B6	Screw, 4:BA, round head, 1/8" long	C	
28S/9447551	A44/B10	Screw, 4:BA, round head, 1/8" long	C	
28S/9145185	A44/B12	Screw, 4:BA, round head, 1" long	C	
28S/1013430	A44/B20	Screw, 4:BA, round head, 1" long	C	
28S/1017078	A44/B24	Screw, 4:BA, round head, 3/4" long	C	
28S/1214166	A44/B28	Screw, 4:BA, round head, 7/8" long	C	
28S/1214172	A44/C20	Screw, 2:BA, round head, 1" long	C	
28S/1214174	A44/C28	Screw, 2:BA, round head, 7/8" long	C	
28S/1214177	A44/C20	Screw, 2:BA, round head, 1 1/4" long	C	
28W/9419465	SP.13/B	Washer, 4 BA, plain	C	
28W/9419402	SP.13/C	Washer	C	
28W/9418921	SP.13/E	Washer, 1" BSF, plain	C	
28W/9419466	SP.13/J	Washer, 3/8" BSF, plain	C	

**EQUIPMENT, AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
28W/9143227	SP.14/B	Washer,	4	BA,	plain			C
28W/9419473	SP.15/A	Washer,	6	BA,	plain			C
28W/9419474	SP.15/B	Washer,	4	BA,	plain			C
28W/9419475	SP.15/C	Washer,	2	BA,	plain			C
28W/9419405	SP.15/E	Washer,	1	"	BSF, plain			C
28W/9419476	SP.15/G	Washer,	1/8	"	BSF, plain			C
28W/9419477	SP.15/J	Washer,	1/8	"	BSF, plain			C
28W/9419478	SP.15/L	Washer,	1/8	"	BSF, plain			C
28W/9419404	SP.16/C	Washer,	2	BA,	plain			C
28W/9419487	SP.16/E	Washer,	1	"	BSF, plain			C
28W/9419488	SP.16/G	Washer,	1/8	"	BSF, plain			C
28W/9416642	SP.47/B	Washer,	4	BA,	spring			C
28W/9416632	SP.47/C	Washer,	2	BA,	spring			C
28W/3537	AGS.1583/D	Washer,	6	BA			C
28W/9419448	AGS.2035/B	Washer			C

**EQUIPMENT, AIRCRAFT
EQUIPMENT FOR B.S.**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		EQUIPMENT FOR B.S. (MOD.1043) (S.O.O.) ...	—	—	—	—	
		Spares for:—					
	E.A3.80.2919	BRACKET, ATTACHMENT, NAVIGATOR'S TABLE TO PILOT'S SEAT RAIL (MOD. 3396)	—	—	—	—	
		Spares for:—					
34174	E.A3.80.2925	Angle	2	L72	—	—	
	E.A3.80.2921	Bracket, assembly	1	—	C	—	
		Attaching parts for E.A3.80.2921:—					
28D/9436920	A25/1C	Bolt, 2 BA	4	—	C	—	
28D/9133012	A25/3C	Bolt, 2 BA	4	—	C	—	
28W/9419454	SP.10/C	Washer	4	—	C	—	
28W/9419402	SP.13/C	Washer	4	—	C	—	
	E.B6.75.657	CABIN PRESSURE SYSTEM, FRONT FUSELAGE, ASSEMBLY	—	—	—	—	
		Spares for:—					
12209	E.B6.75.679	Connection, for flexible pipe at navigator's table	1	—	C	—	
	E.B6.75.665	DIFFUSER, NAVIGATOR'S ASSEMBLY ...	1	—	—	—	
		Spares for:—					
1349	E.B6.75.667	Bracket, diffuser mounting	1	L72	—	—	
6980	E.A3.75.89	Clip, diffuser retaining	1	L72	C	—	
12210	E.B7.75.23	Diffuser	1	—	C	—	
12211	E.B6.75.659	Pipe, flexible, from main branch pipe at frame 2 to pipe joint at navigator's table	1	Bell's asbestos	C	—	
12212	E.B6.75.661	Pipe, flexible, from main branch pipe to navigator's diffuser	1	Bell's asbestos	C	—	
	E.B6.75.677	Pipe, flexible, from pipe joint at navigator's table to navigator's louvre	1	Bell's asbestos	C	—	
	E.A3.81.651/1	CABLE, ASSEMBLY, N.97, FROM CONNECTION AT PRESSURE BULKHEAD TO J.B.266GH (RED ENTRY), GROUP	1	—	—	—	
		Consisting of:—					
5E/4203	†	Cable, Uninyvinmet 12	QR	—	C	—	
10H/0970076	Z.49047	Ferrule, inner	1	—	C	—	
10H/0970075	Z.49048	Ferrule, outer	1	—	C	—	
10H/0970058	Z.54184	Gasket, outlet	1	—	C	—	
10H/0970061	CZ.49178	Outlet, straight	1	—	C	—	
10H/0970087	Z.49049	Ring, sealing	1	—	C	—	
5K/	†	Sleeve, 3/4" long	4	—	—	—	
5K/	†	Sleeve, 1" long	2	—	—	—	
10H/419	†	Socket, assembly, type W.165, 2-way	1	—	C	—	
10H/0560090	CZ.49014	Socket, assembly, 2-way, Mk. 4	1	—	C	—	
	E.B6.81.777	CABLE, ASSEMBLY, N.98, FROM CONNECTION AT PRESSURE BULKHEAD TO J.B.266GH (BLACK ENTRY), GROUP	1	—	—	—	
		Consisting of:—					
5E/4203	†	Cable, Uninyvinmet 12	QR	—	C	—	
10H/0970076	Z.49047	Ferrule, inner	1	—	C	—	
10H/0970075	Z.49048	Ferrule, outer	1	—	C	—	
10H/0970058	Z.60667	Gasket, outlet	1	—	C	—	
10H/0970061	CZ.49178	Outlet, straight	1	—	C	—	
10H/0970087	Z.49049	Ring, sealing	1	—	C	—	
5K/9107067	EEAS.146/C	Sleeve, 3/4" long	4	—	C	—	
5K/9107068	EEAS.146/D1	Sleeve, 1" long	2	—	C	—	
10H/419	†	Socket, assembly, type W.165, 2-way	1	—	C	—	
10H/0560591	CZ.49014/1	Socket, free, Mk. 4, 2-way	1	—	C	—	

**EQUIPMENT, AIRCRAFT
EQUIPMENT FOR B.S.**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
	E.B6.81.2599	CABLE, ASSEMBLY, F.38A, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)	1	—	—	—	
		Consisting of:—					
	5E/4199 †	Cable, Uninyvinmetsheath 20	QR	—	—	C	
	5E/4203 †	Cable, Uninyvinmet 12	QR	—	—	C	
10H/0970296	Z.69738	Clamp, cable	2	—	—	C	
5X/9400051	AS.2672	Ferrule	8	—	—	C	
5X/9400055	AS.2674	Ferrule	8	—	—	C	
30B/1145	†	Gauze, fine wire (cadmium plated)	QR	—	—	C	
10H/	Z.50743	Outlet, 90°	1	—	—	—	
10H/	Z.50744	Outlet, straight	1	—	—	—	
10H/0970059	Z.60668	Outlet, gasket	2	—	—	C	
10H/0560760	CZ.56735	Plug, fixed coupler	1	—	—	C	
5K/9107065	EEAS.146/A	Sleeve, 3/4" long	QR	—	—	C	
5K/9107066	EEAS.146/A1	Sleeve, 1" long	8	—	—	C	
5K/9107066	EEAS.146/B	Sleeve, 1" long	8	—	—	C	
5K/9107070	EEAS.146/J	Sleeve, 1" long	4	—	—	C	
10H/0560180	CZ.49126	Socket	1	—	—	C	
	E.B6.81.2601	CABLE, ASSEMBLY, F.37B, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)	1	—	—	—	
		Consisting of:—					
	5E/4199 †	Cable, Uninyvinmetsheath 20	QR	—	—	C	
	5K/27 Z.23241/4	Ferrule, cut	2	—	—	C	
10H/0970108	Z.62235	Gasket, union	2	—	—	C	
10H/0970058	Z.60667	Outlet, gasket	2	—	—	C	
10H/0970061	CZ.49178	Outlet, assembly, straight	1	—	—	C	
10H/0970068	CZ.49179	Outlet, assembly, 90°	1	—	—	C	
10H/0560720	CZ.56732	Plug, fixed coupler	1	—	—	C	
5K/9107066	EEAS.146/A1	Sleeve, 3/4" long	4	—	—	C	
5K/9107068	EEAS.146/D	Sleeve, 1" long	4	—	—	C	
10H/0560110	CZ.49016	Socket	1	—	—	C	
5E/9102378	†	Wire, tinned copper, 26 SWG	QR	—	—	C	
	E.B6.81.2603	CABLE, ASSEMBLY, F.40A, FROM PLUG BREAK TO ELECTRONIC REGULATOR, GROUP (MOD. 2573)	1	—	—	—	
		Consisting of:—					
	5E/9100010 †	Cable, Trivenmet small, 2.5	QR	—	—	C	
10H/20406	Z.54443	Ferrule, inner	2	—	—	C	
10H/20407	Z.54444	Ferrule, outer	2	—	—	C	
10H/0970058	Z.60667	Gasket, outlet	2	—	—	C	
10H/0970062	CZ.49180	Outlet, assembly (straight)	1	—	—	C	
10H/0970069	CZ.49181	Outlet, 90°	1	—	—	C	
10H/0560710	CZ.56731	Plug, fixed coupler	1	—	—	B	
10H/0970088	Z.62229	Ring, sealing	2	—	—	C	
5K/9107065	EEAS.146/A	Sleeve, 3/4" long	6	—	—	C	
5K/9107068	EEAS.146/D1	Sleeve, 1" long	4	—	—	C	
10H/0560100	CZ.49015	Socket	1	—	—	C	

**EQUIPMENT, AIRCRAFT
EQUIPMENT FOR B.S.**

Ref. No.	Part No.	Description	No. off	Matl. Spec	Cl. of Equip.		Plate No.
					M.R. L.M.		
	E.B6.71.79	OXYGEN SYSTEM, ASSEMBLY	—	—	—		
		Spares for:—					
5780	E.B7.71.49	Bracket, reducing valve mounting	1	—	C		
	E.B7.71.169	Clip, half, pipe	2	DTD.124	—		
5551	EEAS.143/14	Clip, pipe	4	L.72	C		
	E.B7.71.55	Hose, rubber, $\frac{7}{8}$ " i/d x 3'-0" long (make from 32C/445)	1	DTD.625	LM		
12213	E.B6.71.81	Pipe, assembly, L.P., from navigator's reducing valve, to regulator	1	—	C		
12214	E.B6.71.83	Pipe, assembly, H.P., from navigator's reducing valve to tee piece at cross tube	1	—	C		
12215	E.B6.71.85	Pipe, assembly, H.P., from stop valve tee piece to reducing valve connection, port	1	—	C		
12216	E.B6.71.87	Pipe, assembly, H.P., from reducing valve tee to 3-way connector at frame 5	1	—	C		
12217	E.B6.71.93	Pipe, L.P., from hose coupling at navigator's table to hose coupling at frame 5	1	—	C		
12218	E.B6.71.95	Pipe, L.P. bend, Navigator's supply, from hose coupling at navigator's table to coupling between frames 6 and 7	1	—	C		
12219	E.B6.71.121	Pipe, assembly, L.P., from hose coupling at frame 5 to navigator's oxygen regulator	1	—	C		
	E.B6.73.247	PIPES, HYDRAULIC, FROM RESERVOIR TO FRAME 12 AND PRESSURE BULKHEAD, ASSEMBLY	—	—	—		
		Spares for:—					
12220	E.B6.73.225	Pipe, assembly, from return line tee forward of frame 12 to coupling at frame 12	1	—	C		
12221	E.B6.73.227	Pipe, assembly, between reservoir running coupling and return line tee forward of frame 12	1	—	C		
12222	E.B6.73.229	Pipe, assembly, from running coupling at frame 12 to running coupling forward of frame 12 engine driven pump suction line	1	—	C		
12223	E.B6.73.231	Pipe, assembly, from thermal relief valve tee at wheel well wall to hydraulic reservoir tee forward of frame 12	1	—	C		

**EQUIPMENT, AIRCRAFT
L.L.A.B.S. REMOVABLE EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
	E.B6.81.1515	EQUIPMENT, L.L.A.B.S. REMOVABLE FITTINGS, GROUP (MOD. 2198) (S.O.O.)	—	—	—	—	
37709	E.B6.81.1439	Spares for:— BOX, CONTROL, ASSEMBLY	1	—	—	B	
	E.B6.81.1435	Spares for:— Box, engraved	1	—	—	—	
5E/4183	†	Cable, Uninyvin 20	QR	—	—	C	
5E/4185	†	Cable, Uninyvin 16	QR	—	—	C	
	E.B6.81.1437	Cover, assembly	1	—	—	—	
	E.A9.81.3923	Cover, plate	1	—	—	—	
5D/1541	†	Indicator, magnetic	4	—	—	B	
	CANNON						
5X/8351	AN.3102A/14S/2P	Plug	1	—	—	C	
	E.A9.81.3919	Seal, rubber	1	—	—	—	
5CW/6436	D.504	Switch, D.P.	1	—	—	B	
5CW/2910	†	Switch, rotary	1	—	—	B	
	E.A9.81.3917	Tag	1	—	—	—	
	E.A9.81.3921	Window, perspex	1	—	—	—	
	E.B6.81.1467	CRATE, MOUNTING, ASSEMBLY	—	—	—	—	
	E.B6.81.1407	Spares for:— BOX, JUNCTION, ASSEMBLY	1	—	—	—	
	CANNON						
5X/8256	2209/10	Cap, dust	1	—	—	—	
5X/8520	2209/12	Cap, dust	1	—	—	—	
	E.B6.81.1409	LID, ASSEMBLY	1	—	—	—	
	33H/56	Spares for:— Cement, Bostik	QR	—	—	C	
	32C/614	Rubber, synthetic, 0"14 dia.	QR	DTD.552	—	C	
	32368	Screw	6	—	—	C	
	1066	Washer	12	DTD.124	—	C	
	1108	Washer, leather	6	—	—	C	
	E.B6.81.1377	CABLE, ASSEMBLY, FA.63, FROM L.A.B.S. J.B. "A" TO PROTECTIVE RELAY UNIT, GROUP	1	—	—	—	
	5E/4183	Consisting of:— Cable, Uninyvin 20	QR	—	—	C	
	5E/2034	Conduit, flexible	QR	—	—	C	
	26DK/6014	Ferrule	1	—	—	C	
	10H/0970058	Gasket, outlet	1	—	—	C	
	5X/2784	Grommet, tension	1	—	—	C	
	10H/0970062	Outlet, straight	1	—	—	C	
	5X/1529	Ring, clamp	1	—	—	C	
	10H/0970088	Ring, sealing	1	—	—	C	
	5K/9107065	Sleeve	2	—	—	C	
	5K/9107068	Sleeve	4	—	—	C	
	10H/0560120	Socket, 6-way	1	—	—	C	
	5X/9400061	Tag	1	—	—	C	
	5X/9400062	Thimble	1	—	—	C	

**EQUIPMENT, AIRCRAFT
LL.A.B.S. REMOVABLE EQUIPMENT**


Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
	E.B6.81.1379	CABLE, ASSEMBLY, FA.65, FROM L.A.B.S. J.B. TO FUZE CHART UNIT, GROUP	1	—	—	
		Consisting of:—				
5E/4183	†	Cable, Uninyvin 20	QR	—	C	
5F/2037	†	Conduit, flexible	QR	—	C	
	E.B6.81.1495	Ferrule	1	—	—	
10H/0970060	Z.60669	Gasket, outlet	1	—	C	
5X/2789	2026	Grommet, tension	1	—	C	
10H/0970093	CZ.50784	Outlet, angle	1	—	C	
10H/0560390	CZ.53159	Plug, 18-way	1	—	C	
5X/6489	CZ.23144/C	Ring, clamp	1	—	C	
10H/0970092	CZ.62232	Ring, sealing	1	—	C	
5K/9107065	EEAS.146/A	Sleeve	36	—	C	
5K/9107070	EEAS.146/K	Sleeve	4	—	C	
5X/9430396	HC.490	Tag	18	—	C	
	E.B6.81.1381	CABLE, ASSEMBLY, FA.62, FROM L.A.B.S. J.B. TO PROTECTIVE RELAY UNIT, GROUP	1	—	—	
		Consisting of:—				
5E/4183	†	Cable, Uninyvin 20	QR	—	C	
5F/9143294	†	Conduit, flexible	QR	—	C	
26DK/6014	EEAS.111/2	Ferrule	1	—	C	
10H/0970058	Z.60667	Gasket, outlet	1	—	C	
5X/2786	No. 3	Grommet, tension	1	—	C	
10H/0970062	CZ.49180	Outlet, straight	1	—	C	
5X/1529	CZ.69733	Ring, clamp	1	—	C	
10H/0970088	Z.62229	Ring, sealing	1	—	C	
5K/9107065	EEAS.146/A	Sleeve	4	—	C	
5K/9107068	EEAS.146/D	Sleeve	4	—	C	
10H/0560511	CZ.49016/1	Socket, 4-way	1	—	C	
5X/9430396	HC.490	Tag	2	—	C	
	E.B6.81.1383	CABLE, ASSEMBLY, FA.66, FROM L.A.B.S. J.B.A., TO EARTH, GROUP	1	—	—	
		Consisting of:—				
5E/4187	†	Cable, Uninyvin 12	QR	—	C	
5F/9013643	†	Conduit, flexible	QR	—	C	
5X/2786	No. 3	Grommet, tension	1	—	C	
5X/9400389	†	Lug, Mk. 9	2	—	C	
5K/9107066	EEAS.146/A1	Sleeve	4	—	C	
5K/9107069	EEAS.146/F	Sleeve	4	—	C	
5X/9430224	HC.510	Tag	2	—	C	
	E.B6.81.1385	CABLE, ASSEMBLY, FA.64, L.A.B.S. J.B. TO PROTECTIVE RELAY UNIT, GROUP	1	—	—	
		Consisting of:—				
5E/4183	†	Cable, Uninyvin 20	QR	—	C	
5F/2035	†	Conduit, flexible	QR	—	C	
18864	EEAS.111/3	Ferrule	1	—	C	
10H/0970059	Z.60668	Gasket, outlet	1	—	C	
5X/2788	No. 5	Grommet, tension	1	—	C	

**EQUIPMENT AIRCRAFT
L.L.A.B.S. REMOVABLE EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Mati. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.B6.81.5183	PANEL, CONTROL, ASSEMBLY (MOD. 3452) ...	1	—	—		
		Spares for:—					
5L/9959118	†	Bulb, 28 volt ...	1	—	B		
	DOWTY						
5CZ/6114	C.5175Y Mk.66	Indicator, magnetic, 3-way ...	1	—	B		
5D/1541	†	Indicator, magnetic ...	2	—	B		
	PAGE ENG'RING						
5CW/6462	C.330/C	Lamp, amber ...	1	—	B		
33681	E.B6.81.1473	Panel, blanking, assembly ...	1	—	C		
32366	E.A9.81.4659	PANEL, CONTROL, ASSEMBLY ...	1	—	B		
		Spares for:—					
28FP/621	DZUS PRN.3½	Fastener ...	4	—	C		
5CZ/5027	BERCO L.25/GB	Rheostat ...	1	—	B		
	E.B6.81.1431	Seal, rubber ...	1	—	—		
5CW/6435	†	Switch, Rotax ...	1	—	B		
5CW/5823	†	Switch, Rotax ...	1	—	B		
5CW/5825	†	Switch, Rotax ...	1	—	B		
10F/1786	†	Switch, type 1290 ...	1	—	B		
33101	E.A9.81.4401	Tag ...	1	—	C		
	EEAS.28/2HP	Washer, spacing ...	8	—	—		
	E.B6.81.1429	Window, perspex ...	1	—	—		
	E.A9.81.3627	PANEL, CONTROL, AND INVERTER, TYPE 112, INSTALLATION, GROUP	—	—	—		
		Spares for:—					
	E.A9.81.3571	CABLE, ASSEMBLY, FROM PANEL CONTROL TO INVERTER, GROUP	2	—	—		
		Consisting of:—					
5E/9100021	†	Cable, Sextovinmet miniature 6B ...	QR	—	C		
10H/0970077	Z.49042	Ferrule, outer ...	2	—	C		
10H/0970078	Z.49041	Ferrule, inner ...	2	—	C		
10H/0970058	Z.60667	Gasket, outlet ...	2	—	C		
10H/0970069	CZ.49181	Outlet, angle ...	1	—	C		
10H/0970062	CZ.49180	Outlet, straight ...	1	—	C		
10H/0560300	CZ.49222	Plug, free, Mk. 4 ...	1	—	C		
10H/0970088	Z.62229	Ring, sealing ...	2	—	C		
5K/9107065	EEAS.146/16	Sleeve, ¾" long ...	10	—	C		
5K/9107067	EEAS.146/6	Sleeve, 1" long ...	2	—	C		
10H/0560120	CZ.49017	Socket, free, Mk. 4 ...	1	—	C		
	E.A9.81.3573	CABLE, ASSEMBLY, FROM PANEL CONTROL TO INVERTER, GROUP	2	—	—		
		Consisting of:—					
5E/4199	†	Cable, Uninyvinmetsheath 20 ...	QR	—	C		
10H/0970292	†	Clamp, cable ...	1	—	C		
10H/0970293	†	Clamp, cable ...	1	—	C		
10H/0970069	CZ.49181	Outlet, angle ...	1	—	C		
10H/0970058	Z.60667	Outlet, gasket ...	2	—	C		
10H/0970061	CZ.49178	Outlet, straight ...	1	—	C		
10H/0560270	CZ.49216	Plug, free, Mk. 4 ...	1	—	C		
5K/9107065	EEAS.146/16	Sleeve, ¾" long ...	4	—	C		
5K/9107066	EEAS.146/12	Sleeve, 1" long ...	2	—	C		

**EQUIPMENT, AIRCRAFT
LL.A.B.S. REMOVABLE EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
10H/0970114	Z.62240							2	—	C	
10H/0560090	CZ.49014							1	—	C	
37711	E.A9.81.3629							1	—	—	
5UB/6505	ROTAX S.3302/L							2	—	A	
5UC/6030	ROTAX U.1504/L							2	—	A	
28FP/9432062	A.143							4	—	C	
33680	E.A9.81.3661							2	—	—	
	E.A9.81.3675							2	L.72	—	
	E.A9.81.3677							2	L.72	—	
	E.A9.81.3671							2	DTD.215	—	
	E.A9.81.3669							2	L.64	—	
10AJ/158	†							2	—	B	
10AJ/159	†							2	—	B	
	E.A9.81.3673							2	BS.21	—	
	E.A9.81.3683							2	L.64	—	
	E.A9.81.3667							2	S.92	—	
10A/17930	†							4	—	C	



EQUIPMENT IN PRESSURE CABIN

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

