

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A9.80.7	EQUIPMENT IN PRESSURE CABIN, ASSEMBLY ...	—	—	—	
	E.A9.80.1399	Spares for:— ACCELEROMETER INSTALLATION (MOD. 2515)	—	—	—	
6A/3451	†	Spares for:— ACCELEROMETER, Mk. 2	1	—	A	
28S/1005545	A35/B16	Attaching parts for Ref. 6A/3451:—				
28W/9416642	SP.47/B	Screw, 4 BA	3	—	C	
		Washer-spring	3	—	C	
	E.A9.83.10089	BALLAST UNDER BOMB AIMER'S RAMP, ASSEMBLY (MOD. 3485)	—	—	—	
		Spares for:—				
22946	E.A9.84.19	BLOCK , ballast (S.O.O.)	2	—	MR	
22947	E.A9.84.21	BLOCK , ballast (S.O.O.)	1	—	MR	
22948	E.A9.84.23	BLOCK , ballast (S.O.O.)	2	—	MR	
22949	E.A9.84.25	BLOCK , ballast (S.O.O.)	1	—	MR	
22950	E.A9.84.37	BLOCK , ballast (S.O.O.)	1	—	MR	
40920	E.A9.84.10001	BOLT , securing, ballast blocks	12	—	MR	
	E.A9.84.10003	BOLT , securing, ballast blocks	8	—	—	
34543	E.A9.84.10005	BOLT , securing, ballast blocks	4	—	C	
	E.A9.84.10007	BOLT , securing, ballast blocks	4	—	—	
	E.A9.84.10009	PLATE , base for ballast	1	—	—	
	E.A9.84.10011	PLATE , base for ballast	1	—	—	
	E.A9.10.10279	PLATE , protective armour, assembly	1	—	—	
		Attaching parts for E.A9.10.10279:—				
28D/1013172	AS.1245/5C	Bolt, 2 BA	14	—	C	
	E.A9.83.10055	CAMERA, F95, REMOVABLE FITTINGS GROUPS (MOD. 2698-S.O.O.)	—	—	—	
		Spares for:—				
14A/4984	†	CAMERA, F95, Mk. 2, 4"	1	—	A	
	E.A9.83.10057	CAMERA, F95,, INSTALLATION	—	—	—	
		Spares for:—				
33655	E.A9.83.10069	BRACKET, SUPPORT, PORT, ASSEMBLY ...	1	—	C	
		Spares for:—				
	E.A9.83.10059	BRACKET , support	1	L.72	—	
33659	E.A9.83.10081	CLIP , spring	2	—	C	
32A/1058027	†	CORD , stringing, braided	QR	—	C	
33658	E.A9.83.10071	SCREW , mounting	2	S.1	C	
32953	E.A9.97.1018	TAB , locking	2	—	C	
		Attaching parts for E.A9.83.10069:—				
28D/1200119	A25/4C	Bolt, 2 BA	1	—	C	
28D/9140644	A25/9C	Bolt, 2 BA	2	—	C	
28W/9416643	SP.47/C	Washer	3	—	C	
	33656	E.A9.83.10083	BRACKET AND PROTECTIVE PAD, ASSEMBLY	1	—	C
		Spares for:—				
	E.A9.83.10061	BRACKET , support, starboard	1	L.72	—	
33659	E.A9.83.10081	CLIP , spring	2	—	C	
32A/1058027	†	CORD , stringing braided	QR	—	C	
	E.A9.83.10073	PAD, PROTECTIVE, ASSEMBLY	1	—	—	
		Spares for:—				
	E.A9.83.10077	ROD , retaining	1	S.1	—	
33658	E.A9.83.10071	SCREW , mounting	2	S.1	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
32953	E.A9.97.1018 E.A9.83.10079	TAB , locking PLATE , washer Attaching parts for E.A9.83.10083:—	2 1	— L.72	C	—	
28D/1007972 28W/9416643	A25/1/2 C SP.47/C	Bolt, 2 BA Washer	3 3	— —	C	C	
14A/4563	499/1A	CONTROL , single, F95, camera Attaching parts for 499/1A:—	1	—	A		
28S/9436921	A31/C28	Screw, 2 BA	4	—	C		
33657	E.A9.83.10063 E.A9.80.1047	HOOD , lens, F95, camera COMPASS, E2A AND REAR VIEW MIRROR INS- TALLATION (MOD. 1916) Spares for:—	1 —	— —	C	—	
28D/1215159 28W/9457027	E.A9.80.1069 AS.4565/1C AGS.2037/C	BRACKET , mounting compass housing Attaching parts for E.A9.80.1069:— Bolt, 2 BA Washer, shakeproof	1 4 4	— — —	—	C	C
6B/405	†	COMPASS , type E2A Attaching parts for Ref. 6B/405:—	1	—	A		
28S/1212707	A40/B14	Screw, 4 BA	2	—	C		
22178	E.A9.80.689	HOUSING , compass Attaching parts for E.A9.80.689:—	1	—	MR		
28D/1213043 15496	AS.4566/1B EEAS.28/7ER	Bolt, 4 BA Washer, special	4 4	— —	C	C	
25661	E.A9.80.1211	MIRROR , c/w frame Attaching parts for E.A9.80.1211:—	1	—	B		
28D/1212951 28M/10281	A61/19C AGS.2001/C/3 AS.2811/5/100	Bolt, 2 BA Nut, 2 BA Tube, distance	1 1 1	— — L.62	C	C	LM
28W/9419475 28624	SP.15/C EEAS.28/8ER	Washer Washer, special	1 2	— —	C	C	
25662	E.A9.80.1049	MOUNTING, BLOCK, COMPASS AND MIRROR, ASSEMBLY Spares for:—	1	—	C		
28D/1213486 28M/10322 28W/9419476	E.A9.80.1315 A61/15G AGS.2002/G/3 SP.15/G	BUSH Attaching parts for E.A9.80.1049:— Bolt, 1/8" BSF Nut, 1/8" BSF Washer	4 1 1 2	— — — —	—	C	C
12179	E.A9.80.673	PLUG Attaching parts for E.A9.80.673:—	1	—	C		AE.1-8
28S/1214610 28W/9457027	A39/C36 AGS.2037/C	Screw, 2 BA Washer, shakeproof	2 2	— —	C	C	
6B/562	E.A9.80.307 †	COMPASS, MAGNETIC, G.4B, INSTALLATION Spares for:— AMPLIFIER , Mk. 4B	— 1	— —	—	A	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
	E.A9.80.699	COMPASS AND A.D.R. I.S. JUNCTION BOX AND SUPPRESSOR ASSEMBLY						—	—	—		
		Spares for:—										
5CZ/996	†	BOX , junction, 3-way, type A						1	—		C	
5CZ/4105	†	BOX , junction, 6-way						1	—		C	
		Attaching parts for Ref. 5CZ/996 and 5CZ/4105:—										
28S/9992522	A32/B16	Screw, 4 BA						2	—		C	
5CY/7001363	†	SUPPRESSOR , type B4						1	—		C	
		Attaching parts for Ref. 5CY/7001363:—										
28S/9995376	A32/B20	Screw, 4 BA						2	—		C	
	E.A9.80.311	PANEL, CONTROL COMPASS, INSTALLATION						—	—	—		
		Spares for:—										
	E.A9.80.309	BRACKET , mounting						1	—		—	
6B/408	†	PANEL , control, type A						1	—		A	
		Attaching parts for Ref. 6B/408:—										
28S/1214605	A39/C16	Screw, 2 BA						4	—		C	
	6B/437	†										
		TRAY , mounting, amplifier						1	—		C	
		Attaching parts for Ref. 6B/437:—										
28D/1215327	AS.1246/1E	Bolt, 1/2" BSF						4	—		C	
28M/10290	AGS.2001/E/1	Nut, 1/2" BSF						4	—		C	
28W/9418921	SP.13/E	Washer						4	—		C	
	E.A9.80.111	CONSOLE, PILOT'S, ASSEMBLY						—	—	—		
		Spares for:—										
	E.A9.80.10661	BRACKET, CANOPY RELEASE HANDLE ASSEMBLY (MOD. 2687)						1	—		—	
		Consisting of:—										
22177	E.A9.80.207	BLOCK , bearing handle unit						1	LFS.26		C	
		Attaching parts for E.A9.80.207:—										
28D/9133012	A25/3C	Bolt, 2 BA						2	—		C	
28D/9133013	A25/5C	Bolt, 2 BA						2	—		C	
28M/10288	AGS.2001/C/1	Nut, 2 BA						4	—		C	
28W/9419475	SP.15/C	Washer						8	—		C	
23957	E.A9.80.191	PLATE , bearing bracket						1	—		C	
	E.A9.80.10659	PLATE , side						1	L.72		—	
	E.A9.80.10660	PLATE , side						1	L.72		—	
12181	E.A9.80.335	FLAP , cover, canopy operating handle						1	L.72		—	
	E.A9.80.499	PANEL, ACCESS FLYING CONTROLS ASSEMBLY						1	—		—	
		Spares for:—										
12182	E.A9.80.199	PANEL , access						1	L.72		B	
32665	E.A9.80.1193	PANEL, SIDE, REAR, ASSEMBLY (MOD. 1956)						—	—		B	
		Spares for:—										
	E.A9.80.1197	COVER , cable inspection						1	L.72		—	
	E.A9.80.333	PLATE , hinge, handle cover, flaps						1	—		—	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A9.80.775	CONTAINER, URINE, INSTALLATION Consisting of:—	—	—	—	
27H/2315	†	CLIP , spring	1	—	C	
27H/3224	†	CONTAINER , Mk. 2	1	—	C	
27H/2316	†	FUNNEL	1	—	C	
	E.A9.10.4729	COVER, BLANKING, FOR SIGNAL PISTOL MOUNTING ASSEMBLY Spares for:—				
12180	E.A9.10.3753	COVER , blanking, for signal mounting aperture	1	L.34	B	
2738	E.A3.10.2573	PLATE , blanking, cover spreader	1	DTD.683	C	
		Attaching parts for E.A9.10.3753 and E.A3.10.2573:—				
3654	E.A3.10.3003	Bolt:	1	—	C	
28W/9419466	SP.13/J	Washer	1	—	C	
2734	E.A3.10.2659	Washer	1	Rubber	C	
2737	E.A3.10.2575	WASHER , sealing spreader plate	1	Rubber	C	
	E.A9.80.10903	CRATE, ASSEMBLY, DECCA MK. 1, A.I.R. (MOD. 4039) Spares for:—	1	—	—	
	DECCA LTD					
	E55/30C	BACKPLATE , assembly	1	—	—	
	E279/BB	BACKPLATE , assembly	1	—	—	
	B321/BB	BACKPLATE , assembly	1	—	—	
	D.1610/T	BLOWER , assembly	1	—	—	
		Attaching parts for D.1610/T:—				
28D/1018884	A25/9G	Bolt: $\frac{5}{16}$ " BSF	2	—	C	
28DU/9414401	A102/7G	Bolt: $\frac{5}{16}$ " U.N.F. 2A	2	—	C	
28M/9435981	A127/G	Nut: $\frac{5}{16}$ " U.N.F. 2B	2	—	C	
28W/1013781	SP.122/G	Washer	4	—	C	
40202	E.A9.80.10477	BRACKET , assembly, guard hinge	1	—	C	
40203	E.A9.80.10478	BRACKET , assembly, guard hinge	1	—	C	
		Attaching parts for E.A9.80.10477 and E.A9.80.10478:—				
28D/9436920	A25/1C	Bolt: 2 BA	2	—	C	
28M/10288	AGS.2001/C/1	Nut: 2 BA	2	—	C	
28W/9419475	SP.15/C	Washer	2	—	C	
	DECCA LTD.					
	B.1610/37	BRACKET , blower	1	—	—	
		Attaching parts for B.1610/37:—				
28M/10319	AGS.2002/C/3	Nut: 2 BA	7	—	—	
28S/1010009	A43/C16	Screw: 2 BA	3	—	C	
28S/9446545	A45/C16	Screw: 2 BA	4	—	C	
28W/1009752	SP.25/C	Washer	7	—	C	
	DECCA LTD.					
	D.1610/13	BRACKET	1	—	—	
		Attaching parts for D.1610/13:—				
28M/10319	AGS.2002/C/3	Nut: 2 BA	QR	—	C	
28S/1010009	A43/C16	Screw: 2 BA	QR	—	C	
28S/9446545	A45/C16	Screw: 2 BA	QR	—	C	
28W/1009752	SP.25/C	Washer	QR	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
	DECCA LTD.						
	C.1610/A	PLENUM, assembly, box "A"	1	—	—		
	C.1610/B	PLENUM, assembly, box "B"	1	—	—		
	C.1610/AR	RELAY, blower assembly	1	—	—		
	A.1610/56	SPACER	4	—	—		
	B.9471/3714	TY-RAP	2	—	—		
	MARCONI LTD.						
10C/9456205	W.14480C	WASHER, domed	58	—	C		
		Attaching parts for E.A9.80.10903:—					
	E.A9.80.10363	Bolt, special	4	—	—		
10AC/140	†	Washer, check	4	—	C		
	E.A9.83.10001	CUSHIONING AND BLACKOUT CURTAINS NAVIGATOR'S, ASSEMBLY (MOD. 2563)	—	—	—		
		Spares for:—					
	E.A9.10.4633	BRACKET, lift-dot, stud	1	—	—		
37950	E.A9.83.10007	CURTAIN, blackout, frame A	1	—	B		
38374	E.A9.83.10013	CURTAIN, blackout, upper frame 4 (Mod. 3159)	1	—	B		
38373	E.A9.83.10011	CURTAIN, blackout, centre, frame 5 (Mod. 3159)	1	—	B		
38372	E.A9.83.10009	CURTAIN, blackout, lower frame 5 (Mod. 3159)	1	—	B		
22183	E.A9.83.129	CURTAIN, blackout, navigator's window ...	1	—	B		
37948	E.A9.83.10003	CUSHIONING, frames B-A	1	Dun'op	B		
37949	E.A9.83.10005	CUSHIONING AT FRAMES A-1 ASSEMBLY	1	—	B		
		Spares for:—					
22184	E.A9.83.131	CASE, map	1	—	B		AE.1-8
22188	E.A9.83.197	FLAP, for cushion frame B	1	—	B		
		Attaching parts for E.A9.83.197:—					
28D/1008149	A25/2B	Bolt, 4 BA	6	—	C		
28M/10287	AGS.2001/B/1	Nut, 4 BA	6	—	C		
28W/9419465	SP.13/B	Washer	6	—	C		
	E.A9.83.195	STRAP, curtain stowage	2	Webbing	—		
		Attaching parts for E.A9.83.195:—					
28D/9137409	A5.1246/2C	Bolt, 2 BA	1	—	C		
28M/10288	AGS.2001/C/1	Nut, 2 BA	1	—	C		
	E.A9.83.199	Strip	1	—	—		
29G/2180	CARR 882	STUD, single, "Lift-the-Dot"	12	—	C		
29G/4204	CARR 883	STUD, double, "Lift-the-Dot"	1	—	C		
		Attaching parts for Ref. 29G/2180 and 29G/4204:—					
28M/1006473	A27/CT	Nut, 2 BA	1	—	C		
28W/1006946	AGS.2035/C	Washer	1	—	C		
29G/4074	CARR 680	STUD, single, "Lift-the-Dot"	1	—	C		
		Attaching parts for Ref. 29G/4074:—					
28M/9403520	A27/CP	Nut, 2 BA	1	—	C		
28W/9416643	SP.47/C	Washer, spring	1	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
	E.A9.80.715	DRAWER, NAVIGATOR'S INSTALLATION ...						—	—	—		
	E.A9.80.723	Spares for:— BLOCK, stop 2						2	—	—		
28M/10286	AGS.2001/A/1	Attaching parts for E.A9.60.723:— Nut, 6 BA 2						2	—	C		
28S/1200059	A33/A14	Screw, 6 BA 2						2	—	C		
28W/9419464	SP.13/A	Washer 2						2	—	C		
	E.A9.80.717	DRAWER, assembly 1						1	—	—		
	E.A9.80.10077	EQUIPMENT, NAVIGATOR'S CRATE ASSEMBLY (MOD. 3159) 1						—	—	—		
		Spares for:—										
6A/8267/1	†	ALTIMETER, Mk. 19F (Mod. 3971) 1						1	—	A		
		Attaching parts for Ref. 6A/8267/1:—										
28S/1214239	A209/B28	Screw, No. 6, U.N.C. (Alternative) 4						4	—	C		
28S/1214166	A44/B28	Screw, 4 BA (Alternative) 4						4	—	C		
28W/9419474	SP.15/B	Washer 4						4	—	C		
	E.A9.80.10751	AMPLIFIER, INSTALLATION (MOD. 3897) 1						—	—	—		
		Spares for:—										
6A/5465	†	AMPLIFIER, Mk. 1A 1						1	—	A		
		Attaching parts for Ref. 6A/5465:—										
28D/1007982	AS.1248/1C	Bolt, 2 BA 4						4	—	C		
28W/9419402	SP.13/C	Washer 4						4	—	C		
	E.A9.80.10765	PLATE, mounting, assembly 1						1	—	—		
10AR/2268	†	BACK-PLATE, for indicator type 4403 1						1	—	B		
10AR/2407	†	BACK-PLATE, for loop controller 1						1	—	B		
		Attaching parts for Ref. 10AR/2268 and 10AR/2407:—										
28M/10287	AGS.2001/B/1	Nut, 4 BA 4						4	—	C		
28S/1200034	A31/B16	Screw, 4 BA 4						4	—	C		
28W/9419474	SP.15/B	Washer 4						4	—	C		
6B/2757	†	BACK-PLATE, for ground position indicator 1						1	—	B		
		Attaching parts for Ref. 6B/2757:—										
28S/1200034	A31/B16	Screw, 4 BA 4						4	—	C		
5X/1002694	†	BLOCK, terminal, 5-way 2						2	—	C		
5X/2863	†	BLOCK, terminal, 10-way 1						1	—	C		
		Attaching parts for Ref. 5X/1002694 and 5X/2863:—										
28M/10287	AGS 2001/B/1	Nut, 4 BA 2						2	—	C		
5X/9450403	†	Pillar, fixing 2						2	—	C		
28W/9419474	SP.15/B	Washer 2						2	—	C		
5CZ/4105	†	BOX, junction, for G.4B compass 1						1	—	C		
		Attaching parts for 5CZ.4105:—										
28S/1200034	A31/B16	Screw 2						2	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
10D/17921	†	BOX , junction, type 164 Attaching parts for Ref. 10D/17921:—	1	—	B	
28M/10287	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28S/9419453	A31/B14	Screw, 4 BA	4	—	C	
28W/9419474	SP.15/B	Washer	4	—	C	
6B/634	†	COMPASS , G4B, type B Attaching parts for Ref. 6B/634:—	1	—	A	
28S/1220007	A32/C40	Screw, 2 BA	3	—	C	
28W/9419475	SP.15/C	Washer	3	—	C	
5CZ/1961	HV.3060 †	GROMMET HORN , electric, type C Attaching parts for Ref. 5CZ/1961:—	3 1	— —	— C	
28D/1011030	A25/2E	Bolt, 1/2" BSF	2	—	C	
28W/9419405	SP.15/E	Washer	2	—	C	
6A/3147	†	INDICATOR , air, Mk.9, H.P. Attaching parts for Ref. 6A/3147:—	1	—	A	
28M/10288	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28S/1220007	A32/C40	Screw, 2 BA	4	—	C	
28W/9419475	AS.2807/5/070 SP.15/C	Tube, distance, 20 SWG Washer	4 4	T.35 —	LM C	
6A/3682	†	INDICATOR , air temperature, type B Attaching parts for Ref. 6A/3682:—	1	—	A	
28M/10287	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28S/1017078	A44/B24	Screw, 4 BA	4	—	C	
28W/9419474	SP.15/B	Washer	4	—	C	
5Q/1003731	†	INDICATOR , frequency, type S.109/6 Attaching parts for Ref. 5Q/1003731:—	1	—	A	
28S/1214165	A44/B18	Screw, 4 BA	4	—	C	
28W/9419474	SP.15/B	Washer	4	—	C	
6A/3687	†	LABEL , air temperature	1	—	C	
10AS/1013	MARCONI W.14183/C	LOCK , assembly, G.P. indicator Attaching parts for W.14183/C:—	2	—	B	
33253	E.A9.80.10463	Bolt, special	1	—	C	
33254	E.A9.80.10465	Bolt, special	1	—	C	
38356	E.A9.80.10341	Packing, piece tapered	1	—	C	
38355	E.A9.80.10339	Washer, tapered	2	—	C	
	E.A9.80.10773	MOUNTING, STRUCTURE CONTROL UNIT AND INDICATOR (MOD. 4129) Spares for:—	—	—	—	
34761	E.A9.80.10715	ANGLE , indicator panel	1	L.72	C	
34760	E.A9.80.10709	GUSSET , inboard control panel	1	L.72	C	
34759	E.A9.80.10705	GUSSET , outboard control panel	1	L.72	C	
28D/9436920	A25/1C	Attaching parts for E.A9.80.10709 and E.A9.80.10705:—				
28W/9419402	SP.13/C	Bolt, 2 BA Washer	2 2	— —	C C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A9.80.10711	PANEL , control box, engraved	1	L.72	—	
		Attaching parts for E.A9.80.10711:—				
28D/9436920	A25/1C	Bolt, 2 BA	1	—	C	
28D/1007982	AS.1248/1C	Bolt, 2 BA	6	—	C	
28W/9419402	SP.13/C	Washer	1	—	C	
	E.A9.80.10717	PANEL , indicator	1	L.72	—	
		Attaching parts for E.A9.80.10717:—				
28D/1007982	AS.1248/1C	Bolt, 2 BA	6	—	C	
	34758	E.A9.80.10701	1	L.72	C	
		PLATE , mounting, control box				
		Attaching parts for E.A9.80.10701:—				
28D/1013284	AS.1248/2C	Bolt, 2 BA	4	—	C	
	38357	E.A9.80.10343	1	—	C	
		E.A9.80.10079	—	—	—	
		PLATE , blanking				
		RACK, NAVIGATOR'S EQUIPMENT, ASSEMBLY				
		Spares for:—				
	E.A9.80.10185	PANEL , front, starboard, assembly	1	—	—	
	E.A9.80.10183	PANEL , port, assembly	1	—	—	
	E.A9.80.10271	PLATE , access	1	—	—	
29G/2180	CARR 882	STUD , "Lift-the-Dot" single	27	—	C	
5CY/5289	†	SUPPRESSOR , type 603	1	—	A	
		Attaching parts for Ref. 5CY/5289:—				
28M/10287	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28S/9419453	A31/B14	Screw, 4 BA	4	—	C	
28W/9419474	SP.15/B	Washer	4	—	C	
	5CW/6579	8824/B107	1	—	B	
	5CW/6578	8810/B109	1	—	B	
	6B/655	†	1	—	C	
		TRAY , mounting, for Amplifier				
		Attaching parts for Ref. 6B/655:—				
28M/10287	AGS.2001/B/1	Nut, 4 BA	4	—	C	
28S/9419453	A31/B14	Screw, 4 BA	4	—	C	
28W/9419474	SP.15/B	Washer	4	—	C	
	E.A9.80.10791	UNIT, VIBRATOR, INSTALLATION (MOD. 3842)	—	—	—	
		Spares for:—				
6A/7041	†	VIBRATOR , unit	1	—	A	
	E.A9.80.10785	EXTINGUISHER, FIRE, ASSEMBLY (MOD. 3820)	1	—	—	
		Spares for:—				
	E.A9.80.10579	BRACKET , mounting, for holder at stringer 33 ...	1	—	—	
	E.A9.80.10581	BRACKET , mounting, for holder at stringer 32 ...	1	—	—	
27N/299	†	EXTINGUISHER , fire	1	—	A	
27N/106	†	HOLDER , fire extinguisher	1	—	C	
		Attaching parts for Ref. 27N/106:—				
28D/1212944	A61/7C	Bolt, 2 BA	4	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	4	—	C	
	AS.2810/8/055	Tube, distance	4	L.62	LM	
28W/9419402	SP.13/C	Washer	4	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A9.80.10455	HOLDER, CORRECTOR CARD, INSTALLATION (MOD. 3159)	—	—	—	
		Spares for:—				
	E.A9.80.10377	PLATE , card holder, assembly	1	—	—	
	E.A9.80.10435	MACHMETER INSTALLATION (MOD. 2676)	—	—	—	
		Consisting of:—				
38602	E.A9.10.10237	BRACKET , mounting	1	—	C	
38603	E.A9.10.10238	BRACKET , mounting	1	—	C	
38604	E.A9.10.10239	CUSHION , rubber	1	—	C	
6A/3384	†	MACHMETER , Mk. 2	1	—	A	
		Attaching parts for Ref. 6A/3384:—				
28M/10308	AGS.2002/A/4	Nut, 6 BA	4	—	C	
28S/1200060	A33/A16	Screw, 6 BA	4	—	C	
28W/9419473	SP.15/A	Washer	4	—	C	
33039	E.A9.80.10385	MOUNTING , anti-vibration	1	—	C	
		Attaching parts for E.A9.80.10385:—				
28M/10308	AGS.2002/A/4	Nut, 6 BA	4	—	C	
28S/9148119	A43/A10	Screw, 6 BA	4	—	C	
28W/9419473	SP.15/A	Washer	4	—	C	
38600	E.A9.10.10229	PLATE , mounting (May be made from 30B/1726)	1	—	C	
		Attaching parts for E.A9.10.10229:—				
28D/1007285	AS.1242/1B	Bolt, 4 BA	3	—	C	
38601	E.A9.10.10231	RING , frangible	1	—	C	
	E.A9.80.10047	MOUNTING, FIRE AXE, ASSEMBLY (MOD. 2563)	—	—	—	
		Spares for:—				
27N/1	†	AXE , fire	1	—	B	
38011	E.C3.80.457	BRACKET , mounting	1	—	C	
		Attaching parts for E.C3.80.457:—				
28D/9133011	A25/2C	Bolt, 2 BA	2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	2	—	C	
28W/9419475	SP.15/C	Washer	2	—	C	
28E/9513854	AS.2294/8	CLIP , spring	1	—	C	
8595	E.A3.80.1829	PLATE , doubling	1	DTD 390	C	
8596	E.A3.80.1831	STRAP , 1/8" thick	1	Leather	C	
	E.A9.80.1397	MOUNTING, L.A.B.S. INDICATOR, INSTALLATION (MOD. 2515)	—	—	—	
		Spares for:—				
	SILENT-BLOC LTD.					
33997	B.131	MOUNTING , anti-vibration	4	—	C	
		Attaching parts for B.131:—				
28M/9403519	A27/BP	Nut, 4 BA	4	—	C	
28W/9419448	AGS.2035/B	Washer, shakeproof	4	—	C	
	E.A9.80.1351	PACKING , under, forward plate	2	—	—	
	E.A9.80.1361	PLATE , mounting, forward	1	—	—	
		Attaching parts for E.A9.80.1361:—				
28D/1010658	A25/1B	Bolt, 4 BA	2	—	C	
28D/1008149	A25/2B	Bolt, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	4	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
28M/9403519 28W/9419448	E.A9.80.1345	PLATE , mounting, indicator						1	—	—	
	A27/BP	Attaching parts for E.A9.80.1345:—									
	AGS.2035/B	Nut, 4 BA					4	—	C		
		Washer, shakeproof					4	—	C		
	E.A3.80.3	MOUNTING AND BRACKETS, NAVIGATOR'S CRATE (MOD. 2551)						—	—	—	
		Spares for:—									
5K/	AS.3360/C4J	LEAD , bonding						4	—	C	
10AJ/150	†	MOUNTING , anti-vibration						1	—	B	
10AJ/149	†	MOUNTING , anti-vibration						2	—	B	
10AJ/148	†	MOUNTING , anti-vibration						6	—	B	
		Attaching parts for Ref. 10AJ/150, 10AJ/149 and 10AJ/148:—									
28D/9436920 or 28D/9133011 28W/9419475	A25/1C	Bolt, 2 BA						4	—	C	
	A25/2C	Bolt, 2 BA						4	—	C	
	SP.15/C	Washer						4	—	C	
10AC/140	†	WASHER , check						9	—	C	
	E.A9.80.75	PANEL, FUEL MOUNTING, ASSEMBLY						—	—	—	
		Spares for:—									
	E.A9.80.63	BRACKET , mounting						2	—	—	
	E.A9.80.65	BRACKET , mounting						2	—	—	
		Attaching parts for E.A9.80.63 and E.A9.80.65:—									
28M/10280	AGS.2001/B/3	Nut, 4 BA						4	—	C	
28S/1212706	A40/B12	Screw, 4 BA						4	—	C	
5K/3373	TS.3360/B/5B	LEAD , bonding						1	—	C	
		Attaching parts for AS.3360/B/5B:—									
28D/1010658	A25/1B	Bolt, 4 BA						2	—	C	
28M/10280	AGS.2001/B/1	Nut, 4 BA						2	—	C	
27H/2951	†	MOUNTING , anti-vibration, 3lbs.						8	—	C	
		Attaching parts for Ref. 27H/2951:—									
28D/1011011	A25/8B	Bolt, 4 BA (Per pair)						1	—	C	
28M/10287	AGS.2001/B/1	Nut, 4 BA						5	—	C	
28S/1212706	A40/B12	Screw, 4 BA						4	—	C	
2033	E.A3.80.1789	Washer						3	—	C	
	E.A9.80.61	PANEL, FUEL, ASSEMBLY						1	—	—	
		Spares for:—									
	E.A9.81.153	BRACKET						1	—	—	
		Attaching parts for E.A9.81.153:—									
	SIMMONDS	Nut						4	—	—	
5CW/5252	D.536/17/2	CAP , dolly, switch						10	—	C	
6A/3853	HV.3711	GAUGE , fuel contents						1	—	A	
6A/3854	SMITHS AG.26	GAUGE , fuel contents						1	—	A	
	SMITHS AG.27	GAUGE , fuel contents						1	—	A	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
6A/3878	SMITHS AG.28	GAUGE, fuel contents	2	—		A	
6A/7516	SMITHS AG.144	GAUGE, fuel contents (Mod. 3391)	1	—		A	
		Attaching parts for AG.26, AG.27, AG.28, and AG.144:—					
28S/1212710	A40/B24	Screw, 4 BA	4	—		C	
	E.A9.80.59	PANEL, fuel	1	—		—	
5X/7151	2CZ.111226	PLUG, single	1	—		C	
	EEAS.18/2ER	STRIP, packing	4	—		—	
5CW/5823	ROTAX D.5406	SWITCH, S.P.	10	—		B	
		Attaching parts for D.5406:—					
28S/9440345	A40/B8	Screw, 4 BA	2	—		C	
28W/9419448	AGS.2035/B	Washer	2	—		C	
		Attaching parts for E.A9.80.61:—					
28D/1212939	A61/1C	Bolt, 2 BA	4	—		C	
	E.A9.80.10781	PANEL, MID, REMOVABLE, INSTALLATION (MOD. 4320)	—	—		—	
		Spares for:—					
	E.A9.80.10775	PANEL, MID, REMOVABLE, ASSEMBLY (MOD. 4320)	1	—		—	
		Spares for:—					
	E.A9.80.10915	BLOCK, clip	1	BS.2572		—	
	E.A9.81.349	BLOCK, packing, canopy jettison switch	1	LFS.23		—	
	E.A9.80.10855	BRACKET, MOUNTING, CONTROL UNIT, C.1607/4, ASSEMBLY	1	L.72		—	
		Spares for:—					
28FP/9492814	DZUS SX/560	WIRE-FORM	4	—		C	
5E/3898	†	CABLE, Uniersil 12	QR	—		C	
5E/3894	†	CABLE, Uniersil 20	QR	—		C	
	E.A9.81.5945	CABLE, ASSEMBLY, 12G, FROM MID REMOVABLE PANEL TO JB.12	1	—		—	
		Consisting of:—					
5E/3898	†	CABLE, Uniersil 12	QR	—		C	
5E/3894	†	CABLE, Uniersil 20	QR	—		C	
10H/0970296	CZ.69738	CLAMP, cable	1	—		C	
	ZZ.139119	GASKET, union	1	—		—	
26DK/12122	EEAS.276/D	OUTLET, adaptor	1	—		C	
	ZZ.139108	RING, sealing	1	—		—	
10H/0970098	Z.49084	RING, thrust	1	—		C	
5X/1005131	Z.49428	SLEEVE	11	—		C	
5K/9107069	EEAS.146/00	SLEEVE	QR	—		C	
5K/9107066	EEAS.146/12	SLEEVE	QR	—		C	
5K/9107065	EEAS.146/20	SLEEVE	QR	—		C	
5X/7192	2CZ.111238	SOCKET, 26-way	1	—		C	
5F/9454141	NY.18007A	STRAP	QR	—		C	
5F/9138822	NY.3342	STUD	QR	—		C	
5X/7363	HC.295	TAG	9	—		C	
5X/9462951	HC.294	TAG	2	—		C	
5X/6955	12335	TAG	2	—		C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R. L.M.		
	E.A9.81.5947	CABLE, ASSEMBLY, 12H, FROM MID REMOVABLE PANEL TO JB.12	1	—	—		
		Consisting of:—					
5E/3898	†	CABLE, Unifersil 12	QR	—	—	C	
10H/0970294	CZ.69735	CLAMP, cable	1	—	—	C	
	ZZ.139115	GASKET, union	1	—	—	—	
26DK/12101	EEAS.276/B	OUTLET, adaptor	1	—	—	C	
	ZZ.139104	RING, sealing	1	—	—	—	
10H/0120240	Z.66473	RING, thrust	1	—	—	C	
5K/9107067	EEAS.146/6	SLEEVE	QR	—	—	C	
5K/9107066	EEAS.146/12	SLEEVE	QR	—	—	C	
	5X/7181	SOCKET	1	—	—	C	
	5X/6955	TAG	3	—	—	C	
10H/0970293	CZ.9734	CLAMP, cable	1	—	—	C	
10H/0970294	CZ.69735	CLAMP, cable	1	—	—	C	
10H/0970296	CZ.69738	CLAMP, cable	2	—	—	C	
	20387	FLAP, SPRING ASSEMBLY, WARNING HORN SWITCH	1	—	—	C	
		Spares for:—					
5CW/5514	E.A4.81.1657	FLAP	1	—	—	C	
	27353	PIN	1	—	—	C	
	27352	SPRING	1	—	—	C	
	40619	SUPPORT, flap	1	—	—	C	
10A/17225	†	FILTER, colour, type 52	1	—	—	A	
10H/0970058	Z.60667	GASKET, outlet	1	—	—	C	
10H/0970059	Z.60668	GASKET, outlet	1	—	—	C	
10H/0970060	Z.60669	GASKET, outlet	2	—	—	C	
10H/0970107	Z.62234	GASKET, union	1	—	—	C	
10H/0970110	Z.62239	GASKET, union	2	—	—	C	
10H/0970111	Z.62237	GASKET, union	1	—	—	C	
	E.A9.81.2497	GUARD, switch, assembly, canopy jettison ...	1	—	—	—	
6A/3942	SMITH 505FL	INDICATOR, cabin, air	1	—	—	C	
		Attaching parts for 505FL:—					
28S/1212710	A40/B24	Screw, 4 BA	4	—	—	C	
10H/0119115	Z.49030	OUTLET, straight	1	—	—	C	
10H/0119121	Z.49081	OUTLET, straight	2	—	—	C	
10H/0119119	Z.49141	OUTLET, straight	1	—	—	C	
	E.A9.80.10777	PANEL, engraved	1	L.72	—	—	
10H/0560270	CZ.49216	PLUG, code 41, Mk. 4	1	—	—	C	
10H/0560360	CZ.49458	PLUG, code 48, Mk. 4	1	—	—	C	
10H/0560400	CZ.49228	PLUG, Code 50, Mk. 4	1	—	—	C	
10H/0560403	CZ.49228/3	PLUG, Code 50, Mk. 4	1	—	—	B	
10H/0970087	Z.62228	RING, sealing	1	—	—	C	
10H/0970091	Z.62231	RING, sealing	1	—	—	C	
10H/0970090	Z.62233	RING, sealing	2	—	—	C	
10H/0970095	Z.49051	RING, thrust	1	—	—	C	
10H/0970098	Z.49084	RING, thrust	2	—	—	C	
5K/9107069	EEAS.146/00	SLEEVE	QR	—	—	C	
5K/	EEAS.146/0	SLEEVE	QR	—	—	—	
5K/9107068	EEAS.146/2	SLEEVE	QR	—	—	C	
5K/9107066	EEAS.146/12	SLEEVE	QR	—	—	C	
5K/9107065	EEAS.146/20	SLEEVE	QR	—	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1	2	3	4	5	6
5F/9454141	NY.18007A	STRAP	QR	—		C	
5F/9138822	NY.3342	STUD	QR	—		C	
5CW/5818	NSF.8812-K7	SWITCH	1	—		B	
5CW/5813	NSF.7321-B111	SWITCH, S.P.	1	—		B	
5CW/5814	NSF.7360-B114	SWITCH, S.P.	1	—		B	
5CW/5815	NSF.8575-B111	SWITCH, D.P.	14	—		B	
5CW/5856	NSF.8396-B102	SWITCH, S.P.	2	—		B	
5CW/5774	NSF.8295-B120	SWITCH, S.P.	1	—		B	
110FB/19	†	SWITCH, altitude limit Attaching parts for Ref. 110FB/19:—	1	—		B	
28M/10286	AGS.2001/A/1	Nut, 6 BA	4	—		C	
28S/1212434	A40/A28	Screw, 6 BA	4	—		C	
5X/7363	HC.295	TAG	6	—		C	
5X/6955	12335	TAG	1	—		C	
5X/7209	12355	TAG	54	—		C	
5Q/107	†	VOLTMETER, 0-35 (Mod. 1789) Attaching parts for Ref. 5Q/107:—	1	—		B	
28S/1212709	A40/B20	Screw, 4 BA	4	—		C	
17104	E.B7.81.259	WASHER, packing, for switches Attaching parts for E.A9.80.10775:—	19	—		C	
28D/1215159	AS.4566/1C	Bolt, 2 BA	8	—		C	
	E.A9.80.115	PANEL, FORWARD, ASSEMBLY Spares for:—	1	—		—	
6A/2709	†	ALTIMETER, cabin, Mk. 18 Attaching parts for Ref. 6A/2709:—	1	—		A	
28S/1212710	A40/B24	Screw, 4 BA	4	—		C	
28W/9419448	AGS.2035/B	Washer	4	—		C	
6A/2693	†	GAUGE, hydraulic, pressure	1	—		C	
6D/1615	†	GAUGE, oxygen	2	—		A	
or							
6D/2237	†	GAUGE, oxygen Attaching parts for Ref. 6A/2693, 6D/1615 or 6D/2237:—	2	—		C	
28S/1212709	A40/B20	Screw, 4 BA	4	—		C	
28W/9419448	AGS.2035/B	Washer	4	—		C	
	E.A9.80.125	PANEL, bare	1	—		—	
	E.A9.80.769	PANEL, MAIN INSTRUMENT, ASSEMBLY Spares for:—	—	—		—	
6A/9094	†	ALTIMETER, Mk. 22F (Mod. 3879) Attaching parts for Ref. 6A/9094:—	1	—		A	
28DU/1212079	A114/2B	Bolt, No. 6, U.N.C.	4	—		C	
6A/5447	†	ARTIFICIAL HORIZON, MK. 4C (Mod. 2507) (Alternative to 6A/6026)	1	—		A	
6A/6026	†	ARTIFICIAL HORIZON, MK. 4D (Alternative to 6A/5447)	1	—		A	
28S/1212718	A40/C20	Attaching parts for Ref. 6A/5447 or 6A/6026:— Screw, 2 BA	3	—		C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5X/3277	CZ.50206 E.A9.80.939							1	—	C	
								1	—	—	
28S/1214164 28W/1200328	A44/B14 AGS.2037/B							1	—	C	
								1	—	C	
6A/2089	CHX.2104							1	—	A	
28S/1017078	A44/B24							4	—	C	
6B/561	†							1	—	A	
28S/1214173	A44/C24							4	—	C	
28F/19985 10H/0970077 10H/0970078 5L/9951230 10A/17724 28F/19987 10H/0970060 10H/0970058 10H/0970107 6A/2714	AGS.3095 Z.49042 Z.49041 † † AGS.3099 Z.60669 Z.60667 Z.62234 †							1 2 2 6 1 1 2 3 1 2	— — — — — — — — — —	C C C C C C C C C A	
28S/1017078	A44/B24							4	—	C	
6B/556 6A/387 10Q/16356 6A/1825 6A/2801 6A/3953 10Q/61	† † † † † † †							1 1 1 2 2 1 1	— — — — — — —	C C A A A A A	
28S/9474082 28W/1200328	A44/B16 AGS.2037/B							4 4	— —	C C	
5CZ/5074 5CZ/5073 6A/3360	† † †							1 2 1	— — —	C C A	
28S/1214166	A44/B28							4	—	C	
6A/3160 6A/3667 6A/5622 6A/7677	† † † †							1 1 1 1	— — — —	A A A A	
28S/1017078	A44/B24							4	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
110QB/6 5180	† E.A3.90.26/1	INDICATOR, altitude, A.Y.F.	1	—	A		
		INDICATOR, pilot's special (Gee H)	1	—	A		AE 1-8
28S/9474082	A44/B16	Attaching parts for 110QB/6 and E.A3.90.26/1:— Screw, 4 BA	2	—	C		
	E.A9.80.941	LABEL, "I.L.S. Beacon"	1	—	—		
	E.A9.80.1043	LABEL, "A.S.I. Correction Card"	1	—	—		
5CX/1553	†	LAMP, warning, red, generator fail and A.Y.F. limits	3	—	C		
5CX/1552	†	LAMP, warning, green, A.Y.F. limits	1	—	C		
5CX/1645	†	LAMP, warning, white, A.Y.F. limits	1	—	C		
5CX/4192	†	LAMP, warning, amber, I.L.S. beacon	1	—	C		
5X/1004083	Z.50211	LINK, commoning, 3-way	1	—	C		
5X/7209	12355	LUG, 6 BA	5	—	C		
10H/0970068	CZ.49179	OUTLET, angle	1	—	C		
10H/0970062	CZ.49180	OUTLET, straight	2	—	C		
10H/0970067	CZ.49816	OUTLET, straight	2	—	C		
	E.A9.80.771	PANEL, bare	1	—	—		
19962	E.A4.80.377	PLATE, blanking	1	—	C		
	E.A9.80.10369	PLATE, patch (Mod. 3159)	1	—	—		
10H/0560301	CZ.49222/1	PLUG, free, Mk. 4, 6-way	1	—	C		
10H/0560300	CZ.49222	PLUG, free, Mk. 4, 6-way	1	—	C		
10H/0560402	CZ.49228/2	PLUG, free, Mk. 4, 25-way	1	—	C		
10H/0560400	CZ.49228	PLUG, free, Mk. 4, 25-way	1	—	C		
10H/0560700	CZ.56730	PLUG, coupler, 2-way, panel mounting	1	—	C		
	5X/1531	RING, clamp	2	—	C		
10H/0970095	Z.49051	RING, thrust	1	—	C		
10H/0970088	Z.62229	RING, sealing	2	—	C		
10H/0970087	Z.62228	RING, sealing	1	—	C		
10H/0970090	Z.62233	RING, sealing	2	—	C		
5CW/5815	NSF.8375/B111	SWITCH, trim and slip standby supply	1	—	B		
	E.A9.80.10793	PANEL, REMOVABLE, CONSOLE EQUIPMENT AND WIRING, ASSEMBLY (MOD. 4055) Spares for:—	1	—	—		
	E.A9.81.3375	BRACKET, switch, bomb doors	1	—	—		
5X/1002694	CZ.50207	BLOCK, terminal, 5-way	1	—	B		
		Attaching parts for CZ.50207:—					
28M/10287	AGS.2001/B/1	Nut, 4 BA	2	—	C		
28S/1200065	A33/B28	Screw, 4 BA	2	—	C		
5E/4186	†	CABLE, Uninyvin 14	QR	—	C		
5E/4183	†	CABLE, Uninyvin 20	QR	—	C		
5CW/5252	HV.3711	CAP, Helvin, single	3	—	C		
5CW/5253	HV.3710	CAP, Helvin, double	6	—	C		
	CZ.59318	CLAMP, cable (Alternative to CZ.69736)	1	—	—		
10H/0970295	CZ.69736	CLAMP, cable (Alternative to CZ.59318)	1	—	C		
	CZ.59319	CLAMP, cable (Alternative to CZ.69738)	3	—	—		
10H/0970296	CZ.69738	CLAMP, cable (Alternative to CZ.59319)	3	—	C		
	12803	COVER, spring, wing store jettison	1	—	C		
5L/9959118	E.A9.81.3123	FILAMENT	2	—	C		
	A.259						

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.B6.81.6291	FLAP, SPRING, ASSEMBLY, BOMB RELEASE SAFETY LOCK (MOD. 4466) Spares for:—	1	—	—	
	E.B6.81.6289	FLAP	1	BSS.265	—	
27353	E.A4.81.1659	PIN	1	—	C	
27352	E.A4.81.1661	SPRING	1	—	C	
	E.B6.81.6293	SUPPORT, flap	1	BSS.265	C	
10H/0970109	Z.62236	GASKET, union	1	—	C	
10H/0970110	Z.62239	GASKET, union	3	—	C	
10H/0970059	Z.60668	GASKET, outlet	1	—	C	
10H/0970060	Z.60669	GASKET, outlet	3	—	C	
5CW/4222	†	GUARD, switch, locking gunsight master (Mod. 4139)	1	—	B	
1438575	E.A2.81.5915	GUARD, switch, locking bomb flare jettison (Mod. 4308)	1	—	C	
5CW/4222	E.A9.81.3125	GUARD, switch, locking generators	2	—	B	
5K/	HV.3111	GROMMET, Helvin	1	—	—	
5CZ/5073	†	INDICATOR, magnetic, type A, bomb doors and anti-icing	3	—	B	
5CW/4509	E.A3.81.787	KNOB, switch, aileron trim	2	—	B	
		Attaching parts for E.A3.81.787:—				
28S/1008070	A55/A4	Screw, grub (Alternative to E.A3.81.1089)	1	—	C	
	E.A3.81.1089	Screw, grub (Alternative to A55/A4)	1	—	—	
5CW/4832	E.A3.81.2077	KNOB, switch, bomb doors	1	—	B	
		Attaching parts for E.A3.81.2077:—				
28S/1005622	A31/B28	Screw, 4 BA	1	—	C	
28V/1206041	AGS.2035/B	Washer, shakeproof	1	—	C	
40933	E.A9.80.10595	LABEL, engraved	1	—	MR	
10H/0970067	CZ.49186	OUTLET, straight (Alternative to CZ.49081) ...	3	—	C	
	CZ.49081	OUTLET, straight (Alternative to CZ.49186) ...	3	—	—	
10H/0970063	CZ.51528	OUTLET, straight (Alternative to CZ.51526) ...	1	—	C	
	CZ.51526	OUTLET, straight (Alternative to CZ.51528) ...	1	—	—	
	E.A9.80.10845	PANEL, SUB ASSEMBLY, ENGRAVED	1	—	—	
		Spares for:—				
42077	E.B6.80.8007	PLATE, engraved, switch mounting (Mod. 4009)	1	—	C	
37130	E.A9.80.1265	PLATE, cover	1	—	C	
		Attaching parts for E.A9.80.1265:—				
28D/1010658	A25/1B	Bolt, 4 BA	4	—	C	
28V/9419465	SP.13/B	Washer	4	—	C	
5CW/8815	†	PLATE, adaptor, bomb flare jettison switch (Mod. 4308)	1	—	C	
		Attaching parts for Ref. 5CW/8815:—				
28S/1008327	A32/B14	Screw, 4 BA	2	—	C	
10H/0560400	CZ.49228	PLUG, 25-way	1	—	C	
10H/0560402	CZ.49228/2	PLUG, 25-way	1	—	C	
10H/0560403	CZ.49228/3	PLUG, 25-way	1	—	B	
10H/0970089	Z.62230	RING, sealing	1	—	C	
10H/0970090	Z.62233	RING, sealing	3	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
10H/0970097	Z.51342	RING, thrust	1	—	C		
10H/0970098	Z.49084	RING, thrust	3	—	C		
5K/9107069	EEAS.146/00	SLEEVE	2	—	C		
5K/9107068	EEAS.146/2	SLEEVE	2	—	C		
5K/9107067	EEAS.146/6	SLEEVE	3	—	C		
5K/9107065	EEAS.146/16	SLEEVE	10	—	C		
5K/9107065	EEAS.146/20	SLEEVE	114	—	C		
26DK/23688	EEAS.566	SLEEVE, bomb release safety lock switch	1	—	C		
5CW/6634	A.257	SLEEVE	2	—	C		
10H/0560162	CZ.51328/2	SOCKET, 4-way	1	—	C		
5F/9434858	HV.3254	STRAP	QR	—	C		
5F/9138823	NT.3255	STUD	70	—	C		
	E.A9.81.3379	SWITCH, BOMB DOOR ASSEMBLY (MOD. 2142)	1	—	—		
		Spares for:—					
5CW/4612	D.10001	SWITCH, type 8B	1	—	B		
5CW/4835	E.A3.81.2073	TOGGLE	1	—	C		
		Attaching parts for E.A3.81.2073:—					
28S/1200055	A33/A6	Screw, 6 BA	2	—	C		
		Attaching parts for E.A9.81.3379:—					
28S/9992525	A32/B12	Screw, 4 BA	4	—	C		
28W/9419486	SP.16/B	Washer	4	—	C		
28W/1206041	AGS.2035/B	Washer, shakeproof	4	—	C		
42076	E.A3.81.6375	SWITCH, RUDDER TRIM, ASSEMBLY (MOD. 4009)	1	—	B		
		Spares for:—					
	E.A4.81.6801	KNOB, switch	1	—	—		
	†	SWITCH, special (XD.787 with modified dolly, XD.827)	1	—	—		
	DP.1003	WASHER, crinkle, 4 BA	6	—	—		
		Attaching parts for E.A3.81.6375:—					
28S/1012450	A32/B10	Screw, 4 BA	4	—	C		
28W/1206041	AGS.2035/B	Washer, shakeproof	4	—	C		
5CW/540	†	SWITCH, push button, wing stores jettison	1	—	C		
		Attaching parts for Ref. 5CW/540:—					
28M/10286	AGS.2001/A/1	Nut, 6 BA	4	—	C		
28S/9995324	A32/A16	Screw, 6 BA	4	—	C		
5CW/4612	D.10001	SWITCH, D.P., landing lights	1	—	B		
5CW/6435	†	SWITCH, D.P., engine anti-ice	2	—	B		
		Attaching parts for Ref. 5CW/4612 and 5CW/6435:—					
28S/1200080	A32/B8	Screw, 4 BA	4	—	C		
28W/1206041	AGS.2035/B	Washer, shakeproof	4	—	C		
5CW/6428	†	SWITCH, aileron trim (Pre-Mod. 4003)	1	—	B		
5CW/7539	†	SWITCH, aileron trim (Mod. 4003)	1	—	C		
5CW/7540	†	SWITCH, generator and anti-collision	3	—	C		
		Attaching parts for Ref. 5CW/6428 or 5CW/7539 and 5CW/7540:—					
28S/9992525	A32/B12	Screw, 4 BA	2	—	C		
28W/1206041	AGS.2035/B	Washer, shakeproof	2	—	C		
28W/9419486	SP.16/B	Washer	2	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
5CW/6429	†	SWITCH , S.P.						5	—	B	
5CW/6433	†	SWITCH , S.P.						1	—	B	
		Attaching parts for Ref. 5CW/6429 and 5CW/6433:—									
28S/1200080	A32/B8	Screw, 4 BA						2	—	C	
28W/1206041	AGS.2035/B	Washer, shakeproof						2	—	C	
5CW/9235	†	SWITCH , bomb flare jettison (Mod. 4308) ...						1	—	B	
5CW/6461	C.180/B/7	SWITCH , push button, green						1	—	B	
5CW/6462	C.180/C/7	SWITCH , push button, amber						1	—	B	
5CW/9255	†	SWITCH , bomb release safety lock (Mod. 4466) ...						1	—	B	
5X/9462951	HC.294	TAG						1	—	C	
5X/9709513	HC.294D	TAG						2	—	C	
5X/9450396	HC.490	TAG						8	—	C	
5X/7316	HC.1187	TAG						2	—	C	
5X/7214	HC.1189	TAG						1	—	C	
5E/9102377	†	WIRE , tinned copper, 24 SWG						QR	—	C	
5E/9102380	†	WIRE , tinned copper, 30 SWG						QR	—	C	
		PANEL, REMOVABLE, AFT POSITION, ASSEMBLY						—	—	—	
		Spares for:—									
5CY/4520	†	CAP , protective						20	—	C	
5CY/2559	†	CIRCUIT-BREAKER , type A1						8	—	C	
5CY/2560	†	CIRCUIT-BREAKER , type A2						2	—	C	
5CY/2561	†	CIRCUIT-BREAKER , type A3						10	—	C	
		Attaching parts for Ref. 5CY/2559, 5CY/2560 and 5CY/2561:—									
28S/1213081	A44/A6	Screw, 6 BA						2	—	C	
23941	E.A9.80.155	CONNECTOR , circuit-breaker						1	—	C	
	E.A9.80.156	CONNECTOR , circuit-breaker						1	—	—	
23942	E.A9.80.157	CONNECTOR , circuit-breaker						2	—	C	
23909	E.A9.80.69	LABEL						1	—	C	
23910	E.A9.80.71	LABEL						1	—	C	
		Attaching parts for E.A9.80.69 and E.A9.80.71:—									
28D/1213257	AS.4565/5B	Bolt, 4 BA						2	—	C	
28M/10280	AGS.2001/B/3	Nut, 4 BA						2	—	C	
	AS.2801/4/05	Tube, distance						2	—	—	
5X/6508	†	LUG						4	—	C	
23934	E.A9.80.133	PANEL						1	—	MR	
		Attaching parts for E.A9.80.133:—									
28D/1213052	AS.4566/1C	Bolt, 2 BA						4	—	C	
28D/1212939	A61/1C	Bolt, 2 BA						4	—	C	
28W/9417404	SP.16/C	Washer						4	—	C	
		PANEL, STARTER, INSTALLATION (MOD. 4320)						—	—	—	
		Spares for:—									
E.A9.80.10931		PANEL, STARTER, ASSEMBLY (MOD. 4320)						1	—	—	
		Spares for:—									
E.A9.80.10933		BLOCK , mounting, clip						1	BS.2572	—	
E.A9.81.349		BLOCK , packing, battery isolation switch ...						1	—	—	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
5X/3276	CZ.50205	BLOCK , terminal, 2-way	1	—		C	
28M/1278189	AGS.2001/B/1	Attaching parts for CZ.50205:—					
5X/9450403	Z.28426	Nut, 4 BA	2	—		C	
		Pillar fixing	2	—		C	
5E/3898	†	CABLE , Uniersil 12	QR	—		C	
5E/3894	†	CABLE , Uniersil 20	QR	—		C	
5X/3272	CZ.26799	COVER , terminal block	1	—		C	
5X/7545	HC.1352	FERRULE	2	—		C	
24193	E.A9.81.329	GUARD , switch, battery isolation	1	—		C	
	E.A9.80.10861	PANEL , engraved	1	L.72		—	
10H/5809603	508-2-05604-002	PIN , plug, 16/20	37	—		C	
10H/9717833	508-2-04367	PLUG , filler	6	—		C	
5X/8082	UK-AN-9000-28-21P	PLUG , free, 37 x 16	1	—		C	
10H/	508-2-03851-010	RING , anti-choke	1	—		—	
5X/8098	2Z.139623	SLEEVE	31	—		C	
5K/9107069	EEAS.146/00	SLEEVE	QR	—		C	
5K/9107067	EEAS.146/6	SLEEVE	QR	—		C	
5K/9107066	EEAS.146/12	SLEEVE	QR	—		C	
5K/9107065	EEAS.146/20	SLEEVE	QR	—		C	
5F/9454141	NY.18007A	STRAP	QR	—		C	
5F/9138822	NY.3342	STUD	QR	—		C	
5CW/5857	TEDDINGTON FJB.A/6	SWITCH , cartridge selector	2	—		A	
28S/1212709	A40/B20	Attaching parts for FJB.A/6:—					
28W/1206041	AGS.2035/B	Screw, 4 BA	4	—		C	
		Washer	4	—		C	
5CW/11936	NSF.8372-B107	SWITCH , D.P.	2	—		B	
5CW/5815	NSF.8575-B111	SWITCH , D.P.	1	—		B	
5CW/5856	NSF.8396-B102	SWITCH , S.P.	3	—		B	
5X/1010324	HC.296	TAG	35	—		C	
5X/9450396	HC.490	TAG	4	—		C	
5X/9482491	HC.500	TAG	2	—		C	
17104	E.B7.81.259	WASHER , packing, switches	5	—		C	
28D/1007982	AS.1248/1C	Attaching parts for E.A9.80.10865:—					
		Bolt, 2 BA	6	—		C	
	E.A9.80.10867	PANEL SWITCH, INSTALLATION (MOD. 4320)	—	—		—	
		Spares for:—					
	E.A9.80.10877	BRACKET , mounting, assembly	1	L.72		—	
	E.A9.80.10881	BRACKET , mounting	1	L.72		—	
	E.A9.80.11359	PANEL SWITCH, ASSEMBLY (MOD. 4462)	1	—		—	
		Spares for:—					
5E/4183	†	CABLE , Uninyvin 20	QR	—		C	
5E/3896	†	CABLE , Uniersil 16	QR	—		C	
5K/1009086	SP.40/A6	GROMMET	2	—		C	
42522	E.G4.81.2035	GUARD , switch	1	—		C	
	E.A9.81.6033	GUARD , switch	1	—		—	
	E.A9.80.10871	PANEL , engraved	1	L.72		—	
	E.A9.80.11363	PLATE , adaptor (Mod. 4462)	1	L.72		—	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A3.81.2071	SWITCH, FLAPS, ASSEMBLY (PRE-MOD. 4005)	1	—	—	
	E.A3.81.5851	SWITCH, FLAPS, ASSEMBLY (MOD. 4005) ...	1	—	—	
		Spares for:—				
5CW/6435	†	SWITCH, change over D.P., No. 3 (Pre-Mod. 4005)	1	—	B	
5CW/7748	†	SWITCH, D.P. (Mod. 4005)	1	—	C	
5CW/4835	E.A3.81.2073	TOGGLE	1	—	B	
		Attaching parts for E.A3.81.2073:—				
28S/1200055	A33/A6	Screw, 6 BA	2	—	C	
		Attaching parts E.A3.81.2071 or E.A3.81.5851:—				
28M/9403519	A27/BP	Nut, 4 BA	4	—	C	
28S/9474082	A44/B16	Screw, 4 BA	4	—	C	
28W/1200328	AGS.2037/B	Washer, shakeproof	4	—	C	
		SWITCH, unit u/c	1	—	—	
		Attaching parts for C.2524Y:—				
28M/9403519	A27/BP	Nut, 4 BA	2	—	C	
28S/9474082	A44/B16	Screw, 4 BA	2	—	C	
28W/1200328	AGS.2037/B	Washer, shakeproof	2	—	C	
		SWITCH, fuel tank jettison, Type J	1	—	B	
		Attaching parts for Ref. 5CW/1936:—				
28M/9403518	A27/AP	Nut, 6 BA	4	—	C	
28S/9505800	A44/A16	Screw, 6 BA	4	—	C	
28W/9137412	AGS.2037/A	Washer, shakeproof	4	—	C	
		Attaching parts for E.A9.80.1299:—				
28D/1213051	AS.4566/1/2 C	Bolt, 2 BA	2	—	C	
28D/1213052	AS.4566/1 C	Bolt, 2 BA	2	—	C	
	E.A9.80.10995	PANEL, side, assembly (Mod. 4039)	1	—	—	
		Attaching parts for E.A9.80.10995:—				
28D/9436920	A25/1C	Bolt, 2 BA	10	—	C	
	E.A9.80.10469	RACKING FOR I.L.S. EQUIPMENT, ASSEMBLY (MOD. 2674) (PRE-MOD. 4010)	—	—	—	
		Spares for:—				
10AC/9469287	MARCONI W.14183/C	LOCK, equipment	4	—	B	
10A/17606	†	MOUNTING, anti-vibration, 15 lbs.	4	—	C	
		Attaching parts for Ref. 10A/17606:—				
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28S/9997545	A31/C16	Screw, 2 BA	4	—	C	
	MARCONI W.23862/C	PLATE, mounting	4	—	C	
		Attaching parts for W.23862/C:—				
28M/1278190	AGS.2001/C/1	Nut, 2 BA	6	—	C	
28S/9997545	A31/C16	Screw, 2 BA	6	—	C	
33239	E.A9.80.10405	STOWAGE	1	—	C	
	E.A9.80.1109	STRIP, bonding	4	—	—	
10AC/140	†	WASHER, check, A.V. mountings	4	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
	E.A9.80.425	RACKING, FOR I.L.S. AND G.G.S. EQUIPMENT (MOD. 4010)						1	—	—		
	E.A9.80.1139	CHANNEL, ASSEMBLY						1	—	—		
	E.B7.80.721	BOLT, toggle						2	—	—		
28D/1011006	A25/5B	Attaching parts for E.B7.80.721:—										
28M/1278189	AGS.2001/B/1	Bolt, 4 BA						1	—	C		
		Nut, 4 BA						1	—	C		
10AC/9469287	MARCONI W.14183/C	LOCK, equipment						2	—	B		
10A/17606	†	MOUNTING, equiflex, 15 lbs.						4	—	C		
		Attaching parts for Ref. 10A/17606:—										
28M/1278190	AGS.2001/C/1	Nut, 2 BA						4	—	C		
28S/9997545	A31/C16	Screw, 2 BA						4	—	C		
41478	E.B7.80.705	NUT, knurled						2	—	C		
10AS/9466114	MARCONI W.23862/C	PLATE, mounting						4	—	C		
		Attaching parts for W.23862/C:—										
28M/1278190	AGS.2001/C/1	Nut, 2 BA						6	—	C		
28S/9997545	A31/C16	Screw, 2 BA						6	—	C		
10AC/140	E.A9.80.1109	STRIP, bonding						4	—	—		
	†	WASHER, check						4	—	C		
	E.A9.80.10567	RACKING, RECEIVER, POWER AND REPEATER UNIT, ASSEMBLY (MOD. 3508) (PRE-MOD. 4039)						—	—	—		
		Spares for:—										
	DECCA LTD. E.55/30C	BACK-PLATE, assembly						1	—	—		
	DECCA LTD. E.279/BB	BACK-PLATE, assembly						1	—	—		
	DECCA LTD. B.321/BB	BACK-PLATE, assembly						1	—	—		
40202	E.A9.80.10477	BRACKET, assembly, guard hinge						1	—	C		
40203	E.A9.80.10478	BRACKET, assembly, guard hinge						1	—	C		
		Attaching parts for E.A9.80.10477 and E.A9.80.10478:—										
28D/9436920	A25/1C	Bolt, 2 BA						2	—	C		
28M/1278190	AGS.2001/C/1	Nut, 2 BA						2	—	C		
28W/9419475	SP.15/C	Washer						2	—	C		
40201	E.A9.80.10473	GUARD, ASSEMBLY						1	—	C		
		Spares for:—										
28FP/1004892	ODDIE 213/2	STUD						2	—	C		
28FP/1004893	ODDIE 214	WASHER						2	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
10AC/9469287	MARCONI LTD W.14183/C	LOCK , equipment assembly	5	—	B	
10AJ/1202384	†	MOUNTING , equipflex, 20 lbs. Attaching parts for Ref. 10AJ/1202384:—	4	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28S/9139155	A35/C16	Screw, 2 BA	4	—	C	
28W/9419475	SP.15/C	Washer	4	—	C	
10C/9456205	MARCONI LTD. W.14480C E.A9.80.10045	WASHER , domed SEATING IN PRESSURE CABIN, ASSEMBLY (MOD. 2563)	32	—	C	
27C/2409	† E.A9.80.10049	Spares for:— PACK , personal survival, type S	2	—	B	
	E.A9.80.10611	SEAT, PILOT'S EJECTION AND NAVIGATOR'S TAKE-OFF SEAT, ASSEMBLY Spares for:—	—	—	—	
		BRACKETS, LEG RESTRAINT, INSTALLATION (MOD. 2687) Spares for:—	—	—	—	
27L/510	MARTIN BAKER A/MBEU/3666	BRACKET	2	—	C	
28D/9140644	A25/9C	Attaching parts for A/MBEU/3666:— Bolt, 2 BA	4	—	C	
41812	E.A9.80.10645	BRACKET , trip rod, inboard (Mod. 2687) ...	1	L.64	MR	
41813	E.A9.80.10647	BRACKET , trip rod, outboard (Mod. 2687) ...	1	L.64	MR	
	E.A9.80.10629	BREECH, UNIT, INSTALLATION (MOD. 2687) Spares for:—	—	—	—	
27L/5346	MARTIN BAKER B/MBCJ/1280	BREECH , unit	1	—	A	
28D/1214031	AS.1242/8C	Attaching parts for B/MBCJ/1280:— Bolt, 2 BA	3	—	C	
28D/1013173	AS.1242/10C	Bolt, 2 BA	1	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	4	—	C	
28W/9419475	SP.15/C	Washer	4	—	C	
41811	E.A9.80.10631	PLATE , mounting, breech, unit $\frac{5}{8}$ " thick ...	1	DTD.5020	C	
28D/9133012	A25/3C	Attaching parts for E.A9.80.10631:— Bolt, 2 BA	2	—	C	
28D/1011019	A25/8C	Bolt, 2 BA	1	—	C	
28M/1278190	AGS.2001/C/1	Nut, 2 BA	3	—	C	
28W/9419475	SP.15/C	Washer	3	—	C	
12K/1277	†	CARTRIDGE , No. 3, Mk. 1 (Mod. 2687)	1	—	C	
12K/1433	†	CARTRIDGE , No. 13, Mk. 1 (set) (Mod. 4448)	1	—	—	
	E.A9.80.10665	COUPLING, ADAPTOR, ASSEMBLY (MOD. 2687) Consisting of:—	1	—	—	
34480	E.A9.80.10663	COUPLING , adaptor	1	—	C	
28F/9133480	AGS.950/A	UNION , body	1	—	C	
28F/8014021	AGS.1138/B	WASHER , jointing	1	—	C	
27L/1445196	MARTIN BAKER C76/HC/MB	COUPLING , pipe (Mod. 2687)	2	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
6F/235	†							1	—	B	
28D/1202771	A25/4G							2	—	C	
28D/1010030	A25/7C							2	—	C	
28M/1006939	A27/GP							2	—	C	
28M/9403520	A27/CP							2	—	C	
28V/9419403	SP.13/G							2	—	C	
28V/9419402	SP.13/C							2	—	C	
27L/1445247	MARTIN BAKER MBEU/34677 E.A9.10.10309							1	—	A	
								1	—	—	
	—							1	—	—	
27L/2729	MARTIN BAKER B/MBEU/17353							2	—	C	
27L/80	MARTIN BAKER O/MBEU/1434							1	—	C	
33724	E.A9.80.549 E.A9.10.1833							2	—	C	
								2	—	—	
28D/1008151	A25/4E							2	—	C	
28D/1011242	A25/7E							1	—	C	
28M/1011475	A27/EP							3	—	C	
28V/9418921	SP.13/E							3	—	C	
27L/5352	MARTIN BAKER B/MBCJ/1088							1	—	C	
27L/5351	MARTIN BAKER O/MBCJ/1087							1	—	C	
27L/5349	MARTIN BAKER A/MBCJ/1085							1	—	C	
27L/5348	MARTIN BAKER B/MBCJ/1084							1	—	C	
27L/5350	MARTIN BAKER A/MBCJ/1086							1	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
27L/50069	†	RAIL , seat guide	1	—	C	
		Attaching parts for Ref. 27L/50069:—				
28D/1011242	A25/7E	Bolt, $\frac{1}{4}$ " BSF	17	—	C	
28D/1011258	A25/8G	Bolt, $\frac{5}{16}$ " BSF	2	—	C	
28M/9480017	AGS.2001/E/1	Nut, $\frac{1}{2}$ " BSF	17	—	C	
28M/10291	AGS.2001/G/1	Nut, $\frac{5}{16}$ " BSF	2	—	C	
4886	E.A3.80.479	Packing, fillet	2	—	C	
3897	E.A3.80.481	Packing, fillet	17	—	C	
28W/9419405	SP.15/E	Washer	17	—	C	
28W/9419476	SP.15/G	Washer	2	—	C	
27L/1445206	†	SEAT , ejection, type 2CB, Mk. 2 (Mod. 4448) ...	1	—	A	
	E.A9.16.10001	SEAT-PAN. NAVIGATOR'S TAKE-OFF, ASSEMBLY	1	—	—	
		Spares for:—				
38003	E.C3.80.99	BRACKET , cord retaining, assembly ...	2	—	MR	
38004	E.C3.80.397	CORD , retaining	1	—	C	
38013	E.C3.80.579	HOOK , cord retaining	1	—	MR	
38005	E.C3.80.401	PACKING , piece at hook	1	—	MR	
38006	E.C3.80.405	WASHER , spacing for bracket	1	—	MR	
	E.A9.16.10003	SUPPORT, BACK, NAVIGATOR'S TAKE-OFF SEAT	1	—	—	
		Spares for:—				
37986	E.C3.16.109	CUSHION	1	—	C	
29G/2180	CARR 882	STUD , "Lift-the-Dot" single	8	—	C	
		Attaching parts for 882:—				
28M/1006473	A27/CT	Nut, 2 BA	1	—	C	
28W/1006946	AGS.2035/C	Washer, shakeproof	1	—	C	
27L/1074	†	TIME , delay	1	—	A	
26DK/18958	EEAS.237/7AH	WASHER , "D"	9	—	C	
	E.A9.16.10005	SEAT, NAVIGATOR'S OPERATIONAL, INSTALLATION	—	—	—	
		Spares for:—				
37985	E.C3.16.45	BEARING, INBOARD, ASSEMBLY	4	—	B	
		Spares for:—				
	CT.51	BUSH , oilite, $\frac{5}{8}$ " long	1	—	—	
37987	E.C3.16.209	BEARING, OUTBOARD, ASSEMBLY	2	—	B	
		Spares for:—				
	CT.51	BUSH , oilite, $\frac{5}{8}$ " long	1	—	—	
		Attaching parts for E.C3.16.45 and E.C3.16.209:—				
28D/9133012	A25/3C	Bolt, 2 BA (inboard bearing)	2	—	C	
28D/9133011	A25/2C	Bolt, 2 BA (outboard bearings)	2	—	C	
28W/9419475	SP.15/C	Washer	2	—	C	
37978	E.C3.10.765	GUARD , plate, tension rod forward	1	—	C	
37979	E.C3.10.767	GUARD , plate, tension rod rear	1	—	C	
		Attaching parts for E.C3.10.765 and E.C3.10.767:—				
28D/9133653	AS.1248/1/2C	Bolt, 2 BA	7	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	1	2	3	4	5	6	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
											M.R.	L.M.	
37939	E.A9.16.10009							HOUSING , torsion rod, forward	1	—		C	
								Attaching parts for E.A9.16.10009:—					
28D/9133014	A25/13C							Bolt, 2 BA	2	—		C	
28M/9433473	AGS.2002/C/1							Nut, 2 BA	2	—		C	
28W/9419475	SP.15/C							Washer	2	—		C	
37938	E.A9.16.10007							HOUSING , torsion rod, rear	1	—		C	
								Attaching parts for E.A9.16.10007:—					
28D/9133012	A25/3C							Bolt, 2 BA	2	—		C	
28W/9419475	SP.15/C							Washer	2	—		C	
	E.C3.16.175							SEAT, NAVIGATOR'S, ASSEMBLY (MOD. 2563)	1	—		—	
								Spares for:—					
33008	E.C3.16.177							ARM, PIVOT, ASSEMBLY	1	—		C	
								Spares for:—					
	E.C3.16.181							BUSH , serrated	1	—		—	
	E.C3.16.179							FITTING , serrated	1	—		—	
	E.C3.16.169							BASE, UNIT, ASSEMBLY	1	—		—	
								Spares for:—					
32982	E.C3.16.39							BASE , unit	1	—		C	
37874	E.C3.16.17							CAM , centralising	1	—		C	
								Attaching parts for E.C3.16.17:—					
28D/1013172	AS.1242/5C							Bolt, 2 BA	2	—		C	
28M/9995179	A47/C							Nut, 2 BA	2	—		C	
28S/1200053	A33/C16							Screw, 2 BA	11	—		C	
28S/1011503	A33/C18							Screw, 2 BA	7	—		C	
28W/9419402	SP.13/C							Washer	2	—		C	
32984	E.C3.16.11							GEAR , locating	1	—		B	
								Attaching parts for E.C3.16.11:—					
28D/1007976	AS.1242/4C							Bolt, 2 BA	6	—		C	
28D/1013173	AS.1242/10C							Bolt, 2 BA	2	—		C	
28M/9995179	A47/C							Nut, 2 BA	8	—		C	
28S/1011504	A33/C32							Screw, 2 BA	2	—		C	
28S/9435719	A33/C36							Screw, 2 BA	4	—		C	
28W/9419402	SP.13/C							Washer	8	—		C	
37876	E.C3.16.157							SUPPORT , half, seat base (male)	2	—		C	
								Attaching parts for E.C3.16.157:—					
28D/1214038	AS.1242/16C							Bolt, 2 BA	4	—		C	
28M/9995179	A47/C							Nut, 2 BA	4	—		C	
28W/9419402	SP.13/C							Washer	4	—		C	
37877	E.C3.16.159							SUPPORT , half, seat base (female)	2	—		C	
2A/9500571	†							BEARING , ball, $\frac{1}{8}$ " dia., seat rotation	50	—		C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip. M.R. L.M.	Plate No.
		1	2	3	4	5	6				
	E.C3.16.167	LINKAGE, SEAT OPERATING, ASSEMBLY						—	—	—	
		Spares for:—									
37881	E.C3.16.305	HANDLE , seat operating						1	—	C	
37875	E.C3.16.145	LINK , assembly						1	—	C	
37878	E.C3.16.161	LINK						2	—	C	
		Attaching parts for E.C3.16.161:—									
28P/1207877	SP.4Y/D25	Pin, shackle						1	—	C	
28P/9710567	SP.90/C4	Pin, split						1	—	C	
	AS.2806/5/132	Tube, distance, $\frac{5}{16}$ " o/d x 22 SWG, 1"32 long						1	T.45	LM	
28W/9419487	SP.16/E	Washer						1	—	C	
37879	E.C3.16.163	LINK						2	—	C	
		Attaching parts for E.C3.16.163:—									
28P/832	SP.4Y/B6	Pin, shackle						2	—	C	
28P/9710567	SP.90/C4	Pin, split						2	—	C	
28W/9419402	SP.13/C	Washer						2	—	C	
28W/9419475	SP.15/C	Washer						2	—	C	
37880	E.C3.16.165	LINK						2	—	C	
		Attaching parts for E.C3.16.165:—									
28P/1011186	SP.4Y/B17	Pin, shackle						1	—	C	
28P/9710567	SP.90/C4	Pin, split						1	—	C	
	AS.2806/4/055	Tube, distance, $\frac{1}{4}$ " o/d x 22 SWG, 0"55 long						1	T.45	LM	
28W/9419475	SP.15/C	Washer						1	—	C	
28P/1053	SP.4Y/D31	PIN , shackle, securing spring retainer and main link to handle						1	—	C	
	AS.2806/5/075	TUBE , distance, $\frac{5}{16}$ " o/d x 22 SWG, 0"75 long						1	T.45	LM	
	AS.2806/5/043	TUBE , distance, $\frac{5}{16}$ " o/d x 22 SWG, 0"43 long						2	T.45	LM	
	AS.2806/5/016	TUBE , distance, $\frac{5}{16}$ " o/d x 22 SWG, 0"16 long						2	T.45	LM	
33009	E.C3.16.203	PIN , pivot, at base						1	—	C	
28P/1052	SP.4Y/D30	PIN , shackle, securing base to support structure, front						1	—	C	
33011	E.C3.16.191	PIN , special, guide for spring retainer ...						2	—	C	
		Attaching parts for E.C3.16.191:—									
28P/1021104	SP.90/C3	Pin, split						1	—	C	
	AS.2806/4/030	Tube, distance, $\frac{1}{4}$ " o/d x 22 SWG, 0"30 long						1	T.45	LM	
28W/9419454	SP.10/C	Washer						2	—	C	
28W/9419402	SP.13/C	Washer						1	—	C	
32981	E.C3.16.41	SEAT, PAN, ASSEMBLY						1	—	A	
		Consisting of:—									
32980	E.C3.16.243	BUSH , plunger, foot						1	—	C	
32977	E.C3.16.67	BUSH , upper, at seat hinge link						2	—	C	
32978	E.C3.16.69	BUSH , lower, at seat hinge link						2	—	C	
32975	E.C3.16.23	BUSH , shouldered, in lever						1	—	C	
32957	E.C3.16.55	CAM , lever, seat back adjustment						1	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
	E.C3.16.199							1	—		—	
	E.C3.16.197							1	—		—	
	E.C3.16.29							1	—		—	
32959	E.C3.16.59							2	—		C	
32963	E.C3.16.57							1	—		C	
32972	E.C3.16.31							1	—		C	
28D/9709461	AS.1242/3C							1	—		C	
28P/9710567	SP.90/C4							1	—		C	
28W/9419402	SP.13/C							1	—		C	
	E.C3.16.79							1	—		—	
32970	E.C3.16.87							1	—		C	
28M/10330	AGS.2002/E/1							1	—		C	
28W/9418921	SP.13/E							1	—		C	
	E.C3.16.81							1	—		C	
28M/9512070	A27/EC							1	—		C	
28W/9418921	SP.13/E							1	—		C	
28P/9486478	SP.90/C/5							1	—		C	
	E.C3.16.83							1	—		C	
28P/9710567	SP.90/C4							1	—		C	
28W/9419402	SP.13/C							1	—		C	
	E.C3.16.85							1	—		C	
								1	—		C	
28M/1007403	A27/ET							1	—		C	
32969	E.C3.16.85							1	—		C	
32971	E.C3.16.89							1	—		C	
28P/9710567	SP.90/C4							1	—		C	
28W/9419454	SP.10/C							1	—		C	
28W/9419402	SP.13/C							1	—		C	
	E.C3.16.207							2	—		C	
28D/1007976	AS.1242/4C							2	—		C	
28M/1006473	A27/CT							2	—		C	
28W/9419402	SP.13/C							2	—		C	
	E.C3.16.61							2	—		C	
28M/14537	A58/GS							1	—		C	
28P/9496478	SP.90/C5							1	—		C	
32961	E.C3.16.73							1	—		C	
32962	E.C3.16.75							1	—		C	
32960	E.C3.16.71							1	—		C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
32976	E.C3.16.25							1	—	—	
	E.C3.16.19							1	—	C	
	E.C3.16.91							1	—	—	
	32964	E.C3.16.9						1	—	C	
	32973	E.C3.16.27						1	—	C	
	E.C3.16.105							1	—	—	
28D/1007976	AS.1242/4C							17	—	C	
28M/9403520	A27/CP							17	—	C	
28W/9419402	SP.13/C							17	—	C	
	E.C3.16.43							1	—	—	
28N/5549	AGS.899/2							4	—	C	
32979	E.C3.16.201							2	—	C	
28P/9710567	SP.90/C4							4	—	C	
	E.C3.16.35							1	—	—	
28D/1007976	AS.1242/4C							6	—	C	
28M/9995179	A47/C							6	—	C	
28W/9419402	SP.13/C							6	—	C	
32965	E.C3.16.103							2	—	C	
28D/1013172	AS.1242/5C							2	—	C	
28M/10328	AGS.2002/C/1							2	—	C	
28W/9419402	SP.13/C							2	—	C	
32974	E.C3.16.33							1	—	C	
	E.C3.16.95							1	—	—	
32966	E.C3.16.97							1	—	C	
28D/1010658	A25/1B							2	—	C	
28M/10327	AGS.2002/B/1							2	—	C	
28W/9419465	SP.13/B							2	—	C	
	E.C3.16.101							1	—	—	
38078	E.C3.16.365							1	—	C	
28P/19235	SP.90/E10							1	—	C	
38079	E.C3.16.367							1	—	C	
	E.C3.16.113							—	—	—	
32992	E.C3.16.127							1	—	C	
32991	E.C3.16.125							2	—	C	
33001	E.C3.16.295							2	—	C	
32995	E.C3.16.137							1	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
37790	E.C3.16.329	SPRING , torsion, seat frame floor fitting ...	2	—	C	
		Attaching parts for E.C3.16.329:—				
28D/1011019	A25/8C	Bolt, 2 BA (Rear spring) ...	1	—	C	
28D/1215671	A59/15C	Bolt, 2 BA (Forward spring) ...	1	—	C	
28M/10328	AGS.2002/C/1	Nut, 2 BA ...	1	—	C	
28W/9419475	SP.15/C	Washer ...	2	—	C	
	E.A9.10.3751	SIGNAL, PISTOL, INSTALLATION	—	—	—	
		Spares for:—				
7B/1484	†	MOUNTING , pistol, Mk. 1 ...	1	—	A	
		Attaching parts for Ref. 7B/1484:—				
28D/1200119	A25/4C	Bolt, 2 BA ...	4	—	C	
	E.A3.10.3033	PATCH , fabric ...	1	—	—	
7B/1479	†	PISTOL , signal, Mk. 1 ...	1	—	A	
4433	E.A3.10.2995	SEAL , pressure ...	1	—	C	
	E.C3.80.445	STOWAGE, FIRST AID, INSTALLATION (MOD. 2563)	—	—	—	
		Spares for:—				
2167	E.A1.80.881	CONTAINER , first aid ...	1	—	B	
		Attaching parts for E.A1.80.881:—				
28D/9140202	AS.1246/1C	Bolt, 2 BA ...	6	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA ...	6	—	C	
28W/9419475	SP.15/C	Washer ...	6	—	C	
	E.A9.80.10843	STOWAGE, ASBESTOS GLOVES, PARACHUTE AND STATIC LINE FACILITIES, INSTALLATION (MOD. 3832)	—	—	—	
		Spares for:—				
	E.A9.80.10827	PLATE, ANCHOR, STATIC LINE, INSTALLATION	—	—	—	
		Spares for:—				
	E.A9.80.10829	PLATE , anchor ...	1	—	—	
		Attaching parts for E.A9.80.10829:—				
28D/9709461	AS.1242/3C	Bolt, 2 BA ...	2	—	C	
28D/1013172	AC.1242/5C	Bolt, 2 BA ...	2	—	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA ...	4	—	C	
28W/9419402	SP.13/C	Washer ...	4	—	C	
	E.A9.80.10801	STOWAGE, PARACHUTE AND STATIC LINE, ASSEMBLY	1	—	—	
		Spares for:—				
	E.A9.80.10819	CHANNEL , for static line conduit ...	1	—	—	
34670	E.A9.80.10821	CONDUIT , rubber ...	1	—	C	
41954	E.A9.80.10835	STRAP , assembly, bottom ...	1	—	C	
41953	E.A9.80.10833	STRAP , assembly, top ...	1	—	C	
		Attaching parts for E.A9.80.10835 and E.A9.80.10833:—				
28D/1007982	AS.1248/1C	Bolt, 2 BA ...	5	—	C	
	E.A9.80.10841	Strip, reinforcing ...	1	—	—	
	E.A3.80.1225	STRAP , glove stowage, assembly ...	1	—	—	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
	E.A9.83.233	STOWAGE, BOMB DOOR RELEASE AND SAFETY LOCK (MOD. 2363)	—	—	—	
		Spares for:—				
17506	E.A3.83. 149	BAG, stowage	1	—	C	
5CW/4834	E.A3.83.151	PIN, SAFETY LOCK, ASSEMBLY	1	—	B	
		Spares for:—				
28FP/1200982	A.415	PIN, "pip"	1	—	C	
	E.A9.80.575	STOWAGE, LEAK STOPPER, ASSEMBLY	—	—	—	
		Spares for:—				
	NORMALAIR					
	504120	ENVELOPE, stowage, for stopper	5	—	C	
27KD/397	†	STOPPER, leak	5	—	C	
27KD/375						
	E.A9.80.921	STOWAGE, ON WINDBREAK DOOR WELL SKIN, ASSEMBLY	—	—	—	
		Spares for:—				
	E.A9.80.925	BRACKET, mounting, holders	8	—	—	
24088	E.A9.80. 923	HOLDER, bombing angle	1	—	C	
24087	E.A9.80.911	HOLDER, maps	1	—	C	
		Attaching parts for E.A9.80.923 and E.A9.80.911:—				
28S/1214673	A39/B8	Screw, 4 BA	4	—	C	
28W/9416642	SP.47/B	Washer, spring	4	—	C	
6A/409	†	HOLDER, deviation card	1	—	C	
	E.A9.80.299	STOWAGE, NAVIGATOR'S VALISE	—	—	—	
		Spares for:—				
	E.A9.80.303	STRAP, assembly	1	—	C	
35072	E.A9.80.305	STRAP, assembly	1	—	C	
	E.A9.85.1	STOWAGE, SIGNAL AND WINDOW CARTRIDGE, ASSEMBLY	—	—	—	
		Spares for:—				
28E/1201175	AS.2294/9	CLIP, cartridge	12	—	C	
8621	E.A3.85.11	CORD, retaining	2	—	C	
		Attaching parts for E.A3.85.11:—				
28G/3800	AGS.796/B	Eye-bolt, 4 BA	2	—	C	
28M/1278189	AGS.2001/B/1	Nut, 4 BA	2	—	C	
28W/9419465	SP.13/B	Washer	2	—	C	
	E.A9.83.149	STOWAGE OF UNDERCARRIAGE AND FLAP SWITCHES, SAFETY LOCK, INSTALLATION	—	—	—	
		Spares for:—				
8969	E.A3.83.173	BAG, stowage, for flap switch locking pin ...	1	—	B	
22167	E.A3.83.295	BAG, stowage, for undercarriage switch locking pin	1	—	B	
5CW/4751	E.A3.83.175	LOCK, FLAP SWITCH SAFETY, GROUP ...	1	—	B	
		Spares for:—				
28FP/1200982	A.415	PIN, "pip"	1	—	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.A9.80.10969	STOWAGE, PINS, EJECTION SEAT, INSTALLATION (MOD. 4446)	—	—	—		
	E.A3.80.6171	Spares for:— BLOCK , stowage	1	—	—		
		Attaching parts for E.A3.80.6171:—					
28D/1010030	A25/7C	Bolt, 2 BA	2	—	C		
28M/1278190	AGS.2001/C/1	Nut, 2 BA	2	—	C		
28W/9419454	SP.10/C	Washer	2	—	C		
28W/9419475	SP.15/C	Washer	2	—	C		
	E.A9.80.17	STRUCTURE, MAIN INSTRUMENT PANEL	—	—	—		
	AS.2370/C	Spares for:— LEAD , bonding, at centre bracket	1	—	—		
		Attaching parts for AS.2370/C:—					
28D/9436920	A25/1C	Bolt, 2 BA at bracket	1	—	C		
28D/9133011	A25/2C	Bolt, 2 BA	1	—	C		
	5X/9007	† Lug, adaptor	1	—	C		
28M/9433473	AGS.2002/C/1	Nut, 2 BA	2	—	C		
	3510	EEAS.28/20	1	—	C		
28W/9419475	SP.15/C	Washer	2	—	C		
	27H/2783	LORD 150/P6	6	—	B		
	27H/2786	LORD 150/P12	4	—	B		
		Attaching parts for 150/P6 and 150/P12:—					
28D/1008149	A25/2B	Bolt, 4 BA	4	—	C		
28D/7002413	A25/14E	Bolt, 1/2" BSF	1	—	C		
28M/1086618	AGS.2002/B/1	Nut, 4 BA	4	—	C		
28M/9480017	AGS.2001/E/1	Nut, 1/2" BSF	1	—	C		
28W/9419405	SP.15/E	Washer	1	—	C		
	655	EEAS.28/51ER	3	—	C		
	12611	E.B7.80.497	5	SH30	C		
	E.A9.80.10457	SWITCH, MASTER, UNDERCARRIAGE, INSTALLATION (MOD. 3159)	—	—	—		
		Spares for:—					
	5E/4183	† CABLE , Uninyvin 20	QR	—	C		
5CW/5765	†	GUARD , switch	1	—	B		
	E.C3.10.627	LABEL , "Safe"	1	—	—		
	E.C3.10.629	LABEL , "Live"	1	—	—		
5CW/6435	†	SWITCH , D.P. (Pre-Mod. 3849)	1	—	B		
5CW/7748	†	SWITCH , D.P. (Mod. 3849)	1	—	C		
		Attaching parts for Ref. 5CW/6435 or 5CW/7748:—					
28S/9992525	A32/B12	Screw, 4 BA	4	—	C		
28W/9419448	AGS.2035/B	Washer	4	—	C		

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	
SUMMARY OF STOCK ITEMS USED ON PRESSURE CABIN EQUIPMENT, ASSEMBLY											
28D/1010658	A25/1B	Bolt,	4	BA	C	
28D/1008149	A25/2B	Bolt,	4	BA	C	
28D/1011011	A25/8B	Bolt,	4	BA	C	
28D/9436920	A25/1C	Bolt,	2	BA	C	
28D/9133011	A25/2C	Bolt,	2	BA	C	
28D/9133012	A25/3C	Bolt,	2	BA	C	
28D/1200119	A25/4C	Bolt,	2	BA	C	
28D/7002428	A25/6C	Bolt,	2	BA	C	
28D/1010030	A25/7C	Bolt,	2	BA	C	
28D/1011019	A25/8C	Bolt,	2	BA	C	
28D/9133014	A25/13C	Bolt,	2	BA	C	
28D/1011030	A25/2E	Bolt,	1/4"	BSF	C	
28D/1008151	A25/4E	Bolt,	1/4"	BSF	C	
28D/1011242	A25/7E	Bolt,	1/4"	BSF	C	
28D/7002413	A25/14E	Bolt,	1/4"	BSF	C	
28D/1202771	A25/4G	Bolt,	5/16"	BSF	C	
28D/1011258	A25/8G	Bolt,	5/16"	BSF	C	
28D/12953	A28/1B	Bolt,	4	BA	C	
28D/12837	A28/1C	Bolt,	2	BA	C	
28D/1215671	A59/15C	Bolt,	2	BA	C	
28D/1212951	A61/19C	Bolt,	2	BA	C	
28D/1213486	A61/15G	Bolt,	5/8"	BSF	C	
28D/1007285	AS.1242/1B	Bolt,	4	BA	C	
28D/9709461	AS.1242/3C	Bolt,	2	BA	C	
28D/1007976	AS.1242/4C	Bolt,	2	BA	C	
28D/1013172	AS.1242/5C	Bolt,	2	BA	C	
28D/1013173	AS.1242/10C	Bolt,	2	BA	C	
28D/1214038	AS.1242/16C	Bolt,	2	BA	C	
28D/8375	AS.1243/1C	Bolt,	2	BA	C	
28D/1212888	AS.1244/7C	Bolt,	2	BA	C	
28D/9140202	AS.1246/1C	Bolt,	2	BA	C	
28D/9137409	AS.1246/2C	Bolt,	2	BA	C	
28D/1215327	AS.1246/1E	Bolt,	1/4"	BSF	C	
28D/9133653	AS.1248/1/2C	Bolt,	2	BA	C	
28D/1213476	AS.1249/1C	Bolt,	2	BA	C	
28D/1213257	AS.4565/5B	Bolt,	4	BA	C	
28D/1215159	AS.4565/1C	Bolt,	2	BA	C	
28D/1213043	AS.4566/1B	Bolt,	4	BA	C	
28D/1213051	AS.4566/1/2C	Bolt,	2	BA	C	
28D/1213052	AS.4566/1C	Bolt,	2	BA	C	
28E/9513854	AS.2294/8	Clip, spring	C	
28E/1201175	AS.2294/9	Clip, spring	C	
28G/3800	AGS.796/B	Eye-bolt,	4	BA	C	
28M/9403518	A27/AP	Nut,	6	BA	C	
28M/9403519	A27/BP	Nut,	4	BA	C	
28M/9403520	A27/CP	Nut,	2	BA	C	
28M/5808573	A27/CS	Nut,	2	BA	C	
28M/1006473	A27/CT	Nut,	2	BA	C	
28M/9512070	A27/EC	Nut,	1/4"	BSF	C	
28M/1011475	A27/EP	Nut,	1/4"	BSF	C	
28M/1007403	A27/ET	Nut,	1/4"	BSF	C	
28M/1006939	A27/GP	Nut,	5/16"	BSF	C	










**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**


Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
		1 2 3 4 5 6				
28M/9995179	A47/C	Nut, 2 BA	C	
28M/14537	A58/GS	Nut, 1/8" BSF	C	
28M/10286	AGS.2001/A/1	Nut, 6 BA	C	
28M/10287	AGS.2001/B/1	Nut, 4 BA	C	
28M/10280	AGS.2001/B/3	Nut, 4 BA	C	
28M/10288	AGS.2001/C/1	Nut, 2 BA	C	
28M/10281	AGS.2001/C/3	Nut, 2 BA	C	
28M/10290	AGS.2001/E/1	Nut, 1/4" BSF	C	
28M/10291	AGS.2001/G/1	Nut, 1/8" BSF	C	
28M/10308	AGS.2002/A/4	Nut, 6 BA	C	
28M/10327	AGS.2002/B/1	Nut, 4 BA	C	
28M/10328	AGS.2002/C/1	Nut, 2 BA	C	
28M/10310	AGS.2002/C/4	Nut, 2 BA	C	
28M/10330	AGS.2002/E/1	Nut, 1/4" BSF	C	
28M/10332	AGS.2002/G/3	Nut, 1/8" BSF	C	
28P/831	SP.4Y/B5	Pin, shackle	C	
28P/832	SP.4Y/B6	Pin, shackle	C	
28P/1011186	SP.4Y/B17	Pin, shackle	C	
28P/18421	SP.4Y/D25	Pin, shackle	C	
28P/1052	SP.4Y/D30	Pin, shackle	C	
28P/1021104	SP.90/C3	Pin, split	C	
28P/9710567	SP.90/C4	Pin, split	C	
28P/9486478	SP.90/C5	Pin, split	C	
28P/19235	SP.90/E10	Pin, split	C	
28P/19157	SP.90/G10	Pin, split	C	
28S/9419453	A31/B14	Screw, 4 BA	C	
28S/1200034	A31/B16	Screw, 4 BA	C	
28S/1005622	A31/B28	Screw, 4 BA	C	
28S/9997545	A31/C16	Screw, 2 BA	C	
28S/9995324	A32/A16	Screw, 6 BA	C	
28S/1200080	A32/B8	Screw, 4 BA	C	
28S/1012450	A32/B10	Screw, 4 BA	C	
28S/9992525	A32/B12	Screw, 4 BA	C	
28S/9992522	A32/B16	Screw, 4 BA	C	
28S/9995376	A32/B20	Screw, 4 BA	C	
28S/1220007	A32/C40	Screw, 2 BA	C	
28S/1200055	A33/A6	Screw, 6 BA	C	
28S/1200059	A33/A14	Screw, 6 BA	C	
28S/1200060	A33/A16	Screw, 6 BA	C	
28S/1200065	A33/B28	Screw, 4 BA	C	
28S/1200053	A33/C16	Screw, 2 BA	C	
28S/1011503	A33/C18	Screw, 2 BA	C	
28S/1011504	A33/C32	Screw, 2 BA	C	
28S/9435719	A33/C36	Screw, 2 BA	C	
28S/1005545	A35/B16	Screw, 4 BA	C	
28S/9139155	A35/C16	Screw, 2 BA	C	
28S/1214673	A39/B8	Screw, 4 BA	C	
28S/1214605	A39/C16	Screw, 2 BA	C	
28S/1214610	A39/C36	Screw, 2 BA	C	
28S/9440345	A40/B8	Screw, 4 BA	C	
28S/1212706	A40/B12	Screw, 4 BA	C	
28S/1212707	A40/B14	Screw, 4 BA	C	
28S/1212709	A40/B20	Screw, 4 BA	C	
28S/1212710	A40/B24	Screw, 4 BA	C	
28S/1212718	A40/C20	Screw, 2 BA	C	

**EQUIPMENT AIRCRAFT
PRESSURE CABIN EQUIPMENT**

Ref. No.	Part No.	Description						No. off	Matl. Spec.	Cl. of Equip.		Plate No.
		1	2	3	4	5	6			M.R.	L.M.	
28S/9148119	A43/A10	Screw, 6 BA			C	
28S/1213081	A44/A6	Screw, 6 BA			C	
28S/9505800	A44/A16	Screw, 6 BA			C	
28S/1214164	A44/B14	Screw, 4 BA			C	
28S/9474082	A44/B16	Screw, 4 BA			C	
28S/1214165	A44/B18	Screw, 4 BA			C	
28S/1013430	A44/B20	Screw, 4 BA			C	
28S/1017078	A44/B24	Screw, 4 BA			C	
28S/1214166	A44/B28	Screw, 4 BA			C	
28S/1214173	A44/C24	Screw, 2 BA			C	
28S/1214177	A44/C40	Screw, 2 BA			C	
28S/1008070	A55/A4	Screw, grub			C	
28W/1206041	AGS.2035/B	Washer			C	
28W/1006946	AGS.2035/C	Washer			C	
28W/9137412	AGS.2037/A	Washer			C	
28W/1200328	AGS.2037/B	Washer			C	
28W/9457027	AGS.2037/C	Washer			C	
28W/9419454	SP.10/C	Washer			C	
28W/9419464	SP.13/A	Washer			C	
28W/9419465	SP.13/B	Washer			C	
28W/9419402	SP.13/C	Washer			C	
28W/9418921	SP.13/E	Washer			C	
28W/9419403	SP.13/G	Washer			C	
28W/9419466	SP.13/J	Washer			C	
28W/9419473	SP.15/A	Washer			C	
28W/9419474	SP.15/B	Washer			C	
28W/9419475	SP.15/C	Washer			C	
28W/9419405	SP.15/E	Washer			C	
28W/9419476	SP.15/G	Washer			C	
28W/9419486	SP.16/B	Washer			C	
28W/9419404	SP.16/C	Washer			C	
28W/9419487	SP.16/E	Washer			C	
28W/9419447	SP.41/C	Washer			C	
28W/9416642	SP.47/B	Washer			C	
28W/9416643	SP.47/C	Washer			C	

Ref. No.	Part No.							No. off	Matl. Spec.	Cl. of Equip.	Plate No.
		1	2	3	4	5	6			M.R. L.M.	





This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

