

**TANKS**  
**JETTISON WING FUEL TANK, PORT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.	Plate No.
					M.R. L.M.	
12867	E.A3.00.505	<b>JETTISONABLE WING FUEL TANK INSTALLATION, 250 GALLON (LESS DETONATORS, GROUP), PORT, WITHOUT VORTEX GENERATORS (PRE-MOD. 2395)</b> Consisting of:—	1	—	A	
	E.A1.00.81	<b>ATTACHMENT DETAILS, DROP TANK TO WING</b> Consisting of:—	—	—	—	
1577	E.A1.20.2031	<b>BOLT, explosive</b> ... ..	3	DTD.683	C	
	E.A1.81.317	<b>DETONATOR, FORWARD EXPLOSIVE BOLT, GROUP</b> Consisting of:—	1	—	—	
12G/1279	E.A3.81.353	<b>DETONATOR</b> ... ..	1	—	C	
1578	E.A1.81.939	<b>PLUG, detonator</b> ... ..	1	—	C	
5K/9107065		<b>SLEEVE</b> ... ..	2	—	C	
5K/9107067		<b>SLEEVE</b> ... ..	1	—	C	
1579	E.A1.81.938	<b>SPRING</b> ... ..	1	—	C	
5X/9450396	HC.490	<b>TAG, terminal, quick release</b> ... ..	2	—	C	
1580	E.A1.81.428	<b>Tube, detonator</b> ... ..	1	—	C	
5F/2124		<b>TUBE, rubber</b> ... ..	QR	—	C	
	E.A1.81.318	<b>DETONATOR, REAR OUTBOARD EXPLOSIVE BOLT, GROUP</b> Spares for this group are identical with those for group Part No. E.A1.81.317	1	—	—	
	E.A1.81.599	<b>DETONATOR, REAR INBOARD EXPLOSIVE BOLT, GROUP</b> Spares for this group are identical with those for group Part No. E.A1.81.317	1	—	—	
28M/10335	AGS.2002/Q/1	<b>NUT, stiff</b> ... ..	3	—	C	
2134	E.A1.57.1239	<b>PIPE, air brake, c/w stop</b> ... ..	1	—	C	
2135	E.A1.57.1241	<b>PIPE, fuel break, c/w stop</b> ... ..	1	—	C	
1583	E.A1.20.10505	<b>WASHER, special, explosive bolt</b> ... ..	3	DTD.124	C	
1584	E.A1.20.8833	<b>WASHER, special, explosive bolt</b> ... ..	3	DTD.683	C	
	E.A3.62.175	<b>TANK, DROP (LESS ATTACHMENTS) GROUP</b> ... Spares for:—	1	—	A	
	OR					
14683	BRISTOL A/C 75-04.0001			Durestos Plastic	A	
5CZ/4300	E.A3.62.113	<b>BLOCK, contact, navigation light</b> ... ..	1	—	C	
20505	E.A3.62.151	<b>BODY, filler cap</b> ... .. Attaching parts for E.A3.62.151:—	1	—	C	
28D/1215515	AS.4563/1C	<b>Bolt, 2 BA</b> ... ..	18	—	C	
21607	E.A2.62.57	<b>Ring, nut</b> ... ..	1	—	C	
5250	E.A2.62.71	<b>Washer, sealing</b> ... ..	1	—	C	
12940	E.A3.62.191	<b>CAP, FILLER, C/W INWARD VENT VALVE, ASSEMBLY</b> Spares for:—	1	—	C	
13158	E.A3.62.197	<b>WASHER, sealing, vent valve head</b> ... ..	1	Hycatrol257	C	
5249	E.A2.62.143	<b>WASHER, sealing, filler cap, assembly</b> ... ..	1	—	C	

**TANKS**  
**JETTISON WING FUEL TANK, PORT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
	E.A2.62.73	<b>FUEL PIPE AND MOUNTING, ASSEMBLY</b> ...	—	—	—		
		Spares for:—					
2136	E.A2.62.227	<b>CLIP</b> , bottom, air pipe ...	1	—	C		
2137	E.A2.62.229	<b>CLIP</b> , bottom, fuel pipe ...	1	—	C		
28E/9429463	AGS.605/0	<b>CLIP</b> , top, air pipe ...	1	—	C		
28E/9129092	AGS.605/2	<b>CLIP</b> , top, fuel pipe ...	1	—	C		
	EEAS.77/84	<b>HOSE</b> , fuel break pipe, 1 $\frac{1}{4}$ " i/d. x 1 $\frac{5}{8}$ " o/d. x 3" long (Make from 32C/377)	1	DTD.625	LM		
	EEAS.77/32	<b>HOSE</b> , air break pipe, $\frac{1}{2}$ " i/d. x $\frac{3}{4}$ " o/d. x 2 $\frac{1}{4}$ " long (Make from 32C/408)	1	DTD.625	LM		
6381	E.A1.57.339	<b>PLUG</b> , wooden ...	1	—	C		
6382	E.A1.57.341	<b>PLUG</b> , wooden ...	1	—	C		
6158	E.A2.62.203	<b>RING</b> , joint ...	1	—	C		
6155	E.A2.62.79	<b>WASHER</b> , joint ...	1	—	C		
6156	E.A2.62.81	<b>WASHER</b> , joint ...	1	—	C		
3392	E.A3.62.77	<b>PANEL</b> , access, top skin ...	1	—	C		
		Attaching parts for E.A3.62.77:—					
28D/1007982	AS.1248/1C	Bolt, 2 BA ...	18	—	C		
21607	E.A2.62.57	Ring, nut ...	1	—	C		
5250	E.A2.62.71	Washer, sealing ...	1	—	C		
12922	E.A3.62.189	<b>SOCKET, EARTHING, GROUP</b> ...	1	—	C		
		Consisting of:—					
	E.A3.62.181	<b>CAP</b> , sealing ...	1	DTD.683	—		
	E.A3.62.177	<b>SOCKET</b> , earth plug ...	1	DTD.683	—		
	E.A3.62.183	<b>SPRING</b> ...	1	DTD.683	—		
	BRISTOL A/C						
34543	75.04.0341	<b>SOCKET</b> , insulating (Bristol tank only) ...	2	—	C		
	E.A3.62.115	<b>STRIP</b> , sealing, 72" long (Make from Ref. 4432) ...	1	—	LM		
5511	E.A1.20.10897	<b>VALVE, DRAIN, GROUP</b> ...	1	—	B		
		Spares for:—					
	E.A1.20.10901	<b>PLUG, DRAIN, GROUP</b> ...	1	—	—		
		Spares for:—					
	E.A1.20.10903	<b>PLUG</b> , housing ...	1	L.40	—		
5512	E.A1.20.10907	<b>PLUG</b> , $\frac{3}{4}$ " BSP ...	1	L.40	C		
12335	E.A1.20.10905	<b>RING</b> , hycatrol ...	1	Grade HE/4	C		
3458	E.A1.20.2903	<b>WASHER</b> , sealing ...	4	Neo-K-Tex	C		
12904	E.A3.62.117	<b>WASHER</b> , special ...	50	Petrolite	C		
12923	E.A3.62.185	<b>WASHER</b> , sealing, earthing socket ...	1	Neo-K-Tex	C		
6154	E.A2.62.61	<b>WASHER</b> , sealing, inner bolt housing ...	3	—	C		
6153	E.A2.62.59	<b>WASHER</b> , sealing, forward bolt housing ...	3	—	C		
	BRISTOL A/C						
34525	75.04.0386	<b>WASHER</b> , distance (Bristol tank only) ...	3	—	C		
34576	75.04.0387	<b>WASHER</b> , distance (Bristol tank only) ...	6	—	C		

**TANKS**  
**JETTISON WING FUEL TANK, PORT**

Ref. No.	Part No.	Description	No. off	Matl. Spec.	Cl. of Equip.		Plate No.
					M.R.	L.M.	
		1 2 3 4 5 6					
14717	E.B6.00.347	<b>JETTISONABLE WING FUEL TANK, INSTALLATION, 250 GALLON, WITH VORTEX GENERATORS (LESS DETONATORS) PORT (MOD. 2395)</b> Spares for this group are identical with those for group Part No. E.A3.00.505 on page 775, except for the following deletions and additions Delete:—	1	—		A	
14683	E.A3.62.175 OR BRISTOL A/C 75-04.0001	<b>TANK, DROP (LESS ATTACHMENTS), GROUP ...</b>  Add:—	1	—  Durestos Plastic		—  A	
14683	E.A3.62.217 OR BRISTOL A/C 75-04.0001	<b>TANK, DROP (LESS ATTACHMENTS), GROUP ...</b>	1	—  Durestos Plastic		—  A	



Pages 777<sup>9</sup> to 786 not issued


1947  
1948  
1949

CANBERRA B.(I) MK.8

Page 787

**TANKS**  
**JETTISON WING FUEL TANK, STARBOARD**

Ref. No.	Part No.						Description	No. off	Matl. Spec.	Cl. of St.	Plate No.
		1	2	3	4	5				M.R. L.M.	
12868	E.A3.00.506						<b>JETTISONABLE WING FUEL TANK INSTALLATION, 250 GAL. (LESS DETONATORS), STARBOARD, WITHOUT VORTEX GENERATORS (PRE MOD. 2395)</b> Consisting of:—	1	—	A	
	E.A1.00.82						<b>ATTACHMENT DETAILS, DROP TANK TO WINGS</b> Spares for this group are identical with those for group Pt. No. E.A1.00.81 on page 775	—	—	—	
	E.A3.62.176						<b>TANK, DROP (LESS ATTACHMENTS), GROUP</b> Spares for this group are identical with those for group Pt. No. E.A3.62.175 on page 776, except for the following deletion and addition Delete:—	1	—	—	
	E.A2.62.73						<b>FUEL PIPE AND MOUNTING, ASSEMBLY</b> Add:—	—	—	—	
	E.A2.62.74						<b>FUEL PIPE AND MOUNTING, ASSEMBLY</b> Spares for this assembly are identical with those for Pt. No. E.A2.62.73 on page 776	—	—	—	
14718	E.B6.00.348						<b>JETTISONABLE WING FUEL TANK INSTALLATION, 250 GALL., WITH VORTEX GENERATORS (LESS DETONATORS) STARBOARD (MOD. 2395)</b> Spares for this group are identical with those for group Pt. No. E.A3.00.506 except for the following deletion and addition Delete:—	1	—	A	
A49 14684	E.A3.62.176 <i>or</i> <i>bsistat ae/75-040-0002</i>						<b>TANK, DROP (LESS ATTACHMENTS), GROUP</b> Add:—	1	DURESTOR PLASTIC	A	
A49 14684	E.A3.62.218 <i>or</i> <i>bsistat ae/75-040-0002</i>						<b>TANK, DROP (LESS ATTACHMENTS), GROUP</b>	1	DURESTOR PLASTIC	A	





This file was downloaded from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms, and more aircraft documents.

