


SECTION 3

GENERATORS, D.C.12/28-VOLT

LIST OF CHAPTERS

Note: A list of contents appears at the beginning of each chapter.

- 1 Generators, Rotax, B2000 series (Cancelled: now AP 113B-0220-1)
- 2 Generator, Type HX2 (Cancelled: now AP 113B-0226-16)
- 3 Generator, Type KX (Cancelled: now obsolete)
- 4 Generator, Type LX (Cancelled: now obsolete)
- 5 Generators, Rotax, B1800 series (Cancelled: now AP 113B-0219-16)
- 6 Generator, Type O2 (Cancelled: now AP 113B-0216-1)
- 7 Generator, Type P2 (Cancelled: now obsolete)
- 8 Generator, Type P3 (Cancelled: now AP 113B-0217-1) ✓
- 9
- 10 Generator, Rotax, B2100 series (Cancelled: now AP 113B-0212-13A6) ✓
- 11 Generator, Eclipse-Pioneer, Type 30E16-11-C (Cancelled: now AP 113B-0225-1)
- 12
- 13 Generator, E.E.Type AE2515 (Cancelled)
- 14 Generator, Type 507 (Cancelled: now obsolete)
- 15 Generator, Type 512 series (Cancelled: now obsolete)
- 16 Generators, Rotax, B2700 series (Cancelled: now AP 113B-0222-1)
- 17 Generator, Type 505 (Cancelled: now obsolete)
- ▶ 18 Bleed air turbine generator, Rotax, Type BTO102 (incorporating generator, Rotax Type B3601/1) (cancelled: now AP 113B-0204-1) ◀
- 19 Generator, Rotax B3000 series (Cancelled: now obsolete)
- ▶ 20 Generator, Type 514 (E.E. Type AE2505) (cancelled: now AP 113B-0228-1) ◀
- 21 Generators, Type 519 series (Cancelled: now AP 113B-0210-16) ✓
- 22 Generator, Rotax, Type B4101 (Cancelled: now AP 113B-0215-13A6)
- 23 Generator, Delco Remy, Type 11 7086 (Cancelled: now AP 113B-0207-16)
- 24
- 25
- 26 Generator, Rotax, Type B2901 (Cancelled)
- 27 Generators, Rotax, B3500 series (Cancelled: now AP 113B-0202-16 (B3503, B3508) AP 113B-0206-16 (B3501)
- 28 Generator, E.E. Type AE2511 (Cancelled: now AP 113B-0208-1)
- 29 Generator, Type 523 (E.E. Type AE2506) (Cancelled: now obsolete)
- 30 Generator, E.E. Type AE2512 (Cancelled)
- 31 Generator, Type 527A (E.E. Type AE2505 Style 3) (Cancelled: now AP 113B-0203-16)




SECTION 3

GENERATORS, D.C.12/28-VOLT

CLASSIFIED LIST OF CHAPTERS

Type	A.M. types	Chap.	App.	Rotax types	Chap.	App.
	HX2	2	-	B2117 (515A)	10	3
	KX	3	-	B2121 (510LA)	10	4
	LX	4	-	B2122 (515LA)	10	5
	O2	6	-	B2125 (524)	10	6
	P2	7	-	B2127	10	7
	P3	8	-	B2131	10	8
	500 (Rotax B1804)	5	1	B2132	10	9
	501 (Rotax B2104)	10	1	B2134	10	10
	501LA (Rotax B2121)	10	4	B2701/1 (517)	16	1
	504 (Rotax B1815)	5	2	B2702/1 (517)	16	2
	505	17	-	B2704	16	3
	507	14	-	B2706	16	4
	512 (EE AE164)	15	1	B2708	16	5
	512A	15	2	B2901	26	-
	514 (EE AE2505)	20	-	B3001/1 (522)	19	1
	515 (Rotax B2108)	10	2	B3002/1	19	2
	515A (Rotax B2177)	10	3	B3501	27	1
	515LA (Rotax B2122)	10	5	B3502	27	2
	517 (Rotax B2701/1)	16	1	B3503	27	3
	517 (Rotax B2702/1)	16	2	B3505	27	4
	519 (EE AE2507)	21	1	B3507	27	5
	519A (EE AE2509)	21	2	B3508	27	6
	520 (Rotax B1825)	5	3	B3601/1	18	-
	522 (Rotax B3001/1)	19	1	B4101	22	-
	523 (EE AE2506)	29	-	BT0102	18	-
	524 (Rotax B2125)	10	6			
	527A (EE AE2505)	31	-			
				Eng. Elec. Types		
				Type AE164 (512)	15	1
				AE2505 (514)	20	-
				AE2506 (523)	29	-
				AE2507 (519)	21	1
				AE2509 (519A)	21	2
				AE2512	30	-
				AE2515	13	-
				AE2505 (527A)	31	-
				Miscellaneous Types		
				Eclipse-Pioneer		
				Type 30E16-11-C	11	-
Type	Rotax types					
	B1804 (500)	5	1			
	B1815 (504)	5	2			
	B1825 (520)	5	3			
	B2001/2F	1	1			
	B2003/IF	1	2			
	B2005	1	3			
	B2104 (501)	10	1			
	B2108 (515)	10	2			



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

