

NOTE TO READERS

The subject matter of this publication may be affected by Admiralty Fleet Orders, Army Council Instructions, or Air Ministry Orders, or by Servicing schedules (Volume 4 and 5), or "General Orders and Modifications" leaflets in this A.P., in the associated publications listed below, or even in some others. If possible, Amendment Lists are issued to correct this publication accordingly, but it is not always practicable to do so. When an Order, Instruction, Servicing schedule, or leaflet contradicts any portion of this publication, the Order, Instruction, Servicing schedule, or leaflet is to be taken as the overriding authority.

The inclusion of references to items of equipment does not constitute authority for demanding the items.

Each leaf, except the original issue of preliminaries, bears the date of issue and the number of the Amendment List with which it was issued. When this Volume is amended by the insertion of new or replacement leaves in an existing chapter, the new or amended technical information will be indicated by triangles, positioned in the text thus: \leftarrow \rightarrow to show the extent of amended text, and thus: \rightarrow \leftarrow to show where text has been deleted. When a Section or Chapter is issued in a completely revised form, the triangles will not appear.

THE A.P.4343 SERIES		A.P.
<i>Electrical manual — General</i>		4343
<i>Electrical manual — Generators and batteries (Airborne)</i>		4343A
<i>Electrical manual — Control and distribution equipment (Airborne)</i>		4343B, Books 1, 2 and 3
<i>Electrical manual — Switches, cables, wiring and accessories (Airborne)</i>		4343C, Books 1, 2, 3 and 4
<i>Electrical manual — Rotary consumer equipment (Airborne)</i>		4343D, Books 1, 2, 3, 4 and 5
<i>Electrical manual — Static consumer equipment (Airborne)</i>		4343E, Books 1, 2, 3 and 4
<i>Electrical manual — Equipment in foreign aircraft used by the R.N. and R.A.F.</i>		4343F
<i>Electrical manual — Ground equipment</i>		4343G
<i>Electrical manual — Abbreviations, symbols and equipment wiring diagrams</i>		4343H
<i>Electrical manual — Airborne and ground power indicators, testmeters, testers and precision indicating instruments</i>		4343J
<i>Electrical manual — Jet-pipe temperature, throttle control and associated servicing equipment</i>		4343K
<i>Electrical manual — MT. and marine craft equipment</i>		4343M
<i>Data Book of electrical servicing equipment</i>		4343Q
<i>Electrical manual — Servicing equipment</i>		4343S, Books 1, 2, 3 and 4
<i>Electrical manual — Special to aircraft type servicing equipment</i>		4343V, Books 1 and 2
<i>Electrical manual — Armament consumer equipment (Airborne)</i>		4343X, Books 1 and 2

RESTRICTED

This file was downloaded
from the RTFM Library:

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

