

**SECTION 4**

**SWITCHES (RELAY, SOLENOID AND  
AUTOMATIC), 112-VOLT**

**RESTRICTED**

## SECTION 4

## SWITCHES (RELAY, SOLENOID AND AUTOMATIC), 112-VOLT

## LIST OF CHAPTERS

*Note.*—A list of contents appears at the beginning of each chapter.

Switch:—

- 1 Torque, Type B
- 2 Magnetic, Type 3A, No. 1 (Rotax F3104)
- 3 Magnetic, Type 2A, No. 2 (Rotax F3109)
- 4 Magnetic, Type 3A, No. 2 (Rotax F3113)
- 5 Magnetic, Type 13A, No. 1 (Rotax D6103)
- 6 Magnetic, Type 4A, No. 1 (Rotax D6104)
- 7 Magnetic, Type 10A, No. 1 (Rotax D8202)
- 8 Magnetic, Type 5A, No. 1 (Rotax D8701)
- 9 Magnetic, Type 8A, No. 4 (Rotax D8901)
- 10 Magnetic, Type 6A, No. 1 (Rotax D9001)
- 11 Magnetic, Rotax D9021
- 12 Magnetic, Type 1A, No. 1 (Rotax D8601 and D8601/1)
- 13 Magnetic, Type 1A, No. 2 (Rotax D8611)
- 14 Magnetic, Type 6A, No. 5 (Rotax D9011/2)
- 15 Magnetic, Type 8A, No. 1 (Rotax D8801)
- 16 Magnetic, Type 9A, No. 1 (Rotax D9101)
- 17 Magnetic, Type 9A, No. 4 (Rotax D9104)
- 18 Magnetic, Type 14A, No. 1 (Rotax D9201)
- 19 Magnetic, Type 7A, No. 1 (Rotax D9301)
- 20 Magnetic, Type 7A, No. 6 (Rotax D9311)
- 21 Magnetic, Type 7A, No. 5 (Rotax D9321)
- 22 Magnetic, Type 15A, No. 1 (Rotax D9401)
- 23 Magnetic, Type 15A, No. 3 (Rotax D9411)
- 24 Magnetic, Type 11A, No. 1 (Rotax D9501)
- 25 Magnetic, Type 16A, No. 1 (Rotax D9601)

(continued overleaf)  
(A.L.103, Apr. 57)

RESTRICTED

- 26 Magnetic, Type 16A, No. 2 (Rotax D9611)
- 27 Magnetic, Type 27A (Rotax DI0202)
- 28 Magnetic, Type 14A, No. 2 (Rotax D9211)
- 29 Magnetic, Type 2A, No. 3 (Rotax F3115)
- 30 Magnetic, Type 3A, No. 3 (Rotax F3116)
- 31 Magnetic, Type 14A, No. 3 (Rotax D9241/1)
- 32 Magnetic, Type 11A, No. 2 (Rotax D9502/2)
- 33 Magnetic, Type 5Y (Rotax D6301)
- 34 Magnetic, Rotax D6704/2
- 35 Magnetic, Rotax D11401
- 36 Magnetic, Rotax D11601
- 37 Thermal, Rotax, Type D6208/1
- 38 Sequence timer, Rotax DI0702
- 39 Thermal, Type 2A, No. 4 (Rotax D6269)
- 40 Thermal, Type 2A, No. 1 (Rotax D6209)
- 41 Thermal, Type 2A, No. 2 (Rotax D6216)
- 42 Thermal, Type 1A, No. 2 (Rotax D8513)
- 43 Relay, B.T.H. Type LAA.10-A4
- 44 Magnetic, Type 20A (B.T.H. LDA.50-A1/4)
- 45 Contactor, B.T.H., Type LDA 150-A1
- 46 Time, Teddington, Type FHM/A/39
- 47 Magnetic, Type 31A
- 48 Contactor, B.T.H., Type LDA 250-A3/1
- 49 Magnetic, Type 2Y (Rotax D6801/3)
- 50 Magnetic, Type 4Y (Rotax D6812/2)
- 51 Contactor, B.T.H., Type LDA 25-A1/4
- 52 Sensitive warning unit, Elliott, Type 3C/183
- 53 Magnetic, Rotax D6703/2
- 54 Magnetic, Rotax D9422

**RESTRICTED**

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.



**TELEBRIEF  
CONNECTIONS**

**E**