

SECTION 18

INDICATORS AND WARNING DEVICES

12/28 VOLT SYSTEMS

LIST OF CHAPTERS

Note ...

A list of contents appears at the beginning of each chapter.

- 1 Warning bell, Gent, Type 396
- 2 Warning lamps, Page Eng, series (Cancelled: now AP 113F-0627-13A)
- 3 Indicator lamp, Rotax, Type H4201
- 4 Undercarriage indicators, Dowty 1224Y Series, (Cancelled: now AP 113F-0607-1)
- ◀ 5 Intercommunication lamps for drogue control (Cancelled: obsolete) ▶
- 6 Intercommunication lamps
- 7 Warning lamps with push switch combined, Rotax H4300 series
- 8 Electric horn, Type C (Rotax V0214) (Cancelled: now AP 113F-0604-1)
- 9 Warning lamps, Rotax H3200 series
- 10 Warning lamps, Smiths, Type CFP
- 11 Warning lamps, Rotax, H2700, H2800, and H3600 series (Cancelled: now AP 113F-0235-1)
- ◀ 12 Warning lamps, Rotax, H3400 series (Cancelled: obsolete) ▶
- 13 Warning lamps, Rotax H3500 series
- 14 Cockpit warning lamp, Rotax, Type H4401
- 15 Audio warning unit, STC, Type A1205 (Cancelled: now AP 113F-0629-16)
- 16 Fuelling indicators, Flight Refuelling, Mk.6 (Cancelled: now AP 106D-4701-1)
- 17 Fuelling indicators, Flight Refuelling, Mk.7 (Cancelled: now AP 106D-4701-1)
- 18 Indicator, electro-magnetic, two-position, Dowty, Type 516Y (Cancelled: now AP 113F-0615-1)
- 19 Indicator, electro-magnetic, three-position, Dowty, Type 5175Y (Cancelled: now AP 113F-0614-1)
- 20
- 21
- 22 Warning lamps, Smiths, Type V520-524 and V531-535
- 23 Indicator, electro-magnetic, Plessey, three-position, rectangular type
- 24 Indicators, electro-magnetic, Plessey, circular drum and eyeball types (Cancelled: now AP 113F-0610-1)


25 Indicator unit, Page Eng, Type C254 (Cancelled: obsolete)
26 Indicator unit, Page Eng, Type C480 (Cancelled: obsolete)
27 Indicator unit, Page Eng, Type C620 (Cancelled: obsolete)
28 Warning lamps, Rotax H4500, H4600 and H4700 series
29 Indicator unit, Page Eng, Type C640
30 Indicator unit, Page Eng, Type C1201 (Cancelled: obsolete)
31 Indicator unit, Page Eng, Type C1300 (Cancelled: obsolete)
32 Indicator unit, Page Eng, Type C685 (Cancelled: obsolete)
33 Audio warning and flasher unit, Type A, Mk.2 (Cancelled:
now AP 113F-0648-1)
34 Indicator unit, Page Eng, Type C1970 (Cancelled: obsolete)
35 Indicator unit, Page Eng, Type C2180 (Cancelled: now AP 113F-0643-1)
36 Indicator units, Page Eng, Types C2920, C5880 and C5890
(Cancelled: now AP 113F-0659-16)
37 Warning lamp, Phoenix, Type 80116
38 Warning lamps, Thorn miniature type
39 Warning lamps, Thorn press-to-test type
40 Buzzer, Klaxon, Type BB-S24A
41 Buzzer, Klaxon, Type OB-S98
42 Multiple indicator, Thorn Type 80/10/0281
43 Indicator unit, Page Eng, Type C3700 (Cancelled: obsolete)
44 Indicator, electro-magnetic, two-position, Dowty, Type
1047Z (Cancelled: now AP 113F-0615-1)
45 Thorn, passenger notice signs
46 Indicator unit, Page Eng, Types C2760 and C5830 (Cancelled: now AP 113F-
0657-16)
47 Indicator unit, Page Eng, Type C2800 and C5100 (Cancelled: obsolete)
48 Indicator unit, Page Eng, Type C2940 (Cancelled: now AP 113F-0657-16)
49 Indicator unit, Page Eng, Type C3420 (Cancelled: obsolete)
50 Lamp indicator, press-to-test, Dowty, 7647Y series
51 Indicator, U/C, Dowty 1050Z (Cancelled: now AP 113F-0602-1)
52 Indicator unit, Page Eng, Type C6040 (Cancelled: now
AP 113F-0660-13A6)
53 Indicator unit, Page Eng, Type C4120 (Cancelled: now
AP 113F-0632-13A6)
54 Indicator unit, Page Eng, Type C3600 (Cancelled: now
AP 113F-0652-1)
55 Amplifier and relay unit, Type A, Mk.1 (Cancelled: now
AP 113F-0648-1)
56 Lamp, cabin warning, Type FM3043
57 Flight refuelling indicator, Page C5570
58 Warning horn, Klaxon, Type K2 (Cancelled: now AP 113F-
0639-1)
59 Lamp, cabin warning Type V6800
60 Indicator unit, Page Eng Type D6600 (Cancelled: now
AP 113F-0632-13A6)

RESTRICTED

AP 4343E, Vol.1, Book 4, Sect.18
AL 249, Nov.73

◀ 61 Indicator unit, Page Eng Type D7020 (Cancelled: obsolete)▶
62 Low voltage detector unit Mk.1, YEU-10-1 (Cancelled:
now AP 113F-0662-1)

RESTRICTED




SECTION 18

INDICATORS AND WARNING DEVICES

CLASSIFIED LIST OF CHAPTERS

<i>Dowty types</i>		<i>Chap.</i>	<i>Plessey types</i>		<i>Chap.</i>	<i>App.</i>
Type 1224Y, Mk. 5 (Type D)		4	Type 7CZ74109		24	1
	8 (Type D1)	4	7CZ84578		24	1
	12	4	7CZ97135		23	-
	15	4	7CZ97636		23	-
1245Z		18	7CZ106565		24	1
5165Y		18	7CZ107626		24	1
5175Y		19	7CZ143684		24	1
7647Y		50				
1047Z		44				
1050Z		51				
			<i>Rotax types</i>			
			Type H2700 series		11	
			H2800 series		11	
			H3200 series		9	
			H3400 series		12	
			H3500 series		13	
			H3600 series		11	
			H4201		3	
			H4300 series		7	
			H4401		14	
			H4500 series		28	
			H4600 series		28	
			H4700 series		28	
			V0214 (Type C)		8	
			<i>Thorn types</i>			
			Miniature		38	
			Multiple 80/10/0281		42	
			Press-to-test		39	
			Passenger notice signs		45	
			<i>Smiths types</i>			
			Type CFP		10	
			V520 to V524		22	
			V531 to V535		22	
			<i>Miscellaneous Types</i>			
Flight refuelling, Mk. 6		16	S.T.C., Type A1205		15	
" " " " " 7		17	Audio and flasher unit, Type A,			
Gent, Type 396		1	Mk. 2		33	
Intercomm. lamps		6	Amplifier and relay unit, Type A,			
" " (drogue control)		5	Mk. 1		55	
Klaxon, BB-S24A		40	Lamp, cabin warning, Type			
OB-S98		41	FM3043		56	
Warning horn, Klaxon Type K2		58	Low voltage detector unit, Mk. 1,			
Phoenix, Type 80116		37	YEU-10-1		62	

RESTRICTED



This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

