

# CONTENTS

## Leading particulars

### Introduction

Section 1—Controls and exits	... ..	Chapter 1—Pilot's controls and equipment 2—Not applicable 3—Emergency controls, equipment and exit
Section 2—Ground handling and preparation for flight	... ..	Chapter 1—Ground handling 2—Preparation for flight 3—Loading and C.G. data 4—General servicing
Section 3—Airframe	... ..	Chapter 1—Fuselage 2—Main planes 3—Tail unit 4—Flying controls 5—Landing gear 6—Hydraulic system 7—Not applicable 8—Air conditioning system 9—De-icing system 10—Oxygen system 11—Emergency system 12—Not applicable 13—Anti-'G' system
Section 4—Power unit installation	... ..	Chapter 1—Power unit 2—Fuel system 3—Not applicable 4—Not applicable 5—Fire protection system
Section 5—Electrical installation and instrument installation	... ..	Chapter 1—Electrical system 2—Instrument installation
Section 6—Radio installation	... ..	Chapter 1—Wireless installation 2—Radar installation
Section 7—Armament installation	... ..	Chapter 1—Pyrotechnics 2—R.P. equipment 3—Guns 4—Bombing equipment

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

