

EQUIPMENT AIRCRAFT—INSTRUMENTS PANEL

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Score	Plate No.
			1	2	3	4	5			
	C.187696	INSTRUMENT PANELS, ASSEMBLY (Pre Mod. 691)	—	—	—	—	—			
	C.226206	INSTRUMENT PANELS, ASSEMBLY (Mod. 691) ...	—	—	—	—	—			
	C.229153	(Pre Mod. 715)	—	—	—	—	—			
6A/3451	—	INSTRUMENT PANELS, ASSEMBLY (Mod. 715) ...	—	—	—	—	—			
	F.215196	Accelerometer, Mk. 2 (Mod. 268) ...	1	—	—	—	—	A.		
5381	DTD.487/11C	Angle, support for accelerometer (Mod. 465) ...	1	L.72	—	—	—	C.		
8428	A.188487	Bolt, at top light screen lug ...	1	—	—	—	—	C.	FC.1	
8235	A.212857	Bracket, mounting for stand-by compass ...	1	DTD.610	—	—	—	C.	FC.1	
6354	F.208961	Bracket, for R.P. selector panel (Mod. 229) ...	1	L.72	—	—	—	MR/C		
6B/2174	—	Clip, half, for accelerometer (Mod. 268) ...	2	L.72	—	—	—	C.		
	—	Compass, "Stand-by," type E2 ...	1	—	—	—	—	A.		
	D.187863	MOUNTING, PANEL, ASSEMBLY ...	—	—	—	—	—			
5384	DTD.487/13E	Bolt, for "Lord" mountings ...	4	DTD.487	—	—	—	C.		
5372	A.203163	Bracket, top centre panel mounting ...	2	—	—	—	—	C.	FC.1	
5373	A.203162	Bracket, bottom centre panel mounting ...	2	—	—	—	—	C.	FC.1	
	F.203235	Clip, for cross tube ...	2	S.3	—	—	—	C.	FC.1	
3866	Andre B134/AD/4	Block, mounting ...	6	—	—	—	—	C.	FC.1	
27H/3219	—	Mounting (non-magnetic) ...	4	—	—	—	—	B.		
6313	F.211792	Mounting, A.V. (Alternative to 27H/3248) (Mod. 379)	4	—	—	—	—	B.		
27H/3248	—	Mounting, "Lord" (Alternative to F.211792) (Mod. 379)	4	—	—	—	—	B.		
1542	F.187614	Plate, support ...	2	DTD.610	—	—	—	C.	FC.1	
1543	F.187864	Strut, support, port ...	1	T.4	—	—	—	C.	FC.1	
3867	F.195815	Strut, support, starboard ...	1	T.4	—	—	—	C.	FC.1	
	A.203240	Tube, cross ...	1	L.72	—	—	—	C.	FC.1	
3797	Std.1509/24/080	Tube, distance, $\frac{3}{8}$ " o/d x 17 S.W.G. x .80" long (Make from 30B/557)	2	T.4	—	—	—	MR/C	4	
3798	Std.1509/24/034	Tube, distance, $\frac{3}{8}$ " x 17 S.W.G. x .34" long (Make from 30B/559)	4	T.4	—	—	—	MR/C	4	
2724	F.185592	Washer ...	2	DTD.364	—	—	—	MR/C	FC.1	
3868	F.168524	Washer, at "Lord" mounting ...	12	DTD.610	—	—	—	C.	FC.1	
	F.215200	Packing, strip, for accelerometer mounting (Mod. 465)	QR	L.72	—	—	—			
	D.187691	PANEL, CENTRE, ASSEMBLY (Pre Mod. 691) ...	—	—	—	—	—			
	D.226204	PANEL, CENTRE, ASSEMBLY (Mod. 691) ...	—	—	—	—	—			
6A/5040	—	Altimeter, Mk. 19B ...	1	—	—	—	—	A.		
	B.215803	Bracket, for push button switches (Mod. 502) ...	1	—	—	—	—	C.	FC.1	
5CW/5253	—	Cap (sea-grey) (Mod. 452) ...	1	—	—	—	—	C.		
5CW/5252	—	Cap (sea-grey) ...	1	—	—	—	—	C.		
3735	Std.840/16	Clip, $\frac{1}{8}$ " wide x 22 S.W.G. (Make from 30B/1433)	2	DTD.610	—	—	—	MR/C	4	
3791	Std.840/19	Clip, $\frac{1}{8}$ " wide x 22 S.W.G. (Make from 30B/1433)	2	DTD.610	—	—	—	MR/C	4	
6A/2519	—	Connector, static and pressure ...	2	—	—	—	—	C.		
5CW/4222	—	Guard, switch (Mod. 488) ...	1	—	—	—	—	C.		
5CW/5074	—	Indicator, magnetic (Mod. 452) ...	1	—	—	—	—	A.		
6A/2966	—	Indicator, rate of climb, Mk. 3A (P) ...	1	—	—	—	—	A.		
or										
6A/2697	—	Indicator, turn and slip, Mk. 2A ...	1	—	—	—	—	A.		
6A/3953	—	Indicator, artificial horizon, Mk. 4 ...	1	—	—	—	—	A.		
6A/3063	—	Indicator, air speed, Mk. 12A ...	1	—	—	—	—	A.		
6A/3158	—	Indicator, D.M.E. (Mod. 691) ...	1	—	—	—	—	A.		
10AF/530	—	Indicator, tail plane position (Mod. 406) ...	1	—	—	—	—	A.		
6A/4741	Smiths 587.FL	Indicator, flap position ...	1	—	—	—	—	A.		
6A/3567	Smiths 473.FL	Indicator, flap position ...	1	—	—	—	—	A.		

EQUIPMENT AIRCRAFT—INSTRUMENTS PANEL

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5			
6A/3300	—	Machmeter, Mk. 3A						—	A.	
	D.217445	Panel (Mod. 502) (Pre Mod. 488)						—		FC.1
	D.221376	Panel (Mod. 488)						—		
3597	A.191177/1	Pipe, static, rate of climb indicator to A.S.I.						T.9	C.	
3598	A.191177/2	Pipe, static, A.S.I. to machmeter						T.9	C.	
3599	A.191177/3	Pipe, static, machmeter to altimeter						T.9	C.	
3601	A.191177/5	Pipe, pressure, A.S.I. to machmeter						T.9	C.	
8484	A.191177/10	Pipe, static, altimeter to static connector (Mod. 502)						T.9	C.	
8485	A.191177/11	Pipe, pressure, machmeter to pitôt connector (Mod. 502)						T.9	C.	
1178	Std.1606/44/B12	Screw, roundhead, 4 B.A.						Brass	C.	5
3840	Std.1606/44/B28	Screw, for D.M.E. Indicator (Mod. 691)						Brass	C.	5
3857	Std.1606/44/C24	Screw, roundhead, 2 B.A.						Brass	C.	5
9447	Std.1606/44/C28	Screw, roundhead, 2 B.A.						Brass	C.	5
4661	Std.1606/45/B12	Screw, countersunk, 4 B.A.						Brass	C.	5
4660	Std.1606/45/B14	Screw, countersunk, 4 B.A.						Brass	C.	5
1943	Std.1606/45/B16	Screw, countersunk, 4 B.A.						Brass	C.	5
3860	Std.1606/45/B20	Screw, countersunk, 4 B.A. (Pre Mod. 691)						Brass	C.	5
3861	Std.1606/45/B24	Screw, countersunk, 4 B.A.						Brass	C.	5
4114	Std.1606/45/B32	Screw, countersunk, 4 B.A.						Brass	C.	5
4115	Std.1606/45/C20	Screw, countersunk, 2 B.A.						Brass	C.	5
3863	Std.1606/45/C24	Screw, countersunk, 2 B.A.						Brass	C.	5
4116	Std.1606/45/C28	Screw, countersunk, 2 B.A.						Brass	C.	5
3865	Std.1606/45/C32	Screw, countersunk, 2 B.A.						Brass	C.	5
6B/2575	—	Shield, magnetic						—	A.	
5F/2281	Hellermann HV.3341	Strapping						—	C.	
5F/2282	Hellermann HV.3342	Stud						—	C.	
5CW/4861	—	Switch, S.P., 3-way						—	B.	
5CW/5056	—	Switch, push button (Mod. 502)						—	A.	
5CW/5823	—	Screw, S.P.C.O. (Mod. 488)						—	B.	
6A/2801	—	Tachometer, engine speed, Mk. 10A						—	A.	
6A/3577	—	Thermometer, exhaust gas (Mod. 303) (Pre Mod. 691)						—	A.	
6B/2035	—	Unit, gyro, type "A" (Alternative to 6B/563)						—	A.	
6B/563	—	Unit, gyro, type "B" (Alternative to 6B/2035)						—	A.	
4162	Std.915/B22	Washer, 4 B.A.						DTD.610	C.	4
	B.192073	PANEL, PORT, ASSEMBLY						—		
5CW/5253	—	Cap (sea-grey)						—	C.	
3951	Std.840/26	Clip, $\frac{3}{16}$" wide x 22 S.W.G. x 2-6" long						DTD.610	MR/C	4
3738	Std.840/29	Clip, $\frac{3}{16}$" wide x 22 S.W.G. x 2-9" long						DTD.610	MR/C	4
5CX/5000	Std.1512/28	Disc, hydraulic pressure warning lamp						—	C.	4
5L/X.951286	—	Filament, 28V. 3-5W						—	B.	
5L/X.951273	—	Filament, 28V. 3-5W						—	B.	
5CX/5164	—	Indicator, undercarriage position, type D.1						—	B.	
5CZ/5074	Dowty C.5165.Y Mk. 2	Indicator, magnetic, aileron and elevator						—	B.	
5CZ/5073	Dowty C.5165Y Mk. 1	Indicator, magnetic (Mod. 449)						—	B.	
5CX/4013	—	Lamp, undercarriage warning, Iris type						—	B.	
5CX/1553	—	Lamp, hydraulic pressure warning, type B						—	B.	
	A.217498	Panel, group (Mod. 452)						—		FC.1
	A.208107	Bracket, undercarriage position indicator						L.72		FC.1
	B.192562	Bracket, undercarriage control switch						S.3		FC.1
	F.217564	Collar						—		
	B.217444	Panel						DTD.610		

EQUIPMENT AIRCRAFT—INSTRUMENT PANELS

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
3837	Std.1606/44/B10	Screw, roundhead, 4 B.A.	2	Brass	C.	5
1637	Std.1606/44/B14	Screw, roundhead, 4 B.A.	2	Brass	C.	5
3839	Std.1606/44/B16	Screw, roundhead, 4 B.A.	2	Brass	C.	5
1720	Std.1606/44/B24	Screw, roundhead, 4 B.A.	5	Brass	C.	5
3859	Std.1606/45/B.10	Screw, countersunk, 4 B.A.	2	Brass	C.	5
4660	Std.1606/45/B14	Screw, countersunk, 4 B.A.	1	Brass	C.	5
5CW/5643	Dowty C.5182Y Mk. 2	Switch, undercarriage, push button	1	—	A.	
5CW/5119	Dowty C.1223Y Mk. 15	Switch, flap lever	1	—	A.	
5CW/4861	—	Switch, S.P., 3-way (Mod. 452)	1	—	B.	
5767	Std.1509/12/030	Tube, distance	1	T.4	MR/C	
	B.187695	PANEL, STARBOARD, ASSEMBLY (Pre Mod. 691)	—	—		
	B.226205	PANEL, STARBOARD, ASSEMBLY (Mod. 691) (Pre Mod. 715)	—	—		
	C.229152	PANEL, STARBOARD, ASSEMBLY (Mod. 715)	—	—		
6A/2709	—	Altimeter, cabin, Mk. 18	1	—	A.	
—	—	Cable, assembly (See Cable Chart)	—	—	—	
5CW/5252	—	Cap, Helvin, sea-grey (Mod. 715)	1	—	C.	
	F.226393	Cover, switch, safety (Mod. 715)	1	—		FC.1
5CX/5001	Std.1512/29	Disc, warning lamp	1	—	C.	4
5L/X.951273	—	Filament, 28V. 3-5W	2	—	B.	
5CZ/5073	Dowty C.5165Y Mk. 1	Indicator, D.M.E., magnetic (Pre Mod. 519)	1	—	B.	
10AF/530	—	Indicator, D.M.E. (Pre Mod. 691)	1	—	A.	
10Q/61	—	Indicator, heading	1	—	A.	
5CX/1069	—	Lamp, warning, type A (without night screen)	1	—	B.	
		(Mod. 519)				
5CX/1553	—	Lamp, warning, type B (with night screen)	1	—	B.	
1940	Std.1231/1	Lug, locking	1	—	C.	4
957	C.187694	Panel	1	DTD.610	B.	FC.1
5CW/4221	—	Switch, S.P. "ON-OFF" (spring return to centre "OFF") (Pre Mod. 715)	1	—	B.	
5CW/5829	—	Switch, S.P. 3-way (Mod. 715)	1	—	B.	
5CW/4184	—	Switch, S.P. "ON-OFF" (upright "OFF")	1	—	B.	
3858	Std.1606/45/B8	Screw, countersunk, 4 B.A.	4	Brass	C.	5
4661	Std.1606/45/B12	Screw, countersunk, 4 B.A.	1	Brass	C.	5
3860	Std.1606/45/B20	Screw, countersunk, 4 B.A.	4	Brass	C.	5
3861	Std.1606/45/B24	Screw, countersunk, 4 B.A.	4	Brass	C.	5
4179	Std.1606/44/B20	Screw, securing exhaust gas thermometer (Mod. 691)	4	Brass	C.	5
7970	Std.1606/44/B36	Screw, roundhead, 4 B.A. (Pre Mod. 691)	4	Brass	C.	5
5K/9107067	Hellermann P.3 Grey	Sleeve, P.V.C., .9" long (Pre Mod. 715)	2	1738	C.	
5K/9107067	Hellermann P.3 Grey	Sleeve, P.V.C., .9" long (Mod. 715)... ..	1	1738 Type B	C.	
6A/3577	—	Thermometer, exhaust gas (Mod. 691)	1	—	A.	
7152	Std.1509/12/036	Tube, distance, 1/4" o/d x 20 S.W.G. x .36" long (Make from 30B/619) (Pre Mod. 691)	4	T.4	MR/C	4
5CW/4347	—	Transfer, "OUT"	1	—	C.	
5CW/4345	—	Transfer, "BRIGHT"	1	—	C.	
5CW/4344	—	Transfer, "DIM"	1	—	C.	
5CW/4328	—	Transfer, "OFF" (Mod. 715)	1	—	C.	
8234	B.212856	Panel, R.P. selector (Mod. 229)	1	L.72	MR/C	
5246	Std.1606/44/A12	Screw, roundhead, 6 B.A. (Mod. 229)	4	Brass	C.	5
3837	Std.1606/44/B10	Screw, roundhead, 4 B.A. (Mod. 229)	2	Brass	C.	5
1178	Std.1606/44/B12	Screw, roundhead, 4 B.A. (Mod. 229)	4	Brass	C.	5
1637	Std.1606/44/B14	Screw, roundhead, 4 B.A. (Mod. 229)	4	Brass	C.	5
1720	Std.1606/44/B24	Screw, roundhead, 4 B.A. (Mod. 229)	3	Brass	C.	5
5D/1760	—	Switch (Mod. 229)	1	—	A.	
5CW/4179	—	Switch (Mod. 229)	1	—	B.	
5CW/540	—	Switch (Mod. 229)	1	—	B.	
921	Std.915/B12	Washer (Mod. 229)	2	DTD.610	C.	

EQUIPMENT AIRCRAFT—INSTRUMENT PANELS

Ref. No.	Part No.						Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5					

EQUIPMENT AIRCRAFT-INSTRUMENT PANELS

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
SUMMARY OF STOCK ITEMS										
28D/12528	A.25.1B	Bolt,	4	B.A.
28D/12515	A.25.10C	Bolt,	2	B.A.
28D/12674	A.25.9E	Bolt,	1/4"	B.S.F.
28D/12569	A.25.10E	Bolt,	1/4"	B.S.F.
28D/8300	AS.1242.1B	Bolt,	4	B.A.
28D/8301	AS.1242.2B	Bolt,	4	B.A.
5K/3355	AS.3360.B4B	Lead,	connecting	
5K/3404	AS.3360.B4E	Lead,	connecting	
28M/10287	AGS.2001/B1	Nut,	4	B.A.
28M/10280	AGS.2001/B3	Nut,	4	B.A.
28M/10288	AGS.2001/C1	Nut,	2	B.A.
28M/10290	AGS.2001/E1	Nut,	1/4"	B.S.F.
28M/10308	AGS.2002/A4	Nut,	6	B.A.
28M/10327	AGS.2002/B1	Nut,	4	B.A.
28M/10309	AGS.2002/B4	Nut,	4	B.A.
28M/10328	AGS.2002/C1	Nut,	2	B.A.
28M/10330	AGS.2002/E1	Nut,	1/4"	B.S.F.
28L/12931	A.27.ET	Nut,	1/4"	B.S.F.
28L/13734	A.54.B	Nut,	4	B.A.
28L/14534	A.54.C	Nut,	2	B.A.
28S/2875	A.32/B.24	Screw,	4	B.A.
28S/2868	A.32/C20	Screw,	2	B.A.
28V/13603	AGS.838/8	Union,	bush	
28V/5107	AGS.838/3	Union,	elbow	
28V/5108	AGS.838/4	Union,	nut	
28V/5104	AGS.838/1	Union,	straight	
28V/5105	AGS.838/2	Union,	tee	
28W/12496	SP.14E	Washer
28W/12306	SP.15.B	Washer
28W/12296	SP.15.C	Washer
28W/12296	SP.15.E	Washer
28W/12497	SP.16.A	Washer
28W/12731	SP.16.B	Washer
28W/12355	SP.16.C	Washer
28W/12297	SP.16.E	Washer
28W/3090	AGS.163D	Washer,	spring	

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

