

Chap 1 AIRFRAME
Card 1

REPLENISHMENTS
HUNTER F.6,T.7,T.7A,G.A.9 & F.R.10

A.P.4347F,G,J,K & R Vol 4/5
Pt 1 Bk 2 Sect 2 (1st Ed)

Item No	ITEM	OPERATION	OPERATOR
<u>Hydraulic Reservoir. (Pre Mod 589).</u>			
1.	<u>Preparation</u>		
1.1	Undercarriage.	Lower.	Airframe
1.2	Flaps.	Raise.	"
1.3	Air brake.	Close.	"
1.4	Aileron accumulator.	Replenish with air. (Pre Mod 690 1575 p.s.i.). (Post Mod 690 900 p.s.i.).	" "
1.5	Elevator accumulator.	Replenish with air. (1575 p.s.i.).	"

1.6	Brake accumulators.	Replenish with air. (750 p.s.i.).	Airframe
1.7	Hydraulic system.	Pressurize, using handpump. (2800 p.s.i.).	"
1.8	Reservoir filler cap.	Remove, slowly.	"
2.	<u>Replenishment</u>		
2.1	Reservoir.	Replenish, (Oil, OM-15) until fluid level reaches White background below sight glass.	"
2.2	Reservoir filler cap.	Refit.	"

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.



LIGHTNING MK. 1
COVER PITOT HEAD
EB2-88-511