

Chap 2 ARMAMENT  
Card 1  
A.L.17

REPLENISHMENTS  
HUNTER F.6,T.7,T.7A,G.A.9 & F.R.10

A.P.4347F,G,J,K & R Vol 4/5  
Pt 1 Bk 2 Sect 2 (1st Ed)

Item No	ITEM	OPERATION	OPERATOR
1.	<u>Initial Arming</u>		
1.1	Main armament safety break.	Ensure disconnected.	Armament
1.2	Armament selector switches.	Ensure set to 'SAFE' or 'OFF'.	"
1.3	Normal/Ripple switch.	Set to 'NORMAL'.	"
1.4	Ripple/Salvo/Pods switch.	Set to 'SALVO'.	"
1.5	R.P. selector switch.	Set to '2'.	"
1.6	Ballast pack.	Remove. (S.P.65).	"
1.7	Gun barrels.	Dry bore.	"
1.8	Gun firing circuit.	Test. (S.P.204).	Electrical

1.9	Safety Man.	(i) Detail duties. (ii) Post.	Armament
1.10	Armed gun pack.	Fit. (S.P.66).	"
1.11	'Loaded Armament' notice.	Display.	"
1.12	Safety Man.	Withdraw.	"
2.	<u>Re-arming</u>		
2.1	Main armament safety break.	Ensure disconnected.	"
2.2	Bomb master switch.	)	
2.3	R.P. master switch.	)	
2.4	Gun master switch.	)	
2.5	Pylon selector switches.	) Ensure set to 'OFF'.	"
2.6	Fuzing selector switches.	)	
2.7	Butt test switch.	)	
2.8	Bomb/R.P. switch.	)	
2.9	Normal/Ripple switch.	Set to 'NORMAL'.	"
2.10	Ripple/Salvo/Pods switch.	Set to 'SALVO'.	"

(Continued)

Chap 2 ARMAMENT  
Card 2  
A.L.17

REPLENISHMENTS  
HUNTER F.6,T.7,T.7A,G.A.9 & F.R.10

A.P.4347F,G,J,K & R Vol 4/5  
Pt 1 Bk 2 Sect 2 (1st Ed)

Item No	ITEM	OPERATION	OPERATOR
2.	<u>Re-arming</u> (Contd)		
2.11	R.P. selector switch.	Set to '2'.	Armament
2.12	Expended gun package.	Remove. (S.P.65).	"
2.13	Gun firing circuit.	Test. (S.P.204). If stoppages have occurred.	Electrical
2.14	Safety Man.	(i) Detail duties. (ii) Post.	Armament
2.15	Armed gun package.	Fit. (S.P.66).	"
2.16	'Loaded Armament' notice.	Display.	"
2.17	Safety Man.	Withdraw.	"

3.	<u>Disarming</u>		Armament
3.1	Armament safety break.	Disconnect.	Armament
3.2	Armament selector switches.	Ensure set to 'SAFE' or 'OFF'.	"
3.3	Normal/Ripple switch.	Set to 'NORMAL'.	"
3.4	Ripple/Salvo/Pods switch.	Set to 'SALVO'.	"
3.5	R.P. selector switch.	Set to '2'.	"
3.6	Gun package.	Remove. (S.P.65).	"
3.7	Empty case chutes.	Examine. (S.P.456).	"
3.8	Gun barrel.		"
	(a) Bore.	) (i) Clean.	
	(b) Breech face.	) (ii) Lubricate. (Oil, OEP-70).	
	(c) Interrupted thread.	(i) Clean.	
		(ii) Lubricate. (Grease, XG-278).	
3.9	Unarmed gun pack.	Fit. (S.P.66).	"

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

