

Chap 2 ARMAMENT  
Card 11  
A.L.9

REPLENISHMENTS  
HUNTER F.6,T.7,T.7A,G.A.9 & F.R.10

A.P.4347F,G,J,K & R Vol 4/5  
Pt 1 Bk 2 Sect 2 (1st Ed)

Item No	ITEM	OPERATION	OPERATOR
------------	------	-----------	----------

E.R.U. Pylon Installation

1. Initial Loading

1.1	Gun firing safety devices.	} Set to 'OFF'.	Armament
1.2	Bombs/R.P. switch.		
1.3	Securing plates.	Remove.	"
1.4	E.R.U. circuit.	Test. (S.P.208).	Electrical
1.5	E.R.U. circuit.	Carry out 'No Volts' test.	Armament
1.6	Fuel tank.	Load. (S.P.62).	"
1.7	Gun supply leads.	} Connect.	"
1.8	Pylon safety break.		

S.M. 15588 (9)

Continued overleaf

2. Servicing Between Sorties

- |     |                  |                   |          |
|-----|------------------|-------------------|----------|
| 2.1 | Pylon.           | Examine.          | Armament |
| 2.2 | Fuel tank.       | Ensure secure.    | "        |
| 3.  | <u>Unloading</u> |                   |          |
| 3.1 | Fuel tank.       | Remove. (S.P.59). | "        |
| 3.2 | Pylon.           | Examine.          | "        |

This file was downloaded  
from the RTFM Library.

Link: [www.scottbouch.com/rtfm](http://www.scottbouch.com/rtfm)

Please see site for usage terms,  
and more aircraft documents.

