

GROUP C

ENGINE SERVICES

LIST OF SERVICES

| | <u>Group.</u> |
|--|---------------|
| ENGINE STARTING AND CONTROL (CODE S AND SA) | C.1 |
| FIRE WARNING AND EXTINGUISHER (CODE FW AND FE) | C.2 |
| TANK PUMPS AND PRESSURE REFUELLING (CODE BP AND PR) | C.3 |
| ENGINE ANTI-ICING (CODE EA) | C.4 |
| FUEL FILTER DE-ICING (CODE EFD) | C.5 |

NOTE...

A list of contents appears at the beginning of each group.

Introduction

This group contains a description, including the method of operation of the electrical circuits provided for the engine services, together with routing and theoretical diagrams and the necessary servicing information required to maintain the equipment in an efficient condition. A general description of the electrical system as a whole will be found in Group A of this chapter, while detailed information on the standard components employed will be found in the appropriate Air Publications quoted in this group.

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

