

PART VII

ILLUSTRATIONS

KEY TO FIG. 1

1. Cockpit pressure warning test switch
2. Tailplane main motor circuit breaker
3. Flaps emergency air pressure gauge
4. Undercarriage emergency air pressure gauge
5. Cockpit temperature selector
6. Cockpit temperature control
7. Cockpit pressure master switch
8. Canopy locking visual inspection panel
9. Flood flow auto/manual switch
10. Red lamps dimmer switch
11. Press-to-transmit switch
12. Airbrakes control switch
13. Green Salad switch panel
14. Throttle damper
15. VHF sets selectors
16. VHF sets changeover switch
17. Telebriefing pushbutton and warning light
18. Undercarriage emergency selector
19. Target reject switch
20. Brakes accumulator pressure gauge
21. Radar presentation on/off switch
22. Hydraulic pressure warning light
23. Undercarriage selector pushbuttons
24. Flaps emergency control
25. Undercarriage position indicator
26. Flaps selector
27. Radar ranging magnetic indicator
28. Undercarriage warning light
29. Airbrake position magnetic indicator
30. Triple pressure gauge
31. Radar ranging on/off switch
32. GGS selector and dimmer controls
33. Tailplane standby motor switch
34. Rudder/aileron trim position indicators
35. Rudder/aileron trim control
36. HP pump isolating switch
37. HP pump isolating warning light
38. Top temperature control switch
39. HP cock control and relight button
40. LP cock control

KEY TO FIG. 2A


41. Oil pressure gauge
42. Rudder pedals adjusting control
43. Manual emergency selector pushbuttons
44. Flap position indicator


45. Elevator power on/off switch and aileron power magnetic indicator
46. Aileron power on/off switch and elevator power magnetic indicator
47. Tailplane incidence position indicator
48. Outboard stores jettison pushbutton
49. "Clear aircraft" switch bar
50. Inboard stores jettison pushbutton
51. Bombs/RP switch
52. Bomb fusing switch
53. Braking parachute control switch
54. Pupil's flight instruments and artificial horizon magnetic indicator lighting dimmer switch
55. Artificial horizon inverter changeover magnetic indicator
56. Pupil's flight instruments and oil pressure indicator lighting dimmer switch
57. R.p.m. indicator
58. Jet pipe temperature gauge
59. Centre panel, Green Salad indicator and port booster pump switch lighting dimmer switch
60. Centre panel, braking parachute switch and stbd. booster pump switch lighting dimmer switch
61. Oxygen contents gauge
62. Pupil's oxygen regulator
63. Autostabiliser switch
64. Starboard instrument panel lighting dimmer switch
65. Oxygen flow magnetic indicator
66. Elevator power magnetic indicator
67. Aileron power magnetic indicator
68. Flaps selector
69. Undercarriage selector pushbuttons
70. Instructor's PUPIL undercarriage selector pushbutton
71. Aileron manual override switch
72. Elevator manual override switch
73. Rudder pedals adjusting control
74. Bomb/RP pushbutton safety flap
75. Gun-firing safety flap
76. Tailplane incidence main motor control switch
77. Camera pushbutton
78. Generator failure warning lights
79. Ignition switch
80. Engine master switch
81. Pressure head heater switch
82. Camera master switch
83. Battery master switch
84. Starter pushbutton


KEY TO FIG. 2B

85. Cockpit pressure altimeter
86. Tailplane interconnection on/off switch
87. Target reject switch
88. Port booster-pump failure warning light
89. Emergency lamps switch
90. DME indicator
91. GGS on/off switch
92. Accelerometer
93. Canopy open/close control switch
94. Canopy locked indicator light
95. Fire warning light and extinguisher pushbutton

- 96. Port booster-pump on/off switch
- 97. Fire warning light filament test pushbutton
- 98. Port fuel transfer failure magnetic indicator
- 99. Port fuel contents gauge
- 100. Port outboard drop tank transfer indicator
- 101. Fuel low pressure warning light
- 102. Starboard fuel contents gauge
- 103. Starboard outboard drop tank transfer indicator
- 104. Starboard fuel transfer failure magnetic indicator
- 105. Starboard booster-pump on/off switch
- 106. Starboard booster-pump failure warning light
- 107. Camera aperture switch
- 108. Audio warning cut-off switch
- 109. Navigation lights on/off switch
- 110. Braking parachute switch
- 111. Green Salad indicator
- 112. DME control panel
- 113. Cockpit pressure warning light









KEY TO FIG. 3

- 114. GGS selector and dimmer controls
- 115. Anti-G system pressure gauge
- 116. Red lamps dimmer switch
- 117. Anti-G system test pushbutton
- 118. Intercomm. amplifier normal/emergency switch
- 119. Intercomm. amplifier on/off switch
- 120. Canopy locking visual inspection panel
- 121. Oxygen regulator
- 122. Butt test switch
- 123. Seat raising lever
- 124. Emergency oxygen control
- 125. Rudder/aileron trim control
- 126. Aileron trim locking guard
- 127. Rudder/aileron trim position indicators
- 128. Tailplane incidence main motor cut-out switch

KEY TO FIG. 4

- 129. Artificial horizon and oil pressure gauge inverter indicator
- 130. Mk. 4FT compass and miscellaneous instruments inverter indicator
- 131. Engine anti-icing indicator
- 132. Engine anti-icing control switch
- 133. E 2B compass lamp dimmer switch
- 134. E 2B compass lamp normal/emergency switch
- 135. Harness lean-forward release
- 136. Manual separation lever
- 137. Canopy jettison control
- 138. Anti-G system test pushbutton
- 139. Anti-G system on/off cock
- 140. Ejection seat safety pins stowage
- 141. No. 1 group inverters normal/standby switch
- 142. Airbrake test switch
- 143. Starter circuit breaker
- 144. No. 2 group inverters normal/standby switch
- 145. Emergency oxygen control
- 146. Intercomm. muting switch
- 147. Pedestal lamps on/off switch







This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.