

EQUIPMENT AIRCRAFT—FATIGUE METER—INSTALLATION

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5			
	D.239870	METER, FATIGUE, ASSEMBLY (Mod. 912) ...						—		
5CZ/430	—	Block, terminal, type B, 2-way ...						—	B.	
	F.215678	Bolt, special ...						S.96.B		
	F.215679	Bolt, special ...						S.96.B		
—	B.216903	Cable, FM.1, group (See Cable Chart) ...						—	—	
—	B.216904	Cable, F.M.2, group (See Cable Chart) ...						—	—	
—	F.216906	Bracket, fuseholder ...						L.72		
—	A.216905	Cable, F.M.3, group (See Cable Chart) ...						—	—	
7154	Std.840/55	Clip, securing cable ...						DTD.610	MR/C	4
6A/6487	R.A.E.	Meter, structure fatigue, Mk. 14 (Mod. 912) ...						—	A.	
	F.215681	Nut, special ...						S.62.B		
	F.215682	Piece, distance ...						L.65		
	A.215660	Plate, mounting ...						L.72		
1919	Std.1341/3	Stud, earthing point ...						—	C.	
	F.205530	Tube, retaining ...						S.62.B		
	F.215680	Tube, retaining ...						S.62.B		
3767	Std.915/B20	Washer ...						DTD.610	C.	4
4150	Std.915/C22	Washer ...						DTD.610	C.	4
4613	Std.1335/C/18	Washer ...						—	C.	
4659	Std.1335/C/22	Washer ...						—	C.	

EQUIPMENT AIRCRAFT-FATIGUE METER-INSTALLATION

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
SUMMARY OF STOCK ITEMS										
28D/1010658	A25.1.B	Bolt, 4 B.A.	—	—
28D/12533	A25.5.C	Bolt, 2 B.A.	—	—
28S/2810	A33.A.12	Bolt, 6 B.A.	—	—
28M/10326	AGS.2002.A1	Nut, 6 B.A.	—	—
28M/10327	AGS.2002.B1	Nut, 4 B.A.	—	—
28M/1006504	A27.B.T.	Nut, 2 B.A.	—	—
28M/1011467	A27.E.S.	Nut, 1/4" B.S.F.	—	—
28S/2822	A.33.A.20	Screw, 6 B.A.	—	—
28W/9419473	SP.15.A	Washer, 6 B.A....	—	—
28W/9419474	SP.15.B	Washer, 4 B.A....	—	—

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

