

Hunter T. Mk. 7
Issued with A/L No. 11

INSTALLATION
RADIO—U.H.F. INSTALLATION (S.O.O.)

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
		RADIO—U.H.F. INSTALLATION (Mod. 979)	...	—		
	E245500		...	—		
	E.255622	ADDITIONAL DETAILS	...	—		
	A.230814	Bracket, mounting	...	L.72		
	A.230815	Bracket, mounting	...	L.72		
	A.247612	Bracket, mounting	...	L.72		
	A.230887	Channel	...	L.72		
	Std.2045/17/24	Clip	...	—		
	RAE					
	EL.42887/1C	Connector	...	—		
9438	F.223835	Guard	...	L.72	C.	
	A.240910	Link, chain	...	—		
	F.236504	Lug, locking	...	S.3		
	F.233486	Plate, cover	...	L.72		
	A.235562	Plate, blanking	...	L.72		
	F.231975	Plate, blanking	...	L.72		
	F.234709	Plate, cover	...	L.72		
	F.233421	Plate, joint	...	L.72		
	F.233422	Plate, joint	...	L.72		
	B.230884	Plate, mounting	...	L.72		
	F.189234	Plate, stud	...	S.3		
3837	Std.1606/44/B10	Screw, round, 4 B.A.	...	Brass	C.	5
3839	Std.1606/44/B16	Screw, round head, 4 B.A.	...	Brass	C.	5
	Std.1606/44/B18	Screw, round head, 4 B.A.	...	Brass		5
	Std.1606/45/A16	Screw, countersunk, 6 B.A.	...	Brass		5
4660	Std.1606/45/B14	Screw, countersunk, 4 B.A.	...	Brass	C.	5
3860	Std.1606/45/B20	Screw, countersunk, 4 B.A.	...	Brass	C.	5
	A.233423	Stiffener	...	L.72		
5CW/6431	—	Switch	...	—	B.	
5CW/5767	—	Switch, dimmer, type "R"	...	—	B.	
10B/16920	—	Aerial, standby, type 11789	...	—	B.	
5985-99-932-6362	—	Aerial, Derveaux (Alternative to Ref. 5985-99-9911-8266)	...	—	A.	
5985-99-911-8266	—	Aerial (Alternative to Ref. 5985-99-932-6362)	...	—	A.	
10U/16596	—	Amplifier, type A.1961	...	—	A.	
5J/3458	Voltabloc 19.VO.7	Battery, standby	...	—	B.	
5CZ/430	—	Block, terminal, 2 way, T.B.74	...	—	B.	
10D/17805	—	Box, junction, type 154	...	—	A.	
5821-99-932-6361	—	Box, interconnecting	...	—	A.	
	D.252099	Box, radio supplies and relay group	...	—		
	F.234668	Angle, mounting	...	L.72		
	F.234669	Angle, mounting	...	L.72		
5X/6607	Plessey CZ.73898	Block, fuse	...	—	B.	
5CZ/868	—	Block, terminal, 5 way	...	—	B.	
	B.246749	Board, for components, group	...	—		
	A.246748	Board, tag	...	—		
5910-99	—	Capacitor, C.P-70A, .002...	...	—	C.	
012-0886	—					
10C/0115631	—	Capacitor, CP-31J	...	—	C.	
	F.235160	Link	...	BSS.265		
	A.246747	Plate, insulating	...	BS.2966		
10W/0215466	—	Resistor, RC2-D200	...	—	C.	
10W/0215462	—	Resistor, RC2-D220	...	—	C.	
10W/0216092	—	Resistor, RC2-D56K	...	—	C.	
10W/0216002	—	Resistor, RC2-D10K	...	—	C.	
	F.236210	Spacer	...	BSS.972/C		
	F.236209	Tag, rectifier	...	BSS.265		

Hunter T. Mk. 7
Issued with A/L No. 11

RADIO—U.H.F. INSTALLATION (S.O.O.)

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
5F/ 10H/0560233	Hellermann Plessey CZ.49217/3	Sleeve, helsyn, J.P. × ½"	QR	—	C.	
		Socket, panel unit	1	—	C.	
10H/0560260	Plessey CZ.49223	Socket, panel unit	1	—	C.	
10H/0560231	Plessey CZ.49217/1	Socket, panel unit	1	—	C.	
10H/0560332	Plessey CZ.49459/2	Socket, panel unit	1	—	C.	
10H/0560232	Plessey CZ.49217/2	Socket, panel unit	1	—	C.	
10H/0560331	Plessey CZ.49459/1	Socket, panel unit	1	—	C.	
10H/0560330	Plessey CZ.49459	Socket, panel unit	1	—	C.	
5X/7342	Erma 12431	Tag, 6 amp.	12	—	C.	
5X/	Erma 12432	Tag, 12 amp.	2	—	C.	
5X/	Erma 12434	Tag, 24 amp.	1	—	C.	
5K/3469	Ross Courtney 01	Terminal, 6 B.A.	2	—	C.	
5X/9400388	—	Terminal ring, 24 amp.	2	—	C.	
5X/9400382	—	Terminal ring, 6 amp.	8	—	C.	
5X/9400384	—	Terminal ring, 12 amp.	4	—	C.	
	B.233479	Box, resistor, group	1	—		
	A.233481	Base, for resistor unit	1	—		
10396	B.233480	Box, for resistor unit	1	L.72	C.	
10H/0560050	Plessey CZ.48992	Plug	1	—	C.	
10W/ 3838	Zenith Electric Std.1606/44/B8	Resistor, 1-3 ohms.	1	—	C.	
5F/ 5X/6988	Hellermann —	Screw	1	Brass	C.	
	F.231097	Sleeve, helsyn 100 J.P. × ¾"	2	—	C.	
	B.247755	Terminal, 12 amp.	2	—	C.	
	B.247583	Bracket	1	L.72		
	A.247461	Bracket, U.H.F. and tail-chute, group	1	—		
	B.245506	Bracket, switch... ..	1	L.72		
	B.347809	Cable, F.171 (See Cable Chart)	1	—	—	
	—	Cable, F.153 (See Cable Chart)	1	—	—	
	—	Cable, F.151 (See Cable Chart)	1	—	—	
5CW/5252	Helvin HV.3711	Cap, sea grey	1	—	C.	
5CY/5361	A.E.I. Ltd. CX.119950	Cover, trip button	1	—	B.	
5CY/5380	B.T.H. L.G.A.6 BA/1	Circuit, breaker, 6 amp., 28v.	1	—	A.	
10H/11718	Belling Lee 1055/5	Fuse, 5 amp.	1	—	C.	
10H/0590100	Belling Lee L.1348/0	Fuse, holder	1	—	C.	
5CW/5765	Rotax ZA.2402/1	Guard	1	—	C.	
1639	Std.1606/44/A6	Screw	2	Brass	C.	
3838	Std.1606/44/B8	Screw	10	Brass	C.	
5CW/ 5CW/7540	N.S.F. Ltd. —	Switch	1	—	B.	
5CW/6152	Rotax D.10004	Switch, S.P. change-over, No "OFF" position	1	—	B.	
5CW/7544	—	Switch, toggle	1	—	B.	
	—	Switch, "ON-OFF"	1	—	B.	
	B.248606	Cable, T.S.3 (See Cable Chart)	1	—	—	
	B.201469	Cable, T.S.4 (See Cable Chart)	1	—	—	
	B.206538	Cable, T.S.5 (See Cable Chart)	1	—	—	
	B.221724	Cable, F.128 (See Cable Chart)	1	—	—	
	B.221515	Cable, F.129 (See Cable Chart)	1	—	—	
	B.233541	Cable, F.154 (See Cable Chart)	1	—	—	
	A.233549	Cable, F.155 (See Cable Chart)	1	—	—	

RADIO—U.H.F. INSTALLATION (S.O.O.)

Ref. No.	Part No.	Description	No. Off					Material Specification	M.R. Class of Store	Plate No.
			1	2	3	4	5			
—	D.233534	Cable, F.23 (See Cable Chart)	1	—	—	
—	D.257146	Cable, F.62 (See Cable Chart)	1	—	—	
—	B.248320	Cable, main supply (See Cable Chart)	1	—	—	
5CW/5252	Hellermann HV.3711	Cap, helvin	2	—	C.	
5CY/9992777	—	Circuit, breaker, 25 amp.	1	—	A.	
5CY/2564	—	Circuit, breaker, 45 amp.	1	—	A.	
	D.247436	CLIPPING OF U.H.F. CABLES, ASSEMBLY	—	—		
	Std.2046/19/24	Clip	1	—		
	Std.2076/40/22	Clip	1	—		
	Std.2045/21/24	Clip	1	—		
5X/2787	Plessey Z.22432	Grommet, No. 4	2	—	C.	
	F.208641	Plate, cover	1	L.72		
5F/2301	Hellermann NY.18007	Strapping	QR	—	C.	
5F/2302	Hellermann NY.3342	Stud	QR	—	C.	
	Std.2045/38/22	Clip	1	—		
	Std.2045/23/24	Clip	5	—		
	Std.2045/15/26	Clip	1	—		
	Std.2045/34/32	Clip	1	—		
	Std.2076/35/22	Clip	1	—		
	Std.2046/19/24	Clip	1	—		
	Std.2046/36/22	Clip	5	—		
	Std.2076/40/22	Clip	1	—		
5821—	C.233770/1	Connector	1	—	B.	
AP.210666	5821— C.233770/2	Connector	1	—	B.	
AP.210657	5821— D.233433/1	Connector	1	—	B.	
AP.210667	5821— D.233433/2	Connector	1	—	B.	
AP.210665	5821— D.233433/3	Connector	1	—	B.	
AP.210659	5821— D.233433/4	Connector	1	—	B.	
AP.210668	5821— D.233433/5	Connector	1	—	B.	
AP.210655	5821— D.233433/6	Connector	1	—	B.	
AP.210660	5821— D.233433/7	Connector	1	—	B.	
AP.210654	5821— D.233433/9	Connector	1	—	B.	
AP.210664	5821— D.233433/14	Connector	1	—	B.	
10HB/12846	5821— D.233433/15	Connector	1	—	B.	
AP.210663	D.233433/16	Connector	1	—	B.	
10HB/12848	E.227864/1	Connector	1	—	B.	
10HB/6605	E.227864/3	Connector	1	—	B.	
10HB/6606	E.227864/25	Connector	1	—	B.	
10HB/6607	E.227865/2	Connector	1	—	B.	
10HA/16710	E.227865/3	Connector	1	—	B.	
10HA/16711	E.227865/23	Connector	1	—	B.	
10HA/16708	E.227865/24	Connector	1	—	B.	
10HA/16709	B.235731	Connector, inter-com.	1	—		
	A.221617	Connector, mic-tel.	1	—		
	A.240911	Link, chain	1	—		
	F.219731	Lu _k	2	L.72		

Hunter T. Mk. 7
Issued with A/L No. 11

RADIO—U.H.F. INSTALLATION (S.O.O.)

Ref. No.	Part No.	Description	No. Off	Material Specification	M.R. Class of Store	Plate No.
	D.233438	MOUNTING BRACKET FOR AERIAL AND CABLE DUCT, ASSEMBLY	—	—		
	C.233437	Bracket, mounting	1	—		
	F.233440	Bracket, support	1	L.72		
	B.233441	Duct, for aerial cable	1	—		
	C.233315	MOUNTING FOR AERIAL, ASSEMBLY	—	—		
	B.233291	Bracket, mounting	1	L.72		
10732	A.206237	Panel, access	2	L.72	C.	
	A.233439	Plate, mounting	1	—		
10H/0540103	—	Plug, double ended	4	—	C.	
10H/19482	Plessey CZ.62275/1	Plug, socket	1	—	C.	
10H/19451	Plessey CZ.62270	Plug, socket	1	—	C.	
10H/19481	Plessey CZ.62275	Plug, socket	1	—	C.	
5935-99-932-2405	Plessey 2CZ.111209	Plug, socket	2	—	C.	
10H/5F/2301	UG/567A/U	Plug, socket, type UK/C	1	—	C.	
	Hellermann NY.18007/A	Strapping	AR	—	C.	
5F/2302	Hellermann NY.3342	Stud	AR	—	C.	
5CW/7541	—	Switch	2	—	B.	
5821-99-942-8542	—	Transmitter/Receiver, type T.R.5/A.R.C.52	1	—	A.	
10D/23507	—	Transmitter/Receiver, type M.4	1	—	A.	
5821-99-942-6361	—	Tray, mounting, MT.1477/A.R.C.52	1	—	B.	
10AJ/121	—	Tray, mounting, type 936	1	—	B.	
10AJ/212	—	Tray, mounting, type 1031	1	—	B.	
3970	Std.1509/12/020	Tube, distance	2	T.4	MR/C	
	Std.1507/2/186	Tube, distance	3	T.4		
7152	Std.1509/12/036	Tube, distance	1	—	MR/C	
	Std.1509/12/096	Tube, distance	1	—		
	D.244161	UNIT, D.M.E. CONTROL ASSEMBLY, PORT	—	—		
	A.249966	Bracket, switch mounting	1	L.72		
10H/19110	Plessey Z.49081	Outlet, straight	1	—	C.	
	A.247258	Plate, adaptor	1	L.72		
	B.243955	Shelf, detachable, cockpit, port	1	L.72		
	F.231593	Support, switch	1	L.72		
	Std.1509/2/056	Tube, distance	2	—		
5821-99-942-8543	—	Unit, control, type C.1607	1	—	A.	
5821-99-943-3247	—	Unit, muting bias	1	—	A.	
10H/0970049	Plessey Z.54105	Washer, panel mounting	1	—	C.	
10H/0970050	Plessey Z.54106	Washer, panel mounting	1	—	C.	
	Std.1546/20/14	Washer, profile	4	—		

RADIO-U.H.F. INSTALLATION (S.O.O.)

Ref. No.	Part No.	Description					No. Off	Material Specification	M.R. Class of Store	Plate No.
		1	2	3	4	5				
SUMMARY OF STOCK ITEMS										
28D/1007971	A25.1.B	Bolt, 4 B.A.	---	---	---
28D/1010658	A25.1.B	Bolt, 4 B.A.	---	---	---
28D/1008149	A25.2.B	Bolt, 4 B.A.	---	---	---
28D/1010029	A25.6.B	Bolt, 4 B.A.	---	---	---
28D/1200120	A25.14.B	Bolt, 4 B.A.	---	---	---
28D/9436920	A25.1.C	Bolt, 2 B.A.	---	---	---
28D/1010030	A25.7.C	Bolt, 2 B.A.	---	---	---
28D/9419397	A25.12.C	Bolt, 2 B.A.	---	---	---
28D/1011030	A25.2.E	Bolt, 1/2" B.S.F.	---	---	---
28D/9133011	AS.1242.2.C	Bolt, 2 B.A.	---	---	---
28D/8314	AS.1242.10.C	Bolt, 2 B.A.	---	---	---
28D/11243	AS.1242.20.C	Bolt, 2 B.A.	---	---	---
28D/12052	AS.1242.20.E	Bolt, 1/2" B.S.F.	---	---	---
28D/9128739	AS.1248.1.B	Bolt, 4 B.A.	---	---	---
28D/8337	AS.1248.1.B	Bolt, 4 B.A.	---	---	---
28D/1007981	AS.1248.1.C	Bolt, 2 B.A.	---	---	---
28D/1007982	AS.1248.1.C	Bolt, 2 B.A.	---	---	---
28D/1013284	AS.1248.2.C	Bolt, 2 B.A.	---	---	---
28N/255	SP.58.D	Burr	---	---	---
5K/1200715	SP.40.B6	Grommet	---	---	---
5K/3355	AS.3360.B.4.D	Lead, bonding	---	---	---
5K/3408	AS.3360.B.6.B	Lead, bonding	---	---	---
5K/	AS.3360.B.4	Lead, bonding	---	---	---
28M/1006504	A27.BT	Nut	---	---	---
28M/10286	AGS.2001.A.1	Nut, 6 B.A.	---	---	---
28M/10287	AGS.2001.B.1	Nut, 4 B.A.	---	---	---
28M/10297	AGS.2001.B.2	Nut, 4 B.A.	---	---	---
28M/10288	AGS.2001.C.1	Nut, 2 B.A.	---	---	---
28M/10326	AGS.2002.A.1	Nut, 6 B.A.	---	---	---
28M/10327	AGS.2002.B.1	Nut, 4 B.A.	---	---	---
28M/10288	AGS.2002.C.1	Nut, 2 B.A.	---	---	---
28M/7002430	AGS.2002.E.1	Nut, 1/2" B.S.F.	---	---	---
28M/10215	AGS.2008.B.1	Nut, 4 B.A.	---	---	---
28M/9435062	AGS.2008.C.1	Nut, 2 B.A.	---	---	---
28S/1200045	A31.A.10	Screw, 6 B.A.	---	---	---
28S/1006948	A32.A.12	Screw, 6 B.A.	---	---	---
28S/1011484	A32.A.20	Screw, 6 B.A.	---	---	---
28S/6287	A32.B.6	Screw, 4 B.A.	---	---	---
28S/9992522	A32.B.16	Screw, 4 B.A.	---	---	---
28S/9995376	A32.B.20	Screw, 4 B.A.	---	---	---
28S/9435716	A33.B.12	Screw, 4 B.A.	---	---	---
28S/1007469	A33.B.14	Screw, 4 B.A.	---	---	---
28S/9435715	A33.B.16	Screw, 4 B.A.	---	---	---
28S/2413	A44.B.16	Screw, 4 B.A.	---	---	---
28S/1011490	A32.C.16	Screw, 2 B.A.	---	---	---
28W/9419474	SP.15.B	Washer, 4 B.A.	---	---	---
28W/9419475	SP.15.C	Washer, 2 B.A.	---	---	---
28W/9419404	SP.16.C	Washer, 2 B.A.	---	---	---
28W/9419487	SP.16.E	Washer, 1/2"	---	---	---

This file was downloaded
from the RTFM Library.
Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

