

ELECTRICAL INSTALLATIONS
INSTALLATION OF RADAR SCANNER ELECTRO-HYDRAULIC VALVE,
CODED "SS"

Ref. No.	Part No.	Description	No. off	Material Specification	Class of Store or L.M.	Plate No.
	—	INSTALLATION OF RADAR SCANNER ELECTRO-HYDRAULIC VALVE, CODED "SS"	1	—	—	
	—	INSTALLATION AT FUSELAGE NOSE (Drg. Nos. 10-20 N 9465, 10-20 S 3799)	1	—	—	
	—	BLOCK , terminal, coded "BP," group	1	—	—	
	DHS.456/20L	BLOCK , terminal, 20-way, assembly (For breakdown see DHS. Data Sheet)	1	—	—	
5X/9149643	PLESSEY CZ.25111	COVER , terminal block (5940-99-914-9643)	1	—	C	
13589	DHS.870/4	PILLAR , fixing, 4 BA	2	—	C	
26DV/12294	DHS.489/3	SPACER	2	—	C	
	10-20 N 14911A	CABLE , bung "A1," assembly (Mod. 758) (For cables circuit coded "SS")	1	—	ECC	
	10-20 N 14281A	CABLE , coded "EHV-A," assembly (Mod. 758)	1	—	ECC	
26DV/7529	DHS.438/C	TERMINAL , earth, stn. 4, coded "B," group ...	1	—	—	
26DV/4969	DHS.437/C	TAG , corrosion	1	—	C	
		TERMINAL , earth, assembly (For breakdown see DHS. Data Sheet)	1	—	C	
		Attachments for DHS.437/C, Terminal :—				
28D/9133011	A25/2C	Bolt , 2 BA	2	—	C	
28W/9419402	SP.13/C	Washer ,	2	—	C	
	—	VALVE , selector, scanner (See sub-section QQ)	—	—	—	
	—	INSTALLATION AT REAR PRESSURE BULK-HEAD, CODED "Q" (See sub-section ECH)	1	—	—	
32B/—	—	TAPE , identification, numbers and letters, use from Ref. Nos. 32B/1087 and 32B/1120 inclusive, as required	QR	—	C	

ELECTRICAL INSTALLATIONS
INSTALLATION OF RADAR SCANNER ELECTRO-HYDRAULIC VALVE,
CODED "SS"

Ref. No.	Part No.	Description						No. off	Material Specification	Class of Store or L.M.	Plate No.
		1	2	3	4	5	6				

This file was downloaded
from the RTFM Library.

Link: www.scottbouch.com/rtfm

Please see site for usage terms,
and more aircraft documents.

